


부품 매뉴얼 PARTS MANUAL

GEX 20/25/30

SERIAL NUMBER : GEX230 - XXXX - 9655 KF

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Part No. 8049008

Dec. 2013



(본사) 경기도 부천시 오정구 오정동 202-1

(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea

(공장) 경남 창원시 웅남동 40-1


(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea



02-189	ACCELERATOR LINKAGE 악셀레이터 링크케이지	23-433	PARKING BRAKE SYSTEM 파킹 브레이크 시스템
13-028	VALVE SWITCH WIRING 밸브 스위치 와이어링	23-441	BRAKE SYSTEM 브레이크 시스템
13-130	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드&턴시그널 라이트 조립그룹	23-508	PARKING BRAKE SYSTEM 파킹 브레이크 시스템
13-131	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드&턴시그널 라이트 조립그룹	25-143	STEERING UNIT 스티어링 유닛
13-136	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드&턴시그널 라이트 조립그룹	25-193	STEERING WHEEL & COLUMN & GEAR MOUNTING 스티어링 휠&컬럼&기어 마운팅
13-137	REAR ACCESSORY MOUNTING 리어 액세서리 마운팅	25-291	STEERING COLUMN SHAFT ASSEMBLY 스티어링 컬럼 샤프트 어셈블리
13-141	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드&턴시그널 라이트 조립그룹	25-353	STEERING COLUMN ASSEMBLY 스티어링 컬럼 어셈블리
13-145	COMBINATION & REAR WORK LIGHT INSTALLATION 컴비네이션&후방 작업등 조립그룹	26-272	STEER AXLE MOUNTING 스티어링 액슬 마운팅
13-182	STROBE LIGHT 경광등	26-274	STEER CYLINDER 스티어링 실린더
13-194	WORK LIGHT 작업등	26-276	STEER AXLE ASSEMBLY 스티어링 액슬 어셈블리
13-315	ELECTRICAL COMPONENTS (SBR) 전기장치 구성품 (SBR)	26-315	STEER LINES 스티어링 라인
13-316	ELECTRICAL WIRING (CAB) 전기장치 와이어링 (캐빈)	26-320	STEER LINES 스티어링 라인
14-949	ELECTRICAL COMPONENTS 전기장치 구성품	26-321	STEER LINES 스티어링 라인
14-952	ELECTRICAL WIRING 전기장치 와이어링	26-322	STEER LINES 스티어링 라인
15-025	ELECTRICAL COMPONENTS (ELH) 전기장치 구성품 (ELH)	26-323	STEER LINES 스티어링 라인
15-032	ELECTRICAL WIRING (ELH) 전장 와이어링 (ELH)	26-324	STEER LINES 스티어링 라인
15-033	ELECTRICAL WIRING 전기장치 와이어링	26-325	STEER LINES 스티어링 라인
15-034	ELECTRICAL WIRING (ELH) 전장 와이어링 (ELH)	26-326	STEER LINES 스티어링 라인
15-050	CABLE INSTALLATION 케이블 조립그룹	27-002	PRIORITY VALVE ASSEMBLY 우선 밸브 어셈블리
15-052	CABLE INSTALLATION (EE) 케이블 조립그룹 (EE)	29-027	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
15-054	ELECTRICAL COMPONENTS (EE) 전기장치 구성품 (EE)	29-239	HYDRAULIC OIL FILTER 유압 오일 필터
16-024	TRACTION & PUMP MOTORS MOUNTING 트랙션&펌프 모터 마운팅	29-256	SUMP TANK MOUNTING 섬프 탱크 마운팅
16-240	PUMP MOTOR ASSEMBLY 펌프 모터 어셈블리	29-296	HYDRAULIC PUMP ASSEMBLY 유압 펌프 어셈블리
16-241	DRIVE MOTOR ASSEMBLY 드라이브 모터 어셈블리	30-244	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
17-118	CONTACTOR ASSEMBLY 컨택터 어셈블리	30-245	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
19-000	CONTROLLER MOUNTING 컨트롤러 마운팅	30-246	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
20-098	CARRIER ASSEMBLY 캐리어 어셈블리	30-295	HYDRAULIC VALVE MOUNTING 유압 밸브 마운팅
20-104	DRIVE AXLE ASSEMBLY 드라이브 액슬 어셈블리	30-296	HYDRAULIC VALVE MOUNTING 유압 밸브 마운팅
20-108	DRIVE AXLE MOUNTING 드라이브 액슬 마운팅	30-313	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
22-000	DRIVE TIRE MOUNTING 드라이브 타이어 마운팅	30-314	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-012	UNITROL SYSTEM 유닛롤 시스템	30-341	MAIN CONTROL VALVE 4-SPOOL 메인 컨트롤 밸브 - 4 스풀
22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브휠&타이어 마운팅	30-346	MAIN CONTROL VALVE 2-SPOOL 메인 컨트롤 밸브 - 2 스풀
22-014	STEER WHEEL & TIRE MOUNTING 스티어링휠&타이어 마운팅	30-357	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-024	DRIVE WHEEL & TIRE (SOLID TYPE) 드라이브 휠&타이어 (솔리드 타입)	30-572	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
23-164	BRAKE LINES 브레이크 라인	30-597	HYDRAULIC CONTROL VALVE 유압 컨트롤 밸브
23-431	PARKING BRAKE & LINKAGE 파킹 브레이크&링크케이지	30-674	HYDRAULIC CONTROL VALVE-4 SPOOL 유압 컨트롤 밸브 - 4 스풀

31-170	HYDRAULIC LIFT & TILT LINES 유압 리프트& 틸트 라인	39-150	CAB MOUNTING 캐빈 마운팅
31-171	HYDRAULIC SUPPLY LINES 유압 공급 라인	39-221	ENCLOSED CAB 캐빈 (박스형)
31-182	HYDRAULIC LIFT & TILT LINES 유압 리프트& 틸트 라인	39-223	ELECTRICAL-CABIN 전기장치 - 캐빈
31-185	HYDRAULIC SUPPLY LINES 유압 공급 라인	39-519	LOAD BACK REST 로드 백 레스트
31-199	HYDRAULIC RETURN LINES 유압 리턴 라인	39-661	SEAT ASSEMBLY 시트 어셈블리
31-326	HYDRAULIC RETURN LINES 유압 리턴 라인	39-795	SHEET METAL 시트 메탈
32-142	TILT CYLINDER 틸트 실린더	39-798	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅
32-144	ACCUMULATOR 어큐뮬레이터	39-826	SEAT MOUNTING 시트 마운팅
32-145	TILT CYLINDER MOUNTING 틸트 실린더 마운팅	39-829	SEAT MOUNTING 시트 마운팅
32-167	TILT AMOUNT GROUP 틸트 어마운트 그룹	39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리
33-014	SOLENOID VALVE 솔레노이드 밸브	39-835	ARMREST MOUNTING (ELH) 암레스트 마운팅 (ELH)
33-037	CLAMP LEVER LOCK SYSTEM 클램프 레버 록 시스템	39-869	CABIN AND HEATER INSTALLATION 캐빈& 히터 조립그룹
33-069	RELIEF VALVE ASSEMBLY 릴리프 밸브 어셈블리	39-930	OHG - DIDT 오버헤드가드 - DIDT
33-130	SELECTOR SOLENOID VALVE -selector 솔레노이드 밸브	39-942	BATTERY COVER & REAR COVER MOUNTING 배터리 커버& 리어 커버 마운팅
34-009	UPRIGHT MOUNTING 마스트 마운팅	39-944	EE CONSTRUCTION, HOOD/FRAME EE 구성품 후드& 프레임
34-044	LOAD BACK REST MOUNTING 로드 백 레스트 마운팅	39-971	ENCLOSED CAB 캐빈 (박스형)
34-103	CARRIAGE ASSEMBLY 캐리지 어셈블리	39-972	ENCLOSED CAB 캐빈 (박스형)
34-209	CARRIAGE ASSEMBLY 캐리지 어셈블리	39-973	ENCLOSED CAB 캐빈 (박스형)
37-034	SHEET METAL & TRIM 시트 메탈& 트림	40-260	TRUCK FLUIDS 트럭 윤활유
37-035	CAB MOUNTING 캐빈 마운팅	40-270	REFLECTIVE TAPE MOUNTING 반사 테이프 마운팅
37-036	ENCLOSED CAB 캐빈 (박스형)	40-277	SAFETY & LOGO & WIRING DIAGRAM DECALS 안전& 로고& 와이어배선 데칼
37-037	CAB DOOR SASH ASSEMBLY 캐빈 도어 어셈블리	40-278	DECALS 데칼
37-038	CAB ROOF COVER ASSEMBLY 캐빈 루프 커버 어셈블리	47-000	SEAT WING KIT 시트윙 키트
37-040	ELECTRICAL COMPONENTS (CAB) 전기장치 구성품 (캐빈)	47-016	REAR HAND GRIP MOUNTING 리어 핸드 그립 마운팅
37-041	CAB MOUNTING 캐빈 마운팅	50-171	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
37-042	ENCLOSED CAB 캐빈 (박스형)	50-172	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
37-043	ELECTRICAL COMPONENTS (CAB) 전기장치 구성품 (캐빈)	50-175	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
37-045	REAR WINDOW ASSEMBLY 리어 윈도우 어셈블리	50-177	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적응)
37-076	BACK MIRROR 백미러	50-187	AUXILIARY VALVE LINES 보조 밸브 라인
37-122	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	50-232	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
37-123	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	50-269	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
37-124	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	50-270	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
37-125	BATTERY COVER & REAR COVER MOUNTING 배터리 커버& 리어 커버 마운팅	50-289	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
37-168	ARMREST MOUNTING (ELH) 암레스트 마운팅 (ELH)	50-290	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
38-284	MODEL DECALS & COUNTERWEIGHT MOUNTING 모델 데칼& 카운터웨이트 마운팅	50-291	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
39-119	ENCLOSED CAB 캐빈 (박스형)	50-407	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)

50-410	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
50-432	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
50-439	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
50-445	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
50-526	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
50-535	AUXILIARY VALVE LINES 보조 밸브 라인
50-765	HIGH TERMINATION PLUMBING 하이 터미네이션 기관
50-791	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
50-794	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
50-796	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
50-797	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
50-798	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)
50-820	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적응)
51-000	PRESSURE RELIEF VALVE 압력 릴리프 밸브
53-024	FORK POSITIONER 포크 포지셔너
53-084	FORK POSITIONER 포크 포지셔너
53-146	F/P SIDESHIFT CYLINDER 포크포지셔너 사이드 쉬프트 실린더
53-164	FORK POSITIONER 포크 포지셔너
53-168	FORK POSITIONER (SHIFTING) 포크 포지셔너 (쉬프트 타임)
53-170	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
53-187	SIDE SHIFT ASSEMBLY 사이드 쉬프트 어셈블리
53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더
53-223	FORK POSITIONER CYLINDER 포크 포지셔너 실린더
54-015	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
66-058	FORK 포크
66-139	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-169	LIFT CYLINDER ASSEMBLY 리프트 실린더 어셈블리
66-170	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-235	PRIMARY CYLINDER ASSEMBLY 프라이머리 실린더 어셈블리
66-236	PRIMARY CYLINDER ASSEMBLY 프라이머리 실린더 어셈블리
66-246	TRIPLE STAGE UPRIGHT 3단 마스트
66-249	STANDARD UPRIGHT 표준 마스트
66-253	HI-LO UPRIGHT 하이-로우 마스트
75-(33)045	DEVICE HYDRAULIC PRESSURE GAUGE INSTALLATION 디바이스 유압 압력게이지 조립그룹
75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치
75-013	SEAT OPERATED BRAKE 시트 조작 브레이크




ACCELERATOR LINKAGE

02-189


02.258	STOP, ACCELERATOR PEDAL 스톱
02.260	BRACKET, ACCELERATOR LINKAGE MOUNTING 브라켓
02.261	FASTENER, ACCELERATOR LINKAGE MOUNTING BRACKET 패스너
02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.288	BRACKET, ACCELERATOR PEDAL ATTACHING 브라켓
02.289	FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING 패스너
13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너

93.726 WASHER, ACCELERATOR PEDAL PIVOT RETAINER
 와셔

ФОРКЛИФТ
www.forklift.ru




- | | |
|--------|---|
| 13.035 | RELAY, VALVE SWITCH WIRING HARNESS
릴레이 |
| 14.146 | HARNESS, VALVE SWITCH WIRING
하네스 |
| 15.397 | FUSE, SOLENOID VALVE
퓨즈 |



13.270	HEADLAMP, ADJUSTABLE 헤드 램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래셔

60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너






13.270	HEADLAMP, ADJUSTABLE 헤드램프
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.436	HARNESS, RH HEADLAMP WIRING 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래서

18.100	CLIP, HEAD LIGHT WIRE 클립
60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너


ФОРКЛИФТ
www.forklift.ru



13.270	HEADLAMP, ADJUSTABLE 헤드 램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.436	HARNESS, RH HEADLAMP WIRING 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스

15.714	FLASHER, UNIT 플래셔
18.100	CLIP, HEAD LIGHT WIRE 클립
60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너






13.206	BULB, BACK-UP LAMP 전구
13.217	FASTENER, COM STOP & TAIL LAMP ASSY MTG 패스너
13.218	BULB, STOP & TAIL LAMP 전구
13.675	BULB, TURN LIGHT 전구
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
60.795	LIGHT, REAR WORK 라이트
60.797	GROMMET, REAR ACCESSORY WIRE 그롬멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어 하네스
60.907	RELAY, STOP LIGHT 릴레이

60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.960	HARNESS, REAR WORK LAMP EXTENSION 하네스
60.962	SPACER, REAR WORK LAMP MOUNTING 스페이서






13.270	HEADLAMP, ADJUSTABLE 헤드램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래셔

60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.368	RELAY, HEADLIGHTS 릴레이
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너






COMBINATION & REAR WORK LIGHT INSTALLATION

13-145


13.217	FASTENER, COM STOP & TAIL LAMP ASSY MTG 패스너
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
60.795	LIGHT, REAR WORK 라이트
60.797	GROMMET, REAR ACCESSORY WIRE 그롬멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.907	RELAY, STOP LIGHT 릴레이
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.924	FASTENER, REAR WORK LAMP MOUNTING 패스너

60.960	HARNESS, REAR WORK LAMP EXTENSION 하네스
60.962	SPACER, REAR WORK LAMP MOUNTING 스페이서
60.964	RELAY, FOOT BRAKE 릴레이






13.332	ASSEMBLY, WARNING LIGHT 경고등
13.333	BULB, WARNING LIGHT 전구
60.821	GLOBE, STROBE LIGHT 글로브
60.822	BASE, STROBE LIGHT 베이스




- | | |
|--------|--|
| 13.281 | FASTENER, ADJ HEADLAMP SWIVEL
패스너 |
| 13.284 | BRACKET, ADJUSTABLE HEADLAMP
브라켓 |
| 13.285 | FASTENER, ADJUSTABLE HEADLAMP BRACKET
패스너 |
| 60.325 | BULB, HEADLAMP
전구 |
| 60.795 | LIGHT, REAR WORK
라이트 |




ELECTRICAL COMPONENTS (SBR)

13-315

- | | |
|--------|--|
| 12.190 | SWITCH, BATTERY RETAINER INTERLOCK
스위치 |
| 12.191 | HARNESS, BATTERY RETAINER INTERLOCK SWITCH
하네스 |
| 12.192 | FASTENER, BATTERY RETAINER INTERLOCK SWITCH
패스너 |




- | | |
|--------|--|
| 15.377 | WIRING HARNESS, MACHINE TO CABIN
와이어하네스 |
| 19.828 | FUSE, CONTROL CIRCUIT
퓨즈 |
| 67.219 | CONVERTER, DC-DC FOR CAB ACCESSORY
컨버터 |
| 97.169 | FASTENER, DC-DC CONVERTER FOR CAB ACCESSORY
패스너 |



13.000	PANEL, INSTRUMENT CLUSTER 판넬
13.003	HORN 혼
13.004	FASTENER, HORN MOUNTING BRACKET 패스너
13.047	SWITCH, CIRCUIT LOCKING 스위치
13.078	CLAMP, INSTRUMENT CLUSTER TO INST PANEL 클램프
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL 패스너
13.470	SWITCH, DISCONNECT 스위치
39.417	GROUND STRAP, ELECTRIC TRUCK 접지케이블
39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP 패스너


49.101	SENSOR, LEVER POSITION 센서
49.204	BRACKET, LEVER POSITION SENSOR 브라켓
60.260	KEY, CIRCUIT LOCKING SWITCH 키
60.725	POTENTIOMETER, STEERING INTERLOCK 포텐션메터
65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.932	FASTENER, LINE CONTACTOR 패스너
67.118	BRACKET, LINE CONTACTOR MOUNTING 브라켓
67.204	COVER, DC CONVERTER 커버
67.217	CONVERTER, DC-DC FOR ACCESSORY 컨버터
67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL 컨버터
95.972	FASTENER, BATTERY DISCONNECT SWITCH 패스너
96.596	FASTENER, STEERING INTERLOCK POTENTIOMETER 패스너
96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너
97.142	FASTENER, LEVER POSITION SENSOR 패스너
97.143	FASTENER, LEVER POSITION SENSOR BRACKET 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL 패스너



13.739	FILTER, HORN 필터
14.114	HARNESS, MACHINE WIRING 하네스
14.352	FUSE, CONTROL CIRCUIT 퓨즈
14.744	BRACKET, FUSE HOLDER MOUNTING 브라켓
14.745	FASTENER, FUSE HOLDER MOUNTING BRACKET 패스너
15.640	WIRING HARNESS, MACHINE COWL 와이어하네스
15.828	WIRING HARNESS, MACHINE HOOD 와이어하네스
18.010	CLIP, HARNESS 클립
18.011	FASTENER, HARNESS CLIP 패스너

18.012	CLIP, WIRE HARNESS 클립
18.013	FASTENER, HARNESS CLIP 패스너
18.187	TERMINAL, FUSE 터미널
60.957	RESISTOR, WIRING HARNESS 레지스터
65.832	COVER, FUSE BOX 커버
93.661	FASTENER, TERMINAL BLOCK 패스너
95.009	FASTENER, FUSE BOX MOUNTING 패스너
97.193	FASTENER, WIRING HARNESS RESISTOR 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



ELECTRICAL COMPONENTS (ELH)


15-025


13.000	PANEL, INSTRUMENT CLUSTER панель	60.956	BRACKET, ELECTRONIC HYDRAULIC CONTROLLER брасет
13.003	HORN хорн	65.130	CONTACTOR ASSEMBLY, LINE контактор
13.004	FASTENER, HORN MOUNTING BRACKET паснёр	65.932	FASTENER, LINE CONTACTOR паснёр
13.047	SWITCH, CIRCUIT LOCKING свчч	67.118	BRACKET, LINE CONTACTOR MOUNTING брасет
13.078	CLAMP, INSTRUMENT CLUSTER TO INST PANEL клемп	67.204	COVER, DC CONVERTER квер
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL паснёр	67.217	CONVERTER, DC-DC FOR ACCESSORY квервер
13.470	SWITCH, DISCONNECT свчч	67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL квервер
39.417	GROUND STRAP, ELECTRIC TRUCK земзкейбл	95.972	FASTENER, BATTERY DISCONNECT SWITCH паснёр
39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP паснёр	96.596	FASTENER, STEERING INTERLOCK POTENTIOMETER паснёр
60.260	KEY, CIRCUIT LOCKING SWITCH кй	96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET паснёр
60.725	POTENTIOMETER, STEERING INTERLOCK потенснметр	97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY паснёр
60.894	CONTROLLER, ELECTRONIC HYDRAULIC кнтрллер	97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL паснёр
60.927	CARD, ELECTRIC SIGNAL CONTROL кард	97.188	FASTENER, ELECTRONIC HYDRAULIC CONTROLLER паснёр
60.928	BRACKET, ELECTRIC SIGNAL CONTROL CARD брасет	97.189	FASTENER, ELECTRONIC HYDRAULIC CONTROLLER BRACKE паснёр
60.929	FASTENER, ELECTRIC SIGNAL CONTROL CARD паснёр		



13.739	FILTER, HORN 필터
14.114	HARNESS, MACHINE WIRING 하네스
14.352	FUSE, CONTROL CIRCUIT 퓨즈
14.744	BRACKET, FUSE HOLDER MOUNTING 브라켓
14.745	FASTENER, FUSE HOLDER MOUNTING BRACKET 패스너
15.538	HARNESS, VALVE SWITCH WIRING CONNECTOR 하네스
15.640	WIRING HARNESS, MACHINE COWL 와이어 하네스
15.828	WIRING HARNESS, MACHINE HOOD 와이어 하네스
18.010	CLIP, HARNESS 클립


18.011	FASTENER, HARNESS CLIP 패스너
18.012	CLIP, WIRE HARNESS 클립
18.013	FASTENER, HARNESS CLIP 패스너
18.187	TERMINAL, FUSE 터미널
60.957	RESISTOR, WIRING HARNESS 레지스터
65.832	COVER, FUSE BOX 커버
93.661	FASTENER, TERMINAL BLOCK 패스너
95.009	FASTENER, FUSE BOX MOUNTING 패스너
97.193	FASTENER, WIRING HARNESS RESISTOR 패스너






13.739	FILTER, HORN 필터
14.114	HARNESS, MACHINE WIRING 하네스
14.352	FUSE, CONTROL CIRCUIT 퓨즈
14.744	BRACKET, FUSE HOLDER MOUNTING 브라켓
14.745	FASTENER, FUSE HOLDER MOUNTING BRACKET 패스너
15.640	WIRING HARNESS, MACHINE COWL 와이어하네스
15.828	WIRING HARNESS, MACHINE HOOD 와이어하네스
18.010	CLIP, HARNESS 클립
18.011	FASTENER, HARNESS CLIP 패스너


18.012	CLIP, WIRE HARNESS 클립
18.013	FASTENER, HARNESS CLIP 패스너
18.187	TERMINAL, FUSE 터미널
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.957	RESISTOR, WIRING HARNESS 레지스터
65.832	COVER, FUSE BOX 커버
93.661	FASTENER, TERMINAL BLOCK 패스너
95.009	FASTENER, FUSE BOX MOUNTING 패스너
97.193	FASTENER, WIRING HARNESS RESISTOR 패스너






13.739	FILTER, HORN 필터
14.114	HARNESS, MACHINE WIRING 하네스
14.352	FUSE, CONTROL CIRCUIT 퓨즈
14.744	BRACKET, FUSE HOLDER MOUNTING 브라켓
14.745	FASTENER, FUSE HOLDER MOUNTING BRACKET 패스너
15.538	HARNESS, VALVE SWITCH WIRING CONNECTOR 하네스
15.640	WIRING HARNESS, MACHINE COWL 와이어 하네스
15.828	WIRING HARNESS, MACHINE HOOD 와이어 하네스
18.010	CLIP, HARNESS 클립

18.011	FASTENER, HARNESS CLIP 패스너
18.012	CLIP, WIRE HARNESS 클립
18.013	FASTENER, HARNESS CLIP 패스너
18.187	TERMINAL, FUSE 터미널
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.957	RESISTOR, WIRING HARNESS 레지스터
65.832	COVER, FUSE BOX 커버
93.661	FASTENER, TERMINAL BLOCK 패스너
95.009	FASTENER, FUSE BOX MOUNTING 패스너
97.193	FASTENER, WIRING HARNESS RESISTOR 패스너






- | | |
|--------|--|
| 14.039 | RECEPTACLE & LEAD ASSEMBLY, BATTERY
리셉터클& 리드 |
| 14.040 | RECEPTACLE, BATTERY
리셉터클 |
| 14.764 | BRACKET, BATTERY RECEPTACLE MOUNTING
브라켓 |
| 14.765 | FASTENER, BATTERY RECEPTACLE MOUNTING BRACKET
패스너 |
| 15.623 | CABLE, CONTACTOR R+
케이블 |
| 15.624 | CABLE, CONTACTOR L-
케이블 |
| 15.625 | CABLE, CONTACTOR L+
케이블 |
| 15.633 | CABLE, CONTACTOR B-T TO CONTACTOR B-P
케이블 |
| 15.770 | CABLE, DRIVE MOTOR (TMUR TO TCUR)
케이블 |


15.771	CABLE, DRIVE MOTOR (TMWR TO TCVR) 케이블
15.772	CABLE, DRIVE MOTOR (TMVR TO TCWR) 케이블
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블
15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
15.820	BOOT, CABLE 부트
94.069	FASTENER, BATTERY RECEPTACLE 패스너






- 14.039 RECEPTACLE & LEAD ASSEMBLY, BATTERY
리셉터클& 리드
- 14.040 RECEPTACLE, BATTERY
리셉터클
- 14.764 BRACKET, BATTERY RECEPTACLE MOUNTING
브라켓
- 14.765 FASTENER, BATTERY RECEPTACLE MOUNTING BRACKET
패스너
- 15.431 SPACER, BATTERY RECEPTACLE FASTENER
스페이서
- 15.600 CABLE, CONTACTOR
케이블
- 15.623 CABLE, CONTACTOR R+
케이블
- 15.624 CABLE, CONTACTOR L-
케이블
- 15.625 CABLE, CONTACTOR L+
케이블

15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블
15.770	CABLE, DRIVE MOTOR (TMUR TO TCUR) 케이블
15.771	CABLE, DRIVE MOTOR (TMWR TO TCVR) 케이블
15.772	CABLE, DRIVE MOTOR (TMVR TO TCWR) 케이블
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블
15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
15.820	BOOT, CABLE 부트
94.069	FASTENER, BATTERY RECEPTACLE 패스너






15.396	BOX, FUSE MOUNTING 박스
17.154	FASTENER, FUSE TERMINAL ANGLE BUS 패스너
17.678	FASTENER, FUSE BOX MOUNTING BRACKET 패스너
19.636	FASTENER, CONTACTOR CONTROL TERMINAL 패스너
19.921	GROMMET, FUSE BOX LEADS 그로멧
19.999	BRACKET, CONTACTOR PANEL FUSE HOLDER MOUNTING 브라켓
60.936	BRACKET, CONTACTOR COVERING BODY 브라켓
60.937	BRACKET, CONTACTOR COVERING 브라켓
60.938	TERMINAL, CONTACTOR CONNECTING 터미날

65.336	CONDUCTOR, CONTROL PANEL FUSE CONNECTING 컨덕터
65.707	COVER, CONTROL PANEL FUSE BOX 커버
65.769	CONDUCTOR, CONTROL PANEL FUSE CONNECTING 컨덕터
90.200	FASTENER, CONTACTOR PANEL FUSE HOLDER MTG BRKT 패스너
92.112	FASTENER, CONTACTOR BOX 패스너
94.016	FASTENER, CONTROL PANEL FUSE BOX COVER 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TRACTION & PUMP MOTORS MOUNTING


16-024

16.000	MOTOR ASSEMBLY, DRIVE 모터
16.001	FASTENER, DRIVE MOTOR 패스너
16.287	WIRE, LEAD GROUND FROM MOTOR 와이어
16.500	MOTOR ASSEMBLY, PUMP 모터
16.704	DAMPENER, PUMP MOTOR VIBRATION 댐프너
16.708	FASTENER, PUMP MOTOR VIBRATION DAMPENER 패스너
65.861	BRACKET, PUMP CONTROL PANEL CABLE CLAMP 브라켓




16.152	SENSOR BEARING, PUMP MOTOR ROTOR 센서베어링
16.154	COVER, PUMP MOTOR ROTOR END 커버
16.155	WASHER, PUMP MOTOR ROTOR BEARING 와셔
16.156	RING, PUMP MOTOR ROTOR BEARING 링
16.157	ROTOR, PUMP MOTOR 로터
16.500	MOTOR ASSEMBLY, PUMP 모터
16.502	BEARING, PUMP MOTOR DRIVE END 베어링
16.533	FRAME, PUMP MOTOR DRIVE END 프레임
16.555	RETAINER, PUMP MOTOR DRIVE END BEARING 리테이너


16.571	SEAL, HYDRAULIC PUMP MOTOR ARMATURE SHAFT DRIVE EN 셀
16.573	TERMINAL BLOCK, HYDRAULIC PUMP MOTOR 터미널블록
16.587	SENSOR, PUMP MOTOR BRUSH WEAR INDICATOR 센서
16.588	SENSOR, PUMP MOTOR TEMPERATURE WARNING INDICATOR 센서
16.593	STATOR ASSY, HYDRAULIC-PUMP MOTOR 스테이터
16.594	RETAINER, HYDRAULIC PUMP MOTOR DRIVE END FRAME 리테이너
16.714	SPACER, PUMP MOTOR MOUNTING 스페이서
92.974	NUT, HYDRAULIC PUMP MOTOR RETAINER FASTENER 너트
93.258	FASTENER, PUMP MOTOR DRIVE END FRAME COVER 패스너
93.265	FASTENER, HYDRAULIC PUMP MOTOR TERMINAL 패스너
95.045	WASHER, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 와셔
95.501	FASTENER, PUMP MOTOR TERMINAL BLOCK CONNECTOR 패스너
95.873	NUT, HYDRAULIC PUMP MOTOR TERMINAL CLAMP FASTENER 너트




16.000	MOTOR ASSEMBLY, DRIVE 모터
16.012	BEARING, DRIVE MOTOR END 베어링
16.029	SEAL, DRIVE MOTOR ARMATURE SHAFT DRIVE END 씰
16.070	FASTENER, DRIVE MOTOR_LIFT LUG PLUG 패스너
16.071	SEAL, DRIVE MOTOR TO AXLE 씰
16.098	CONNECTOR, DRIVE MOTOR BRUSH-WEAR INDICATOR 센서
16.106	TERMINAL BLOCK, DRIVE MOTOR 터미널블록
16.107	SENSOR, DRIVE MOTOR TEMPERATURE WARNING INDICATOR 센서
16.114	WASHER, DRIVE MOTOR DRIVE END THRUST 와셔

16.116	FASTENER, DRIVE MOTOR TERMINAL 패스너
16.132	YOKE, STATOR 요크
16.147	SENSOR BEARING, DRIVE MOTOR ROTOR 센서베어링
16.148	RING, DRIVE MOTOR ROTOR BEARING 링
16.149	ROTOR, DRIVE MOTOR 로터
16.150	COVER, DRIVE MOTOR ROTOR END 커버
16.572	COVER, HYDRAULIC PUMP MOTOR DRIVE END FRAME 커버
65.168	BASE, DRIVE MOTOR FIELD CONTACTOR 베이스
93.232	WASHER, DRIVE MOTOR TERMINAL BLOCK FASTENER 와셔
93.233	FASTENER, DRIVE MOTOR TERMINAL 패스너
93.731	NUT, DRIVE MOTOR FASTENER 너트






65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.664	CONDUCTOR, CONTACTOR STATIONARY CONTACT 컨덕터
65.930	ASSEMBLED COIL & MAGNET FRAME, LINE CONTACTOR 코일& 마그넷
65.942	CONTACT SET, LINE CONTACTOR 컨택트세트
67.170	SUPPORT, LINE CONTACTOR STATIONARY CONTACT 서포트



CONTROLLER MOUNTING


19-000


19.240	FASTENER, CONTROL PANEL MOUNTING 패스너
67.211	FUSE, TRACTION CONTROLLER 퓨즈
67.213	FUSE, PUMP CONTROLLER 퓨즈
67.300	CONTROLLER, TRACTION 컨트롤러
67.400	CONTROLLER, PUMP 컨트롤러
93.999	FASTENER, CONTROL PANEL MOUNTING 패스너



20.190	WHEEL ASSY, DRIVE AXLE 휠
20.215	RETAINER, DIFFERENTIAL PINION OIL SEAL 리테이너
20.507	BEARING, INTERNAL GEAR HUB PINION SHAFT - OUTBOARD 베어링
20.509	BEARING, INTERNAL GEAR HUB PINION SHAFT - INBOARD 베어링
20.551	CAP, DRIVE AXLE HUB 캡
20.554	FASTENER, DRIVE AXLE HUB CAP 패스너
20.570	FASTENER, DRIVE WHEEL MOUNTING 패스너
20.574	SHAFT, DRIVE AXLE PLANET PINION 샤프트
20.581	HUB ASSEMBLY, DRIVE AXLE 허브

20.592	PLANET, DRIVE AXLE 플래닛
20.593	WASHER, PLANET PINION GEAR THRUST 와셔
20.598	GEAR, DRIVE AXLE PLANET PINION 기어
20.841	LOCATOR, DRIVE AXLE PLANET 로케이터
20.846	BEARING, DRIVE AXLE PLANET PINION GEAR 베어링
22.270	SEAL, DRIVE AXLE END HOUSING 씰
22.516	SEAL, BRAKE DISC HOUSING TO AXLE END HOUSING 씰
22.966	SPACER, AXLE END 스페이서
22.968	BEARING, PLANTEARY GEAR ASSEMBLY 베어링
22.969	THRUST WASHER, PLANTEARY GEAR ASSEMBLY 스러스트와셔
23.133	FASTENER, BRAKE LOCK UNIT ATTACHING 패스너
23.350	FLANGE & DRUM ASSEMBLY 플랜지& 드럼






DRIVE AXLE ASSEMBLY

20-104


20.080	BREATHER, DRIVE UNIT 브리더	20.561	SNAP RING, DRIVE AXLE SUN GEAR 스냅링
20.116	PIN, DRIVE AXLE HOUSING & DIFF ALIGNMENT 핀	20.569	RETAINER, DRIVE AXLE INTER GEAR 리테이너
20.190	WHEEL ASSY, DRIVE AXLE 휠	20.577	FASTENER, DRIVE AXLE PLANET 패스너
20.322	SPACER, DRIVE AXLE SHAFT BEARING 스페이서	20.585	KEY, HUB MOUNTING 키
20.371	FASTENER, DRIVE AXLE PLANET 패스너	20.586	SHAFT, DRIVE AXLE 샤프트
20.384	PLUG, DRIVE AXLE HOUSING 플러그	20.591	SEAL, AXLE HOUSING FASTENER 씰
20.431	SEAL, DRIVE AXLE INLET FITTING 씰	20.592	PLANET, DRIVE AXLE 플래닛
20.500	AXLE END ASSEMBLY, DRIVE RH 엑슬엔드	20.598	GEAR, DRIVE AXLE PLANET PINION 기어
20.501	AXLE END ASSEMBLY, DRIVE LH 엑슬엔드	20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.503	KEY, DRIVE AXLE SUN GEAR THRUST WASHER 키	20.631	SEAL, DRIVE AXLE PLANET CARRIER 씰
20.522	GEAR, DRIVE AXLE SHAFT 기어	20.636	SHAFT, DRIVE AXLE RING GEAR 샤프트
20.524	BEARING, DRIVE AXLE INTERMEDIATE GEAR SHAFT 베어링	20.638	BEARING, RING GEAR SHAFT OUTBOARD 베어링
20.542	BEARING, DRIVE AXLE SHAFT 베어링	20.640	SEAL, RING GEAR SHAFT BEARING HOUSING 씰
20.543	FASTENER, DRIVE AXLE SHAFT BEARING 패스너	20.668	SPACER, DRIVE AXLE SHAFT INBOARD BEARING 스페이서
20.553	BEARING, DRIVE AXLE SHAFT (INBOARD) 베어링	20.806	SPRING, DRIVE AXLE LUBRICATING PUMP PISTON 스프링

20.811	PLUG, DRIVE AXLE HOUSING 플러그
20.835	RETAINER, DRIVE AXLE RING GEAR 리테이너
20.837	BEARING, DRIVE AXLE RING GEAR SHAFT 베어링
20.849	PLUG, DRIVE AXLE HOUSING 플러그
22.390	DISC, BRAKE - INNER 디스크
22.391	DISC, BRAKE - OUTER 디스크
22.394	FASTENER, BRAKE DISC HUB 패스너
22.397	PLUG, BRAKE DISC HOUSING 플러그
22.642	FITTING, DRIVE AXLE INLET 피팅
22.702	DOWEL PIN, BRAKE DISC PISTON SLEEVE 다웰 핀
22.706	WASHER, DRIVE AXLE SHAFT BEARING 와셔
22.920	SPRING, BRAKE DISC PISTON PLATE FASTENER 스프링
23.286	PLATE, BRAKE BACKING 플레이트
23.346	ARM, PARKING BRAKE 암
23.750	PIN, BRAKE ACTUATING LEVER PIVOT 핀
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너
44.226	RING, DRIVE SHAFT BEARING 링
66.528	KIT, UPRIGHT TRUNNION *
93.270	FASTENER, RING GEAR SHAFT BEARING HOUSING 패스너



20.377	FASTENER, DRIVE AXLE TO FRAME 패스너
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
34.039	FITTING-LUB, UPRIGHT TRUNNION 피팅

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE TIRE MOUNTING

22-000

- | | |
|--------|---|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠& 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




BRAKE MOUNTING & COVER

22-012

02.285	STOP, ACCELERATOR PEDAL LINKAGE 스톱	22.758	SEAL, UNITROL PEDAL PAD STOP PLATE 씰
02.317	ROLLER, ACCELERATOR PEDAL 롤러	22.759	FASTENER, UNITROL PEDAL PAD STOP PLATE 패스너
02.465	FASTENER, ACCELERATOR CONTROL LINKAGE 패스너	22.760	HARNESS, UNITROL PEDAL SWITCH WIRING 하네스
03.465	PAD, ACCELERATOR PEDAL 패드	22.761	NUT, UNITROL PEDAL PAD TENSION SPRING RETAINER 너트
03.761	FASTENER, THROTTLE POSITIONER BRACKET 패스너	22.763	RETAINER, UNITROL PEDAL PAD TENSION SPRING 리테이너
03.903	BRACKET, ACCELERATOR PEDAL ROLLER 브라켓	22.764	GUIDE, UNITROL PEDAL PAD TENSION SPRING 가이드
03.904	FASTENER, ACCELERATOR PEDAL ROLLER BRACKET 패스너	22.765	SPRING, UNITROL PEDAL PAD TENSION 스프링
13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤	22.768	PIVOT, UNITROL PEDAL 피봇
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너	22.769	BEARING, UNITROL PEDAL BRACKET 베어링
13.572	BRACKET, ACCEL CONTROL ASSEMBLY MOUNTING 브라켓	22.770	BRACKET, UNITROL PEDAL 브라켓
13.573	FASTENER, ACCELERATOR CONTROL ASSY MOUNTING BRAC 패스너	22.771	SPRING, UNITROL PEDAL RETURN 스프링
22.754	PAD, UNITROL PEDAL 패드	22.772	BRACKET, UNITROL PEDAL MOUNTING 브라켓
22.755	SHAFT, UNITROL PEDAL PAD PIVOT 샤프트	22.773	WASHER, UNITROL PEDAL PIVOT FASTENER 와셔
22.756	FASTENER, UNITROL PEDAL PAD PIVOT 패스너	22.774	FASTENER, UNITROL PEDAL PIVOT 패스너
22.757	PLATE, UNITROL PEDAL PAD STOP 플레이트	22.881	WASHER, UNITROL PEDAL PAD STOP PLATE FASTENER 와셔

22.882	FASTENER, UNITROL PEDAL SWITCH 패스너
22.883	CONNECTOR, UNITROL PEDAL SWITCH WIRING HARNESS 커넥터
22.884	LOCK, UNITROL PEDAL SWITCH WIRING HARNESS CONNEC 로크
22.885	GROMMET, UNITROL PEDAL WIRING HARNESS 그로멧
22.886	RETAINER, UNITROL PEDAL RETURN SPRING 리테이너
22.888	FASTENER, UNITROL PEDAL MOUNTING BRACKET 패스너
22.889	BUMPER, UNITROL PEDAL PAD 범퍼
22.916	FASTENER, UNITROL SWITCH WIRE RETAINER 패스너
37.902	MAT, FLOORPLATE 매트
39.475	PLATE, FRONT FLOOR 플레이트
40.211	DECAL, WARNING UNITROL 데칼
60.596	HARNESS, UNITROL ASEMBLY TO TRUCK HARNESS 하네스

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE WHEEL & TIRE MOUNTING

22-013

- | | |
|--------|--|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠 & 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER WHEEL & TIRE MOUNTING

22-014

- | | |
|--------|---|
| 23.026 | FASTENER, STEER WHEEL
패스너 |
| 23.031 | STEER WHEEL AND TIRE ASSEMBLY
스티어휠 & 타이어 |


ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE (SOLID TYPE)

22-024

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어



- | | |
|--------|--|
| 22.338 | CLAMP, BRAKE FLUID RESERVOIR
클램프 |
| 22.452 | CLAMP, BRAKE MASTER CYLINDER FILLER LINE
클램프 |
| 22.614 | LINE, STABILIZER WHEEL BRAKE
라인 |
| 22.817 | FASTENER, BRAKE PIVOT RETAINER
패스너 |
| 23.207 | LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE
라인 |
| 23.208 | LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE
라인 |
| 23.792 | RESERVOIR, BRAKE FLUID
리저버 |




PARKING BRAKE & LINKAGE


23-431

- | | |
|--------|---|
| 15.571 | WIRE HARNESS, PARKING BRAKE SWITCH
와이어하네스 |
| 22.028 | ROD END, PARKING BRAKE RELEASE CYLINDER
로드엔드 |
| 22.030 | CYLINDER ASSEMBLY, PARKING BRAKE RELEASE
실린더 |
| 22.231 | LINE, PARKING BRAKE RELEASE VALVE PRESSURE
라인 |
| 22.372 | COVER, PARKING BRAKE RELEASE CYLINDER GLAND
커버 |
| 22.373 | SPRING, PARKING BRAKE RELEASE CYLINDER
스프링 |
| 22.374 | SPACER, PARKING BRAKE RELEASE CYLINDER
스페이서 |
| 22.963 | PLUG, MASTER CYLINDER
플러그 |
| 23.901 | FASTENER, SEAT BRAKE ACTUATING CYLINDER
패스너 |

23.954	SPRING, P/B RELEASE VALVE SPOOL RETURN 스프링
23.958	SPRING, P/B RELEASE CYLINDER RETURN 스프링
23.964	FASTENER, P/B RELEASE VALVE ACTUATOR 패스너
23.965	BRACKET, PARKING BRAKE RELEASE CYL MTG 브라켓
23.966	FASTENER, P/B RELEASE CYL MOUNTING BRACKET 패스너
23.977	CLAMP P/B REL VALVE SUMP RETURN HOSE 클램프
23.981	FITTING, P/B RELEASE VALVE INLET PORT 피팅
23.983	FITTING, P/B RELEASE VALVE PRESSURE LINE 피팅
23.985	LINE, P/B RELEASE VALVE PRESSURE 라인
28.947	LINE, AUXILIARY VALVE SUMP RETURN 라인
33.086	VALVE, SOLENOID 밸브
33.522	FITTING, SOLENOID VALVE OPTIONAL OUTLET 피팅
44.304	HOUSING, SOLENOID VALVE 하우징
91.796	NUT, PARKING BRAKE RELEASE CYLINDER ROD END 너트
91.797	WASHER, PARKING BRAKE RELEASE CYLINDER ROD END FAS 와셔
97.242	FASTENER, P/B RELEASE CYLINDER GLAND COVER 패스너
97.243	FASTENER, P/B RELEASE CYLINDER GLAND COVER 패스너




23.271	FASTENER, PARKING BRAKE LEVER 패스너
23.272	CABLE, PARKING BRAKE 케이블
23.281	CLEVIS, PARKING BRAKE CABLE END 클레비스
23.284	FASTENER, PARKING BRAKE CABLE BRACKET 패스너
23.287	BRACKET, PARKING BRAKE CABLE 브라켓
23.372	FASTENER, PARKING BRAKE DRAW ROD 패스너
23.544	ROD, PARKING BRAKE DRAW 로드
39.451	COVER, PARKING BRAKE LEVER 커버
90.047	FASTENER, PARKING BRAKE LEVER COVER 패스너



13.142	SWITCH, BRAKE INTERLOCK 스위치
13.145	FASTENER, BRAKE INTERLOCK SWITCH 패스너
22.111	ADAPTOR, BRAKE MASTER CYLINDER MOUNTING 어댑터
22.420	CLEVIS, MASTER CYLINDER PUSH ROD 클레비스
22.528	BLEEDER, BRAKE LINES ADAPTOR 블리더
23.051	FASTENER, MASTER CYLINDER MOUNTING BRACKET 패스너
23.100	PEDAL, BRAKE 페달
23.101	SHAFT, BRAKE PEDAL 샤프트
23.114	PAD & FASTENER, BRAKE PEDAL 패드& 패스너

23.136	SPRING, BRAKE PEDAL RETURN 스프링
23.145	FASTENER, BRAKE PEDAL SHAFT 패스너
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.157	FASTENER, BRAKE MASTER CYLINDER ATTACHING 패스너
23.160	ROD, PUSH 로드
23.174	GASKET, BRAKE MASTER CYLINDER OUTLET FITTING 가스켓
23.209	TEE, BRAKE LINE W/INTEGRAL MOUNT 티
23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.435	FASTENER, BRAKE PEDAL PIVOT BRACKET 패스너
23.464	SEAL, BRAKE CYLINDER BLEEDER PORT 씰
23.589	RETAINER, BRAKE ACTUATING LEVER 리테이너
38.189	PLATE, SWITCH MOUNTING 플레이트
90.144	WASHER, BRAKE INTERLOCK SWITCH FASTENER 와셔
92.026	RETAINER, BRAKE MASTER CYLINDER ACTUATING ROD PIN 리테이너




PARKING BRAKE SYSTEM

23-508


14.538	SWITCH, PARK BRAKE 스위치
22.115	SUPPORT, PARKING BRAKE LEVER MOUNTING BRACKET 서포트
22.473	COVER, HAND BRAKE LEVER 커버
23.266	FASTENER, PARKING BRAKE CABLE CLAMP 패스너
23.267	LEVER, PARKING BRAKE 레버
23.269	FASTENER, PARKING BRAKE LEVER 패스너
23.271	FASTENER, PARKING BRAKE LEVER 패스너
23.272	CABLE, PARKING BRAKE 케이블
23.273	CLAMP, PARKING BRAKE LEVER TO CABLE 클램프

23.281	CLEVIS, PARKING BRAKE CABLE END 클레비스
23.284	FASTENER, PARKING BRAKE CABLE BRACKET 패스너
23.287	BRACKET, PARKING BRAKE CABLE 브라켓
23.372	FASTENER, PARKING BRAKE DRAW ROD 패스너
23.486	SIDE PLATE, PARKING BRAKE 사이드플레이트
23.488	FASTENER, PARKING BRAKE SIDE PLATE 패스너
23.544	ROD, PARKING BRAKE DRAW 로드
23.862	BRACKET, PARKING BRAKE LEVER MOUNTING 브라켓



- | | |
|--------|--------------------------------------|
| 25.109 | KIT, STEER GEAR SEAL
키트 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |
| 25.630 | REPAIR KIT, STEERING COLUMN
리페어키트 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEERING WHEEL & COLUMN & GEAR MOUNTING


25-193

25.002	HORN BUTTON KIT 혼버튼키트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.034	FASTENER, STEERING GEAR ATTACHING 패스너
25.150	GEAR BOX ASSEMBLY, STEERING 기어박스
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.576	SPACER, STEERING HAND WHEEL 스페이서
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
25.804	COVER, HANDLE CONTROL ASSEMBLY 커버

25.936	PLUG, STEER COLUMN SWITCH 플러그
39.178	SWITCH, WINDSHIELD WIPER 스위치

ФОРКЛИФТ
www.forklift.ru

ASSEMBLY
COMPLETE 25.030




STEERING COLUMN SHAFT ASSEMBLY

25-291

25.003	NUT, HANDWHEEL 너트
25.011	FASTENER, STEERING COLUMN 패스너
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.038	HOUSING ASSEMBLY-CUP & BUSHING, STEERING 하우징
25.141	SHAFT, STEERING GEAR 샤프트
25.187	BEARING, STEER SHAFT 베어링
25.393	PIN, STEERING LINK (STEERING ARM) 핀
25.407	KEY, STEER COLUMN SHAFT COUPLING 키
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링


25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.873	BUSHING, STEER COLUMN AXIAL 부싱
25.874	BUSHING, STEER COLUMN TELESCOPING 부싱
25.933	FASTENER, STEERING COLUMN 패스너
25.954	ARM, TILT STEERING COLUMN ADJUSTOR 암
25.955	SUPPORT, STEERING COLUMN SHAFT 서포트
25.956	BRUSH, STEERING COLUMN SHAFT 브러쉬
25.957	BRUSH HOLDER, STEERING COLUMN SHAFT 브러쉬홀더
25.958	PIVOT, TILT STEERING COLUMN ADJUSTOR ARM 피봇
25.959	PIN, TILT STEERING COLUMN ADJUSTOR ARM 핀
26.351	WASHER, STEERING ARM PIN 와셔
91.631	WASHER, STEERING COLUMN UPPER BRACKET FASTENER 와셔
92.885	NUT, STEERING COLUMN UPPER BRACKET FASTENER 너트
92.895	WASHER, STEERING COLUMN SUPPORT FASTENER 와셔
92.897	NUT, STEERING COLUMN SUPPORT FASTENER 너트
93.603	FASTENER, STEERING COLUMN TILTING SPRING BALL STUD 패스너
94.888	RETAINER, STEERING COLUMN ADJUSTOR 리테이너



06.101	LEVER ASSEMBLY, FORWARD & REVERSE 레버
13.655	SWITCH, TURN INDICATOR 스위치
14.050	HARNESS, CONTROL CIRCUIT WIRING 하네스
15.709	SWITCH, EMERGENCY 스위치
25.012	CUSHION, STEERING COLUMN 쿠션
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.082	FASTENER, LEVER MOUNTING BRACKET 패스너
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.926	COVER, STEER COLUMN FRONT UPPER 커버

25.927	COVER, STEER COLUMN REAR UPPER 커버
25.928	COVER, STEER COLUMN FRONT LOWER 커버
25.929	COVER, STEER COLUMN REAR LOWER 커버
25.934	FASTENER, STEER COLUMN COVER 패스너
25.935	FASTENER, STEER COLUMN COVER 패스너
25.936	PLUG, STEER COLUMN SWITCH 플러그
60.904	SWITCH, STROBE LIGHT 스위치
97.084	FASTENER, STEER COLUMN COVER 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER AXLE MOUNTING

26-272

- | | |
|--------|---|
| 26.100 | AXLE ASSEMBLY, STEERING
스티어액슬 |
| 26.174 | SILENT BLOCK, AXLE MOUNTING (REAR)
사일런트블록 |
| 26.175 | FASTENER, SILENT BLOCK TO FRAME (REAR)
패스너 |
| 38.113 | PLATE, AXLE SILENT BLOCK COVER
플레이트 |




26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.003	SEAL KIT, PISTON ROD 씰키트
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 스티어실린더피스톤
26.093	GLAND, STEERING CYLINDER 그랜드
26.099	BUSHING, STEERING CYLINDER GLAND 부싱



26.000	CYLINDER ASSEMBLY, STEERING 실린더	26.139	CONE, STEER WHEEL HUB BEARING (OUTER) 콘
26.085	FASTENER, STEERING CYLINDER MOUNTING BRKT 패스너	26.140	WASHER, STEER WHEEL HUB BEARING THRUST 와셔
26.100	AXLE ASSEMBLY, STEERING 스티어액슬	26.141	FASTENER, STEER WHEEL HUB 패스너
26.119	AXLE, STEER 액슬	26.143	CAP, STEER WHEEL HUB 캡
26.124	SHIM, STEER AXLE KNUCKLE 심	26.148	KNUCKLE, STEER AXLE (LH) 너트
26.125	PIN, STEER AXLE KNUCKLE 핀	26.190	SEAL, STEER AXLE KNUCKLE OIL 씰
26.129	FITTING - LUB, STEER AXLE KNUCKLE 피팅	26.191	PLUG - EXPANSION, STEER AXLE KNUCKLE PIN 플러그
26.130	BEARING, STEER AXLE KNUCKLE PIN 베어링	26.227	SEAL, STEER AXLE FORK HOUSING 씰
26.132	KNUCKLE, STEER AXLE (RH) 너트	26.239	SEAL, STEER AXLE FORK COVER 씰
26.133	SEAL, STEER WHEEL HUB 씰	26.281	RETAINER, STEER AXLE HUB BRG KNUCKLE NUT 리테이너
26.134	CONE, STEER WHEEL HUB BEARING (INNER) 콘	26.338	PIN, STEERING ARM 핀
26.135	CUP, STEER WHEEL HUB BEARING (INNER) 컵	26.339	LUB-FITTING, STEERING ARM 윤활피팅
26.136	HUB & CUP, STEER WHEEL 허브&컵	26.340	BEARING, STEERING ARM PIN 베어링
26.137	FASTENER, STEER WHEEL 패스너	26.341	SPACER, STEER AXLE PIVOT BUSHING 스페이서
26.138	CUP, STEER WHEEL HUB BEARING (OUTER) 컵	26.347	PIN, STEER ARM 핀

26.348	LOCATOR, STEER CYLINDER 로케이터
26.351	WASHER, STEERING ARM PIN 와셔
26.417	ARM, STEERING 암
26.433	COVER, STEER AXLE KNUCKLE PIVOT (TOP) 커버
26.434	COVER, STEER AXLE KNUCKLE PIVOT (BOTTOM) 커버
92.507	WASHER, STEERING ARM FASTENER 와셔
93.700	FASTENER, STEER AXLE KNUCKLE PIN COVER 패스너
94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너
94.855	RETAINER, STEERING ARM PIN 리테이너




STEER LINES

26-315

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.807	CLAMP, POWER STEERING LINES 클램프

28.855	FITTING, POWER STEERING LINE 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






STEER LINES

26-320

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.807	CLAMP, POWER STEERING LINES 클램프
28.855	FITTING, POWER STEERING LINE 피팅

31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






STEER LINES

26-321

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.807	CLAMP, POWER STEERING LINES 클램프

28.855	FITTING, POWER STEERING LINE 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.807	CLAMP, POWER STEERING LINES 클램프
28.855	FITTING, POWER STEERING LINE 피팅

31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






STEER LINES

26-323

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.676	FITTING, STEER VALVE DISCHARGE LINE 피팅

28.807	CLAMP, POWER STEERING LINES 클램프
28.855	FITTING, POWER STEERING LINE 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






STEER LINES

26-324

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.676	FITTING, STEER VALVE DISCHARGE LINE 피팅
28.807	CLAMP, POWER STEERING LINES 클램프

28.855	FITTING, POWER STEERING LINE 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






STEER LINES

26-325

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.676	FITTING, STEER VALVE DISCHARGE LINE 피팅

28.807	CLAMP, POWER STEERING LINES 클램프
28.855	FITTING, POWER STEERING LINE 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너





STEER LINES


26-326

28.052	FITTING, STEERING GEAR 피팅
28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.448	FITTING, STEER CYLINDER LINE 피팅
28.676	FITTING, STEER VALVE DISCHARGE LINE 피팅
28.807	CLAMP, POWER STEERING LINES 클램프

28.855	FITTING, POWER STEERING LINE 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너



ASSEMBLY
COMPLETE — 33.000




PRIORITY VALVE ASSEMBLY

27-002

27.085	SEAL, FLOW CONTROL VALVE 씰
33.000	VALVE ASSEMBLY, FLOW CONTROL 밸브

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC PUMP MOUNTING

29-027


29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.119	FASTENER, PUMP HOUSING 패스너
29.474	SEAL, PUMP INLET FITTING 씰
29.608	MANIFOLD, HYDRAULIC PUMP INLET SUCTION 매니폴드
97.097	FASTENER, HYDRAULIC PUMP INLET SUCTION MANIFOLD 패스너

ASSEMBLY
COMPLETE

29.000



29.906




29.007

HYDRAULIC OIL FILTER

29-239

29.000	FILTER, HYDRAULIC OIL 필터
29.007	CARTRIDGE, HYDRAULIC OIL FILTER 카트리지
29.906	HEAD ASSEMBLY, HYDROSTATIC OIL FILTER 헤드




29.000	FILTER, HYDRAULIC OIL 필터
29.002	FASTENER, HYDRAULIC OIL FILTER 패스너
29.591	RUBBER, SUMP TANK MOUNTING 러버
29.701	TANK, SUMP 탱크
29.702	FASTENER, SUMP TANK 패스너
29.703	SEAL, SUMP TANK 씰
29.728	CAP, HYDRAULIC SUMP FILLER 캡
29.767	SEAL, SUMP TANK COVER 씰
29.768	FASTENER, SUMP TANK COVER 패스너

29.798 SCREEN, HYDRAULIC SUMP PRE FILTER
스크린

ФОРКЛИФТ
www.forklift.ru

ASSEMBLY
COMPLETE — 29.100

SEAL KIT — 29.028




HYDRAULIC PUMP ASSEMBLY

29-296

- | | |
|--------|--------------------------------------|
| 29.028 | SEAL KIT, HYDRAULIC UNIT PUMP
씰키트 |
| 29.087 | SEAL, HYDRAULIC PUMP HOUSING
씰 |
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.268 | COUPLING, MAIN HYDRAULIC PUMP
커플링 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (2SPOOL)

30-244

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	49.042	CAP, TILT CONTROL LEVER 캡
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐퍼
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	49.081	CAP, LIFT CONTROL LEVER 캡
30.085	LINK, CONTROL VALVE SPOOL 링크	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.089	LEVER, LIFT CONTROL 레버	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
30.094	KNOB, LIFT CONTROL LEVER 노브	91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
30.097	KNOB, TILT CONTROL LEVER 노브	91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너
30.787	BOOT, VALVE CONTROL LEVER 부트		

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (3SPOOL)


30-245

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	49.042	CAP, TILT CONTROL LEVER 캡
30.085	LINK, CONTROL VALVE SPOOL 링크	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐프너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.081	CAP, LIFT CONTROL LEVER 캡
30.089	LEVER, LIFT CONTROL 레버	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.090	LEVER, TILT CONTROL 레버	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
30.787	BOOT, VALVE CONTROL LEVER 부트	91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트

93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (4SPOOL)

30-246

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	30.787	BOOT, VALVE CONTROL LEVER 부트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.085	LINK, CONTROL VALVE SPOOL 링크	49.042	CAP, TILT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐프너
30.089	LEVER, LIFT CONTROL 레버	49.081	CAP, LIFT CONTROL LEVER 캡
30.090	LEVER, TILT CONTROL 레버	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.094	KNOB, LIFT CONTROL LEVER 노브	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.097	KNOB, TILT CONTROL LEVER 노브	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트

91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너






30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐프너
60.895	JOYSTICK, ELECTRONIC HYDRAULIC 조이스틱


60.896	JOYSTICK, ELECTRONIC HYDRAULIC 조이스틱
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
96.816	FASTENER, JOYSTICK 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너






30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐프너
60.900	FINGER TIP, MINI LEVER 핑거팁

60.901	PLUG, FINGER TIP 플러그
60.902	PLATE, MINI LEVER 플레이트
60.903	FASTENER, FINGER TIP MOUNTING 패스너
60.953	KNOB, MINI LEVER 노브
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (3SPOOL)


30-313

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	32.138	SWITCH, PUSH BUTTON 스위치
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.085	LINK, CONTROL VALVE SPOOL 링크	49.042	CAP, TILT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐퍼
30.089	LEVER, LIFT CONTROL 레버	49.081	CAP, LIFT CONTROL LEVER 캡
30.090	LEVER, TILT CONTROL 레버	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.094	KNOB, LIFT CONTROL LEVER 노브	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.097	KNOB, TILT CONTROL LEVER 노브	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.787	BOOT, VALVE CONTROL LEVER 부트	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (4SPOOL)

30-314

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	30.787	BOOT, VALVE CONTROL LEVER 부트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	32.138	SWITCH, PUSH BUTTON 스위치
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.085	LINK, CONTROL VALVE SPOOL 링크	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.042	CAP, TILT CONTROL LEVER 캡
30.089	LEVER, LIFT CONTROL 레버	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐퍼
30.090	LEVER, TILT CONTROL 레버	49.081	CAP, LIFT CONTROL LEVER 캡
30.094	KNOB, LIFT CONTROL LEVER 노브	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.097	KNOB, TILT CONTROL LEVER 노브	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터


52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너






27.052	VALVE ASSEMBLY, AUXILIARY SOLENOID 밸브
27.055	FASTENER, AUXILIARY SOLENOID VALVE 패스너
27.112	PLUG, VALVE SOLENOID TERMINAL 플러그
27.113	SEAL, LIFT VALVE SOLENOID 씰
27.114	SEAL, AUXILIARY VALVE SOLENOID 씰
28.960	COIL, HYDRAULIC AUXILIARY SOLENOID VALVE 코일
29.194	CAP, RELIEF VALVE 캡
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.116	SEAL KIT, HYDRAULIC VALVE SECTION 씰키트

30.530	FASTENER, VALVE THRU 패스너
30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.048	FASTENER, RELIEF VALVE COVER 패스너
33.056	FASTENER, RELIEF VALVE 패스너
33.230	VALVE ASSEMBLY, LIFT SOLENOID 밸브
33.232	FASTENER, LIFT VALVE SOLENOID COIL 패스너
33.233	COIL, LIFT VALVE SOLENOID 코일
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
33.349	SPRING, LIFT LINE CHECK VALVE RELIEF POPPET 스프링
33.669	BALL, RELIEF VALVE POPPET CHECK 볼
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.190	MANIFOLD, HYDRAULIC VALVE TILT 매니폴드
49.191	MANIFOLD, HYDRAULIC VALVE AUX 매니폴드
49.192	PIN, HYDRAULIC VALVE BODY 핀
93.671	FASTENER, HYDRAULIC VALVE COVER 패스너



06.415	VALVE, SELECTOR SHUT - OFF 밸브
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.106	PLUG, INLET SECTION CHECK VALVE 플러그
30.107	FASTENER, VALVE THRU 패스너
30.530	FASTENER, VALVE THRU 패스너
30.715	FASTENER, VALVE THRU 패스너
33.236	SEAL KIT, LIFT VALVE 씰키트
39.347	FASTENER, CAB REAR WINDOW LATCH 패스너

49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.164	ADAPTOR, FILTER 어댑터
49.183	VALVE KIT, 1ST AUXILIARY 밸브키트
49.193	SEAL KIT, TILT SECTION 씰키트
49.194	SEAL KIT, INLET SECTION 씰키트
91.040	NUT, VALVE THRU FASTENER 너트



13.537 SWITCH, CONTROL VALVE PUMP OPERATING
스위치

30.000 VALVE ASSEMBLY, HYDRAULIC
밸브

30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너

30.073 BRACKET, HYDRAULIC VALVE MOUNTING
브라켓

30.080 PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET
플런저

30.081 BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT
베어링

30.085 LINK, CONTROL VALVE SPOOL
링크

30.087 PIN, VALVE CONTROL LEVER PIVOT
핀

30.089 LEVER, LIFT CONTROL
레버

30.090 LEVER, TILT CONTROL
레버

30.094 KNOB, LIFT CONTROL LEVER
노브

30.097 KNOB, TILT CONTROL LEVER
노브

30.102 BRACKET, HYDRAULIC VALVE SWITCH
브라켓

30.148 FASTENER, CONTROL LINKAGE BRACKET
패스너

30.256 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.787 BOOT, VALVE CONTROL LEVER
부트

30.817 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.843 LEVER, AUXILIARY VALVE CONTROL (1ST AUX)
레버

30.844 LEVER, AUXILIARY VALVE CONTROL (2ND AUX)
레버

32.138 SWITCH, PUSH BUTTON
스위치

32.142 PLATE, SWITCH MOUNTING BRACKET
플레이트

49.024 FASTENER, HYDRAULIC VALVE MOUNTING BRACKET
패스너

49.042 CAP, TILT CONTROL LEVER
캡

49.071 DAMPENER, HYDRAULIC VALVE BRACKET
댐퍼

49.081 CAP, LIFT CONTROL LEVER
캡

49.102 FASTENER, VALVE CONTROL LEVER PIVOT RETAINER
패스너

49.110 PIN, VALVE SPOOL CLEVIS ROD
핀

49.111 RETAINER, VALVE SPOOL CLEVIS ROD PIN
리테이너


49.124 CAP, AUXILIARY CONTROL LEVER
캡

52.162 CONNECTOR, AUXILIARY VALVE LEVER WIRE
커넥터

52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (2SPOOL)

30-572

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.138	SWITCH, PUSH BUTTON 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	49.042	CAP, TILT CONTROL LEVER 캡
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐퍼
30.085	LINK, CONTROL VALVE SPOOL 링크	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.090	LEVER, TILT CONTROL 레버	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.094	KNOB, LIFT CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.097	KNOB, TILT CONTROL LEVER 노브	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
30.787	BOOT, VALVE CONTROL LEVER 부트	91.793	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트

93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너






30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.250	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너


30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.230	VALVE ASSEMBLY, LIFT SOLENOID 밸브
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.077	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 씰
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.206	VALVE, HYDRAULIC SHUT-OFF 밸브
49.209	VALVE, HYDRAULIC SHUT-OFF (LIFT) 밸브





30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.250	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너


30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.077	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 씰
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.206	VALVE, HYDRAULIC SHUT-OFF 밸브



- | | |
|--------|---|
| 31.030 | LINE, VALVE TO LIFT CYLINDER
라인 |
| 31.061 | FITTING, VALVE TILT PORT "A"
피팅 |
| 31.062 | FITTING, VALVE TILT PORT "B"
피팅 |
| 31.072 | LINE, RH TILT CYLINDER ROD PORT
라인 |
| 31.077 | FITTING, LH TILT CYLINDER ROD PORT
피팅 |
| 31.083 | LINE, RH TILT CYLINDER ANCHOR PORT
라인 |
| 31.160 | FITTING, LH TILT CYLINDER ANCHOR PORT
피팅 |
| 31.162 | FITTING, RH TILT CYLINDER ANCHOR PORT
피팅 |
| 31.175 | LINE, VALVE TILT PORT "B"
라인 |

31.182	LINE, VALVE TILT PORT "A" 라인
31.200	FITTING, MAIN VALVE LIFT PORT 피팅
31.600	FITTING, RH TILT CYLINDER ROD PORT 피팅


ФОРКЛИФТ
www.forklift.ru



28.801	SEAL, HYD PUMP OUTLET PORT FITTING 씰
28.912	LINE, HYDRAULIC SUMP TO PUMP 라인
29.607	MANIFOLD, HYDRAULIC PUMP OUTLET LINE 매니폴드
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.001	LINE, SUMP OUTLET 라인
31.002	CLAMP, SUMP OUTLET LINE 클램프
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프
31.014	FITTING, PUMP OUTLET 피팅

31.018	LINE, PUMP OUTLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
37.541	COVER, HYDRAULIC LINES 커버
95.026	FASTENER, HYDRAULIC LINES COVER 패스너
95.234	FASTENER, HYDRAULIC LINE CLAMP BRACKET 패스너
97.096	FASTENER, HYDRAULIC PUMP OUTLET LINE MANIFOLD 패스너






HYDRAULIC LIFT & TILT LINES

31-182

- | | |
|--------|---|
| 31.030 | LINE, VALVE TO LIFT CYLINDER
라인 |
| 31.061 | FITTING, VALVE TILT PORT "A"
피팅 |
| 31.062 | FITTING, VALVE TILT PORT "B"
피팅 |
| 31.072 | LINE, RH TILT CYLINDER ROD PORT
라인 |
| 31.077 | FITTING, LH TILT CYLINDER ROD PORT
피팅 |
| 31.083 | LINE, RH TILT CYLINDER ANCHOR PORT
라인 |
| 31.160 | FITTING, LH TILT CYLINDER ANCHOR PORT
피팅 |
| 31.162 | FITTING, RH TILT CYLINDER ANCHOR PORT
피팅 |
| 31.175 | LINE, VALVE TILT PORT "B"
라인 |

31.182	LINE, VALVE TILT PORT "A" 라인
31.200	FITTING, MAIN VALVE LIFT PORT 피팅
31.476	FITTING, VALVE LIFT PORT 피팅
31.600	FITTING, RH TILT CYLINDER ROD PORT 피팅






28.912	LINE, HYDRAULIC SUMP TO PUMP 라인
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.001	LINE, SUMP OUTLET 라인
31.002	CLAMP, SUMP OUTLET LINE 클램프
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프
31.014	FITTING, PUMP OUTLET 피팅
31.018	LINE, PUMP OUTLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅

31.480	PLUG, PRESSURE GAUGE PORT 플러그
33.000	VALVE ASSEMBLY, FLOW CONTROL 밸브
95.090	FASTENER, HYDRAULIC PRIORITY VALVE 패스너
95.234	FASTENER, HYDRAULIC LINE CLAMP BRACKET 패스너






28.266	CLAMP, POWER STEERING SUMP RETURN LINE 클램프
28.498	LINE, SUMP RETURN 라인
28.914	FITTING, VALVE SUMP RETURN PORT 피팅
31.120	LINE, SUMP RETURN (POWER STEERING) 라인
31.163	CLAMP, SUMP RETURN LINE 클램프
31.197	LINE, MAIN VALVE TO SUMP RETURN 라인
31.446	FITTING, FILTER OUTLET PORT 피팅
31.639	FITTING, FILTER INLET PORT 피팅
31.746	FITTING, POWER STEERING SUMP RETURN PORT 피팅

31.822 LINE, FILTER OUTLET TO SUMP
라인


ФОРКЛИФТ
www.forklift.ru




28.266	CLAMP, POWER STEERING SUMP RETURN LINE 클램프
28.498	LINE, SUMP RETURN 라인
28.914	FITTING, VALVE SUMP RETURN PORT 피팅
31.120	LINE, SUMP RETURN (POWER STEERING) 라인
31.163	CLAMP, SUMP RETURN LINE 클램프
31.197	LINE, MAIN VALVE TO SUMP RETURN 라인
31.446	FITTING, FILTER OUTLET PORT 피팅
31.639	FITTING, FILTER INLET PORT 피팅
31.746	FITTING, POWER STEERING SUMP RETURN PORT 피팅

31.822 LINE, FILTER OUTLET TO SUMP
라인

ФОРКЛИФТ
www.forklift.ru



32.000	CYLINDER ASSEMBLY, TILT 실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드& 피스톤
32.072	PACKING KIT, TILT CYLINDER 패킹키트
32.129	SPACER, TILT CYLINDER BARREL END 스페이서




32.196	ROD, HYDRAULIC ACCUMULATOR LINE 로드
32.800	ACCUMULATOR, HYDRAULIC 어큐물레이터
32.801	CLAMP, HYDRAULIC ACCUMULATOR MOUNTING 클램프
32.802	BRACKET, HYDRAULIC ACCUMULATOR 브라켓
32.805	SEAL, HYDRAULIC ACCUMULATOR CONNECTOR 씰
32.806	CONNECTOR, HYDRAULIC ACCUMULATOR 커넥터
32.810	LINE, HYDRAULIC ACCUMULATOR 라인
32.814	FITTING, HYDRAULIC ACCUMULATOR LINE 피팅
32.819	LINE, HYDRAULIC ACCUMULATOR 라인

32.841	NUT, HYDRAULIC ACCUMULATOR FITTING 너트
32.842	SEAL, HYDRAULIC ACCUMULATOR FITTING 씰



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT CYLINDER MOUNTING


32-145

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링
32.053	BEARING, TILT CYLINDER ROD END 베어링

32.075	RETAINER, TILT CYL ROD END BEARING 리테이너
97.124	FASTENER, POWER STEERING MOTOR SENSOR MAGNET 패스너
97.215	FASTENER, TILT CYL ROD END BEARING RETAINER 패스너




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT AMOUNT GP


32-167

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심



- | | |
|--------|--|
| 33.330 | VALVE ASSEMBLY, CLAMP SOLENOID
밸브 |
| 33.333 | COIL, CLAMP VALVE SOLENOID
코일 |
| 33.387 | SEAL KIT, DEVICE SELECTOR VALVE
씰키트 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




CLAMP LEVER LOCK SYSTEM


33-037

- | | |
|--------|--|
| 14.648 | CONNECTOR, SOLENOID VALVE FEED WIRE
커넥터 |
| 14.837 | TERMINAL, SOLENOID VALVE WIRING CONNECTOR
터미널 |
| 14.964 | LOCK, SOLENOID VALVE FEED WIRE CONNECTOR
로크 |
| 15.397 | FUSE, SOLENOID VALVE
퓨즈 |
| 15.830 | WIRING HARNESS, CLAMP SOLENOID VALVE
와이어하네스 |
| 33.330 | VALVE ASSEMBLY, CLAMP SOLENOID
밸브 |
| 33.338 | FASTENER, CLAMP SOLENOID VALVE
패스너 |
| 33.526 | RELAY, CLAMP SOLENOID VALVE
릴레이 |
| 33.840 | FITTING, CLAMP SOLENOID VALVE INLET PORT
피팅 |


33.842	FITTING, CLAMP SOLENOID VALVE OUTLET PORT 피팅
50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
50.427	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.428	LINE, 2ND AUXILIARY VALVE "B" PORT 라인
50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅
59.099	LINE, 2ND AUXILIARY FUNCTION 라인



- | | |
|--------|---|
| 33.600 | RELIEF VALVE, DEVICE VARIABLE PRESSURE
릴리프밸브 |
| 33.601 | LEVER, DEVICE VARIABLE RELIEF VALVE
레버 |
| 33.610 | SEAL, DEVICE PRESS RELIEF VAL CHECK PORT PLUG
씰 |
| 33.613 | SEAL, DEVICE RELIEF VALVE PISTON ADJ END
씰 |
| 33.618 | CARTRIDGE KIT, DEVICE VARIABLE RELIEF VALVE
카트리지키트 |
| 33.631 | FASTENER, DEVICE RELIEF VALVE
패스너 |



- 33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
밸브
- 33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너
- 33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
씰키트
- 33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어키트




UPRIGHT MOUNTING

34-009

34.036 BUSHING, UPRIGHT TRUNNION
부싱

34.045 SHIM, UPRIGHT TRUNNION
십




LOAD BACK REST MOUNTING


34-044

- | | |
|--------|--|
| 34.998 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 66.431 | RETAINER, LBR CAPSCREW
리테이너 |


ASSEMBLY
COMPLETE 34.300




TYPE - 1



TYPE - 2



TYPE - 3



TYPE - 4

CARRIAGE ASSEMBLY

34-103

34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.307	ROLLER, CARRIAGE INNER THRUST 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.321	FASTENER, CARRIAGE ROLLER SHAFT 패스너
34.328	ROLLER, CARRIAGE CAPTIVE 롤러
34.329	RETAINER, CARRIAGE CAPTIVE ROLLER 리테이너
34.330	FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER 패스너
34.332	SHIM, CARRIAGE CAPTIVE ROLLER 심

34.340

CARRIAGE WELDED ASSEMBLY

캐리지용 접물

ФОРКЛИФТ
www.forklift.ru


This Carriage assembly was manufactured by the CASCADE CORPORATION and is not serviced by CLARK Material Handling Company.

CASCADE parts manuals, technical specifications and lists of worldwide distributors are available on-line at:

<http://www.cascorp.com>.

When ordering service parts, it will be necessary to provide CASCADE with the CASCADE model and serial numbers of the carriage. CASCADE will not recognize the CLARK carriage part number listed on the PIC or in PartsPRO.

34.300	CARRIAGE ASSEMBLY COMPLETE
34.340	CARRIAGE WELDED ASSEMBLY




SHEET METAL & TRIM

37-034

15.790	WIRE, BATTERY STOPPER 와이어	38.245	ROLLER ASSEMBLY, BATTERY 롤러
15.791	HOLDER, BATTERY 홀더	38.282	COVER, BATTERY RETAINER INTERLOCK SWITCH 커버
15.792	SLEEVE, BATTERY STOOPER WIRE 슬리브	38.283	FASTENER, BATTERY RETAINER INTERLOCK SWITCH COVE 패스너
15.861	SHIELD, SPARK PROVENTION 실드	38.472	PAD, RH STEP NON-SKID 패드
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너	39.475	PLATE, FRONT FLOOR 플레이트
37.374	COVER, HYDRAULIC VALVE 커버	39.556	COVER, VALVE LINKAGE ACCESS 커버
37.741	SOUND ABSORBER, FLOOR PLATE 흡음재	39.570	COVER ASSEMBLY, DASH 커버
37.808	COVER, REAR RH 커버	39.571	FASTENER, DASH COVER 패스너
37.809	COVER, REAR LH 커버	47.361	KNOB, SIDE COVER 노브
37.902	MAT, FLOORPLATE 매트	47.362	COVER, CABLE PROTECTION 커버
38.050	STEP ASSEMBLY, LH 스텝	47.363	FASTENER, CABLE PROTECTION COVER 패스너
38.052	FASTENER, STEP FRONT 패스너	93.671	FASTENER, HYDRAULIC VALVE COVER 패스너
38.146	PLATE, BATTERY STOP 플레이트	97.162	FASTENER, SIDE COVER TO FRAME 패스너
38.227	POCKET, DASH PANEL 포켓	97.163	FASTENER, SIDE COVER 패스너
38.233	RUBBER, FRAME SIDE COVER 러버		


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



CAB MOUNTING

37-035

37.300	CAB ASSEMBLY 캐빈
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너




37.300	CAB ASSEMBLY 캐빈	39.144	HANDLE, RH DOOR OUTSIDE 핸들
37.468	CATCH, CAB DOOR LATCH 캐치	39.147	FASTENER, RIGHT HAND DOOR LATCH 패스너
37.554	REAR GLASS COMPLETE, CABIN 리어글래스	39.152	DOOR ASSEMBLY, LEFT HAND 도어
37.636	COVERING, CAB INSIDE ROOF 커버링	39.187	SEAL, DOOR HINGE 씰
37.675	COVER, CAB DOOR INSIDE LEFT 커버	39.192	GLASS, RIGHT HAND DOOR (LOWER) 글래스
37.679	HANDLE, RH DOOR INSIDE 핸들	39.193	WEATHERSEAL, RH DOOR GLASS (LOWER) 웨더씰
37.687	COVER, CAB DOOR INSIDE RIGHT 커버	39.205	GLASS, RH DOOR REAR 글래스
37.835	COVER, CAB ROOF 커버	39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
38.235	WEATHERSEAL, REAR DOOR 웨더씰	39.295	WEATHERSEAL, DOOR REAR GLASS 웨더씰
39.101	GLASS, WINDSHIELD 글래스	39.318	PANEL, REAR LOWER 판넬
39.117	ROOF SCREEN 루프스크린	39.319	FASTENER, LOWER REAR PANEL 패스너
39.131	DOOR ASSEMBLY, RIGHT HAND 도어	39.320	SEAL STRIP, REAR PANEL LOWER 씰스트립
39.138	WEATHERSEAL, RIGHT HAND DOOR 웨더씰	39.339	FASTENER, RH DOOR INSIDE HANDLE 패스너
39.139	SEAL, RIGHT HAND DOOR LOWER 씰	39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.141	SEAL, RIGHT HAND DOOR LOWER 씰	39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너

39.946	LANYARD, OVERHEAD GUARD REAR SUPPORT FASTENER 랜야드
39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우
41.133	PANEL, RH DOOR INNER 판넬
41.135	PANEL, LH DOOR INNER 판넬
47.144	LATCH, RH DOOR INSIDE 래치
47.145	LATCH, LH DOOR INSIDE 래치
47.241	DOOR ASSY, CAB REAR (RH) 도어
47.242	DOOR ASSY, CAB REAR (LH) 도어
47.370	SPACER, CAB DOOR HINGE 스페이서
94.582	FASTENER, CAB DOOR LATCH CATCH 패스너
95.323	FASTENER, CAB INSIDE ROOF COVERING 패스너
95.383	FASTENER, DOOR INSIDE LATCH COVER 패스너
97.168	FASTENER, OVERHEAD GUARD REAR SUPPORT LANYARD 패스너

ASSEMBLY
COMPLETE — 39.248LH
39.977RH


NOTE :
ITEMS TO BE NOT SOLD
SEPARATELY MARKED "NSS"



CAB DOOR SASH ASSEMBLY


37-037

37.799	LATCH, CAB DOOR WINDOW ASSEMBLY 래치
39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
39.298	CHANNEL, FRONT DOOR GLASS - FRONT 채널
39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우
47.303	GLASS, CAB DOOR (FRONT) 글래스
47.304	GLASS, CAB DOOR (REAR) 글래스
47.307	CHANNEL, CAB SIDE DOOR WINDOW 채널
47.364	CHANNEL, CAB SIDE DOOR WINDOW (CENTER) 채널
47.365	STOPPER, CAB SIDE DOOR WINDOW GLASS 스토퍼



37.166	HINGE, COVER CAB ROOF 힌지
37.835	COVER, CAB ROOF 커버
41.608	SOUND ABSORBER, CAB ROOF COVER 흡음재
41.609	SOUND ABSORBER, CAB ROOF COVER 흡음재
47.122	SEAL, COVER CAB ROOF HANDLE 셀
47.127	RUBBER, CAB ROOF COVER 리버
47.207	SEAL, COVER CAB ROOF HANDLE 셀
47.366	BRACKET, CAB ROOF COVER MOUNTING 브라켓
47.367	PIN, CAB ROOF COVER HINGE PIVOT 핀


47.368	SPRING, CAB ROOF COVER HINGE PIVOT 스프링
47.369	PIVOT, CAB ROOF COVER HINGE 피벗
96.833	FASTENER, COVER CAB ROOF HINGE 패스너
97.167	FASTENER, CAB ROOF COVER MOUNTING BRACKET 패스너




13.228	LAMP ASSEMBLY, DOME 램프	39.233	ARM, REAR WINDOW WIPER 암
13.229	BULB, DOME LAMP 전구	39.234	BLADE, REAR WINDOW WIPER 블레이드
15.430	GROMMET, CABIN WIRING HARNESS 그로멧	41.401	BOX, AUDIO AND TRANSCEIVER MOUNTING 박스
15.448	DIODE, HARNESS 다이오드	41.402	COVER, AUDIO AND TRANSCEIVER MOUNTING BOX 커버
37.300	CAB ASSEMBLY 캐빈	41.404	ANTENNA, AUDIO 안테나
37.437	PUMP & TANK, WINDSHIELD WASHER 펌프& 탱크	41.407	AUDIO 오디오
37.461	NOZZLE, WINDSHIELD GLASS WASHER 노즐	41.411	BRACKET, AUDIO AND TRANSCEIVER BOX MOUNTING 브라켓
37.481	LINE, WINDOW GLASS WASHER 라인	41.412	CAP, AUDIO AND TRANSCEIVER MOUNTING BOX 캡
37.624	SPEAKER, CABIN 스피커	41.599	PLATE, AUDIO COVER 플레이트
37.667	COVER, CAB REAR PANEL WIPER MOTOR 커버	60.292	COVER, CAB SWITCH PANEL 커버
37.794	CLIP, CAB WINDSHIELD WASHING LINE 클립	60.295	FUSE, CAB SWITCH PANEL 퓨즈
39.200	MOTOR, WINDSHIELD WIPER 모터	60.296	SWITCH, WINDSHIELD WIPER (REAR) 스위치
39.203	ARM, WINDSHIELD WIPER 암	60.299	SWITCH, HEATER ON/OFF 스위치
39.204	BLADE, WINDSHIELD WIPER 블레이드	60.330	WIRING HARNESS, CAB 와이어하네스
39.230	MOTOR, REAR WINDOW WIPER 모터	94.497	FASTENER, WINDSHIELD WASHER TANK 패스너

94.570	FASTENER, CAB SWITCH PANEL COVER 패스너
95.302	FASTENER, LOUDSPEAKER 패스너
95.304	FASTENER, AUDIO AND TRANSCEIVER BOX MOUNTING BRA 패스너
95.305	FASTENER, AUDIO AND TRANSCEIVER BOX TO MOUNTING 패스너
97.172	FASTENER, CAB WINDSHIELD WASHING LINE 패스너






15.377	WIRING HARNESS, MACHINE TO CABIN 와이어하네스
19.828	FUSE, CONTROL CIRCUIT 퓨즈
37.300	CAB ASSEMBLY 캐빈
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너




37.300	CAB ASSEMBLY 캐빈
37.835	COVER,CAB ROOF 커버
39.101	GLASS, WINDSHIELD 글래스
39.117	ROOF SCREEN 루프스크린



15.430	GROMMET, CABIN WIRING HARNESS 그로멧
37.300	CAB ASSEMBLY 캐빈
37.437	PUMP & TANK, WINDSHIELD WASHER 펌프& 탱크
37.461	NOZZLE, WINDSHIELD GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
39.200	MOTOR, WINDSHIELD WIPER 모터
39.203	ARM, WINDSHIELD WIPER 암
39.204	BLADE, WINDSHIELD WIPER 블레이드
60.330	WIRING HARNESS, CAB 와이어하네스

94.497 FASTENER, WINDSHIELD WASHER TANK
패스너

ФОРКЛИФТ
www.forklift.ru




37.554	REAR GLASS COMPLETE, CABIN 리어글래스
37.559	PIN, CABIN REAR GLASS HANGER 핀
37.560	RETAINER, CAB REAR GLASS HANGER PIN 리테이너
39.110	WEATHERSEAL, REAR GLASS SETTING 웨더셀
39.280	GLASS, REAR WINDOW - MOVEABLE 글래스
39.346	LATCH, CAB REAR WINDOW 래치
39.347	FASTENER, CAB REAR WINDOW LATCH 패스너
39.349	WEATHERSEAL, CAB REAR WINDOW 웨더셀
47.271	RUBBER, CAB REAR GLASS GAS SPRING MOUNTING 리버

47.272	BRACKET, CAB REAR GLASS GAS SPRING MOUNTING 브라켓
47.371	CAP, CAB REAR GLASS GAS SPRING MOUNTING FASTENER 캡
47.372	SEAL, CAB REAR GLASS GAS SPRING MOUNTING FASTENER 씰
47.373	SHOCK ABSORBER, CAB REAR GLASS 쇼크업쇼버
97.171	FASTENER, CAB REAR GLASS GAS SPRING MOUNTING 패스너



ASSEMBLY
COMPLETE — 39.689




BACK MIRROR

37-076

39.184 FASTENER, REAR VIEW MIRROR
패스너

39.689 MIRROR, REAR VIEW
미러

ASSEMBLY
COMPLETE 37.920




SEAT ARMREST ASSEMBLY

37-122

- | | |
|--------|--|
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 47.418 | ADJUSTOR, SEAT ARMREST ASSEMBLY
어드저스터 |
| 47.420 | SLIDER, SEAT ARMREST
슬라이더 |
| 47.422 | POSITIONER, SEAT ARMREST
포지셔너 |


ASSEMBLY
COMPLETE 37.920



SEAT ARMREST ASSEMBLY

37-123

37.920	ARMREST RH, SEAT 암레스트
47.418	ADJUSTOR, SEAT ARMREST ASSEMBLY 어드저스터
47.419	COVER, SEAT ARMREST ADJUSTOR 커버
47.420	SLIDER, SEAT ARMREST 슬라이더
47.421	PLATE, SEAT ARMREST ADJUSTOR 플레이트
47.422	POSITIONER, SEAT ARMREST 포지셔너
96.406	SCREW, SEAT ARMREST ADJUSTING 스크류




SEAT ARMREST ASSEMBLY

37-124

- | | |
|--------|---------------------------------------|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |

NOTE :
NON SERVICEABLE
ITEMS MARKED "N"




BATTERY COVER & REAR COVER MOUNTING

37-125

- | | |
|--------|------------------------------------|
| 37.022 | SPRING, HOOD PROP INNER
스프링 |
| 37.497 | HANDLE, TOP HOOD LATCH
핸들 |
| 39.422 | HINGE, TOP HOOD
힌지 |
| 39.460 | COVER ASSEMBLY, BATTERY
커버 |
| 39.599 | FASTENER, HOOD PIVOT HINGE
패스너 |
| 39.611 | FASTENER, HOOD PROP SUPPORT
패스너 |
| 39.616 | FASTENER, TOP HOOD LATCH
패스너 |
| 39.704 | SPRING, HOOD PROP (OUTER)
스프링 |
| 39.705 | FASTENER, HOOD PROP
패스너 |

47.283	COVER, FRAME REAR 커버
47.284	WEATHERSTRIP, FRAME REAR COVER 웨더스트립
47.285	LATCH, FRAME REAR COVER 래치
47.387	BRACKET, FRAME COVERING HOOD LINKAGE 브라켓
47.388	HINGE, FRAME REAR COVER 힌지
47.389	HOLDER, REAR COVER LATCH 홀더
94.436	FASTENER, HOOD PROP BRACKET SUPPORT 패스너
97.217	FASTENER, FRAME COVERING HOOD LINKAGE BRACKET 패스너
97.218	FASTENER, REAR COVER LATCH HOLDER 패스너
97.219	FASTENER, REAR COVER LATCH 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




ARMREST MOUNTING (ELH)

37-168

- | | |
|--------|---|
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 37.923 | BRACKET, SEAT ARMREST RIGHT HAND
브라켓 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |



38.869	COUNTERWEIGHT 카운터웨이트
38.870	FASTENER, COUNTERWEIGHT (LOWER) 패스너
38.871	FASTENER, COUNTERWEIGHT (UPPER) CONTINUED 패스너
38.920	PIN, COUPLER 핀
40.014	DECAL, MODEL NAME 데칼




37.300	CAB ASSEMBLY 캐빈	39.131	DOOR ASSEMBLY, RIGHT HAND 도어
37.468	CATCH, CAB DOOR LATCH 캐치	39.138	WEATHERSEAL, RIGHT HAND DOOR 웨더셀
37.487	FILLER, DOOR WINDOW WEATHERSEAL 필러	39.144	HANDLE, RH DOOR OUTSIDE 핸들
37.675	COVER, CAB DOOR INSIDE LEFT 커버	39.146	LATCH, RH DOOR INSIDE 래치
37.679	HANDLE, RH DOOR INSIDE 핸들	39.147	FASTENER, RIGHT HAND DOOR LATCH 패스너
37.686	SPACER, DOOR INSIDE HANDLE 스페이스	39.152	DOOR ASSEMBLY, LEFT HAND 도어
37.799	LATCH, CAB DOOR WINDOW ASSEMBLY 래치	39.192	GLASS, RIGHT HAND DOOR (LOWER) 글래스
37.808	COVER, REAR RH 커버	39.193	WEATHERSEAL, RH DOOR GLASS (LOWER) 웨더셀
37.809	COVER, REAR LH 커버	39.205	GLASS, RH DOOR REAR 글래스
37.877	FRAME, CAB DOOR-RH 프레임	39.228	WEATHERSEAL, WINDSHIELD SETTING 웨더셀
37.878	FRAME, CAB DOOR-LH 프레임	39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
38.102	DOOR, REAR (LH) 도어	39.295	WEATHERSEAL, DOOR REAR GLASS 웨더셀
38.158	DOOR, REAR (RH) 도어	39.296	WEATHERSEAL, DOOR FRONT GLASS - REAR 웨더셀
39.102	WEATHERSEAL, WINDSHIELD SETTING 웨더셀	39.339	FASTENER, RH DOOR INSIDE HANDLE 패스너
39.110	WEATHERSEAL, REAR GLASS SETTING 웨더셀	39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우

47.241	DOOR ASSY, CAB REAR (RH) 도어
47.242	DOOR ASSY, CAB REAR (LH) 도어
94.582	FASTENER, CAB DOOR LATCH CATCH 패스너
95.383	FASTENER, DOOR INSIDE LATCH COVER 패스너
95.885	FASTENER, CAB DOOR HINGE 패스너




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



CAB MOUNTING


39-150

37.300	CAB ASSEMBLY 캐빈
39.265	FASTENER, CAB TO MOUNT 패스너



13.228	LAMP ASSEMBLY, DOME 램프
14.134	WIRE ASSEMBLY, WIPER MOTOR TO AMP METER 와이어
37.300	CAB ASSEMBLY 캐빈
37.437	PUMP & TANK, WINDSHIELD WASHER 펌프& 탱크
37.461	NOZZLE, WINDSHIELD GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
37.759	GROMMET, COVER WINDSHIELD WIPER MOTOR 그로멧
37.773	WINDSHIELD WIPER INSTALLATION 윈드실드와이퍼
39.200	MOTOR, WINDSHIELD WIPER 모터


39.204	BLADE, WINDSHIELD WIPER 블레이드
39.230	MOTOR, REAR WINDOW WIPER 모터
39.233	ARM, REAR WINDOW WIPER 암
39.234	BLADE, REAR WINDOW WIPER 블레이드
60.296	SWITCH, WINDSHIELD WIPER (REAR) 스위치
60.299	SWITCH, HEATER ON/OFF 스위치




CABIN AND HEATER INSTALLATION

39-223

- | | |
|--------|--|
| 60.330 | WIRING HARNESS, CAB
와이어하네스 |
| 65.701 | CONVERTER, CONTROL PANEL
컨버터 |
| 95.733 | NUT, CONTROL PANEL CONVERTER FASTENER
너트 |
| 97.064 | FASTENER, CONTROLLER BRACKET MOUNTING
패스너 |





- | | |
|--------|---|
| 34.977 | RETAINER, LOAD BACK REST TRUNNION PIN
리테이너 |
| 34.991 | FASTENER, LOAD SAFETY BACK REST EXT
패스너 |
| 34.995 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 92.226 | NUT, LOAD SAFETY BACK REST FASTENER
너트 |



- | | |
|--------|--|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
안전벨트 |
| 37.531 | BRACKET, SEAT SAFETY BELT MOUNTING
브라켓 |
| 37.720 | COVER, OPERATOR SEAT LATERAL RESTRAINT
커버 |
| 37.743 | COVER, SEAT SUPPORT LATCH
커버 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너






SHEET METAL & TRIM

39-795

15.790	WIRE, BATTERY STOPPER 와이어
15.791	HOLDER, BATTERY 홀더
15.792	SLEEVE, BATTERY STOPPER WIRE 슬리브
15.861	SHIELD, SPARK PROVENTION 쉴드
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너
37.374	COVER, HYDRAULIC VALVE 커버
37.741	SOUND ABSORBER, FLOOR PLATE 흡음재
37.808	COVER, REAR RH 커버
37.809	COVER, REAR LH 커버


37.902	MAT, FLOORPLATE 매트
38.050	STEP ASSEMBLY, LH 스텝
38.052	FASTENER, STEP FRONT 패스너
38.227	POCKET, DASH PANEL 포켓
38.233	RUBBER, FRAME SIDE COVER 러버
38.241	COVER ASSEMBLY, SIDE LH 커버
38.242	COVER ASSEMBLY, SIDE RH 커버
38.472	PAD, RH STEP NON-SKID 패드
39.475	PLATE, FRONT FLOOR 플레이트
39.556	COVER, VALVE LINKAGE ACCESS 커버
39.570	COVER ASSEMBLY, DASH 커버
39.571	FASTENER, DASH COVER 패스너
47.279	RUBBER, SIDE COVER RH 러버
47.280	RUBBER, SIDE COVER LH 러버
47.361	KNOB, SIDE COVER 노브
47.362	COVER, CABLE PROTECTION 커버
47.363	FASTENER, CABLE PROTECTION COVER 패스너
93.671	FASTENER, HYDRAULIC VALVE COVER 패스너
97.162	FASTENER, SIDE COVER TO FRAME 패스너



OVERHEAD GUARD MOUNTING


39-798

39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.395	BUMPER, FRAME COVERING HOOD SUPPORT 범퍼
97.231	FASTENER, FRAME COVERING HOOD SUPPORT BUMPER 패스너



- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 39.080 | FASTENER, OPERATOR SAFETY GUARD
패스너 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



SEAT MOUNTING


39-829

39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔




37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.915	SUSPENSION COVER, SEAT SUSPENSION 서스펜션커버
37.918	SUSPENSION ASSEMBLY, SEAT 서스펜션
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션
39.721	CUSHION, SEAT BACK REST 쿠션

39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



ARMREST MOUNTING (ELH)

39-835


- | | |
|--------|---|
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 37.923 | BRACKET, SEAT ARMREST RIGHT HAND
브라켓 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |



CABIN AND HEATER INSTALLATION


39-869

- | | |
|--------|--|
| 15.767 | WIRE HARNESS, ELECTRONIC CONTROL UNIT
와이어하네스 |
| 65.130 | CONTACTOR ASSEMBLY, LINE
컨택터 |
| 65.932 | FASTENER, LINE CONTACTOR
패스너 |
| 67.130 | HEAT SINK, PUMP CONTROL POWER TRANSISTOR
히트싱크 |
| 96.606 | FASTENER, LINE CONTACTOR MOUNTING BRACKET
패스너 |



39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
39.953	FASTENER, OVERHEAD GUARD (FRONT LEGS) 패스너

NOTE :
NON SERVICEABLE
ITEMS MARKED "N"




BATTERY COVER & REAR COVER MOUNTING


39-942

- | | |
|--------|------------------------------------|
| 37.022 | SPRING, HOOD PROP INNER
스프링 |
| 37.497 | HANDLE, TOP HOOD LATCH
핸들 |
| 37.897 | BUMPER, TOP HOOD
범퍼 |
| 39.422 | HINGE, TOP HOOD
힌지 |
| 39.423 | FASTENER, TOP HOOD
패스너 |
| 39.460 | COVER ASSEMBLY, BATTERY
커버 |
| 39.599 | FASTENER, HOOD PIVOT HINGE
패스너 |
| 39.611 | FASTENER, HOOD PROP SUPPORT
패스너 |
| 39.616 | FASTENER, TOP HOOD LATCH
패스너 |


39.704	SPRING, HOOD PROP (OUTER) 스프링
39.705	FASTENER, HOOD PROP 패스너
47.283	COVER, FRAME REAR 커버
47.284	WEATHERSTRIP, FRAME REAR COVER 웨더스트립
47.285	LATCH, FRAME REAR COVER 래치
47.387	BRACKET, FRAME COVERING HOOD LINKAGE 브라켓
47.388	HINGE, FRAME REAR COVER 힌지
47.389	HOLDER, REAR COVER LATCH 홀더
47.417	CAP, SEAT WIRING HARNESS HOLE 캡
94.436	FASTENER, HOOD PROP BRACKET SUPPORT 패스너
97.217	FASTENER, FRAME COVERING HOOD LINKAGE BRACKET 패스너
97.218	FASTENER, REAR COVER LATCH HOLDER 패스너
97.219	FASTENER, REAR COVER LATCH 패스너



37.933	COVER, HOOD ACCESS 커버
37.935	FASTENER, HOOD ACCESS COVER 패스너
47.069	PLUG, TOP HOOD 플러그
94.763	FASTENER, HOOD SUPPORT 패스너





37.300	CAB ASSEMBLY 캐빈
37.799	LATCH, CAB DOOR WINDOW ASSEMBLY 래치
39.131	DOOR ASSEMBLY, RIGHT HAND 도어
39.152	DOOR ASSEMBLY, LEFT HAND 도어
39.205	GLASS, RH DOOR REAR 글래스
39.206	GLASS, RH DOOR FRONT 글래스
39.298	CHANNEL, FRONT DOOR GLASS - FRONT 채널
39.344	WEATHERSEAL, RH DOOR WINDOW ASSEMBLY 웨더셀
37.799	FASTENER, ADJUSTOR TO EXTRA SEAT SUPPORT REAR 패스너



37.300	CAB ASSEMBLY 캐빈
37.551	HANGER, CAB REAR GLASS 행거
37.559	PIN, CABIN REAR GLASS HANGER 핀
37.698	HINGE, CORNER WINDOW GLASS 힌지
37.703	RUBBER PLATE, WINDOW GLASS RETAINER FASTENER 리버플레이트
37.785	SHOCK ABSORBER, CAB INSPECTION FRAME 쇼크업쇼버
39.101	GLASS, WINDSHIELD 글래스
39.109	GLASS, REAR 글래스
39.110	WEATHERSEAL, REAR GLASS SETTING 웨더셀


39.117	ROOF SCREEN 루프스크린
39.215	FASTENER, GAS SPRING 패스너
39.280	GLASS, REAR WINDOW - MOVEABLE 글래스
39.321	GUARD, REAR WINDOW 가드
39.347	FASTENER, CAB REAR WINDOW LATCH 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.269	BRACKET, CAB REAR GLASS GAS SPRING SUPPORT 브라켓
47.272	BRACKET, CAB REAR GLASS GAS SPRING MOUNTING 브라켓
47.274	HANDLE, CAB REAR GLASS 핸들
97.063	FASTENER, REAR DOOR HANDLE MOUNTING 패스너






37.229	HINGE, DRIVE UNIT COVER 힌지
37.300	CAB ASSEMBLY 캐빈
37.396	PLATE, DRIVERS OVERHEAD GUARD TOP SECTION COVER 플레이트
37.573	SUPPORT, DOOR STOP 서포트
37.575	COVER, LOWER REAR PANEL 커버
37.636	COVERING, CAB INSIDE ROOF 커버링
37.731	CUSHION, WINDSHIELD GLASS MOUNTING 쿠션
39.228	WEATHERSEAL, WINDSHIELD SETTING 웨더셀
39.322	FASTENER, REAR WINDOW GUARD 패스너

39.685	COVER, ROOF ASSEMBLY RH SUPPORT 커버
39.940	SPRING, OVERHEAD GUARD REAR SUPPORT OVER CENTER 스프링
41.265	SOUND ABSORBER, CAB ROOF 흡음재
41.266	SOUND ABSORBER, CAB ROOF 흡음재
44.361	PIN, CLEVIS 핀
94.568	FASTENER, CAB REAR COVER 패스너
94.586	FASTENER, CAB PROP 패스너
95.325	FASTENER, CAB ROOF 패스너
95.870	FASTENER, CAB ROOF SOUND ABSORBER SUPPORT 패스너
96.224	FASTENER, CAB WEATHERSEAL SUPPORT 패스너






NOTE: All Trucks Do Not Use All Fluid Key Numbers

TRUCK FLUIDS

40-260


99.901	ENGINE OIL 엔진오일
99.902	TRANSMISSION FLUID 트랜스미션오일
99.903	DRIVE AXLE FLUID 드라이브액슬
99.904	HYDRAULIC SUMP OIL 유압섬프오일
99.905	BRAKE FLUID 브레이크오일
99.906	AXLE END FLUID 액슬엔드오일
99.907	ENGINE ANTIFREEZE 부동액




40.332	REFLECTOR, OVERHEAD GUARD 리플렉터
40.333	REFLECTOR, COUNTERWEIGHT 리플렉터
40.334	REFLECTOR, UPRIGHT RAIL FRONT 리플렉터
40.335	REFLECTOR, UPRIGHT RAIL FRONT 리플렉터
40.336	REFLECTOR, TOP HOOD 리플렉터
40.337	REFLECTOR, UPRIGHT RAIL SIDE 리플렉터
40.338	REFLECTOR, OVERHEAD GUARD REAR 리플렉터
40.339	DECAL, REAR CAUTION 데칼
40.340	DECAL, SIDE CAUTION 데칼

40.347 REFLECTOR, FRAME SIDE COVER
리플렉터






40.010	DECAL, CLARK 데칼
40.013	DECAL, CLARK LOGO-LARGE 데칼
40.130	LEGEND, SAFETY 범례
40.131	LEGEND, SAFETY 범례
40.142	DECAL, ELECTRICAL CIRCUIT DIAGRAM 데칼
40.268	DECAL, SPEC 데칼
40.309	DECAL, AC LOGO 데칼
40.314	DECAL, AC LOGO 데칼




40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너
40.024	PLATE, UNDERWRITERS LABEL 플레이트
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너
40.042	DECAL, POLARITY 데칼
40.062	DECAL, DRIVERS CAUTION 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼
40.076	DECAL, ELECTRIC TRUCK CAUTION 데칼
40.089	PLATE, SAFETY INSTRUCTION 플레이트

40.138	DECAL, SAFETY 데칼
40.173	DECAL, IMPORTANT 데칼
40.183	DECAL, BATTERY DISCONNECT WARNING 데칼
40.241	DECAL, BRAKE OIL SPEC 데칼
40.248	DECAL, SERVICE CHART 데칼
40.318	DECAL, BATTERY LOCATION 데칼
40.321	DECAL, DISTILLED WATER 데칼
40.326	DECAL, EE MARKING 데칼
40.328	DECAL, WHEEL NUT WARNING 데칼
40.345	DECAL, VOLTAGE WARNING 데칼
40.351	DECAL, HOOD OPEN OPERATING INSTRUCTIONS 데칼



SEAT SAFETY
WING KIT


37.970



SEAT WING KIT

47-000


- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 37.970 | KIT, SEAT SAFETY
키트 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |




REAR HAND GRIP MOUNTING

47-016


- | | |
|--------|--|
| 47.385 | GRIP, OVERHEAD GUARD REAR HAND
그립 |
| 47.386 | BRACKET, OVERHEAD GUARD REAR HAND GRIP
브라켓 |
| 97.216 | FASTENER, OVERHEAD GUARD REAR HAND GRIP
패스너 |



HINGED BUCKET (HB) / FORK (HF) - BASIC



ROTATING FORK (RF) - BASIC




LOAD STABILIZER (LS) - BASIC

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-171

50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.405	COUPLING, DEVICE HOSE 커플링
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅




HIGH TERMINATION FOR DEVICE HOSE ADAPTION

50-172

- 59.134 LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인
- 59.135 LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인
- 59.136 LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인
- 59.137 LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인
- 59.142 FITTING, DEVICE LINE FOR HIGH TERMINATION
피팅
- 59.143 CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
캡
- 59.144 BRACKET, DEVICE LINE FOR HIGH TERMINATION
브라켓
- 59.145 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
셀
- 59.146 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
셀

97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너
97.238	FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION 패스너






- | | |
|--------|---|
| 59.134 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.135 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.136 | LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인 |
| 59.137 | LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인 |
| 59.142 | FITTING, DEVICE LINE FOR HIGH TERMINATION
피팅 |
| 59.143 | CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
캡 |
| 59.144 | BRACKET, DEVICE LINE FOR HIGH TERMINATION
브라켓 |
| 59.145 | SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
셀 |
| 59.146 | SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
셀 |

97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너
97.238	FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE





SOLENOID VALVE FOR DEVICE HOSE ADAPTATION

50-177

14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.972	CLIP, DEVICE SELECTOR VALVE LINE 클립
33.973	FASTENER, DEVICE SELECTOR VALVE LINE CLIP 패스너






50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인
50.427	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.428	LINE, 2ND AUXILIARY VALVE "B" PORT 라인
50.430	CLAMP, AUXILIARY VALVE LINES 클램프
50.431	FASTENER, AUX VALVE LINES CLAMP 패스너
50.440	FITTING, 1ST AUXILIARY VALVE "A" PORT 피팅

50.441 FITTING, 2ND AUXILIARY VALVE "A" PORT
 피팅



ATTACHMENT HOSE REFERENCE




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-232

50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.610	FASTENER, DEVICE HOSE GUARD 패스너
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.811	NUT, DEVICE HOSE FITTING 너트
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.156	CLIP, DEVICE HOSE 클립	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.200	COUPLING, DEVICE HOSE 커플링	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.571	BRACKET, DEVICE HOSE 브라켓	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.572	FASTENER, DEVICE HOSE BRACKET 패스너	75.015	MODULE, ATTACHMENT HOSE LINES 모듈

93.316	DOWEL, STEERING INTERLOCK SWITCH FASTENER 다웰
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너





50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
씰

50.132 BRACKET, DEVICE HOSE REEL
브라켓

50.155 FASTENER, DEVICE HOSE CLIP
패스너

50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.295 ROLLER, DEVICE HOSE UPPER
롤러

50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.316 GUARD, DEVICE RH HOSE
가드

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.433 BRACKET, DEVICE HOSE CLAMP
브라켓

50.571 BRACKET, DEVICE HOSE
브라켓

50.572 FASTENER, DEVICE HOSE BRACKET
패스너

50.610 FASTENER, DEVICE HOSE GUARD
패스너

50.811 NUT, DEVICE HOSE FITTING
너트

59.016 JUNCTION BLOCK, DEVICE HOSE
정크션 블록

59.023 BRACKET, DEVICE HOSE REEL MOUNTING
브라켓

59.034 TUBE, DEVICE HOSE REEL MOUNTING BRACKET
튜브

59.054 PLUG, DEVICE HOSE JUNCTION BLOCK
플러그

59.072 GUARD, DEVICE HOSE
가드

59.077 FASTENER, DEVICE HOSE GUARD
패스너

59.086 FASTENER, DEVICE HOSE CLIP BRACKET
패스너

59.101 TIE STRAP, AUXILIARY FUNCTION LINES
타이스트랩

59.118 LINE, DEVICE HYDRAULIC (OUTER RAIL)
라인

59.122 LINE, DEVICE HYDRAULIC (INNER RAIL)
라인

59.125 BRACKET, DEVICE HOSE GUARD MOUNTING
브라켓


59.126 BRACKET, DEVICE HOSE GUARD MOUNTING
브라켓

75.015 MODULE, ATTACHMENT HOSE LINES
모듈

93.316 DOWEL, STEERING INTERLOCK SWITCH FASTENER
다웰

93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너






50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.686	WIRE, DEVICE 와이어

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너

ATTACHMENT HOSE
REFERENCE 75.015




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-289

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.588	BRACKET, DEVICE CABLE CLAMP 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.590	CLAMP, DEVICE CABLE LOWER 클램프
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.591	FASTENER, DEVICE CABLE CLAMP LOWER 패스너
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.623	BRACKET, DEVICE CABLE LOWER SHEAVE 브라켓
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.624	SHEAVE, DEVICE CABLE 쉬브
50.156	CLIP, DEVICE HOSE 클립	50.625	RETAINER, DEVICE CABLE LOWER SHEAVE 리테이너
50.200	COUPLING, DEVICE HOSE 커플링	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.686	WIRE, DEVICE 와이어
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	50.732	SPACER, DEVICE CABLE SHEAVE 스페이서
50.586	CLIP, DEVICE CABLE 클립	50.733	SPACER, DEVICE CABLE CLAMP BRACKET 스페이서
50.587	FASTENER, DEVICE CABLE CLIP 패스너	50.734	BRACKET, DEVICE CABLE TERMINAL CLAMP 브라켓


50.745	BRACKET, DEVICE CABLE TERMINAL CLAMP MOUNTING 브라켓
50.746	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.182	FASTENER, DEVICE CABLE LOWER SHEAVE BRACKET 패스너



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.686	WIRE, DEVICE 와이어

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너






50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너

ATTACHMENT HOSE
REFERENCE 75.015




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-407


50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너




50.006	SHEAVE, DEVICE HOSE UPPER шнёр
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING сальник
50.156	CLIP, DEVICE HOSE зажим
50.200	COUPLING, DEVICE HOSE соединитель
50.215	TERMINAL BLOCK, DEVICE HOSE терминальный блок
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE опора
50.298	BRACKET, DEVICE HOSE TERMINAL кронштейн
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK крепёжка
50.414	FITTING, DEVICE HOSE CONNECTOR фитинг


50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



50.006	SHEAVE, DEVICE HOSE UPPER шнёр
50.007	RETAINER, DEVICE HOSE SHEAVE ритейнер
50.009	SHEAVE, DEVICE HOSE LOWER шнёр
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING сальник
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE шарнир
50.156	CLIP, DEVICE HOSE клип
50.200	COUPLING, DEVICE HOSE соединитель
50.215	TERMINAL BLOCK, DEVICE HOSE терминальный блок
50.218	TERMINAL BLOCK, DEVICE LH HOSE терминальный блок


50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너





50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅

50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
씰

50.132 BRACKET, DEVICE HOSE REEL
브라켓

50.155 FASTENER, DEVICE HOSE CLIP
패스너

50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.295 ROLLER, DEVICE HOSE UPPER
롤러

50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.316 GUARD, DEVICE RH HOSE
가드

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.433 BRACKET, DEVICE HOSE CLAMP
브라켓

50.571 BRACKET, DEVICE HOSE
브라켓

50.572 FASTENER, DEVICE HOSE BRACKET
패스너

50.610 FASTENER, DEVICE HOSE GUARD
패스너

50.686 WIRE, DEVICE
와이어

50.697 CONNECTOR, DEVICE CABLE (PIN END)
커넥터

50.698 CONNECTOR, DEVICE CABLE (SOCKET END)
커넥터

50.714 LOCK, DEVICE CABLE CONNECTOR
로크

50.811 NUT, DEVICE HOSE FITTING
너트

50.871 SPACER, DEVICE HOSE ROLLER
스페이서

50.873 SPACER, DEVICE HOSE ROLLER
스페이서

59.016 JUNCTION BLOCK, DEVICE HOSE
정크션 블록

59.023 BRACKET, DEVICE HOSE REEL MOUNTING
브라켓

59.034 TUBE, DEVICE HOSE REEL MOUNTING BRACKET
튜브

59.054 PLUG, DEVICE HOSE JUNCTION BLOCK
플러그


59.072 GUARD, DEVICE HOSE
가드

59.077 FASTENER, DEVICE HOSE GUARD
패스너

59.086 FASTENER, DEVICE HOSE CLIP BRACKET
패스너

59.118 LINE, DEVICE HYDRAULIC (OUTER RAIL)
라인

59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너



50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
씰

50.132 BRACKET, DEVICE HOSE REEL
브라켓

50.155 FASTENER, DEVICE HOSE CLIP
패스너

50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.218 TERMINAL BLOCK, DEVICE LH HOSE
터미널블록

50.295 ROLLER, DEVICE HOSE UPPER
롤러

50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.316 GUARD, DEVICE RH HOSE
가드

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.433 BRACKET, DEVICE HOSE CLAMP
브라켓

50.571 BRACKET, DEVICE HOSE
브라켓

50.572 FASTENER, DEVICE HOSE BRACKET
패스너

50.610 FASTENER, DEVICE HOSE GUARD
패스너

50.686 WIRE, DEVICE
와이어

50.697 CONNECTOR, DEVICE CABLE (PIN END)
커넥터

50.698 CONNECTOR, DEVICE CABLE (SOCKET END)
커넥터

50.714 LOCK, DEVICE CABLE CONNECTOR
로크

50.811 NUT, DEVICE HOSE FITTING
너트

50.873 SPACER, DEVICE HOSE ROLLER
스페이서

59.016 JUNCTION BLOCK, DEVICE HOSE
정크션 블록

59.023 BRACKET, DEVICE HOSE REEL MOUNTING
브라켓

59.034 TUBE, DEVICE HOSE REEL MOUNTING BRACKET
튜브

59.054 PLUG, DEVICE HOSE JUNCTION BLOCK
플러그


59.072 GUARD, DEVICE HOSE
가드

59.077 FASTENER, DEVICE HOSE GUARD
패스너

59.086 FASTENER, DEVICE HOSE CLIP BRACKET
패스너

59.118 LINE, DEVICE HYDRAULIC (OUTER RAIL)
라인


59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너



50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인
50.427	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.428	LINE, 2ND AUXILIARY VALVE "B" PORT 라인
50.430	CLAMP, AUXILIARY VALVE LINES 클램프
50.431	FASTENER, AUX VALVE LINES CLAMP 패스너
50.440	FITTING, 1ST AUXILIARY VALVE "A" PORT 피팅


50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅
97.186	FASTENER, AUX VALVE LINES CLAMP 패스너






50.019	FASTENER, DEVICE HOSE DISCONNECT 패스너
50.105	SEAL, DEVICE HOSE SWIVEL COUPLING PLUG 씰
50.108	SEAL, DEVICE HOSE SWIVEL COUPLING INLET PORT 씰
50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.292	FITTING, DEVICE RH HYDRAULIC HOSE 피팅
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.643	LINE, DEVICE UPPER (AT CARRIAGE) 라인
50.646	LINE, DEVICE 라인


50.786	SEAL, DEVICE RH HOSE TERMINAL BLOCK PORT 씰
50.830	CAP, DEVICE HOSE REEL FITTING 캡
53.033	FASTENER, HOSE TERMINAL BRACKET 패스너
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
75.033	KIT, CARRIAGE TERMINATION PIPING - RH 키트
75.034	KIT, CARRIAGE TERMINATION PIPING - LH 키트




**MODEL: GTX162
GEX162**
UPRIGHT: STANDARD




**MODEL: GTX162,GEX162
EPX162,CMP158
P152,TMX250,ESX250**
UPRIGHT: TRIPLE STAGE&HI-LO




**MODEL: GTX162,GEX162
EPX162,CMP158
P152,TMX250,ESX250**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX162,CMP158
P152,TMX250,ESX250**
UPRIGHT: STANDARD



**MODEL: EPX360,ECX360
GEX230,P232
GTS232,CQ230**
UPRIGHT: STANDARD



**MODEL: EPX360,ECX360
GEX230,P232
GTS232,CQ230**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX360,ECX360
GEX230,P232
GTS232,CQ230**
UPRIGHT: HI-LO

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-791


- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-794


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-796


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-797


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.343	FITTING, DEVICE LH LINE 피팅
50.344	FITTING, DEVICE LH LINE 피팅
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅
59.091	FITTING, DEVICE HYDRAULIC LINE 피팅



QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION

50-798


- | | |
|--------|---|
| 59.092 | QUICK DISCONNECT, DEVICE HOSE
퀵디스커넥트 |
| 59.131 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |
| 59.132 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |



14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디स्क넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT 피팅
59.132	FITTING, DEVICE LINE QUICK DISCONNECT 피팅







33.054	PLUG, RELIEF VALVE PORT 플러그
33.600	RELIEF VALVE, DEVICE VARIABLE PRESSURE 릴리프밸브
33.603	BRACKET, DEVICE CARIABLE RELIEF VALVE 브라켓
33.604	FASTENER, DEVICE VARIABLE RELIEF VALVE 패스너
33.661	FITTING, DEVICE RELIEF VALVE OUTLET PORT 피팅
33.702	LINE, DEVICE RELIEF VALVE INLET 라인
33.706	FITTING, DEVICE RELIEF VALVE INLET PORT 피팅
33.712	COUPLING, DEVICE RELIEF VALVE DISCHARGE HOSE 커플링
33.732	FITTING, DEVICE RELIEF VALVE INLET 피팅

91.221 NUT, DEV VARIABLE RELIEF VALVE FASTENER
너트

ФОРКЛИФТ
www.forklift.ru





37.457	HOOK, CAB CLOTHING HANGER 후크	53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
52.149	NUT, SIDE SHIFT CYLINDER ANCHOR PORT LINE FITTING 너트	53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더	54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
53.024	ANCHOR, SIDE SHIFTER CYLINDER BASE 앵커	54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
53.025	GUIDE, SIDE SHIFTER MOVABLE FRAME LOWER 가이드	54.152	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링	54.155	FITTING, SIDE SHIFTER CYLINDER ROD PORT LINE 피팅
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너	54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
53.090	FASTENER, SIDE SHIFTER MOVABLE FRAME 패스너	54.197	FASTENER, SIDE SHIFTING BASE PLATE TO ARM 패스너
53.180	SPACER, SIDE SHIFTER BEARING 스페이서	54.198	BEARING, SIDE SHIFTER BASE PLATE ARM 베어링
53.182	FASTENER, SIDE SHIFTER HANGER 패스너	54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
53.201	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT 피팅	54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인	54.403	FITTING-LUB, SIDE SHIFTER BASE PLATE ARM 피팅
53.209	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅	66.162	STOP, CARRIAGE TRAVEL 스톱
53.210	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅	92.483	NIPPLE, LUBRICATION 니플
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인		




37.457	HOOK, CAB CLOTHING HANGER 후크
52.149	NUT, SIDE SHIFTER CYLINDER ANCHOR PORT LINE FITTING 너트
53.025	GUIDE, SIDE SHIFTER MOVABLE FRAME LOWER 가이드
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.090	FASTENER, SIDE SHIFTER MOVABLE FRAME 패스너
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.209	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인

53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
54.152	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.197	FASTENER, SIDE SHIFTING BASE PLATE TO ARM 패스너
54.198	BEARING, SIDE SHIFTER BASE PLATE ARM 베어링
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
66.162	STOP, CARRIAGE TRAVEL 스톱





- 53.020 CYLINDER ASSEMBLY, SIDE SHIFTER
실린더
- 54.222 PACKING KIT, SIDE SHIFTER CYLINDER
패킹키트




FORK POSITIONER

53-164

53.054	GUIDE, FORK 가이드
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크

54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너






FORK POSITIONER (SHIFTING)

53-168


53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.024	ANCHOR, SIDE SHIFTER CYLINDER BASE 앵커
53.054	GUIDE, FORK 가이드
53.069	FASTENER, FORK CYLINDER ROD END 패스너
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.180	SPACER, SIDE SHIFTER BEARING 스페이서
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.210	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅


53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.403	FITTING-LUB, SIDE SHIFTER BASE PLATE ARM 피팅
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크
54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
92.483	NIPPLE, LUBRICATION 니플
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너



53.054	GUIDE, FORK 가이드
53.069	FASTENER, FORK CYLINDER ROD END 패스너
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.746	LINE, FORK CYLINDER ROD END 라인
53.772	LINE, FORK CYLINDER ANCHOR END 라인
53.887	LINE, FORK CYLINDER ANCHOR END 라인
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그

54.215	LINE, FORK CYLINDER ROD END 라인
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크
54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
54.553	FITTING - LUB, FORK POSITIONER 피팅
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너






40.343	DECAL, ATTACHMENT SAFETY 데칼
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링

54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서
54.314	SPACER, SIDE SHIFTER CYLINDER REAR 스페이서



ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹키트
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT 볼

97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
세트스크류






53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.637	GLAND, INBOARD LH FORK CYLINDER 그랜드
53.648	BUSHING, LH FORK CYLINDER GLAND 부싱
53.687	GLAND, INBOARD RH FORK CYLINDER 그랜드
53.698	BUSHING, RH FORK CYLINDER GLAND 부싱
54.212	SEAL KIT, FORK CYLINDER 씰키트
54.484	ROD, FORK CYLINDER PISTON 로드
54.486	PISTON, FORK CYLINDER 피스톤

54.488 NUT, FORK CYLINDER PISTON
너트







52.149	NUT, SIDE SHIFTER CYLINDER ANCHOR PORT LINE FITTING 너트
53.023	ANCHOR, SIDE SHIFTER CYLINDER ROD END 앵커
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인

54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트






- 34.350 FORK ASSEMBLY
포크
- 34.359 KIT, FORK STOP PIN (CAPTIVE)
키트




66.207	PISTON, FINAL LIFT CYLINDER 피스톤
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서
66.444	GLAND, FINAL LIFT CYLINDER 그랜드



34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.443	RING, LIFT CYLINDER PISTON WEAR 링
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너

96.274 WASHER, LIFT CYLINDER CHECK VALVE
 옥셔


ФОРКЛИФТ
www.forklift.ru



66.395	CHECK VALVE, FINAL LIFT CYLINDER 체크밸브
66.397	WASHER, FINAL LIFT CYLINDER CHECK VALVE 와셔
66.398	SNAP RING, FINAL LIFT CYLINDER CHECK VALVE 스냅링
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.407	WEAR RING, FINAL LIFT CYLINDER PISTON 웨어링
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서

66.444 GLAND, FINAL LIFT CYLINDER
 그로드


ФОРКЛИФТ
www.forklift.ru



34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너

66.502	CUSHION, LIFT CYLINDER 쿠션
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔






34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너

66.502	CUSHION, LIFT CYLINDER 쿠션
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔






28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브	34.081	SPACER, LIFT CHAIN SHEAVE CARRIER 스페이서
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피봇	34.084	SHEAVE, LIFT CHAIN 쉬브
28.729	LINE, LIFT CYLINDER 라인	34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.101	CHAIN, LIFT 체인
28.746	FITTING, LIFT CYLINDER LINE 피팅	34.102	FASTENER, SHEAVE CARRIER 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.107	ANCHOR, LIFT CHAIN 앵커
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일	34.186	ROLLER, UPRIGHT 롤러
34.013	ROLLER, UPRIGHT 롤러	34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.014	SHIM, UPRIGHT ROLLER 심	34.271	FASTENER, LIFT CYLINDER LOWER 패스너
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브

66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.167	SHIM, LIFT CYLINDER UPPER 심
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.433	SHIM, CYLINDER MOUNT 심
66.438	SHEAVE, HOSE 쉬브
66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리지
66.506	CLAMP, LIFT CYLINDER 클램프
66.507	TEE, LIFT CYLINDER LINE 티
66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너
97.179	FASTENER, LIFT CYLINDER CLAMP 패스너






28.746	FITTING, LIFT CYLINDER LINE 피팅	34.150	CHAIN, UPRIGHT RAIL LIFT 체인
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.186	ROLLER, UPRIGHT 롤러
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.400	CYLINDER ASSEMBLY, LIFT 실린더
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃더레일	66.167	SHIM, LIFT CYLINDER UPPER 심
34.013	ROLLER, UPRIGHT 롤러	66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
34.014	SHIM, UPRIGHT ROLLER 심	66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리리지
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	66.507	TEE, LIFT CYLINDER LINE 티
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
34.084	SHEAVE, LIFT CHAIN 쉬브	91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
34.107	ANCHOR, LIFT CHAIN 앵커	91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너	93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너	94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너

94.655 FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK
패스너


ФОРКЛИФТ
www.forklift.ru




28.729	LINE, LIFT CYLINDER 라인	34.084	SHEAVE, LIFT CHAIN 쉬브
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
28.746	FITTING, LIFT CYLINDER LINE 피팅	34.101	CHAIN, LIFT 체인
28.747	FITTING, LIFT CYLINDER LINE 피팅	34.102	FASTENER, SHEAVE CARRIER 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.107	ANCHOR, LIFT CHAIN 앵커
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일	34.186	ROLLER, UPRIGHT 롤러
34.013	ROLLER, UPRIGHT 롤러	34.271	FASTENER, LIFT CYLINDER LOWER 패스너
34.014	SHIM, UPRIGHT ROLLER shim	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
34.081	SPACER, LIFT CHAIN SHEAVE CARRIER 스페이서	66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브

66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.167	SHIM, LIFT CYLINDER UPPER 삼
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
66.304	FASTENER, LIFT CYLINDER LINE CLAMP 패스너
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.471	LINE, LIFT CYLINDER FEED 라인
66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리지
66.507	TEE, LIFT CYLINDER LINE 티
66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
66.509	CLAMP, LIFT CYLINDER LINE 클램프
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너






- | | |
|--------|--|
| 33.720 | GAUGE, DEVICE HYDRAULIC PRESSURE
게이지 |
| 33.724 | FITTING, DEVICE HYD PRESSURE GAUGE
피팅 |
| 75.301 | DEVICE, HYDRAULIC PRESSURE GAUGE
디바이스 |



39.706	SUPPORT, SEAT 서포트
39.719	SEAT ASSEMBLY 시트
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트



SEAT OPERATED BRAKE SWITCH INSTALLATION

75-013

- | | |
|--------|---|
| 15.689 | FASTENER, SEAT SWITCH HARNESS RETAINER
패스너 |
| 18.087 | CLIP, SEAT SAFETY SWITCH WIRE
클립 |
| 37.973 | GROMMET, SEAT WIRING HARNESS
그로멧 |
| 40.306 | DECAL, SEAT SWITCH
데칼 |