


부품 매뉴얼 PARTS MANUAL

GEX 40/45/50

SERIAL NUMBER : GEX450 - XXXX - 9868 KF

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Part No. 8106245
Dec. 2013




(본사) 경기도 부천시 오정구 오정동 202-1
(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea
(공장) 경남 창원시 웅남동 40-1
(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea



02-189	ACCELERATOR LINKAGE 악셀레이터 링크케이지	25-145	STEERING UNIT 스티어링 유닛
13-064	BACK-UP ALARM INSTALLATION 백업 알람 조립그룹	25-278	STEERING COLUMN ASSEMBLY 스티어링 컬럼 어셈블리
13-066	ELECTRICAL COMPONENTS (SBR) 전기장치 구성품 (SBR)	25-291	STEERING COLUMN SHAFT ASSEMBLY 스티어링 컬럼 샤프트 어셈블리
13-162	STROBE LIGHT MOUNTING 경광등 마운팅	25-292	STEERING WHEEL & COLUMN MOUNTING 스티어링 휠& 컬럼 마운팅
13-182	STROBE LIGHT 경광등	25-372	STEERING GEAR MOUNTING 스티어링 기어 마운팅
13-194	WORK LIGHT 작업등	26-000	STEER AXLE ASSEMBLY 스티어링 액슬 어셈블리
13-346	HEAD LAMP INSTALLATION 헤드램프 조립그룹	26-003	HYDRAULIC STEERING LINES 유압 스티어링 라인
13-347	TURN SIGNAL LAMP INSTALLATION 턴 시그널 램프 조립그룹	26-004	STEER AXLE MOUNTING 스티어링 액슬 마운팅
13-348	REAR WORK LIGHT INSTALLATION 후방등 조립그룹	26-266	STEER CYLINDER 스티어링 실린더
13-349	COMBINATION LAMP INSTALLATION 컴비네이션 램프 조립그룹	27-000	PRIORITY VALVE ASSEMBLY 우선 밸브 어셈블리
13-352	TILT LIMIT SYSTEM 틸트 제어 시스템	29-139	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
14-161	ELECTRICAL WIRING 전기장치 와이어링	29-198	HYDRAULIC TANK & COMPONENTS MOUNTING 유압탱크& 구성품 마운팅
14-359	ELECTRICAL COMPONENTS 전기장치 구성품	29-296	HYDRAULIC PUMP ASSEMBLY 유압 펌프 어셈블리
15-078	ELECTRICAL COMPONENTS (ELH) 전기장치 구성품 (ELH)	30-609	HYDRAULIC VALVE MOUNTING 유압 밸브 마운팅
15-079	ELECTRICAL WIRING (ELH) 전장 와이어링 (ELH)	30-610	HYDRAULIC VALVE MOUNTING 유압 밸브 마운팅
15-080	CABLE INSTALLATION 케이블 조립그룹	30-611	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
15-081	ELECTRICAL COMPONENTS (EE) 전기장치 구성품 (EE)	30-612	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
15-082	CABLE INSTALLATION 케이블 조립그룹	30-613	HYDRAULIC CONTROL VALVE 유압 컨트롤 밸브
15-083	CABLE INSTALLATION (EE) 케이블 조립그룹 (EE)	30-615	HYDRAULIC CONTROL VALVE-3 SPOOL 유압 컨트롤 밸브 - 3 스풀
16-192	PUMP MOTOR ASSEMBLY 펌프 모터 어셈블리	30-616	HYDRAULIC CONTROL VALVE-4 SPOOL 유압 컨트롤 밸브 - 4 스풀
16-193	DRIVE MOTOR ASSEMBLY 드라이브 모터 어셈블리	31-357	HYDRAULIC SUPPLY LINES 유압 공급 라인
16-196	TRACTION & PUMP MOTORS MOUNTING 트랙션& 펌프 모터 마운팅	31-358	HYDRAULIC LIFT & TILT LINES 유압 리프트& 틸트 라인
17-030	LINE CONTACTOR ASSEMBLY 라인 컨택터 어셈블리	31-359	HYDRAULIC RETURN LINES 유압 리턴 라인
19-018	CONTROLLER MOUNTING 컨트롤러 마운팅	32-167	TILT AMOUNT GROUP 틸트 어마운트 그룹
20-275	DRIVE AXLE MOUNTING 드라이브 액슬 마운팅	32-174	TILT CYLINDER MOUNTING 틸트 실린더 마운팅
20-276	DRIVE AXLE ASSEMBLY 드라이브 액슬 어셈블리	32-175	TILT CYLINDER 틸트 실린더
22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브휠& 타이어 마운팅	33-049	SOLENOID VALVE 솔레노이드 밸브
22-014	STEER WHEEL & TIRE MOUNTING 스티어링휠& 타이어 마운팅	33-056	CLAMP LEVER LOCK SYSTEM 클램프 레버 록 시스템
22-024	DRIVE WHEEL & TIRE (SOLID TYPE) 드라이브 휠& 타이어 (솔리드 타입)	34-119	UPRIGHT MOUNTING 마스트 마운팅
22-025	STEER WHEEL & TIRE (SOLID TYPE) 스티어링 휠& 타이어 (솔리드 타입)	34-189	CARRIAGE ASSEMBLY 캐리지 어셈블리
22-050	DRIVE WHEEL & TIRE MOUNTING 드라이브휠& 타이어 마운팅	34-190	LOAD BACK REST MOUNTING 로드 백 레스트 마운팅
23-235	BRAKE MASTER CYLINDER 브레이크 마스터 실린더	37-009	SEAT ASSEMBLY 시트 어셈블리
23-416	BRAKE MASTER CYLINDER 브레이크 마스터 실린더	37-076	BACK MIRROR 백미러
23-425	BRAKE SYSTEM 브레이크 시스템	37-128	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅
23-550	BRAKE LINES 브레이크 라인	37-129	SHEET METAL & HOOD MOUNTING 시트메탈& 후드 마운팅
23-552	PARKING BRAKE SYSTEM 파킹 브레이크 시스템	37-130	ARMREST MOUNTING (ELH) 암레스트 마운팅 (ELH)

37-131	ARMREST MOUNTING (ELH) 암레스트 마운팅 (ELH)	66-269	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
37-133	SEAT BELT MOUNTING 시트 벨트 마운팅	66-271	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
37-154	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	66-273	STANDARD UPRIGHT 표준 마스트
37-177	SEAT ARMREST STAND ASSEMBLY 시트 암레스트 어셈블리	66-274	TRIPLE STAGE UPRIGHT 3단 마스트
38-236	MODEL DECALS & COUNTERWEIGHT MOUNTING 모델 데칼& 카운터웨이트 마운팅	66-275	HI-LO UPRIGHT 하이-로우 마스트
38-240	BATTERY STOPPER MOUNTING 배터리 스톱퍼 마운팅	66-999	EXTENTION FORK 익스텐션 포크
39-661	SEAT ASSEMBLY 시트 어셈블리	75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치
39-829	SEAT MOUNTING 시트 마운팅	75-013	SEAT OPERATED BRAKE 시트 조작 브레이크
39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리		
39-928	SEAT ASSEMBLY 시트 어셈블리		
40-260	TRUCK FLUIDS 트럭 윤활유		
40-287	DECALS 데칼		
47-000	SEAT WING KIT 시트윙 키트		
50-234	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)		
50-263	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)		
50-264	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)		
50-272	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)		
50-273	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)		
50-277	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)		
50-286	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)		
50-287	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)		
50-288	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)		
50-298	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)		
50-299	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)		
50-374	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)		
50-375	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)		
50-775	ATTACHMENT HOSE & CABLE SETTINGS (UPRIGHT) 어태치 호스& 케이블 세팅 (마스트)		
50-798	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)		
50-807	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적응)		
50-822	AUXILIARY VALVE LINES 보조 밸브 라인		
53-134	SIDE SHIFT ASSEMBLY 사이드 쉬프트 어셈블리		
53-146	F/P SIDESHIFT CYLINDER 포크포지셔너 사이드 쉬프트 실린더		
53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더		
53-212	FORK POSITIONER (SHIFTING) 포크 포지셔너 (쉬프트 타임)		
66-058	FORK 포크		
66-148	PRIMARY CYLINDER ASSEMBLY 프라이머리 실린더 어셈블리		




ACCELERATOR LINKAGE

02-189

02.258	STOP, ACCELERATOR PEDAL 스톱
02.260	BRACKET, ACCELERATOR LINKAGE MOUNTING 브라켓
02.261	FASTENER, ACCELERATOR LINKAGE MOUNTING BRACKET 패스너
02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.288	BRACKET, ACCELERATOR PEDAL ATTACHING 브라켓
02.289	FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING 패스너
13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너

93.726 WASHER, ACCELERATOR PEDAL PIVOT RETAINER
 와셔


ФОРКЛИФТ
www.forklift.ru



BACK-UP ALARM INSTALLATION

13-064


13.681	FASTENER, WARNING DEVICE 패스너
42.001	WARNING DEVICE, AUDIBLE (AIR OPER) 경고장치
42.024	HARNESS, TRAVEL ALARM 하네스
42.025	FASTENER, TRAVEL ALARM 패스너




ELECTRICAL COMPONENTS (SBR)

13-066

12.190	SWITCH, BATTERY RETAINER INTERLOCK 스위치
12.191	HARNESS, BATTERY RETAINER INTERLOCK SWITCH 하네스
12.192	FASTENER, BATTERY RETAINER INTERLOCK SWITCH 패스너
12.374	FITTING, BATTERY RETAINER INTERLOCK SWITCH HARNESS 피팅
18.010	CLIP, HARNESS 클립
18.011	FASTENER, HARNESS CLIP 패스너
38.146	PLATE, BATTERY STOP 플레이트




- | | |
|--------|--|
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |



13.332	ASSEMBLY, WARNING LIGHT 경고등
13.333	BULB, WARNING LIGHT 전구
60.821	GLOBE, STROBE LIGHT 글로브
60.822	BASE, STROBE LIGHT 베이스


60.795 ASSEMBLY COMPLETE



WORK LIGHT

13-194

- | | |
|--------|--|
| 13.281 | FASTENER, ADJ HEADLAMP SWIVEL
패스너 |
| 13.284 | BRACKET, ADJUSTABLE HEADLAMP
브라켓 |
| 13.285 | FASTENER, ADJUSTABLE HEADLAMP BRACKET
패스너 |
| 60.325 | BULB, HEADLAMP
전구 |
| 60.795 | LIGHT, REAR WORK
라이트 |




13.270	HEADLAMP, ADJUSTABLE 헤드램프
13.299	GUARD, HEADLIGHT 가드
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNES, HEADLAMP WIRING 하네스
60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.324	BULB, HEADLAMP 전구
60.368	RELAY, HEADLIGHTS 릴레이
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서

95.299


FASTENER, HEADLAMP GUARD

패스너

ФОРКЛИФТ
www.forklift.ru




13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
15.714	FLASHER, UNIT 플래서



REAR WORK LIGHT INSTALLATION

13-348


60.795	LIGHT, REAR WORK 라이트
60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.924	FASTENER, REAR WORK LAMP MOUNTING 패스너
60.960	HARNESS, REAR WORK LAMP EXTENSION 하네스
60.962	SPACER, REAR WORK LAMP MOUNTING 스페이서
60.963	GROMMET, REAR ACCESSORY WIRING 그로멧




COMBINATION LAMP INSTALLATION

13-349

13.206	BULB, BACK-UP LAMP 전구
13.218	BULB, STOP & TAIL LAMP 전구
13.675	BULB, TURN LIGHT 전구
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.964	RELAY, FOOT BRAKE 릴레이




14.232	WIRE, TILT SOLENOID VALVE 와이어
15.448	DIODE, HARNESS 다이오드
60.991	WIRE HARNESS, TILT LIMIT SENSOR 와이어하네스
60.992	SENSOR, TILT LIMIT 센서
60.993	BRACKET, TILT LIMIT SENSOR MOUNTING 브라켓
60.994	BRACKET, TILT LIMIT SENSING PLATE 브라켓
97.303	FASTENER, TILT LIMIT SENSOR MOUNTING 패스너
97.304	FASTENER, TILT LIMIT SENSOR MOUNTING BRACKET 패스너
97.370	FASTENER, TILT LIMIT SENSING PLATE BRACKET 패스너




14.114	HARNESS, MACHINE WIRING 하네스
14.352	FUSE, CONTROL CIRCUIT 퓨즈
14.744	BRACKET, FUSE HOLDER MOUNTING 브라켓
14.761	BAR, WIRING HARNESS POSITION 바
14.958	INSULATOR, WIRING HARNESS GROUND 절연체
15.447	DIODE, HARNESS 다이오드
15.640	WIRING HARNESS, MACHINE COWL 와이어하네스
15.721	FASTENER, RELAY BRACKET 패스너
18.000	CLIP, WIRING HARNESS 클립

18.001	FASTENER, WIRING HARNESS CLIP 패스너
18.002	CLIP, WIRING HARNESS 클립
18.004	CLIP, WIRING HARNESS 클립
18.006	CLIP, WIRING HARNESS 클립
37.973	GROMMET, SEAT WIRING HARNESS 그로멧
40.142	DECAL, ELECTRICAL CIRCUIT DIAGRAM 데칼
47.417	CAP, SEAT WIRING HARNESS HOLE 캡
65.289	BODY, FUSE BOX 바디
65.832	COVER, FUSE BOX 커버
67.241	WIRE HARNESS, CONTACTOR EXTENSION 와이어하네스
97.301	FASTENER, WIRING HARNESS GROUND INSULATOR 패스너
97.302	FASTENER, WIRING HARNESS POSITION BAR 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



ELECTRICAL COMPONENTS


14-359

13.000	PANEL, INSTRUMENT CLUSTER панель	39.417	GROUND STRAP, ELECTRIC TRUCK земляной кабель
13.003	HORN рог	39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP крепёжник
13.004	FASTENER, HORN MOUNTING BRACKET крепёжник	49.101	SENSOR, LEVER POSITION сенсор
13.047	SWITCH, CIRCUIT LOCKING свечи	49.204	BRACKET, LEVER POSITION SENSOR бракет
13.078	CLAMP, INSTRUMENT CLUSTER TO INST PANEL крепёжник	60.260	KEY, CIRCUIT LOCKING SWITCH ключ
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL крепёжник	60.725	POTENTIOMETER, STEERING INTERLOCK потенциометр
15.710	RELAY, ELECTRICAL реле	65.130	CONTACTOR ASSEMBLY, LINE контактор
17.013	BUS, 2A CONTACTOR бус	67.118	BRACKET, LINE CONTACTOR MOUNTING бракет
17.021	BUS, 1A CONTACTOR бус	67.204	COVER, DC CONVERTER крышка
17.041	FUSE, POWER фуз	67.217	CONVERTER, DC-DC FOR ACCESSORY конвертер
17.129	FASTENER, 1A CONTACTOR BUS крепёжник	67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL конвертер
17.154	FASTENER, FUSE TERMINAL ANGLE BUS крепёжник	95.303	FASTENER, DC-DC CONVERTER GUARD крепёжник
17.196	BUS, MAIN FUSE CONNECTING бус	96.596	FASTENER, STEERING INTERLOCK POTENTIOMETER крепёжник
19.324	BUS, MAIN FUSE FUSED TERMINAL бус	96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET крепёжник
19.949	INSULATOR, CONTACTOR PANEL FUSE HOLDER изоляционный элемент	96.976	FASTENER, CONTACTOR MOUNTING крепёжник

97.142	FASTENER, LEVER POSITION SENSOR 패스너
97.143	FASTENER, LEVER POSITION SENSOR BRACKET 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




ELECTRICAL COMPONENTS (ELH)

15-078

13.000	PANEL, INSTRUMENT CLUSTER панель	39.417	GROUND STRAP, ELECTRIC TRUCK земляной кабель
13.003	HORN рог	39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP крепёжник
13.004	FASTENER, HORN MOUNTING BRACKET крепёжник	60.260	KEY, CIRCUIT LOCKING SWITCH ключ
13.047	SWITCH, CIRCUIT LOCKING свитч	60.725	POTENTIOMETER, STEERING INTERLOCK потенциометр
13.078	CLAMP, INSTRUMENT CLUSTER TO INST PANEL зажим	60.894	CONTROLLER, ELECTRONIC HYDRAULIC контроллер
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL крепёжник	65.130	CONTACTOR ASSEMBLY, LINE контактор
15.710	RELAY, ELECTRICAL реле	67.118	BRACKET, LINE CONTACTOR MOUNTING бракет
17.013	BUS, 2A CONTACTOR бус	67.204	COVER, DC CONVERTER крышка
17.021	BUS, 1A CONTACTOR бус	67.217	CONVERTER, DC-DC FOR ACCESSORY конвертер
17.041	FUSE, POWER фуз	67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL конвертер
17.129	FASTENER, 1A CONTACTOR BUS крепёжник	95.303	FASTENER, DC-DC CONVERTER GUARD крепёжник
17.154	FASTENER, FUSE TERMINAL ANGLE BUS крепёжник	96.596	FASTENER, STEERING INTERLOCK POTENTIOMETER крепёжник
17.196	BUS, MAIN FUSE CONNECTING бус	96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET крепёжник
19.324	BUS, MAIN FUSE FUSED TERMINAL бус	96.976	FASTENER, CONTACTOR MOUNTING крепёжник
19.949	INSULATOR, CONTACTOR PANEL FUSE HOLDER изоляционный материал	97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY крепёжник

97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL 패스너
97.188	FASTENER, ELECTRONIC HYDRAULIC CONTROLLER 패스너

ФОРКЛИФТ
www.forklift.ru





ELECTRICAL WIRING (ELH)

15-079

- | | |
|--------|---|
| 14.114 | HARNESS, MACHINE WIRING
하네스 |
| 14.352 | FUSE, CONTROL CIRCUIT
퓨즈 |
| 14.744 | BRACKET, FUSE HOLDER MOUNTING
브라켓 |
| 14.958 | INSULATOR, WIRING HARNESS GROUND
절연체 |
| 15.447 | DIODE, HARNESS
다이오드 |
| 15.538 | HARNESS, VALVE SWITCH WIRING CONNECTOR
하네스 |
| 15.640 | WIRING HARNESS, MACHINE COWL
와이어하네스 |
| 15.721 | FASTENER, RELAY BRACKET
패스너 |
| 18.000 | CLIP, WIRING HARNESS
클립 |

18.001	FASTENER, WIRING HARNESS CLIP 패스너
18.002	CLIP, WIRING HARNESS 클립
18.003	FASTENER, WIRING HARNESS CLIP 패스너
18.004	CLIP, WIRING HARNESS 클립
18.006	CLIP, WIRING HARNESS 클립
37.973	GROMMET, SEAT WIRING HARNESS 그로멧
40.142	DECAL, ELECTRICAL CIRCUIT DIAGRAM 데칼
65.289	BODY, FUSE BOX 바디
65.832	COVER, FUSE BOX 커버
97.301	FASTENER, WIRING HARNESS GROUND INSULATOR 패스너






15-080

13.470	SWITCH, DISCONNECT 스위치	15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
14.039	RECEPTACLE & LEAD ASSEMBLY, BATTERY 리셉터클& 리드	15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
14.040	RECEPTACLE, BATTERY 리셉터클	15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
14.041	FASTENER, BATTERY RECEPTACLE 패스너	15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
14.599	BRACKET, BATTERY RECEPTACLE MOUNTING 브라켓	15.820	BOOT, CABLE 부트
14.600	FASTENER, BATTERY RECEPTACLE MOUNTING BRACKET 패스너	15.851	CABLE, DRIVE MOTOR (TMVR TO TCVR) 케이블
15.600	CABLE, CONTACTOR 케이블	15.852	CABLE, DRIVE MOTOR (TMWR TO TCWR) 케이블
15.624	CABLE, CONTACTOR L- 케이블	18.016	CLIP, CABLE 클립
15.625	CABLE, CONTACTOR L+ 케이블	18.017	FASTENER, CABLE CLIP 패스너
15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블	47.362	COVER, CABLE PROTECTION 커버
15.648	FASTENER, DISCONNECT SWITCH MOUNTING BRACKET 패스너	47.363	FASTENER, CABLE PROTECTION COVER 패스너
15.651	BRACKET, DISCONNECT SWITCH MOUNTING 브라켓	47.384	COVER, DISCONNECT SWITCH 커버
15.770	CABLE, DRIVE MOTOR (TMUR TO TCUR) 케이블	67.238	BUS, BATTERY DISCONNECT SWITCH 버스
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블	67.239	BUSHING, BATTERY DISCONNECT SWITCH 부싱
15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블	95.972	FASTENER, BATTERY DISCONNECT SWITCH 패스너

- 97.211 FASTENER, DISCONNECT SWITCH COVER
패스너
- 97.305 FASTENER, BATTERY DISCONNECTOR SWITCH BUS
패스너






ELECTRICAL COMPONENTS (EE)

15-081


17.490	GROMMET, CONTACTOR PANEL BOX LEADS 그로멧
17.539	GROMMET, CONTACTOR BOX 그로멧
60.936	BRACKET, CONTACTOR COVERING BODY 브라켓
60.937	BRACKET, CONTACTOR COVERING 브라켓
60.939	GROMMET, CONTACTOR CONNECTING CONDUCTOR 그로멧
65.932	FASTENER, LINE CONTACTOR 패스너
67.064	CONDUCTOR, LINE CONTACTOR 컨덕터
92.112	FASTENER, CONTACTOR BOX 패스너



13.470	SWITCH, DISCONNECT 스위치	15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블
14.039	RECEPTACLE & LEAD ASSEMBLY, BATTERY 리셉터클& 리드	15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
14.040	RECEPTACLE, BATTERY 리셉터클	15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
14.041	FASTENER, BATTERY RECEPTACLE 패스너	15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
14.476	SHIELD, BATTERY CABLE 실드	15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
14.477	FASTENER, BATTERY CABLE SHIELD 패스너	15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
14.599	BRACKET, BATTERY RECEPTACLE MOUNTING 브라켓	15.820	BOOT, CABLE 부트
14.600	FASTENER, BATTERY RECEPTACLE MOUNTING BRACKET 패스너	15.851	CABLE, DRIVE MOTOR (TMVR TO TCVR) 케이블
15.600	CABLE, CONTACTOR 케이블	15.852	CABLE, DRIVE MOTOR (TMWR TO TCWR) 케이블
15.624	CABLE, CONTACTOR L- 케이블	18.016	CLIP, CABLE 클립
15.625	CABLE, CONTACTOR L+ 케이블	18.017	FASTENER, CABLE CLIP 패스너
15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블	47.362	COVER, CABLE PROTECTION 커버
15.648	FASTENER, DISCONNECT SWITCH MOUNTING BRACKET 패스너	47.363	FASTENER, CABLE PROTECTION COVER 패스너
15.651	BRACKET, DISCONNECT SWITCH MOUNTING 브라켓	47.384	COVER, DISCONNECT SWITCH 커버
15.770	CABLE, DRIVE MOTOR (TMUR TO TCUR) 케이블	67.238	BUS, BATTERY DISCONNECT SWITCH 버스

67.239	BUSHING, BATTERY DISCONNECT SWITCH 부싱
95.972	FASTENER, BATTERY DISCONNECT SWITCH 패스너
97.211	FASTENER, DISCONNECT SWITCH COVER 패스너
97.305	FASTENER, BATTERY DISCONNECTOR SWITCH BUS 패스너






13.470	SWITCH, DISCONNECT 스위치	15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
14.039	RECEPTACLE & LEAD ASSEMBLY, BATTERY 리셉터클& 리드	15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
14.040	RECEPTACLE, BATTERY 리셉터클	15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
14.041	FASTENER, BATTERY RECEPTACLE 패스너	15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
14.599	BRACKET, BATTERY RECEPTACLE MOUNTING 브라켓	15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
14.600	FASTENER, BATTERY RECEPTACLE MOUNTING BRACKET 패스너	15.820	BOOT, CABLE 부트
15.600	CABLE, CONTACTOR 케이블	15.851	CABLE, DRIVE MOTOR (TMVR TO TCVR) 케이블
15.624	CABLE, CONTACTOR L- 케이블	15.852	CABLE, DRIVE MOTOR (TMWR TO TCWR) 케이블
15.625	CABLE, CONTACTOR L+ 케이블	18.016	CLIP, CABLE 클립
15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블	18.017	FASTENER, CABLE CLIP 패스너
15.648	FASTENER, DISCONNECT SWITCH MOUNTING BRACKET 패스너	47.362	COVER, CABLE PROTECTION 커버
15.651	BRACKET, DISCONNECT SWITCH MOUNTING 브라켓	47.363	FASTENER, CABLE PROTECTION COVER 패스너
15.764	FASTENER, CABLE MOUNTING 패스너	47.384	COVER, DISCONNECT SWITCH 커버
15.770	CABLE, DRIVE MOTOR (TMUR TO TCUR) 케이블	67.238	BUS, BATTERY DISCONNECT SWITCH 버스
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블	67.239	BUSHING, BATTERY DISCONNECT SWITCH 부싱


95.972	FASTENER, BATTERY DISCONNECT SWITCH 패스너
97.211	FASTENER, DISCONNECT SWITCH COVER 패스너
97.305	FASTENER, BATTERY DISCONNECTOR SWITCH BUS 패스너





- | | |
|--------|---|
| 16.154 | COVER, PUMP MOTOR ROTOR END
커버 |
| 16.155 | WASHER, PUMP MOTOR ROTOR BEARING
와셔 |
| 16.156 | RING, PUMP MOTOR ROTOR BEARING
링 |
| 16.157 | ROTOR, PUMP MOTOR
로터 |
| 16.178 | BASE, PUMP MOTOR TERMINAL
베이스 |
| 16.180 | SENSOR KIT, PUMP MOTOR ROTOR
센서 |
| 16.181 | PLATE, PUMP MOTOR ROTOR SENSOR TARGET
플레이트 |
| 16.182 | COVER, PUMP MOTOR DRIVE END
커버 |
| 16.183 | BEARING, PUMP MOTOR ROTOR END
베어링 |


16.184	SENSOR KIT, PUMP MOTOR TEMPERATURE 센서키트
16.285	SEAL, PUMP MOTOR ROTOR BEARING 셀
16.500	MOTOR ASSEMBLY, PUMP 모터
16.524	FASTENER, PUMP MOTOR MOUNTING 패스너
16.543	COVER, PUMP MOTOR COMMUTATOR END BEARING 커버
16.544	FASTENER, COMMUTATOR END BEARING COVER 패스너
16.545	RETAINER, PUMP MOTOR COMMUTATOR END BEARING 리테이너
16.573	TERMINAL BLOCK, HYDRAULIC PUMP MOTOR 터미널블록
16.593	STATOR ASSY, HYDRAULIC-PUMP MOTOR 스테이터
16.594	RETAINER, HYDRAULIC PUMP MOTOR DRIVE END FRAME 리테이너
93.265	FASTENER, HYDRAULIC PUMP MOTOR TERMINAL 패스너
95.045	WASHER, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 와셔
95.501	FASTENER, PUMP MOTOR TERMINAL BLOCK CONNECTOR 패스너
97.069	FASTENER, PUMP MOTOR SPEED SENSOR 패스너



16.000	MOTOR ASSEMBLY, DRIVE 모터
16.004	RETAINER, DRIVE MOTOR COMMUTATOR END BEARING 리테이너
16.023	FASTENER, DRIVE MOTOR DRIVE END FRAME 패스너
16.029	SEAL, DRIVE MOTOR ARMATURE SHAFT DRIVE END 씰
16.090	COVER, DRIVE MOTOR COMMUTATOR END 커버
16.106	TERMINAL BLOCK, DRIVE MOTOR 터미널블록
16.114	WASHER, DRIVE MOTOR DRIVE END THRUST 와셔
16.116	FASTENER, DRIVE MOTOR TERMINAL 패스너
16.149	ROTOR, DRIVE MOTOR 로터

16.162	SEAL, DRIVE MOTOR DRIVE END 씰
16.165	BEARING, DRIVE MOTOR DRIVE END 베어링
16.166	BEARING, DRIVE MOTOR NON DRIVE END 베어링
16.185	STATOR ASSY, DRIVE MOTOR 스테이터
16.186	BASE, DRIVE MOTOR TERMINAL 베이스
16.187	SENSOR KIT, DRIVE MOTOR ROTOR 센서키트
16.189	COVER, DRIVE MOTOR DRIVE END 커버
16.191	SENSOR KIT, DRIVE MOTOR TEMPERATURE 센서키트
16.194	PLATE, DRIVE MOTOR ROTOR SENSOR TARGET 플레이트
16.290	SEAL, DRIVE MOTOR ROTOR BEARING 씰
16.512	FASTENER, PUMP MOTOR COMMUTATOR END FRAME 패스너
16.543	COVER, PUMP MOTOR COMMUTATOR END BEARING 커버
93.232	WASHER, DRIVE MOTOR TERMINAL BLOCK FASTENER 와셔
93.233	FASTENER, DRIVE MOTOR TERMINAL 패스너
97.068	FASTENER, DRIVE MOTOR SPEED SENSOR 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




TRACTION & PUMP MOTORS MOUNTING

16-196

16.000	MOTOR ASSEMBLY, DRIVE 모터
16.001	FASTENER, DRIVE MOTOR 패스너
16.500	MOTOR ASSEMBLY, PUMP 모터
16.704	DAMPENER, PUMP MOTOR VIBRATION 댐프너
16.708	FASTENER, PUMP MOTOR VIBRATION DAMPENER 패스너



65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.930	ASSEMBLED COIL & MAGNET FRAME, LINE CONTACTOR 코일& 마그넷
65.931	TOP COVER, LINE CONTACTOR 탑커버
65.932	FASTENER, LINE CONTACTOR 패스너
65.933	CONTACT KIT, LINE CONTACTOR 컨택트키트
65.934	RETURN SPRING, LINE CONTACTOR 리턴스프링
65.942	CONTACT SET, LINE CONTACTOR 컨택트세트
67.124	END CAP, LINE CONTACTOR 엔드캡
67.173	BASE, LINE CONTACTOR 베이스




CONTROLLER MOUNTING

19-018

19.240	FASTENER, CONTROL PANEL MOUNTING 패스너
67.213	FUSE, PUMP CONTROLLER 퓨즈
67.300	CONTROLLER, TRACTION 컨트롤러
67.400	CONTROLLER, PUMP 컨트롤러
93.999	FASTENER, CONTROL PANEL MOUNTING 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE AXLE MOUNTING

20-275

20.120	SPACER, DRIVE AXLE MOUNTING 스페이서
20.186	KIT, DRIVE GEAR 키트
20.377	FASTENER, DRIVE AXLE TO FRAME 패스너
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드

ASSEMBLY
COMPLETE { 20.500(RH)
20.501(LH)




DRIVE AXLE ASSEMBLY

20-276

20.004	BEARING, DRIVE HOUSING SPINDLE 베어링	20.517	COVER, DRIVE AXLE PLANET 커버
20.050	BEARING, DRIVE HOUSING SPINDLE 베어링	20.523	GEAR, DRIVE AXLE OUTPUT 기어
20.053	RETAINER, DRIVE UNIT PINION BEARING 리테이너	20.524	BEARING, DRIVE AXLE INTERMEDIATE GEAR SHAFT 베어링
20.080	BREATHER, DRIVE UNIT 브리더	20.530	SHAFT, DRIVE AXLE INPUT GEAR 샤프트
20.116	PIN, DRIVE AXLE HOUSING & DIFF ALIGNMENT 핀	20.542	BEARING, DRIVE AXLE SHAFT 베어링
20.178	KEY, INPUT SHAFT 키	20.554	FASTENER, DRIVE AXLE HUB CAP 패스너
20.196	HOUSING ASSEMBLY, DRIVE AXLE 하우징	20.570	FASTENER, DRIVE WHEEL MOUNTING 패스너
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너	20.571	CONE, DRIVE AXLE HUB OUTER BEARING 콘
20.338	PLUG, DRIVE UNIT HOUSING CAP 플러그	20.574	SHAFT, DRIVE AXLE PLANET PINION 샤프트
20.371	FASTENER, DRIVE AXLE PLANET 패스너	20.577	FASTENER, DRIVE AXLE PLANET 패스너
20.372	FASTENER, AXLE HOUSING 패스너	20.581	HUB ASSEMBLY, DRIVE AXLE 허브
20.380	PLATE, HOUSING COVER 플레이트	20.586	SHAFT, DRIVE AXLE 샤프트
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드	20.592	PLANET, DRIVE AXLE 플래닛
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드	20.593	WASHER, PLANET PINION GEAR THRUST 와셔
20.512	SHIM, DRIVE AXLE HUB BEARING 심	20.598	GEAR, DRIVE AXLE PLANET PINION 기어

20.604	PLUG, DRIVE AXLE HUB DRAIN 플러그
20.609	HUB, DRIVE AXLE INTERNAL GEAR 허브
20.610	PLUG, DRIVE AXLE HUB FILLER 플러그
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.628	ADAPTOR, DRIVE AXLE BREATHER VENT 어댑터
20.631	SEAL, DRIVE AXLE PLANET CARRIER 씰
20.640	SEAL, RING GEAR SHAFT BEARING HOUSING 씰
20.661	SEAL, DRIVE AXLE RING GEAR SHAFT BEARING CAP 씰
20.662	SEAL, DRIVE AXLE RING GEAR SHAFT BEARING CAP 씰
20.663	SPACER, DRIVE AXLE HUB BEARING 스페이서
20.675	DOWEL PIN, DRIVE AXLE END HOUSING 다웰핀
20.815	RETAINER, DRIVE AXLE HOUSING CARRIER BEARING 리테이너
20.820	BEARING, DRIVE AXLE PINION SHAFT 베어링
20.822	CARRIER, DRIVE AXLE HOUSING 캐리어
20.829	BEARING, DRIVE AXLE RING GEAR 베어링
20.835	RETAINER, DRIVE AXLE RING GEAR 리테이너
20.841	LOCATOR, DRIVE AXLE PLANET 로케이터
20.843	LOCATOR, DRIVE AXLE OUTPUT GEAR BEARING 로케이터
20.859	HOUSING, DRIVE AXLE 하우징
22.349	PLUG, SERVICE BRAKE HOUSING 플러그
22.353	FITTING, SERVICE BRAKE INLET PORT 피팅
22.354	SEAL, SERVICE BRAKE INLET PORT FITTING 씰
22.390	DISC, BRAKE - INNER 디스크
22.391	DISC, BRAKE - OUTER 디스크
22.394	FASTENER, BRAKE DISC HUB 패스너
22.396	RETAINER, BRAKE DISC 리테이너
22.702	DOWEL PIN, BRAKE DISC PISTON SLEEVE 다웰핀
22.704	PLATE, DRIVE AXLE END HOUSING 플레이트
22.920	SPRING, BRAKE DISC PISTON PLATE FASTENER 스프링
23.286	PLATE, BRAKE BACKING 플레이트
23.346	ARM, PARKING BRAKE 암
23.614	FASTENER, DRIVE WHEEL BRK DRUM TO HUB (RH) 패스너
23.750	PIN, BRAKE ACTUATING LEVER PIVOT 핀
44.226	RING, DRIVE SHAFT BEARING 링
90.660	NUT, DRIVE AXLE PLANET FASTENER 너트

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE WHEEL & TIRE MOUNTING

22-013

- | | |
|--------|--|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠 & 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER WHEEL & TIRE MOUNTING

22-014

- | | |
|--------|---|
| 23.026 | FASTENER, STEER WHEEL
패스너 |
| 23.031 | STEER WHEEL AND TIRE ASSEMBLY
스티어휠 & 타이어 |

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE (SOLID TYPE)

22-024

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어

ASSEMBLY
COMPLETE — 23.031




STEER WHEEL & TIRE (SOLID TYPE)

22-025

22.990	TIRE ASSEMBLY, STEER 타이어
23.000	RIM ASSEMBLY, STEER WHEEL 립
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠 & 타이어


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



DRIVE WHEEL & TIRE MOUNTING


22-050

23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어
23.335	FASTENER, DRIVE WHEEL 패스너
38.780	FENDER, RIGHT HAND FRONT 펜더
38.790	FENDER, LEFT HAND FRONT 펜더
39.632	FASTENER, FENDER SUPPORT 패스너



22.026	ROD END, BRAKE PEDAL LINKAGE 로드엔드
22.342	SEAL, BRAKE MASTER CYLINDER INLET FITTING 씰
22.417	SPRING, MASTER CYLINDER PISTON RETURN 스프링
22.453	BLEEDER, MASTER CYLINDER RELIEF VALVE LINE 블리더
22.482	CUP, MASTER CYLINDER PISTON RETURN SPRING 컵
22.973	HOUSING, BRAKE MASTER CYLINDER 하우징
22.975	STOP-SPRING, BRAKE MASTER CYLINDER 스톱스프링
23.086	SPRING, MASTER CYL CHECK VALVE 스프링
23.148	CLAMP, MASTER CYLINDER BOOT (SMALL) 클램프


23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.159	REPAIR KIT, MASTER CYLINDER 리페어키트
23.160	ROD, PUSH 로드
23.161	BOOT, MASTER CYLINDER 부트
23.495	SEAL KIT, MASTER CYLINDER 셀키트
23.589	RETAINER, BRAKE ACTUATING LEVER 리테이너
23.795	FITTING, BRAKE MASTER CYLINDER INLET 피팅
92.026	RETAINER, BRAKE MASTER CYLINDER ACTUATING ROD PIN 리테이너
94.398	NUT, BRAKE MASTER CYLINDER ACTUATING ROD FASTENER 너트
94.701	WASHER, BRAKE MASTER CYLINDER ACTUATING ROD PIN 와셔



ASSEMBLY
COMPLETE — 23.150

REPAIR KIT
INCLUDES ITEMS
MARKED "K" — 23.159

ROD KIT
INCLUDES ITEMS
MARKED "R" — 24.393




BRAKE MASTER CYLINDER

23-416

- | | |
|--------|---|
| 22.453 | BLEEDER, MASTER CYLINDER RELIEF VALVE LINE
블리더 |
| 23.150 | CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE
실린더 |
| 23.159 | REPAIR KIT, MASTER CYLINDER
리페어키트 |
| 23.161 | BOOT, MASTER CYLINDER
부트 |
| 24.393 | ROD KIT, BRAKE MASTER CYLINDER
로드키트 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




BRAKE SYSTEM

23-425

- | | |
|--------|---|
| 13.142 | SWITCH, BRAKE INTERLOCK
스위치 |
| 22.972 | FASTENER, BRAKE MASTER CYLINDER MOUNTING
패스너 |
| 23.100 | PEDAL, BRAKE
페달 |
| 23.101 | SHAFT, BRAKE PEDAL
샤프트 |
| 23.114 | PAD & FASTENER, BRAKE PEDAL
패드& 패스너 |
| 23.118 | FASTENER, BRAKE PEDAL TO MASTER CYL PUSH ROD
패스너 |
| 23.136 | SPRING, BRAKE PEDAL RETURN
스프링 |
| 23.145 | FASTENER, BRAKE PEDAL SHAFT
패스너 |
| 23.150 | CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE
실린더 |

23.157	FASTENER, BRAKE MASTER CYLINDER ATTACHING 패스너
23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.435	FASTENER, BRAKE PEDAL PIVOT BRACKET 패스너





BRAKE LINES
23-550

22.109	FASTENER, BRAKE CYLINDER BLEEDER LINE 패스너
22.338	CLAMP, BRAKE FLUID RESERVOIR 클램프
22.527	ADAPTER, BRAKE LINES 어댑터
22.558	BLEEDER, BRAKE LINES 블리더
22.559	FITTING, BRAKE LINES BLEEDER 피팅
22.604	CLAMP, BRAKE FLUID RESERVOIR LINE 클램프
22.627	TEE, BRAKE LINE 티
22.697	SEAL, BRAKE LINE FITTING 셀
23.186	LINE, BRAKE MASTER CYLINDER OUTLET 라인

23.199	FASTENER, BRAKE LINE TEE 패스너
23.207	LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.666	LINE, BRAKE CYLINDER BLEEDER (RH) 라인
23.667	LINE, BRAKE CYLINDER BLEEDER (LH) 라인
23.792	RESERVOIR, BRAKE FLUID 리저버
23.793	FASTENER, BRAKE FLUID RESERVOIR 패스너
23.794	LINE, BRAKE MASTER CYLINDER INLET 라인






PARKING BRAKE SYSTEM

23-552


22.045	BRACKET, PARKING BRAKE PEDAL PIVOT MTG 브라켓	23.264	BRAKE ASSEMBLY, PARKING 브레이크
22.052	GUIDE, PARKING BRAKE DRAW ROD 가이드	23.378	FASTENER, PARKING BRAKE DRAW ROD CLEVIS 패스너
22.053	FASTENER, PARKING BRK DRAW ROD GUIDE 패스너	23.384	FASTENER, PARKING BRAKE LINK 패스너
22.263	RETAINER, PARKING BRAKE RELEASE LEVER PIVOT 리테이너	23.394	BEARING, PARKING BRAKE LEVER PIVOT BRACKET 베어링
22.264	ADJUSTOR, PARKING BRAKE 어드저스터	23.481	LEVER, PARKING BRAKE RELEASE 레버
22.442	PAD, PARKING BRAKE PEDAL 패드	23.482	SPRING, PARKING BRAKE RELEASE LEVER 스프링
22.853	SWITCH, PARKING BRAKE PEDAL ACTUATING 스위치	23.489	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
22.854	FASTENER, PARKING BRAKE PEDAL ACTUATING 패스너	23.571	BUMPER, PARKING BRAKE LEVER 범퍼
22.855	PIVOT, PARKING BRAKE PEDAL 피봇	23.638	ANCHOR, PARKING BRAKE CABLE 앵커
22.856	RETAINER, PARKING BRAKE PEDAL PIVOT 리테이너	23.639	FASTENER, PARKING BRAKE CABLE ANCHOR 패스너
22.860	PEDAL, PARKING BRAKE 페달	23.763	PIVOT, PARKING BRAKE OPERATING LEVER 피봇
22.895	FASTENER, PARKING BRAKE PEDAL PIVOT RETAINER 패스너	23.767	SPRING, PARKING BRAKE DRAW 스프링
22.898	CABLE, PARKING BRAKE DRAW - LH 케이블	23.851	LINK, PARKING BRAKE 링크
22.900	CABLE, PARKING BRAKE DRAW - RH 케이블	23.918	FASTENER, PARKING BRAKE PEDAL PIVOT BRACKET 패스너
22.955	PLATE, PARKING BRAKE PEDAL ACTUATING SWITCH 플레이트	23.919	FASTENER, PARKING BRAKE PIVOT BRACKET 패스너

97.300 FASTENER, PARKING BRAKE PEDAL PAD
패스너






- 25.109 KIT, STEER GEAR SEAL
키트
- 25.150 GEAR BOX ASSEMBLY, STEERING
기어박스
- 25.630 REPAIR KIT, STEERING COLUMN
리페어키트



06.101	LEVER ASSEMBLY, FORWARD & REVERSE 레버
13.655	SWITCH, TURN INDICATOR 스위치
14.050	HARNESS, CONTROL CIRCUIT WIRING 하네스
15.709	SWITCH, EMERGENCY 스위치
25.012	CUSHION, STEERING COLUMN 쿠션
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.082	FASTENER, LEVER MOUNTING BRACKET 패스너
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.926	COVER, STEER COLUMN FRONT UPPER 커버

25.927	COVER, STEER COLUMN REAR UPPER 커버
25.928	COVER, STEER COLUMN FRONT LOWER 커버
25.929	COVER, STEER COLUMN REAR LOWER 커버
25.934	FASTENER, STEER COLUMN COVER 패스너
25.935	FASTENER, STEER COLUMN COVER 패스너
25.936	PLUG, STEER COLUMN SWITCH 플러그
60.904	SWITCH, STROBE LIGHT 스위치
97.084	FASTENER, STEER COLUMN COVER 패스너

ASSEMBLY
COMPLETE 25.030




STEERING COLUMN SHAFT ASSEMBLY

25-291

25.003	NUT, HANDWHEEL 너트
25.011	FASTENER, STEERING COLUMN 패스너
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.038	HOUSING ASSEMBLY-CUP & BUSHING, STEERING 하우징
25.141	SHAFT, STEERING GEAR 샤프트
25.187	BEARING, STEER SHAFT 베어링
25.393	PIN, STEERING LINK (STEERING ARM) 핀
25.407	KEY, STEER COLUMN SHAFT COUPLING 키
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링

25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.873	BUSHING, STEER COLUMN AXIAL 부싱
25.874	BUSHING, STEER COLUMN TELESCOPING 부싱
25.933	FASTENER, STEERING COLUMN 패스너
25.954	ARM, TILT STEERING COLUMN ADJUSTOR 암
25.955	SUPPORT, STEERING COLUMN SHAFT 서포트
25.956	BRUSH, STEERING COLUMN SHAFT 브러쉬
25.957	BRUSH HOLDER, STEERING COLUMN SHAFT 브러쉬홀더
25.958	PIVOT, TILT STEERING COLUMN ADJUSTOR ARM 피봇
25.959	PIN, TILT STEERING COLUMN ADJUSTOR ARM 핀
26.351	WASHER, STEERING ARM PIN 와셔
91.631	WASHER, STEERING COLUMN UPPER BRACKET FASTENER 와셔
92.885	NUT, STEERING COLUMN UPPER BRACKET FASTENER 너트
92.895	WASHER, STEERING COLUMN SUPPORT FASTENER 와셔
92.897	NUT, STEERING COLUMN SUPPORT FASTENER 너트
93.603	FASTENER, STEERING COLUMN TILTING SPRING BALL STUD 패스너
94.888	RETAINER, STEERING COLUMN ADJUSTOR 리테이너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEERING WHEEL & COLUMN MOUNTING

25-292

25.002	HORN BUTTON KIT 혼버튼키트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.576	SPACER, STEERING HAND WHEEL 스페이서
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
25.804	COVER, HANDLE CONTROL ASSEMBLY 커버

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEERING GEAR MOUNTING

25-372

- | | |
|--------|--|
| 25.034 | FASTENER, STEERING GEAR ATTACHING
패스너 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |

ASSEMBLY
COMPLETE 26.100

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER AXLE ASSEMBLY

26-000

26.000	CYLINDER ASSEMBLY, STEERING 실린더	26.140	WASHER, STEER WHEEL HUB BEARING THRUST 와셔
26.085	FASTENER, STEERING CYLINDER MOUNTING BRKT 패스너	26.141	FASTENER, STEER WHEEL HUB 패스너
26.100	AXLE ASSEMBLY, STEERING 스티어액슬	26.143	CAP, STEER WHEEL HUB 캡
26.119	AXLE, STEER 액슬	26.148	KNUCKLE, STEER AXLE (LH) 너트
26.124	SHIM, STEER AXLE KNUCKLE 심	26.190	SEAL, STEER AXLE KNUCKLE OIL 씰
26.125	PIN, STEER AXLE KNUCKLE 핀	26.222	SHAFT, STEER AXLE 샤프트
26.126	ARM, RH STEERING 암	26.242	FASTENER, STEER AXLE SHAFT 패스너
26.129	FITTING - LUB, STEER AXLE KNUCKLE 피팅	26.281	RETAINER, STEER AXLE HUB BRG KNUCKLE NUT 리테이너
26.131	BEARING, STEER AXLE KNUCKLE PIN LOWER 베어링	26.338	PIN, STEERING ARM 핀
26.132	KNUCKLE, STEER AXLE (RH) 너트	26.339	LUB-FITTING, STEERING ARM 윤활피팅
26.133	SEAL, STEER WHEEL HUB 씰	26.340	BEARING, STEERING ARM PIN 베어링
26.134	CONE, STEER WHEEL HUB BEARING (INNER) 콘	26.347	PIN, STEER ARM 핀
26.136	HUB & CUP, STEER WHEEL 허브& 컵	26.348	LOCATOR, STEER CYLINDER 로케이터
26.137	FASTENER, STEER WHEEL 패스너	26.434	COVER, STEER AXLE KNUCKLE PIVOT (BOTTOM) 커버
26.139	CONE, STEER WHEEL HUB BEARING (OUTER) 콘	92.507	WASHER, STEERING ARM FASTENER 와셔

93.700	FASTENER, STEER AXLE KNUCKLE PIN COVER 패스너
94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너
94.855	RETAINER, STEERING ARM PIN 리테이너





HYDRAULIC STEERING LINES


26-003

28.051	LINE, STEERING GEAR 라인
28.052	FITTING, STEERING GEAR 피팅
28.054	LINE, STEERING GEAR 라인
28.055	FITTING, STEERING GEAR 피팅
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.448	FITTING, STEER CYLINDER LINE 피팅
28.807	CLAMP, POWER STEERING LINES 클램프
29.470	FITTING, PRIORITY VALVE 피팅

29.473	FITTING, PRIORITY VALVE 피팅
31.116	FITTING, STEER CYLINDER PORT 피팅
31.749	CLAMP, POWER STEERING LINES 클램프
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER AXLE MOUNTING

26-004

- | | |
|--------|----------------------------------|
| 26.100 | AXLE ASSEMBLY, STEERING
스티어액슬 |
| 26.436 | SHIM, STEER AXLE SHAFT
심 |
| 26.437 | BUSHING, STEER AXLE SHAFT
부싱 |




26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.003	SEAL KIT, PISTON ROD 씰키트
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 스티어실린더피스톤
26.093	GLAND, STEERING CYLINDER 그랜드
26.099	BUSHING, STEERING CYLINDER GLAND 부싱



27.009	VALVE ASSEMBLY, HYDRAULIC PRIORITY 밸브
29.471	SEAL, PRIORITY VALVE FITTING 씰
29.472	SEAL, PRIORITY VALVE FITTING 씰

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC PUMP MOUNTING

29-139

16.287	WIRE, LEAD GROUND FROM MOTOR 와이어
29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.119	FASTENER, PUMP HOUSING 패스너
29.474	SEAL, PUMP INLET FITTING 씰
29.608	MANIFOLD, HYDRAULIC PUMP INLET SUCTION 매니폴드
97.097	FASTENER, HYDRAULIC PUMP INLET SUCTION MANIFOLD 패스너

NOTE :
NON SERVICEABLE
ITEMS MARKED "N"



HYDRAULIC TANK & COMPONENTS MOUNTING

29-198


29.000	FILTER, HYDRAULIC OIL 필터
29.002	FASTENER, HYDRAULIC OIL FILTER 패스너
29.007	CARTRIDGE, HYDRAULIC OIL FILTER 카트리지
29.048	PIPE, HYDRAULIC FILTER 파이프
29.591	RUBBER, SUMP TANK MOUNTING 리버
29.617	PLUG, SUMP TANK DRAIN 플러그
29.618	SEAL, SUMP TANK DRAIN PLUG 셀
29.701	TANK, SUMP 탱크
29.702	FASTENER, SUMP TANK 패스너

29.728	CAP, HYDRAULIC SUMP FILLER 캡
29.748	STRAINER, HYDRAULIC 스트레이너
29.767	SEAL, SUMP TANK COVER 씰
29.768	FASTENER, SUMP TANK COVER 패스너
31.822	LINE, FILTER OUTLET TO SUMP 라인
31.823	CLAMP, FILTER OUTLET LINE 클램프



ASSEMBLY
COMPLETE — 29.100


SEAL KIT — 29.028



HYDRAULIC PUMP ASSEMBLY

29-296

- | | |
|--------|--------------------------------------|
| 29.028 | SEAL KIT, HYDRAULIC UNIT PUMP
씰키트 |
| 29.087 | SEAL, HYDRAULIC PUMP HOUSING
씰 |
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.268 | COUPLING, MAIN HYDRAULIC PUMP
커플링 |




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링
30.085	LINK, CONTROL VALVE SPOOL 링크
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브

30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
49.042	CAP, TILT CONTROL LEVER 캡
49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐퍼너
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서

91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너
97.161	FASTENER, HYDRAULIC VALVE BRACKET HINGE PIVOT 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING


30-610

30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐프너
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서

91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
96.070	FASTENER, SUPPORT HYDRAULIC VALVE BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너
97.161	FASTENER, HYDRAULIC VALVE BRACKET HINGE PIVOT 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (3SP00L)

30-611

13.537 SWITCH, CONTROL VALVE PUMP OPERATING
스위치

30.000 VALVE ASSEMBLY, HYDRAULIC
밸브

30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너

30.073 BRACKET, HYDRAULIC VALVE MOUNTING
브라켓

30.080 PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET
플런저

30.081 BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT
베어링

30.085 LINK, CONTROL VALVE SPOOL
링크

30.087 PIN, VALVE CONTROL LEVER PIVOT
핀

30.089 LEVER, LIFT CONTROL
레버

30.090 LEVER, TILT CONTROL
레버

30.094 KNOB, LIFT CONTROL LEVER
노브

30.097 KNOB, TILT CONTROL LEVER
노브

30.102 BRACKET, HYDRAULIC VALVE SWITCH
브라켓

30.148 FASTENER, CONTROL LINKAGE BRACKET
패스너

30.787 BOOT, VALVE CONTROL LEVER
부트

30.817 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.843 LEVER, AUXILIARY VALVE CONTROL (1ST AUX)
레버

32.138 SWITCH, PUSH BUTTON
스위치

32.142 PLATE, SWITCH MOUNTING BRACKET
플레이트

49.024 FASTENER, HYDRAULIC VALVE MOUNTING BRACKET
패스너

49.042 CAP, TILT CONTROL LEVER
캡

49.071 DAMPENER, HYDRAULIC VALVE BRACKET
댐프너

49.081 CAP, LIFT CONTROL LEVER
캡

49.102 FASTENER, VALVE CONTROL LEVER PIVOT RETAINER
패스너

49.110 PIN, VALVE SPOOL CLEVIS ROD
핀

49.111 RETAINER, VALVE SPOOL CLEVIS ROD PIN
리테이너

49.124 CAP, AUXILIARY CONTROL LEVER
캡

49.210 FASTENER, HYDRAULIC VALVE MOUNTING
패스너


52.162 CONNECTOR, AUXILIARY VALVE LEVER WIRE
커넥터

52.171 LOCK, AUXILIARY VALVE LEVER WIRE
로크

91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너
97.161	FASTENER, HYDRAULIC VALVE BRACKET HINGE PIVOT 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (4SP00L)

30-612

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	30.787	BOOT, VALVE CONTROL LEVER 부트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.073	BRACKET, HYDRAULIC VALVE MOUNTING 브라켓	30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
30.080	PLUNGER, HYDRAULIC VALVE MOUNTING BRACKET 플런저	32.138	SWITCH, PUSH BUTTON 스위치
30.081	BEARING, HYDRAULIC VALVE BRACKET HINGE PIVOT 베어링	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.085	LINK, CONTROL VALVE SPOOL 링크	49.024	FASTENER, HYDRAULIC VALVE MOUNTING BRACKET 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.042	CAP, TILT CONTROL LEVER 캡
30.089	LEVER, LIFT CONTROL 레버	49.071	DAMPENER, HYDRAULIC VALVE BRACKET 댐퍼너
30.090	LEVER, TILT CONTROL 레버	49.081	CAP, LIFT CONTROL LEVER 캡
30.094	KNOB, LIFT CONTROL LEVER 노브	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.097	KNOB, TILT CONTROL LEVER 노브	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.148	FASTENER, CONTROL LINKAGE BRACKET 패스너	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너


52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
91.789	SPACER, HYDRAULIC VALVE MOUNTING FASTENER 스페이서
91.790	NUT, HYDRAULIC VALVE MOUNTING BRACKET FASTENER 너트
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
97.159	FASTENER, HYDRAULIC VALVE BRACKET DAMPENER 패스너
97.161	FASTENER, HYDRAULIC VALVE BRACKET HINGE PIVOT 패스너






- | | |
|--------|---|
| 30.000 | VALVE ASSEMBLY, HYDRAULIC
밸브 |
| 30.067 | RELIEF VALVE KIT, VALVE INLET SECTION
릴리프밸브 |
| 30.250 | SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
씰키트 |
| 30.435 | RELIEF VALVE ASSEMBLY, AUXILIARY VALVE
릴리프밸브 |
| 30.507 | SEAL KIT, HYDRAULIC VALVE (TILT)
씰키트 |
| 30.530 | FASTENER, VALVE THRU
패스너 |
| 30.714 | SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
씰키트 |
| 30.762 | END COVER, HYDRAULIC VALVE
엔드커버 |
| 33.230 | VALVE ASSEMBLY, LIFT SOLENOID
밸브 |

49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트



22.177	BODY, HYDRAULIC VALVE 바디
27.031	VALVE, SELECTOR SOLENOID VALVE COUNTER BALANCE 밸브
27.052	VALVE ASSEMBLY, AUXILIARY SOLENOID 밸브
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.074	CHECK VALVE ASSEMBLY, HYDRAULIC VALVE 체크밸브
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.481	COIL, HYDRAULIC VALVE SOLENOID 코일
30.508	PLUG, HYDRAULIC VALVE CHECK VALVE 플러그
30.572	COIL, HYDRAULIC VALVE LOWER SOLENOID 코일


30.605	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.757	PLUG, HYDRAULIC VALVE CHECK VALVE 플러그
33.099	VALVE, PROPORTIONAL 밸브
33.427	VALVE ASSEMBLY, DIRECTIONAL CONTROL SOLENOID 밸브
49.100	PLUG, MAIN HYDRAULIC VALVE 플러그
49.227	ORIFICE PLUG, HYDRAULIC VALVE MAIN CHECK VALVE 오리피스플러그
49.228	ORIFICE PLUG, HYDRAULIC VALVE CHECK VALVE 오리피스플러그
49.229	ORIFICE PLUG, HYDRAULIC VALVE CHECK VALVE 오리피스플러그
49.230	COMPENSATOR, HYDRAULIC VALVE 보상기
49.231	COMPENSATOR, HYDRAULIC VALVE 보상기
49.232	COMPENSATOR, HYDRAULIC VALVE VENT LOGIC VALVE 보상기
49.233	KNOB, HYDRAULIC VALVE SOLENOID COIL 노브
49.234	VALVE, HYDRAULIC VALVE LOAD SHUTTLE 밸브
49.235	VALVE, HYDRAULIC VALVE PROPORTIONAL 밸브
49.236	VALVE, HYDRAULIC VALVE PROPORTIONAL 밸브
49.505	PRESSURE REDUCING VALVE 감압밸브



22.177	BODY, HYDRAULIC VALVE 바디
27.031	VALVE, SELECTOR SOLENOID VALVE COUNTER BALANCE 밸브
27.052	VALVE ASSEMBLY, AUXILIARY SOLENOID 밸브
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.074	CHECK VALVE ASSEMBLY, HYDRAULIC VALVE 체크밸브
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.481	COIL, HYDRAULIC VALVE SOLENOID 코일
30.508	PLUG, HYDRAULIC VALVE CHECK VALVE 플러그
30.572	COIL, HYDRAULIC VALVE LOWER SOLENOID 코일

30.605	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.757	PLUG, HYDRAULIC VALVE CHECK VALVE 플러그
33.099	VALVE, PROPORTIONAL 밸브
33.427	VALVE ASSEMBLY, DIRECTIONAL CONTROL SOLENOID 밸브
49.100	PLUG, MAIN HYDRAULIC VALVE 플러그
49.227	ORIFICE PLUG, HYDRAULIC VALVE MAIN CHECK VALVE 오리피스플러그
49.228	ORIFICE PLUG, HYDRAULIC VALVE CHECK VALVE 오리피스플러그
49.229	ORIFICE PLUG, HYDRAULIC VALVE CHECK VALVE 오리피스플러그
49.230	COMPENSATOR, HYDRAULIC VALVE 보상기
49.231	COMPENSATOR, HYDRAULIC VALVE 보상기
49.232	COMPENSATOR, HYDRAULIC VALVE VENT LOGIC VALVE 보상기
49.233	KNOB, HYDRAULIC VALVE SOLENOID COIL 노브
49.234	VALVE, HYDRAULIC VALVE LOAD SHUTTLE 밸브
49.235	VALVE, HYDRAULIC VALVE PROPORTIONAL 밸브
49.236	VALVE, HYDRAULIC VALVE PROPORTIONAL 밸브
49.505	PRESSURE REDUCING VALVE 감압밸브

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE





HYDRAULIC SUPPLY LINES

31-357

- | | |
|--------|---|
| 27.009 | VALVE ASSEMBLY, HYDRAULIC PRIORITY
밸브 |
| 28.801 | SEAL, HYD PUMP OUTLET PORT FITTING
씰 |
| 29.607 | MANIFOLD, HYDRAULIC PUMP OUTLET LINE
매니폴드 |
| 30.952 | DUST CAP, PRESSURE GAUGE PORT FITTING
더스트캡 |
| 31.001 | LINE, SUMP OUTLET
라인 |
| 31.002 | CLAMP, SUMP OUTLET LINE
클램프 |
| 31.003 | LINE, PUMP INLET
라인 |
| 31.004 | CLAMP, PUMP INLET LINE
클램프 |
| 31.014 | FITTING, PUMP OUTLET
피팅 |

31.018	LINE, PUMP OUTLET 라인
31.019	LINE, VALVE INLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
31.947	FITTING, PRIORITY VALVE 피팅
46.200	PIPE ASSEMBLY, HYDRAULIC LINES 파이프
95.090	FASTENER, HYDRAULIC PRIORITY VALVE 패스너
97.096	FASTENER, HYDRAULIC PUMP OUTLET LINE MANIFOLD 패스너
97.297	FASTENER, HYDRAULIC LINES PIPE 패스너






HYDRAULIC LIFT & TILT LINES

31-358

31.030	LINE, VALVE TO LIFT CYLINDER 라인
31.061	FITTING, VALVE TILT PORT "A" 피팅
31.062	FITTING, VALVE TILT PORT "B" 피팅
31.072	LINE, RH TILT CYLINDER ROD PORT 라인
31.075	FITTING, RH TILT CYLINDER ROD PORT 피팅
31.077	FITTING, LH TILT CYLINDER ROD PORT 피팅
31.083	LINE, RH TILT CYLINDER ANCHOR PORT 라인
31.160	FITTING, LH TILT CYLINDER ANCHOR PORT 피팅
31.162	FITTING, RH TILT CYLINDER ANCHOR PORT 피팅

31.175	LINE, VALVE TILT PORT "B" 라인
31.182	LINE, VALVE TILT PORT "A" 라인
31.200	FITTING, MAIN VALVE LIFT PORT 피팅


ФОРКЛИФТ
www.forklift.ru



28.266	CLAMP, POWER STEERING SUMP RETURN LINE 클램프
28.498	LINE, SUMP RETURN 라인
28.506	LINE, SUMP RETURN 라인
28.891	FASTENER, PUMP TO MAIN VALVE LINE CLAMP 패스너
28.914	FITTING, VALVE SUMP RETURN PORT 피팅
31.054	LINE, LIFT CYLINDER VENT TO SUMP 라인
31.094	CLAMP, LIFT CYLINDER VENT TO SUMP LINE 클램프
31.120	LINE, SUMP RETURN (POWER STEERING) 라인
31.121	FITTING, POWER STEERING SUMP RETURN 피팅

31.163	CLAMP, SUMP RETURN LINE 클램프
31.195	LINE, MAIN VALVE TO SUMP RETURN 라인
31.196	CLAMP, MAIN VALVE TO SUMP LINE 클램프
31.847	CLAMP, SUMP RETURN LINE 클램프
46.150	PIPE ASSEMBLY, SUMP RETURN LINE 파이프
97.298	FASTENER, SUMP RETURN LINE PIPE 패스너
97.299	FASTENER, HYDRAULIC SUMP COVER 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




TILT AMOUNT GP

32-167

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




TILT CYLINDER MOUNTING

32-174

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.030	PIN, TILT CYLINDER TO UPRIGHT 핀
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링

32.053	BEARING, TILT CYLINDER ROD END 베어링
97.214	FASTENER, TILT CYLINDER TO FRAME PIN 패스너
97.224	FASTENER, TILT CYLINDER TO UPRIGHT PIN 패스너





TILT CYLINDER ASSEMBLY


32-175

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.010	PISTON, TILT CYLINDER 피스톤
32.014	SPACER, TILT CYLINDER PISTON 스페이서
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.026	SETSCREW, TILT CYLINDER GLAND NUT PLUG 세트스크류
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드& 피스톤

32.067	FASTENER, TILT CYL PISTON PAD COVER TO PISTON ROD 패스너
32.072	PACKING KIT, TILT CYLINDER 패킹키트




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




SOLENOID VALVE INSTALLATION

33-049

- 13.994 BODY, TILT SOLENOID VALVE SWITCH ACTUATOR
바디
- 27.048 CARTRIDGE, SOLENOID VALVE - DEVICE
카트리지
- 33.330 VALVE ASSEMBLY, CLAMP SOLENOID
밸브
- 33.333 COIL, CLAMP VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
셀키트




15.397	FUSE, SOLENOID VALVE 퓨즈
15.830	WIRING HARNESS, CLAMP SOLENOID VALVE 와이어하네스
33.330	VALVE ASSEMBLY, CLAMP SOLENOID 밸브
33.338	FASTENER, CLAMP SOLENOID VALVE 패스너
33.526	RELAY, CLAMP SOLENOID VALVE 릴레이
33.840	FITTING, CLAMP SOLENOID VALVE INLET PORT 피팅
33.842	FITTING, CLAMP SOLENOID VALVE OUTLET PORT 피팅
50.865	LINE, AUXILIARY VALVE B PORT 라인
50.866	LINE, AUXILIARY VALVE A PORT 라인



UPRIGHT MOUNTING

34-119


34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.039	FITTING-LUB, UPRIGHT TRUNNION 피팅
34.135	SHAFT, UPRIGHT TRUNNION 샤프트
66.522	BLOCK, UPRIGHT TRUNNION LUB LINE JUNCTION 블록
66.523	LINE, UPRIGHT TRUNNION LUBRICATION RH 라인
66.524	LINE, UPRIGHT TRUNNION LUBRICATION LH 라인
97.295	FASTENER, UPRIGHT TRUNNION SHAFT 패스너
97.296	FASTENER, UPRIGHT TRUNNION LUB LINE JUNCTION BLOCK 패스너




CARRIAGE ASSEMBLY

34-189

34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.316	ROLLER, CARRIAGE 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.321	FASTENER, CARRIAGE ROLLER SHAFT 패스너
34.333	SHIM, CARRIAGE ROLLER 심
34.340	CARRIAGE WELDED ASSEMBLY 캐리지용접물




34.998 FASTENER, LOAD SAFETY BACK REST
패스너



37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.585	KNOB, SEAT BACK REST CUSHION ADJUSTOR 노브
37.915	SUSPENSION COVER, SEAT SUSPENSION 서스펜션커버
37.918	SUSPENSION ASSEMBLY, SEAT 서스펜션
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션

39.721	CUSHION, SEAT BACK REST 쿠션
39.725	FASTENER, SEAT BACK REST CLIP TO FRAME 패스너
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.423	SPRING, SEAT SWITCH 스프링
47.424	GROMMET, SEAT SWITCH SPRING 그로멧
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
97.309	FASTENER, SEAT SWITCH SPRING 패스너

ASSEMBLY
COMPLETE — 39.689




BACK MIRROR

37-076

39.184 FASTENER, REAR VIEW MIRROR
패스너


39.689 MIRROR, REAR VIEW
미러



OVERHEAD GUARD MOUNTING

37-128

39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.395	BUMPER, FRAME COVERING HOOD SUPPORT 범퍼




SHEET METAL & HOOD MOUNTING

37-129

12.108	HINGE, BATTERY COVER 힌지	37.809	COVER, REAR LH 커버
12.109	FASTENER, BATTERY COVER HINGE 패스너	37.854	SEAL, FLOOR PLATE 씰
12.146	HANDLE, BATTERY COVER 핸들	37.858	SUPPORT, FLOOR PLATE 서포트
12.147	FASTENER, BATTERY COVER HANDLE 패스너	37.866	PLATE, FLOOR-LH 플레이트
12.170	BUMPER, BATTERY COVER 범퍼	37.867	PLATE, FLOOR-RH 플레이트
12.301	LATCH, BATTERY COVER 래치	37.902	MAT, FLOORPLATE 매트
12.302	FASTENER, BATTERY COVER LATCH 패스너	38.471	PAD, LH STEP NON-SKID 패드
12.453	PIVOT, BATTERY COVER HINGE 피봇	38.831	PLUG, FRAME CLOSURE 플러그
12.454	RETAINER, BATTERY COVER HINGE 리테이너	39.460	COVER ASSEMBLY, BATTERY 커버
15.790	WIRE, BATTERY STOPPER 와이어	39.556	COVER, VALVE LINKAGE ACCESS 커버
15.791	HOLDER, BATTERY 홀더	39.571	FASTENER, DASH COVER 패스너
15.792	SLEEVE, BATTERY STOOPER WIRE 슬리브	39.704	SPRING, HOOD PROP (OUTER) 스프링
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너	39.705	FASTENER, HOOD PROP 패스너
37.374	COVER, HYDRAULIC VALVE 커버	47.283	COVER, FRAME REAR 커버
37.808	COVER, REAR RH 커버	47.284	WEATHERSTRIP, FRAME REAR COVER 웨더스트립

47.290	COVER ASSEMBLY, DASH LH 커버
47.291	COVER ASSEMBLY, DASH RH 커버
47.294	WEATHERSTRIP, REAR HOOD 웨더스트립
47.297	WEATHERSTRIP, REAR HOOD 웨더스트립
47.384	COVER, DISCONNECT SWITCH 커버
47.394	BRACKET, FRAME REAR COVER MOUNTING 브라켓
91.489	FASTENER, FLOOR PLATE 패스너
93.671	FASTENER, HYDRAULIC VALVE COVER 패스너
94.765	FASTENER, PAD NON-SKID 패스너
96.089	FASTENER, FLOOR PLATE SUPPORT 패스너
97.162	FASTENER, SIDE COVER TO FRAME 패스너
97.211	FASTENER, DISCONNECT SWITCH COVER 패스너
97.229	FASTENER, FRAME REAR COVER 패스너
97.230	FASTENER, FRAME REAR COVER MOUNTING 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




ARMREST MOUNTING (ELH)

37-130

13.034	CLIP, VALVE SWITCH WIRING HARNESS 클립
37.392	SAFETY BELT ASSEMBLY 안전벨트
37.920	ARMREST RH, SEAT 암레스트
37.923	BRACKET, SEAT ARMREST RIGHT HAND 브라켓
94.547	FASTENER, SEAT SAFETY BELT MOUNTING BRACKET 패스너
96.403	FASTENER, SEAT ARMREST BRACKET 패스너
96.405	FASTENER, SEAT ARMREST BRACKET 패스너
97.256	FASTENER, VALVE SWITCH WIRING HARNESS CLIP 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



ARMREST MOUNTING (ELH)

37-131


13.034	CLIP, VALVE SWITCH WIRING HARNESS 클립
37.920	ARMREST RH, SEAT 암레스트
37.923	BRACKET, SEAT ARMREST RIGHT HAND 브라켓
96.403	FASTENER, SEAT ARMREST BRACKET 패스너
96.405	FASTENER, SEAT ARMREST BRACKET 패스너
97.256	FASTENER, VALVE SWITCH WIRING HARNESS CLIP 패스너



SEAT BELT MOUNTING


37-133

- | | |
|--------|--|
| 37.392 | SAFETY BELT ASSEMBLY
안전벨트 |
| 94.547 | FASTENER, SEAT SAFETY BELT MOUNTING BRACKET
패스너 |
| 94.780 | BUSHING, SEAT SAFETY BELT FASTENER
부싱 |




13.576	SWITCH, HORN 스위치
15.767	WIRE HARNESS, ELECTRONIC CONTROL UNIT 와이어하네스
17.929	LEVER ASSEMBLY, FORWARD & REVERSE 레버
32.138	SWITCH, PUSH BUTTON 스위치
37.920	ARMREST RH, SEAT 암레스트
47.275	COVER, SEAT ARMREST 커버
47.276	COVER, SEAT ARMREST BOTTOM 커버
47.421	PLATE, SEAT ARMREST ADJUSTOR 플레이트
47.429	PLUG, SEAT ARMREST ASSEMBLY SWITCH 플러그

47.430	KNOB, SEAT ARMREST ADJUSTOR 노브
47.431	PLUG, SEAT ARMREST ASSEMBLY SWITCH 플러그
60.900	FINGER TIP, MINI LEVER 핑거팁
60.903	FASTENER, FINGER TIP MOUNTING 패스너
60.927	CARD, ELECTRIC SIGNAL CONTROL 카드
60.928	BRACKET, ELECTRIC SIGNAL CONTROL CARD 브라켓
60.929	FASTENER, ELECTRIC SIGNAL CONTROL CARD 패스너
97.333	FASTENER, SEAT ARMREST ADJUSTOR KNOB 패스너
97.334	FASTENER, SEAT ARMREST BOTTOM COVER 패스너
97.335	FASTENER, SEAT ARMREST ADJUSTOR PLATE 패스너
97.336	FASTENER, SEAT ARMREST ADJUSTOR PLATE MOUNTING 패스너



ASSEMBLY
COMPLETE — 37.923

NOTE :
NON SERVICEABLE
ITEMS MARKED "N"




SEAT ARMREST ASSEMBLY

37-177

- | | |
|--------|--|
| 37.923 | BRACKET, SEAT ARMREST RIGHT HAND
브라켓 |
| 47.435 | PIN, SEAT ARMREST STAND ANGLE ADJUST
핀 |
| 47.436 | SPRING, SEAT ARMREST STAND ANGLE ADJUST PIN
스프링 |
| 47.437 | SUPPORT, SEAT ARMREST STAND
서포트 |
| 47.438 | KNOB, SEAT ARMREST STAND HEIGHT ADJUST
노브 |
| 47.439 | BLOCK, SEAT ARMREST STAND HEIGHT ADJUST
블록 |
| 47.440 | KNOB, SEAT ARMREST STAND ANGLE ADJUST
노브 |
| 47.441 | BUSH, SEAT ARMREST STAND SUPPORT
부시 |
| 97.350 | FASTENER, SEAT ARMREST STAND SUPPORT BUSH
패스너 |

97.351 FASTENER, SEAT ARMREST STAND HEIGHT ADJUST
패스너






MODEL DECALS & COUNTERWEIGHT MOUNTING

38-236


38.869	COUNTERWEIGHT 카운터웨이트
38.870	FASTENER, COUNTERWEIGHT (LOWER) 패스너
38.920	PIN, COUPLER 핀
38.921	PIN, COUPLER PIN CROSS 핀
38.928	RETAINER, COUPLER PIN 리테이너
40.014	DECAL, MODEL NAME 데칼



BATTERY STOPPER MOUNTING


38-240

12.437	SPACER, BATTERY STOP 스페이서
12.438	SPACER, BATTERY STOP 스페이서
12.455	SPACER, BATTERY STOP BOTTOM 스페이서
97.092	FASTENER, BATTERY STOP SPACER 패스너
97.307	FASTENER, BATTERY STOP BOTTOM SPACER 패스너




37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.531	BRACKET, SEAT SAFETY BELT MOUNTING 브라켓
37.720	COVER, OPERATOR SEAT LATERAL RESTRAINT 커버
37.743	COVER, SEAT SUPPORT LATCH 커버
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



SEAT MOUNTING


39-829


39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔




- | | |
|--------|---|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
안전벨트 |
| 37.915 | SUSPENSION COVER, SEAT SUSPENSION
서스펜션커버 |
| 37.918 | SUSPENSION ASSEMBLY, SEAT
서스펜션 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |
| 39.721 | CUSHION, SEAT BACK REST
쿠션 |

39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너





13.135	SWITCH, SEAT SAFETY 스위치	39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
14.084	HARNESS, SEAT SAFETY SWITCH 하네스	39.745	BUMPER, SEAT SUPPORT 범퍼
37.409	HANDLE, SEAT CUSHION TENSION ADJUSTOR LEVER 핸들	47.031	SWIVEL, SEAT 스위블
37.410	LEVER, SEAT CUSHION TENSION ADJUSTOR 레버	47.053	LUMBAR FLEXOLATOR 롬바
37.412	SPRING, SEAT SUSPENSION TENSION 스프링	47.055	SEAT FLEXOLATOR 시트
37.439	SAFETY BELT, SEAT 안전벨트	47.062	PAN, SUSPENSION 팬
37.531	BRACKET, SEAT SAFETY BELT MOUNTING 브라켓	47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTOR 노브
37.597	SHAFT, SEAT LOWER 샤프트	47.065	WEIGHT INDICATOR ASSEMBLY 웨이트인디케이터
37.613	PLUG, SEAT CUSHION MOUNTING PLATE 플러그	47.068	BAR, WEIGHT ADJUSTOR 바
37.720	COVER, OPERATOR SEAT LATERAL RESTRAINT 커버	47.106	SHOCK ABSORBER, SUSPENSION SEAT 쇼크업쇼버
37.918	SUSPENSION ASSEMBLY, SEAT 서스펜션	47.266	LINKAGE ASSY, SEAT FRAME 링크지
37.947	LAYARD, LITERATURE TRAY 랜야드	47.267	FRAME, SEAT BACK 프레임
39.719	SEAT ASSEMBLY 시트	47.268	DECAL, SEAT ADJUSTMENTS 데칼
39.720	CUSHION, SEAT 쿠션	94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
39.721	CUSHION, SEAT BACK REST 쿠션		




NOTE: All Trucks Do Not Use All Fluid Key Numbers

TRUCK FLUIDS

40-260

99.901	ENGINE OIL 엔진오일
99.902	TRANSMISSION FLUID 트랜스미션오일
99.903	DRIVE AXLE FLUID 드라이브액슬
99.904	HYDRAULIC SUMP OIL 유압섬프오일
99.905	BRAKE FLUID 브레이크오일
99.906	AXLE END FLUID 액슬엔드오일
99.907	ENGINE ANTIFREEZE 부동액




40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너
40.012	DECAL, CLARK LOGO-SMALL 데칼
40.024	PLATE, UNDERWRITERS LABEL 플레이트
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너
40.030	DECAL, CLARK VERTICAL 데칼
40.042	DECAL, POLARITY 데칼
40.062	DECAL, DRIVERS CAUTION 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼

40.076	DECAL, ELECTRIC TRUCK CAUTION 데칼
40.089	PLATE, SAFETY INSTRUCTION 플레이트
40.130	LEGEND, SAFETY 범례
40.131	LEGEND, SAFETY 범례
40.138	DECAL, SAFETY 데칼
40.173	DECAL, IMPORTANT 데칼
40.183	DECAL, BATTERY DISCONNECT WARNING 데칼
40.241	DECAL, BRAKE OIL SPEC 데칼
40.279	DECAL, STARTING PROCEDURE 데칼
40.309	DECAL, AC LOGO 데칼
40.318	DECAL, BATTERY LOCATION 데칼
40.321	DECAL, DISTILLED WATER 데칼
40.326	DECAL, EE MARKING 데칼
40.328	DECAL, WHEEL NUT WARNING 데칼
40.345	DECAL, VOLTAGE WARNING 데칼
40.351	DECAL, HOOD OPEN OPERATING INSTRUCTIONS 데칼
40.363	DECAL, NO STEP 데칼

SEAT SAFETY
WING KIT


37.970



SEAT WING KIT

47-000

- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 37.970 | KIT, SEAT SAFETY
키트 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-234

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.631	SPACER, DEVICE HOSE SHEAVE 스페이서

50.811	NUT, DEVICE HOSE FITTING 너트
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너







ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-263

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗

50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.561	BRACKET, DEVICE HOSE LOWER SHEAVE 브라켓
50.565	FASTENER, DEVICE HOSE LOWER SHEAVE MTG BRACKET 패스너
50.631	SPACER, DEVICE HOSE SHEAVE 스페이서
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너






50.006	SHEAVE, DEVICE HOSE UPPER шнёр
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING сальник
50.155	FASTENER, DEVICE HOSE CLIP защелка
50.156	CLIP, DEVICE HOSE защелка
50.200	COUPLING, DEVICE HOSE соединитель
50.215	TERMINAL BLOCK, DEVICE HOSE терминальный блок
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE опора
50.298	BRACKET, DEVICE HOSE TERMINAL кронштейн
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK защелка

50.382	ROLLER, DEVICE HOSE 롤러
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.631	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너






ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-272

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.561	BRACKET, DEVICE HOSE LOWER SHEAVE 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.565	FASTENER, DEVICE HOSE LOWER SHEAVE MTG BRACKET 패스너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.631	SPACER, DEVICE HOSE SHEAVE 스페이서
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.811	NUT, DEVICE HOSE FITTING 너트
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.156	CLIP, DEVICE HOSE 클립	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
50.200	COUPLING, DEVICE HOSE 커플링	59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	91.008	FASTENER, DEVICE JUNCTION BLOCK 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
50.382	ROLLER, DEVICE HOSE 롤러	93.798	SPACER, DEVICE HOSE JUNCTION BLOCK FASTENER 스페이서
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-273

50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.316	GUARD, DEVICE RH HOSE 가드
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.382	ROLLER, DEVICE HOSE 롤러
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.610	FASTENER, DEVICE HOSE GUARD 패스너

50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.072	GUARD, DEVICE HOSE 가드
59.077	FASTENER, DEVICE HOSE GUARD 패스너
59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너
97.769	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너






ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-277

50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.155	FASTENER, DEVICE HOSE CLIP 패스너
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.316	GUARD, DEVICE RH HOSE 가드
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너

50.382	ROLLER, DEVICE HOSE 롤러
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.610	FASTENER, DEVICE HOSE GUARD 패스너
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.072	GUARD, DEVICE HOSE 가드
59.077	FASTENER, DEVICE HOSE GUARD 패스너
59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
91.008	FASTENER, DEVICE JUNCTION BLOCK 패스너
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
93.798	SPACER, DEVICE HOSE JUNCTION BLOCK FASTENER 스페이서
97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-286

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.155	FASTENER, DEVICE HOSE CLIP 패스너
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너

50.382	ROLLER, DEVICE HOSE 롤러
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.631	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-287

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.382	ROLLER, DEVICE HOSE 롤러
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.561	BRACKET, DEVICE HOSE LOWER SHEAVE 브라켓
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.565	FASTENER, DEVICE HOSE LOWER SHEAVE MTG BRACKET 패스너
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.631	SPACER, DEVICE HOSE SHEAVE 스페이서
50.155	FASTENER, DEVICE HOSE CLIP 패스너	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.156	CLIP, DEVICE HOSE 클립	50.686	WIRE, DEVICE 와이어
50.157	FASTENER, DEVICE RH HOSE CLIP 패스너	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.159	CLIP, DEVICE HOSE RH 클립	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.200	COUPLING, DEVICE HOSE 커플링	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.811	NUT, DEVICE HOSE FITTING 너트
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.826	TERMINAL, DEVICE CABLE 터미널
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인


59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
91.008	FASTENER, DEVICE JUNCTION BLOCK 패스너
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
93.798	SPACER, DEVICE HOSE JUNCTION BLOCK FASTENER 스페이서
97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너



ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)


50-288


50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.155	FASTENER, DEVICE HOSE CLIP 패스너	50.811	NUT, DEVICE HOSE FITTING 너트
50.156	CLIP, DEVICE HOSE 클립	50.826	TERMINAL, DEVICE CABLE 터미널
50.200	COUPLING, DEVICE HOSE 커플링	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.382	ROLLER, DEVICE HOSE 롤러	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.610	FASTENER, DEVICE HOSE GUARD 패스너	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.686	WIRE, DEVICE 와이어	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터	97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터	97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너
50.714	LOCK, DEVICE CABLE CONNECTOR 로크		



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.631	SPACER, DEVICE HOSE SHEAVE 스페이서

50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너






ATTACHMENT HOSE & CABLE ADAPTATION

50-299

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗


50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.561	BRACKET, DEVICE HOSE LOWER SHEAVE 브라켓
50.565	FASTENER, DEVICE HOSE LOWER SHEAVE MTG BRACKET 패스너
50.631	SPACER, DEVICE HOSE SHEAVE 스페이서
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너


ATTACHMENT HOSE & CABLE ADAPTATION
50-374


50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.155	FASTENER, DEVICE HOSE CLIP 패스너	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.156	CLIP, DEVICE HOSE 클립	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.157	FASTENER, DEVICE RH HOSE CLIP 패스너	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.159	CLIP, DEVICE HOSE RH 클립	50.811	NUT, DEVICE HOSE FITTING 너트
50.200	COUPLING, DEVICE HOSE 커플링	50.826	TERMINAL, DEVICE CABLE 터미널
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.382	ROLLER, DEVICE HOSE 롤러	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.686	WIRE, DEVICE 와이어	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓

91.008	FASTENER, DEVICE JUNCTION BLOCK 패스너
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.001	FASTENER, DEVICE HOSE ROLLER BRACKET 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너





TRIPLE STAGE / HI - LO UPRIGHT




STANDARD UPRIGHT


HIGH TERMINATION FOR DEVICE HOSE ADAPTATION

50-375

- | | |
|--------|---|
| 59.134 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.135 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.136 | LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인 |
| 59.137 | LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인 |
| 59.138 | CLAMP, DEVICE LINE FOR HIGH TERMINATION
클램프 |
| 59.139 | CLAMP, DEVICE LINE FOR HIGH TERMINATION
클램프 |
| 59.143 | CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
캡 |
| 97.235 | FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION
패스너 |




50.686	WIRE, DEVICE 와이어
59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인



QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION

50-798


- | | |
|--------|---|
| 59.092 | QUICK DISCONNECT, DEVICE HOSE
퀵디스커넥트 |
| 59.131 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |
| 59.132 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |



14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디स्क넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT 피팅
59.132	FITTING, DEVICE LINE QUICK DISCONNECT 피팅





AUXILIARY VALVE LINES


50-822

50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인
50.427	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.428	LINE, 2ND AUXILIARY VALVE "B" PORT 라인
50.440	FITTING, 1ST AUXILIARY VALVE "A" PORT 피팅
50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅
59.096	LINE, 1ST AUXILIARY FUNCTION 라인

59.099


LINE, 2ND AUXILIARY FUNCTION
라인





40.343	DECAL, ATTACHMENT SAFETY 데칼
50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너


53.497	STRAP, DEVICE HOSE 스트랩
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서



- 53.020 CYLINDER ASSEMBLY, SIDE SHIFTER
실린더
- 54.222 PACKING KIT, SIDE SHIFTER CYLINDER
패킹키트

ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹키트
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT 볼


97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
 세트스크류


ФОРКЛИФТ
www.forklift.ru




- | | |
|--------|---|
| 53.020 | CYLINDER ASSEMBLY, SIDE SHIFTER
실린더 |
| 53.024 | ANCHOR, SIDE SHIFTER CYLINDER BASE
앵커 |
| 53.054 | GUIDE, FORK
가이드 |
| 53.069 | FASTENER, FORK CYLINDER ROD END
패스너 |
| 53.075 | BEARING, SIDE SHIFTER (LOWER)
베어링 |
| 53.083 | FASTENER, SIDE SHIFTER CYLINDER ANCHOR
패스너 |
| 53.180 | SPACER, SIDE SHIFTER BEARING
스페이서 |
| 53.600 | CYLINDER ASSEMBLY, INBOARD RH FORK
실린더 |
| 53.603 | CYLINDER ASSEMBLY, INBOARD LH FORK
실린더 |

54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크
54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
92.483	NIPPLE, LUBRICATION 니플
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너






- 34.350 FORK ASSEMBLY
포크
- 34.359 KIT, FORK STOP PIN (CAPTIVE)
키트




34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
66.502	CUSHION, LIFT CYLINDER 쿠션

96.274 WASHER, LIFT CYLINDER CHECK VALVE
 옥셔






66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서
66.444	GLAND, FINAL LIFT CYLINDER 그랜드



66.207	PISTON, FINAL LIFT CYLINDER 피스톤
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서
66.414	BEARING, FINAL LIFT CYLINDER GLAND CAP 베어링
66.444	GLAND, FINAL LIFT CYLINDER 그랜드

ASSEMBLY
COMPLETE — 34.000

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STANDARD UPRIGHT

66-273

28.230	CLAMP, LIFT CYLINDER VENT LINE 클램프	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
31.074	LINE, LIFT CYLINDER VENT 라인	34.400	CYLINDER ASSEMBLY, LIFT 실린더
31.076	LINE, LIFT CYLINDER VENT 라인	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.572	STRAP, VENT LINE TO LIFT CYLINDER 스트랩
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.592	FITTING, LIFT CYLINDER VENT LINE 피팅
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일	66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
34.013	ROLLER, UPRIGHT 롤러	66.167	SHIM, LIFT CYLINDER UPPER 심
34.014	SHIM, UPRIGHT ROLLER 심	66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	66.506	CLAMP, LIFT CYLINDER 클램프
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	66.507	TEE, LIFT CYLINDER LINE 티
34.084	SHEAVE, LIFT CHAIN 쉬브	91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
34.101	CHAIN, LIFT 체인	91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
34.107	ANCHOR, LIFT CHAIN 앵커	93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너	93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIF 패스너


94.054 FASTENER, LIFT CYLINDER (UPPER)
패스너

ФОРКЛИФТ
www.forklift.ru




28.230	CLAMP, LIFT CYLINDER VENT LINE 클램프	34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브	34.101	CHAIN, LIFT 체인
28.729	LINE, LIFT CYLINDER 라인	34.102	FASTENER, SHEAVE CARRIER 패스너
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.107	ANCHOR, LIFT CHAIN 앵커
31.074	LINE, LIFT CYLINDER VENT 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
31.076	LINE, LIFT CYLINDER VENT 라인	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.181	FASTENER, LIFT CYLINDER PISTON ROD 패스너
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃터레일	34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.013	ROLLER, UPRIGHT 롤러	34.271	FASTENER, LIFT CYLINDER LOWER 패스너
34.014	SHIM, UPRIGHT ROLLER 심	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	34.567	LINE, LIFT CYLINDER VENT 라인
34.084	SHEAVE, LIFT CHAIN 쉬브	34.569	LINE, LIFT CYLINDER VENT 라인

34.572	STRAP, VENT LINE TO LIFT CYLINDER 스트랩
34.592	FITTING, LIFT CYLINDER VENT LINE 피팅
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.160	BRACKET, LIFT CYLINDER HOSE SHEAVE 브라켓
66.167	SHIM, LIFT CYLINDER UPPER 삼
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
66.251	SPACER, LIFT CYLINDER LINE SHEAVE 스페이서
66.304	FASTENER, LIFT CYLINDER LINE CLAMP 패스너
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.432	COVER, SHEAVE CARRIER 커버
66.506	CLAMP, LIFT CYLINDER 클램프
66.507	TEE, LIFT CYLINDER LINE 티
66.509	CLAMP, LIFT CYLINDER LINE 클램프
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIF 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.658	FASTENER, LIFT CYLINDER HOSE SHEAVE BRACKET 패스너
95.199	FASTENER, LIFT LINE SHEAVE 패스너
95.522	FASTENER, LIFT CYLINDER LINE 패스너




28.729	LINE, LIFT CYLINDER 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.181	FASTENER, LIFT CYLINDER PISTON ROD 패스너
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.271	FASTENER, LIFT CYLINDER LOWER 패스너
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃더레일	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.013	ROLLER, UPRIGHT 롤러	34.567	LINE, LIFT CYLINDER VENT 라인
34.014	SHIM, UPRIGHT ROLLER 심	34.569	LINE, LIFT CYLINDER VENT 라인
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	34.592	FITTING, LIFT CYLINDER VENT LINE 피팅
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
34.084	SHEAVE, LIFT CHAIN 쉬브	66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어	66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
34.101	CHAIN, LIFT 체인	66.167	SHIM, LIFT CYLINDER UPPER 심
34.102	FASTENER, SHEAVE CARRIER 패스너	66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
34.107	ANCHOR, LIFT CHAIN 앵커	66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브


66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.432	COVER, SHEAVE CARRIER 커버
66.471	LINE, LIFT CYLINDER FEED 라인
66.507	TEE, LIFT CYLINDER LINE 티
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIF 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
95.522	FASTENER, LIFT CYLINDER LINE 패스너



- | | |
|--------|---|
| 34.704 | EXTENSION, FORK ASSEMBLY COMPLETE
익스텐션 |
| 66.465 | PIN, EXTENSION FORK
핀 |
| 66.466 | PIN, EXTENSION FORK
핀 |



39.706	SUPPORT, SEAT 서포트
39.719	SEAT ASSEMBLY 시트
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트



SEAT OPERATED BRAKE SWITCH INSTALLATION

75-013

- | | |
|--------|---|
| 15.689 | FASTENER, SEAT SWITCH HARNESS RETAINER
패스너 |
| 18.087 | CLIP, SEAT SAFETY SWITCH WIRE
클립 |
| 37.973 | GROMMET, SEAT WIRING HARNESS
그로멧 |
| 40.306 | DECAL, SEAT SWITCH
데칼 |