


부품 매뉴얼 PARTS MANUAL

C 15/18/20s L

SERIAL NUMBER : P152L - XXXX - 9830 CNF (HMC, Tier4)

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Publication Date : Dec. 2013




(본사) 경기도 부천시 오정구 오정동 202-1
(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea
(공장) 경남 창원시 웅남동 40-1
(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea




00-535	ENGINE MOUNTING 엔진 마운팅	13-183	STROBE LIGHT MOUNTING 경광등 마운팅
00-688	ENGINE GASKET KIT 엔진 가스켓 키트	13-228	BACK-UP ALARM INSTALLATION 백업 알람 조립그룹
00-690	CYLINDER HEAD & COVERS 실린더 헤드& 커버	13-236	COMBINATION & REAR WORK LIGHT INSTALLATION 컴비네이션& 후방 작업등 조립그룹
00-691	CRANKCASE 크랭크케이스	13-338	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드& 턴시그널 라이트 조립그룹
01-338	COOLING SYSTEM 쿨링 시스템	13-342	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드& 턴시그널 라이트 조립그룹
01-349	COOLING WATER SYSTEM 쿨링 워터 시스템	14-412	ELECTRICAL WIRING (MAIN) 전기장치 와이어링 (메인)
02-154	NON PRE-CLEANER GP 논-프리 크리너 그룹	14-428	ELECTRICAL WIRING (INSTRUMENT) 전기장치 와이어링 (계기판)
02-474	AIR CLEANER ASSEMBLY 에어 크리너 어셈블리	14-438	STATIC STRAP 스태틱 스트랩
02-478	INDICATOR LIGHT INSTALLATION 지시등 조립그룹	15-074	DELAY TIMER MOUNTING 타임 딜레이 마운팅
02-493	ACCELERATOR SYSTEM 악셀레이터 시스템	22-009	BRAKE ASSEMBLY LH 브레이크 어셈블리 - 좌
03-184	LPG TANK MOUNTING LPG 탱크 마운팅	22-010	BRAKE ASSEMBLY RH 브레이크 어셈블리 - 우
03-350	FUEL LOCK-OFF VALVE 연료 잠금 밸브	22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브휠& 타이어 마운팅
03-360	FUEL SYSTEM (LPG) 연료시스템 (LPG)	22-014	STEER WHEEL & TIRE MOUNTING 스티어휠& 타이어 마운팅
03-558	SWING DOWN BRACKET ASSEMBLY 스윙 다운 브라켓 어셈블리	22-024	DRIVE WHEEL & TIRE (SOLID TYPE) 드라이브 휠& 타이어 (솔리드 타입)
03-559	SWING DOWN BRACKET ASSEMBLY 스윙 다운 브라켓 어셈블리	22-025	STEER WHEEL & TIRE (SOLID TYPE) 스티어 휠& 타이어 (솔리드 타입)
03-581	SWITCH INSTALLATION 스위치 조립그룹	22-041	DRIVE WHEEL AND TIRE 드라이브 휠& 타이어
03-599	INTAKE & EXHAUST MANIFOLD 흡기& 배기 기관	22-042	STEER WHEEL & TIRE 스티어링 휠& 타이어
03-604	FUEL SYSTEM 연료 시스템	23-214	INCHING MASTER CYLINDER 인칭 마스터 실린더
03-605	FUEL LINES 연료 라인	23-242	BRAKE MASTER CYLINDER 브레이크 마스터 실린더
03-611	EXHAUST SYSTEM 배기 시스템	23-390	BRAKE & INCHING LINES 브레이크& 인칭라인
03-641	SWING DOWN LPG TANK MTG 스윙 다운 LPG 탱크 마운팅	23-392	BRAKE LINES 브레이크 라인
03-683	INTAKE & EXHAUST MANIFOLD 흡기& 배기 기관	23-545	PARKING BRAKE LINKAGE 파킹 브레이크 링크이지
03-684	FUEL LINES 연료 라인	25-050	STEER COLUMN & GEAR MOUNTING 스티어 컬럼& 기어 마운팅
03-698	INTAKE SYSTEM 흡기 시스템 (듀얼)	25-076	STEERING UNIT 스티어링 유닛
05-043	TRANSMISSION PUMP & HYDRAULICS 트랜스미션 펌프& 유압	25-144	STEERING COLUMN ASSEMBLY 스티어링 컬럼 어셈블리
05-044	DIFFERENTIAL & DRIVE AXLE 디퍼렌셜& 드라이브 액슬	25-250	STEERING WHEEL MOUNTING 스티어링 휠 마운팅
06-113	TRANSMISSION CLUTCH PACK 트랜스미션 클러치 팩	26-030	HYDRAULIC RETURN LINES 유압 리턴 라인
06-114	CONTROL VALVE ASSEMBLY 컨트롤 밸브 어셈블리	26-219	STEER AXLE MOUNTING 스티어링 액슬 마운팅
07-076	TRANSAXLE MOUNTING 트랜스액슬 마운팅	26-255	STEERING AXLE 스티어링 액슬
10-129	TRANS COOLING LINES 트랜스미션 쿨링 라인	26-256	STEERING CYLINDER 스티어링 실린더
11-110	ELECTRICAL CONTROL 전기장치 컨트롤	26-309	HYDRAULIC STEERING LINES 유압 스티어링 라인
12-193	ALTERNATOR ASSEMBLY 알터네이터 어셈블리	29-140	HYDRAULIC SUMP FILTER 유압 쉘프 필터
12-200	BATTERY MOUNTING 배터리 마운팅	29-230	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
13-033	KEY & DIRECTIONAL SWITCH INSTALLATION 키& 방향스위치 조립그룹	29-252	HYDRAULIC SUMP 유압 쉘프
13-162	STROBE LIGHT MOUNTING 경광등 마운팅	30-206	MAIN CONTROL VALVE 2-SPOOL 메인 컨트롤 밸브 - 2 스톨
13-182	STROBE LIGHT 경광등	30-207	MAIN CONTROL VALVE 3-SPOOL 메인 컨트롤 밸브 - 3 스톨

30-208	MAIN CONTROL VALVE 4-SPOOL 메인 컨트롤 밸브 - 4 스푼	39-969	POD INSTALLATION 패드 조립 그룹
30-209	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)	39-976	CAB MOUNTING 캐빈 마운팅
30-210	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)	39-977	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅
30-211	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)	39-978	HOOD MOUNTING 후드 마운팅
31-128	HYDRAULIC LIFT & TILT LINES 유압 리프트& 틸트 라인	39-983	SHEET METAL & TRIM 시트 메탈& 트림
31-130	TILT LIMIT WITH OVERRIDE 틸트 제어해제	40-069	DECALS 데칼
31-323	HYDRAULIC SUPPLY LINES 유압 공급 라인	40-285	MODEL & SPECIFICATION DECALS 모델& 사양 데칼
32-124	TILT CYLINDER 틸트 실린더	41-008	STORAGE CONSOLE 저장 콘솔
32-147	TILT CYLINDER MOUNTING 틸트 실린더 마운팅	41-038	HEATER INSTALLATION 히터 조립 그룹
32-167	TILT AMOUNT GROUP 틸트 어마운트 그룹	47-000	SEAT WING KIT 시트윙 키트
32-850	ACCUMULATOR 어큐뮬레이터	47-005	REAR HAND GRIP MOUNTING 리어 핸드 그립 마운팅
33-020	FLOW CONTROL VALVE 플로우 컨트롤 밸브	50-780	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
33-069	RELIEF VALVE ASSEMBLY 릴리프 밸브 어셈블리	50-781	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
33-130	SELECTOR SOLENOID VALVE 셀렉터 솔레노이드 밸브	50-782	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
34-044	LOAD BACK REST MOUNTING 로드 백 레스트 마운팅	50-783	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
34-050	UPRIGHT MOUNTING 마스트 마운팅	50-784	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
34-109	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-785	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적응 (마스트)
37-003	OVERHEAD GUARD COVER 오버헤드가드 커버	50-786	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
37-029	COWL MOUNTING 카울 마운팅	50-787	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
37-050	REAR WIPER INSTALLATION 리어 와이퍼 조립 그룹	50-791	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
37-054	CAB DOOR SASH ASSEMBLY 캐빈 도어 어셈블리	50-794	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
37-056	ENCLOSED CAB 캐빈 (박스형)	50-796	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
37-076	BACK MIRROR 백미러	50-798	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)
37-083	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅	50-799	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
37-124	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	50-800	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
38-247	COUNTERWEIGHT MOUNTING 카운터웨이트 조립 그룹	50-807	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적응)
38-270	FRAME TANK BOTTOM PLUG 프레임 탱크 하단 플러그	50-818	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
39-012	LEAD WIRE GROUND 접지선	50-819	DEVICE LINE ADAPTORS 디바이스 라인 어댑터
39-235	ELECTRICAL COMPONENTS (CAB) 전기장치 구성품 (캐빈)	53-187	SIDE SHIFT ASSEMBLY 사이드 쉬프트 어셈블리
39-519	LOAD BACK REST 로드 백 레스트	53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더
39-626	ENCLOSED CAB 캐빈 (박스형)	54-015	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
39-661	SEAT ASSEMBLY 시트 어셈블리	66-058	FORK 포크
39-674	FLOOR PLATE MOUNTING 플로어 플레이트 마운팅	66-060	LIFT CYLINDER PIPING 리프트 실린더 파이핑
39-829	SEAT MOUNTING 시트 마운팅	66-062	LIFT CYLINDER PIPING 리프트 실린더 파이핑
39-831	ENCLOSED CAB 캐빈 (박스형)	66-065	LIFT CYLINDER PIPING 리프트 실린더 파이핑
39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리	66-072	STANDARD UPRIGHT 표준 마스트

66-073	LIFT CHAIN 리프트 체인
66-076	LIFT CHAIN 리프트 체인
66-078	PRIMARY CYLINDER 프라이머리 실린더
66-082	HI-LO UPRIGHT 하이-로우 마스트
66-083	HI-LO SECONDARY CYLINDER 하이-로우 2차 실린더
66-157	LIFT CYLINDER ASSEMBLY 리프트 실린더 어셈블리
66-158	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-240	TRIPLE STAGE UPRIGHT 3단 마스트
66-245	EXTENTION FORK 익스텐션 포크
66-335	LIFT CHAIN 리프트 체인
75-(30)264	AUXILIARY VALVE LINES 보조 밸브 라인
75-(30)266	AUXILIARY VALVE LINES 보조 밸브 라인
75-(33)014	VARIABLE RELIEF VALVE INSTALLATION 가변 릴리프 밸브 조립그룹
75-(33)045	DEVICE HYDRAULIC PRESSURE GAUGE INSTALLATION 디바이스 유압 압력게이지 조립그룹
75-001	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치
75-004	SEAT OPERATED BRAKE 시트 조작 브레이크
75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치






00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.047	DAMPENER, ENGINE FRONT VIBRATION 댐퍼너
00.055	FASTENER, ENGINE FRONT VIBRATION DAMPENER 패스너
00.056	MOUNT, ENGINE RH 마운트
00.071	MOUNT, ENGINE LH 마운트
00.352	ADAPTOR, FLYWHEEL MOUNTING 어댑터
00.871	FASTENER, FLYWHEEL HOUSING 패스너
01.195	BELT, FAN 벨트
01.467	FITTING, ENGINE OIL FILTER ADAPTOR PORT 피팅


40.331	DECAL, CLARK LOGO (ENGINE) 데칼
94.705	FASTENER, ENGINE MOUNTING BRACKET 패스너
95.471	FASTENER, ENGINE MOUNT 패스너
95.472	FASTENER, ENGINE MOUNT 패스너






00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓키트
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓키트
00.427	SEAL, CRANKCASE REAR OIL 씰
00.547	SEAL, ENGINE FRONT GEAR COVER 씰
00.604	GASKET, CRANKCASE HEAD 가스켓
00.664	GASKET, ROCKER ARM COVER 가스켓
00.703	SEAT, INTAKE VALVE SPRING 시트
00.705	SEAT, EXHAUST VALVE SPRING 시트


01.018	SEAL, OIL LEVEL DIPSTICK ADAPTOR 씰
01.100	GASKET, CRANKCASE OIL PAN DRAIN PLUG 가스켓
01.286	GASKET, OIL FILLER CAP 가스켓
01.322	GASKET, ENGINE OIL FILTER ADAPTOR 가스켓
01.441	GASKET, ENGINE WATER PUMP ATTACHING 가스켓
01.481	GASKET, ENGINE WATER PUMP BODY 가스켓
01.751	SEAL, OIL PAN DIPSTICK HOLE PLUG 씰
02.928	GASKET, EXHAUST MANIFOLD 가스켓
02.929	GASKET, INTAKE MANIFOLD 가스켓
62.201	GASKET, ENGINE WATER TEMPERATURE CONTROL 가스켓






00.000	PRODUCTION ENGINE ASSEMBLY 엔진	00.464	BRACKET, ENGINE LIFTING 브라켓
00.063	PLUG, CRANKCASE HEAD 플러그	00.466	BRACKET, ENGINE LIFTING 브라켓
00.064	SEAL, CAMSHAFT OIL 씰	00.600	HEAD ASSEMBLY, CRANKCASE 헤드
00.069	FASTENER, ENGINE LIFTING BRACKET 패스너	00.604	GASKET, CRANKCASE HEAD 가스켓
00.070	FASTENER, ENGINE LIFTING BRACKET 패스너	00.606	FASTENER, CRANKCASE HEAD 패스너
00.072	COVER, CRANKCASE HEAD END 커버	00.607	FASTENER, CRANKCASE HEAD 패스너
00.074	FASTENER, CRANKCASE HEAD END COVER 패스너	00.608	FASTENER, CRANKCASE HEAD 패스너
00.075	FASTENER, CRANKCASE HEAD END COVER 패스너	00.609	FASTENER, CRANKCASE HEAD 패스너
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓키트	00.610	HEAD, CRANKCASE 헤드
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓키트	00.611	FASTENER, CRANKCASE HEAD 패스너
00.151	PLUG, CRANKCASE HEAD REAR 플러그	00.646	FASTENER, ENGINE ROCKER ARM PIVOT SUPPORT 패스너
00.247	TENSIONER, CAMSHAFT TIMING BELT 텐서너	00.650	CAMSHAFT 캠샤프트
00.248	GUIDE, CAMSHAFT TIMING BELT TENSIONER 가이드	00.663	COVER, ROCKER ARM 커버
00.256	FASTENER, CAMSHAFT TIMING GEAR 패스너	00.664	GASKET, ROCKER ARM COVER 가스켓
00.345	BUSHING, CRANKCASE HEAD 부싱	00.665	FASTENER, ROCKER ARM COVER 패스너

00.677	GEAR, CAMSHAFT TIMING 기어
00.683	SEAT, EXHAUST VALVE INSERT 시트
00.684	SEAT, INTAKE VALVE INSERT 시트
00.685	VALVE, EXHAUST 밸브
00.688	VALVE, INTAKE 밸브
00.689	RETAINER, ENGINE VALVE SEAL 리테이너
00.691	SPRING, ENGINE INTAKE VALVE 스프링
00.692	SPRING, ENGINE EXHAUST VALVE 스프링
00.693	GUIDE, INTAKE VALVE 가이드
00.694	GUIDE, EXHAUST VALVE 가이드
00.698	LOCK, EXHAUST VALVE SPRING SEAT 로크
00.700	LOCK, INTAKE VALVE SPRING SEAT 로크
00.703	SEAT, INTAKE VALVE SPRING 시트
00.705	SEAT, EXHAUST VALVE SPRING 시트
00.707	LIFTER, ENGINE VALVE 리프터
00.728	CHAIN, CAMSHAFT TIMING 체인
00.752	RETAINER, CRANKCASE HEAD COMBUSTION CHAMBER INSE 리테이너
00.769	TENSIONER, CAMSHAFT TIMING CHAIN 텐셔너
00.793	BUSHING, ENGINE LOCKER ARM PIVOT SUPPORT 부싱
00.809	SLEEVE, CRANKCASE VENT TUBE VALVE 슬리브
01.283	CAP, CRANKCASE OIL FILLER 캡
01.286	GASKET, OIL FILLER CAP 가스켓
01.791	CHAIN, OIL PUMP DRIVE 체인
02.381	VALVE, PCV 밸브
62.177	CAMSHAFT, EXHAUST 캠샤프트
62.178	GUIDE, ENGINE OIL PUMP CHAIN 가이드
62.179	FASTENER, ENGINE OIL PUMP CHAIN TENSION 패스너
62.180	TENSIONER, ENGINE OIL PUMP CHAIN 텐셔너
62.200	GEAR, CAMSHAFT TIMING 기어
91.073	LOCKWASHER, CRANKCASE HEAD FASTENER 로크와셔
94.071	FASTENER, ROCKER ARM PIVOT SUPPORT 패스너
94.978	FASTENER, CAMSHAFT TIMING BELT TENSIONER 패스너
95.478	FASTENER, ENGINE BALANCER WEIGHT DRIVE CHAIN GUI 패스너
95.481	FASTENER, ENGINE BALANCER WEIGHT DRIVE CHAIN GUI 패스너




00.000	PRODUCTION ENGINE ASSEMBLY 엔진	00.351	PLATE, FLYWHEEL REINFORCING 플레이트
00.010	SHORT ENGINE ASSEMBLY 숏엔진	00.353	PLATE, CRANKSHAFT THRUST 플레이트
00.011	CRANKCASE 크랭크케이스	00.360	BEARING, NO. 1 MAIN JOURNAL 베어링
00.020	COVER, CRANKCASE ACCESS HOLE 커버	00.361	BEARING, NO. 2 MAIN JOURNAL 베어링
00.043	BUSHING, ENGINE REAR SUPPORT BRACKET 부싱	00.362	BEARING, NO. 3 MAIN JOURNAL 베어링
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓키트	00.363	BEARING, NO. 4 MAIN JOURNAL 베어링
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓키트	00.364	BEARING, NO. 5 MAIN JOURNAL 베어링
00.149	PLUG - EXPANSION, CRANKCASE SIDE 플러그	00.380	PULLEY, CRANKSHAFT 풀리
00.200	FASTENER, CRANKSHAFT BEARING NO. 1 CAP 패스너	00.390	WASHER, CRANKSHAFT PULLEY 와셔
00.237	GUIDE, CRANKSHAFT TIMING SPROCKET 가이드	00.395	FASTENER, CRANKSHAFT PULLEY 패스너
00.260	BEARING, CONNECTING ROD (CYL. #1) 베어링	00.405	KEY, CRANKSHAFT TIMING GEAR 키
00.261	BEARING, CONNECTING ROD (CYL. #2) 베어링	00.427	SEAL, CRANKCASE REAR OIL 씰
00.262	BEARING, CONNECTING ROD (CYL. #3) 베어링	00.450	FLYWHEEL 플라이휠
00.263	BEARING, CONNECTING ROD (CYL. #4) 베어링	00.453	GEAR, FLYWHEEL RING 기어
00.350	CRANKSHAFT 크랭크샤프트	00.456	FASTENER, CRANKSHAFT TO FLYWHEEL 패스너

00.461	DOWEL, CRANKCASE HEAD 다웰	01.700	OIL PUMP ASSEMBLY 오일펌프
00.463	DOWEL, CRANKSHAFT 다웰	01.702	FASTENER, OIL PUMP 패스너
00.482	PLATE, GEAR COVER BACKING 플레이트	01.751	SEAL, OIL PAN DIPSTICK HOLE PLUG 씰
00.501	SPACER, FLYWHEEL RING GEAR 스페이서	01.851	STUD, OIL PAN 스터드
00.530	COVER, ENGINE FRONT GEAR 커버	01.868	FASTENER, CRANKSHAFT PULLEY 패스너
00.547	SEAL, ENGINE FRONT GEAR COVER 씰	62.174	OIL JET, ENGINE OIL PUMP CHAIN 오일젯
00.564	FASTENER, ENGINE FRONT GEAR COVER 패스너	62.175	FASTENER, ENGINE OIL JET 패스너
00.566	FASTENER, ENGINE FRONT GEAR COVER 패스너	62.181	BUSHING, ENGINE KNOCK 부싱
00.567	FASTENER, ENGINE FRONT GEAR COVER 패스너	62.184	PULLEY, ENGINE CRANKSHAFT DAMPER 풀리
00.579	PLUG, ENGINE FRONT GEAR COVER 플러그	62.260	PLUG, ENGINE FRONT GEAR COVER NIPPLE 플러그
00.628	PLUG, CRANKCASE HEAD 플러그	95.969	FASTENER, ENGINE OIL LEVEL CONTROL 패스너
00.668	PLUG, CRANKCASE WATER 플러그		
00.760	ROD ASSEMBLY, CONNECTING 로드		
00.767	FASTENER, CONNECTING ROD BEARING CAP 패스너		
00.803	PISTON (ONE CYLINDER) 피스톤& 핀		
00.805	PIN, PISTON 핀		
00.820	PISTON RING 피스톤링		
00.845	HOUSING, FLYWHEEL 하우징		
00.861	FASTENER, FLYWHEEL HOUSING TO CRANKCASE 패스너		
00.862	FASTENER, FLYWHEEL HOUSING TO CRANKCASE 패스너		
00.863	FASTENER, FLYWHEEL HOUSING TO CRANKCASE 패스너		
01.018	SEAL, OIL LEVEL DIPSTICK ADAPTOR 씰		
01.075	PAN, CRANKCASE OIL 팬		
01.079	FASTENER, CRANKCASE OIL PAN 패스너		
01.099	PLUG, CRANKCASE OIL PAN DRAIN 플러그		
01.100	GASKET, CRANKCASE OIL PAN DRAIN PLUG 가스켓		
01.125	DIPSTICK, CRANKCASE OIL LEVEL 딤스틱		
01.188	PAN, CRANKCASE OIL UPPER 팬		
01.189	PIN, ENGINE OIL PAN 핀		
01.191	PIN, ENGINE OIL PAN 핀		
01.295	FASTENER, ENGINE OIL FILTER ATTACHING 패스너		
01.307	CARTRIDGE & GASKET, ENGINE OIL FILTER 카트리지와 가스켓		
01.322	GASKET, ENGINE OIL FILTER ADAPTOR 가스켓		
01.353	FITTING, BLOCK TO OIL FILTER 피팅		
01.494	TUBE, OIL LEVEL DIPSTICK ADAPTOR 튜브		
01.511	ADAPTOR, ENGINE OIL FILTER 어댑터		




01.151	GUARD, RADIATOR FAN 가드
01.193	ISOLATOR, RADIATOR MOUNTING 절연체
01.194	ISOLATOR, RADIATOR MOUNTING 절연체
01.381	BLADE, FAN 블레이드
01.416	SPACER, FAN BLADE 스페이서
01.465	FASTENER, FAN BLADE SPACER 패스너
01.520	COMPENSATION TANK, COOLING SYSTEM 보상기
01.521	COVER, COMPENSATION TANK 커버
01.523	LINE, COOLING SYSTEM COMPENSATION TANK 라인

01.529	CLAMP, RADIATOR OVERFLOW LINE 클램프
01.530	LINE, RADIATOR FILLER 라인
01.537	PAD, RADIATOR MOUNTING LOWER 패드
01.547	DRAIN COCK, RADIATOR 드레인콕
01.550	RADIATOR 라디에이터
01.555	LINE, RADIATOR OVERFLOW 라인
01.559	FASTENER, RADIATOR UPPER SUPPORT (RADIATOR END) 패스너
01.563	FASTENER, RADIATOR MOUNTING BRACKET 패스너
01.565	SPACER, RADIATOR MOUNTING 스페이서
01.570	CAP, RADIATOR 캡
01.577	HOSE, RADIATOR UPPER 호스
01.579	CLAMP, RADIATOR UPPER HOSE 클램프
01.600	HOSE, RADIATOR LOWER 호스
01.601	CLAMP, RADIATOR LOWER HOSE 클램프
01.640	FASTENER, RADIATOR SHROUD EXTENTION 패스너
01.660	SHROUD, RADIATOR 슈라우드
90.424	WASHER, RADIATOR MOUNTING FASTENER 와셔



00.000	PRODUCTION ENGINE ASSEMBLY 엔진	01.481	GASKET, ENGINE WATER PUMP BODY 가스켓
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓키트	01.504	PIPE, ENGINE WATER PUMP INLET 파이프
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓키트	01.532	FASTENER, ENG THERMOSTAT BY-PASS FITTING 패스너
01.187	ENGINE WATER PUMP SET 엔진워터펌프세트	01.543	LINE, ENGINE THERMO BY PASS 라인
01.219	FITTING, WATER PUMP INLET 피팅	01.585	FASTENER, WATER OUTLET ELBOW-REAR 패스너
01.399	BRACKET, FAN MOUNTING 브라켓	01.587	FASTENER, WATER INLET COVER 패스너
01.410	FASTENER, IDLER ADJUSTMENT 패스너	01.588	FASTENER, WATER OUTLET ELBOW 패스너
01.417	PULLEY, FAN 풀리	01.589	GASKET, WATER OUTLET ELBOW 가스켓
01.418	BELT, WATER PUMP 벨트	01.594	GASKET, ENGINE THERMOSTAT HOUSING ATT 가스켓
01.430	PUMP ASSEMBLY, ENGINE WATER 펌프	01.596	THERMOSTAT, ENGINE 서모스탯
01.432	PULLEY, WATER PUMP 풀리	01.666	FASTENER, WATER PUMP PULLEY 패스너
01.434	COVER, WATER PUMP 커버	01.860	FASTENER, FAN DRIVE HUB MOUNTING SHAFT 패스너
01.438	FASTENER, WATER PUMP 패스너	01.872	IDLER, V-BELT 아이들러
01.439	FASTENER, WATER PUMP 패스너	12.100	BRACKET, ALTERNATOR MOUNTING 브라켓
01.441	GASKET, ENGINE WATER PUMP ATTACHING 가스켓	12.103	FASTENER, ALTERNATOR TO BRACKET 패스너

12.182	PULLEY, ALTERNATOR TENSIONER 풀리
62.167	BRACKET, ENGINE TENTION PULLEY 브라켓
62.168	CONTROL ASSEMBLY, ENGINE WATER TEMPERATURE 컨트롤
62.201	GASKET, ENGINE WATER TEMPERATURE CONTROL 가스켓
62.202	FASTENER, ENGINE WATER TEMPERATURE CONTROL 패스너
62.203	FASTENER, ENGINE WATER TEMPERATURE CONTROL 패스너
62.243	SENSOR, ENGINE COOLANT TEMPERTURE (ECU) 센서
94.100	FASTENER, WATER PUMP DISCHARGE FLANGE 패스너
96.577	FASTENER, FAN MOUNTING BRACKET 패스너




NON PRE-CLEANER GP

02-154

- | | |
|--------|---|
| 02.422 | SCREEN, ENGINE INTAKE AIR
스크린 |
| 03.567 | PLUG, AIR INTAKE DRIVER OVERHEAD GUARD
플러그 |
| 93.761 | FASTENER, DRIVERS OVERHEAD GUARD TOP SECTION COVER
패스너 |
| 95.735 | FASTENER, ENGINE AIR INTAKE SCREEN
패스너 |


ASSEMBLY
COMPLETE — 02.225




AIR CLEANER ASSEMBLY

02-474

02.225	CLEANER ASSEMBLY, ENGINE INTAKE AIR 에어클리너
02.232	CLAMP, INTAKE AIR CLEANER 클램프
02.242	ELEMENT & GASKET, ENGINE INTAKE AIR CLEANER 엘리먼트& 가스켓
02.380	CAP, FILTER 캡
02.790	VALVE, ENGINE INTAKE AIR CLEANER DUST UNLDR 밸브



02.252	FITTING, MAIN AIR CLEANER OUTLET TUBE 피팅
02.257	INDICATOR, ENGINE INTAKE AIR CLEANER AIR RES 인디케이터
62.067	HOSE, AIR CLEANER INTAKE 호스
62.068	HOSE, AIR CLEANER INTAKE 호스
62.069	TUBE, AIR CLEANER INTAKE 튜브




ACCELERATOR SYSTEM

02-493

02.258	STOP, ACCELERATOR PEDAL 스톱
02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.288	BRACKET, ACCELERATOR PEDAL ATTACHING 브라켓
02.289	FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING 패스너
02.329	FASTENER, ACCELERATOR PEDAL 패스너
02.337	BRACKET, ACCELERATOR LEVER MOUNTING 브라켓
02.338	FASTENER, ACCELERATOR LEVER MOUNTING BRACKET 패스너
03.419	WEAR PLATE, ACCELERATOR PEDAL ROLLER 웨어플레이트

03.904	FASTENER, ACCELERATOR PEDAL ROLLER BRACKET 패스너
62.050	PEDAL ASSEMBLY, ACCELERATOR 페달
93.726	WASHER, ACCELERATOR PEDAL PIVOT RETAINER 와셔






LPG TANK MOUNTING

03-184

02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
02.020	TANK, FUEL 탱크
02.389	FASTENER, TANK LOCATING PIN 패스너
03.299	SPACER, LPG TANK GUARD MOUNTING FASTENER 스페이서
03.635	BRACKET, LPG TANK 브라켓
62.003	CLAMP, LPG TANK 클램프
62.004	PLATE, LICENSE 플레이트
62.006	LOCK, LICENSE 로크
62.042	LAMP ASSEMBLY, LICENSE PLATE 램프


62.043	BULB, LICENSE PLATE LAMP 전구
62.044	FASTENER, LICENSE PLATE MOUNTING 패스너
62.214	BRACKET, LICENSE PLATE MOUNTING 브라켓
97.082	CLIP, LICENSE PLATE 클립






02.050	VALVE, LPG LOCK OFF 밸브
02.753	GASKET, FUEL FILTER BODY 가스켓
02.754	ELEMENT, FUEL FILTER 엘리먼트
02.772	FASTENER, FUEL FILTER COVER 패스너
03.396	REPAIR KIT, FUEL VALVE AND FILTER 리페어키트
03.397	FULCRUM, FUEL VALVE OPERATING VALVE LEVER 지지대
03.398	LEVER, FUEL VALVE OPERATING VALVE 레버
03.399	SPRING, FUEL VALVE OPERATING VALVE 스프링
92.931	FASTENER, FUEL VALVE DIAPHRAGM COVER 패스너


92.932	LOCKWASHER, FUEL VALVE DIAPHRAGM COVER FASTENER 로크와셔
92.933	FASTENER, FUEL VALVE OPERATING VALVE LEVER FULCRUM 패스너
92.934	RETAINER, FUEL VALVE OPERATING VALVE SEAL 리테이너
92.935	FASTENER, LOCK-OFF VALVE AND FILTER 패스너
92.936	LOCKWASHER, LOCK-OFF VALVE AND FILTER FASTENER 로크와셔
92.937	LOCKWASHER, FUEL VALVE OPERATING VALVE SPRING FAST 로크와셔
92.938	FASTENER, FUEL FILTER COVER FASTENER 패스너
92.939	LOCKWASHER, FUEL FILTER COVER FASTENER 로크와셔






01.627	LINE, VAPORIZER WATER OUTLET 라인	02.053	LINE, REGULATOR OUTLET 라인
01.629	FITTING, VAPORIZER WATER INLET 피팅	02.059	FITTING, LPG VAPORIZER INLET 피팅
01.630	LINE, VAPORIZER WATER INLET 라인	02.063	FITTING, LOCK-OFF VALVE OUTLET 피팅
01.638	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.065	FITTING, LOCK OFF VALVE INLET 피팅
01.645	LINE, VAPORIZER WATER OUTLET 라인	02.087	FITTING, VAPORIZER OUTLET 피팅
01.646	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.092	FITTING, LPG VAPORIZER OUTLET 피팅
02.040	COUPLER, LPG QUICK DISCONNECT 커플러	02.601	REGULATOR, VAPORIZER ASSY 레귤레이터
02.041	LINE, LP GAS TANK OUTLET 라인	02.717	FITTING, CARBURETOR INLET 피팅
02.044	VALVE, HYDROSTATIC RELIEF 밸브	02.869	CLIP, LPG LINE 클립
02.045	ADAPTOR, THREE WAY THRU HOOD 어댑터	03.018	FITTING, THREE WAY VALVE OUTLET LINE 피팅
02.046	FASTENER, ADAPTOR 패스너	03.143	COUPLER, LPG QUICK DISCONNECT 커플러
02.047	FITTING, LPG ADAPTOR OUTLET 피팅	03.144	COUPLER, LPG QUICK DISCONNECT 커플러
02.049	LINE, ADAPTOR OUTLET 라인	03.145	COUPLER, LPG QUICK DISCONNECT 커플러
02.050	VALVE, LPG LOCK OFF 밸브	03.322	BRACKET, LPG REGULATOR MOUNTING 브라켓
02.052	CLAMP, REGULATOR OUTLET HOSE 클램프	03.326	FASTENER, LPG REGULATOR MOUNTING BRACKET 패스너

03.402	LINE, LPG LOCK-OFF VALVE VACUUM 라인
03.403	FITTING, LPG LOCK-OFF VALVE VACUUM PORT 피팅
03.558	VALVE, FUEL CONTROL 밸브
03.733	SWITCH, LPG PRESSURE 스위치
03.762	HOSE, VACUUM 호스
03.919	FITTING, RELIEF VALVE 피팅
03.921	HOSE, RELIEF VALVE 호스
03.942	CLAMP, RELIEF VALVE HOSE 클램프
03.943	VALVE, HYDROSTATIC RELIEF 밸브




02.009	FASTENER, LPG TANK GUARD MOUNTING 패스너
02.015	STRAP, LPG TANK CLAMP 스트랩
02.097	FASTENER, TANK GUARD PIVOT ROD 패스너
02.388	PIN, TANK LOCATING 핀
03.358	CAP, FUEL TANK 캡
03.458	BRACKET, LPG TANK LOCATING PIN 브라켓
03.468	HANDLE, LPG TANK MOUNTING BRACKET 핸들
03.634	SUPPORT, LPG TANK BRACKET 서포트
03.636	SUPPORT, LPG TANK MOUNTING BRACKET 서포트

03.676	STOP, LPG TANK PIVOT 스톱
03.677	BUSHING, LPG TANK PIVOT 부싱
37.253	WASHER, GAS TANK SHIELD FASTENER 와셔
62.053	PROP, SWING DOWN LPG TANK MTG 지지대
62.055	BRACKET, SWING DOWN LPG TANK MTG 브라켓
62.241	FITTING-LUB, LPG TANK BRACKET PIVOT 피팅
91.422	NUT, LPG TANK SUPPORT 너트
96.420	FASTENER, LPG TANK MOUNTING BRACKET 패스너
96.422	WASHER, LPG TANK BRACKET PIVOT 와셔




02.009	FASTENER, LPG TANK GUARD MOUNTING 패스너
02.015	STRAP, LPG TANK CLAMP 스트랩
02.097	FASTENER, TANK GUARD PIVOT ROD 패스너
02.388	PIN, TANK LOCATING 핀
03.358	CAP, FUEL TANK 캡
03.458	BRACKET, LPG TANK LOCATING PIN 브라켓
03.468	HANDLE, LPG TANK MOUNTING BRACKET 핸들
03.634	SUPPORT, LPG TANK BRACKET 서포트
03.636	SUPPORT, LPG TANK MOUNTING BRACKET 서포트

03.676	STOP, LPG TANK PIVOT 스톱
03.677	BUSHING, LPG TANK PIVOT 부싱
37.253	WASHER, GAS TANK SHIELD FASTENER 와셔
62.053	PROP, SWING DOWN LPG TANK MTG 지지대
62.055	BRACKET, SWING DOWN LPG TANK MTG 브라켓
62.241	FITTING-LUB, LPG TANK BRACKET PIVOT 피팅
91.422	NUT, LPG TANK SUPPORT 너트
96.420	FASTENER, LPG TANK MOUNTING BRACKET 패스너
96.422	WASHER, LPG TANK BRACKET PIVOT 와셔





03.733 SWITCH,LPG PRESSURE
스위치



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓키트
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓키트
02.548	MANIFOLD, INTAKE 매니폴드
02.549	MANIFOLD, EXHAUST 매니폴드
02.589	SHIELD, HEAT (AT MANIFOLD) 실트
02.631	FASTENER, HEAT SHIELD 패스너
02.928	GASKET, EXHAUST MANIFOLD 가스켓
02.929	GASKET, INTAKE MANIFOLD 가스켓


03.457	SHIELD, MANIFOLD HEAT 실드
03.726	FASTENER, INTAKE MANIFOLD 패스너
11.275	CONDENSER, IGNITION 컨덴서
11.276	FASTENER, IGNITION CONDENSER 패스너
60.830	SENSOR, ENG CONTROL OXYGEN 센서
62.142	SENSOR, ENGINE MAP 센서
62.176	FASTENER, ENGINE MAP SENSOR 패스너
62.204	LINE, PCV 라인
90.253	NUT, MANIFOLD FASTENER 너트
90.738	NUT, MANIFOLD FASTENER 너트
95.877	FASTENER, HEAD SHIELD 패스너






02.040	COUPLER, LPG QUICK DISCONNECT 커플러
02.041	LINE, LP GAS TANK OUTLET 라인
02.044	VALVE, HYDROSTATIC RELIEF 밸브
02.045	ADAPTOR, THREE WAY THRU HOOD 어댑터
02.046	FASTENER, ADAPTOR 패스너
02.047	FITTING, LPG ADAPTOR OUTLET 피팅
02.049	LINE, ADAPTOR OUTLET 라인
02.090	BRACKET, LPG THREE WAY ADAPTOR MOUNTING 브라켓
02.091	FASTENER, LPG ADAPTOR MOUNTING BRACKET 패스너

02.095	FITTING, LPG THREE WAY ADAPTOR 피팅
03.018	FITTING, THREE WAY VALVE OUTLET LINE 피팅
03.143	COUPLER, LPG QUICK DISCONNECT 커플러
03.144	COUPLER, LPG QUICK DISCONNECT 커플러
97.080	FASTENER, ECU MOUNTING 패스너



00.000	PRODUCTION ENGINE ASSEMBLY 엔진	02.633	LINE, VAPORIZER OUTLET 라인
01.627	LINE, VAPORIZER WATER OUTLET 라인	02.647	CLIP, FUEL FILTER OUTLET LINE CLIP 클립
01.630	LINE, VAPORIZER WATER INLET 라인	02.802	FITTING, LPG VAPORIZER INLET 피팅
01.638	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.940	LINE, INJECTOR LEAK OFF 라인
01.644	CLAMP, VAPORIZER WATER INLET LINE 클램프	02.944	NOZZLE, FUEL INJECTOR 노즐
01.645	LINE, VAPORIZER WATER OUTLET 라인	02.949	LINE, INJECTOR (NO 1 CYLINDER) 라인
01.646	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.950	LINE, INJECTOR (NO 2 CYLINDER) 라인
02.043	FILTER, FUEL 필터	02.951	LINE, INJECTOR (NO 3 CYLINDER) 라인
02.050	VALVE, LPG LOCK OFF 밸브	02.952	LINE, INJECTOR (NO 4 CYLINDER) 라인
02.052	CLAMP, REGULATOR OUTLET HOSE 클램프	03.030	INJECTOR ASSEMBLY, FUEL 인젝터
02.053	LINE, REGULATOR OUTLET 라인	03.033	FASTENER, FUEL INJECTOR 패스너
02.371	CONTROL UNIT, ELECTRONIC (ECU) 컨트롤유닛	03.310	FITTING, FUEL LOCK-OFF VALVE OUTLET 피팅
02.373	FASTENER, ECU TO FUEL MODULE 패스너	03.322	BRACKET, LPG REGULATOR MOUNTING 브라켓
02.426	FASTENER, FUEL FILTER BRACKET 패스너	03.338	DAMPENER, FUEL INJECTOR LINE VIBRATION 댐프너
02.601	REGULATOR, VAPORIZER ASSY 레귤레이터	03.375	REPAIR KIT, LP GAS VAPOR REGULATOR 리페어키트


03.396	REPAIR KIT, FUEL VALVE AND FILTER 리페어키트
03.437	CLAMP, FUEL INJECTOR LINE 클램프
03.479	NOZZLE, TIP FUEL INJECTOR 노즐
03.564	NOZZLE, VACUUM REDUCTION 노즐
03.577	LINE, ENGINE FUEL FILTER 라인
03.638	CLAMP, VACUUM LINE 클램프
03.761	FASTENER, THROTTLE POSITIONER BRACKET 패스너
03.762	HOSE, VACUUM 호스
03.826	GASKET, THROTTLE BODY 가스켓
03.829	THROTTLE BODY AND SHAFT 스로틀
11.213	FASTENER, TRANSISTOR IGNITION RESISTOR 패스너
11.274	TRANSISTOR, ENGINE IGNITION 트랜지스터
11.277	COVER, ENGINE IGNITION TRANSISTOR 커버
15.641	WIRING HARNESS, ENGINE 와이어하네스
62.045	BRACKET, ELECTRONIC CONTROL UNIT 브라켓
62.205	BRACKET, FUEL INJECTOR 브라켓
62.209	CLAMP, FUEL FILTER 클램프
62.240	SOLENOID, FUEL LOCK-OFF VALVE 솔레노이드
62.256	REPAIR KIT, FUEL INJECTOR 리페어키트
62.261	COIL, FUEL INJECTOR 코일
92.935	FASTENER, LOCK-OFF VALVE AND FILTER 패스너
93.405	NUT, FUEL INJECTOR FASTENER 너트
94.884	FASTENER, LPG VAPORIZER MOUNTING 패스너



EXHAUST SYSTEM

03-611

02.567	GASKET, EXHAUST PIPE FLANGE TO MANIFOLD 가스켓
02.569	FASTENER, EXHAUST PIPE FLANGE TO MANIFOLD 패스너
02.572	FASTENER, EXHAUST PIPE STRAP 패스너
02.582	MUFFLER 머플러
02.583	PIPE, TAIL 파이프
02.591	FASTENER, MUFFLER MOUNTING 패스너
02.783	DAMPENER, MUFFLER MOUNTING VIBRATION 댐프너
03.359	PIPE, EXHAUST 파이프
95.249	FASTENER, TAIL PIPE CONNECTION FLANGE 패스너




02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
02.041	LINE, LP GAS TANK OUTLET 라인
02.047	FITTING, LPG ADAPTOR OUTLET 피팅
02.426	FASTENER, FUEL FILTER BRACKET 패스너
03.299	SPACER, LPG TANK GUARD MOUNTING FASTENER 스페이서
39.823	BRACKET, FUEL FILTER 브라켓
62.003	CLAMP, LPG TANK 클램프
62.004	PLATE, LICENSE 플레이트
62.044	FASTENER, LICENSE PLATE MOUNTING 패스너

62.055


BRACKET, SWING DOWN LPG TANK MTG
브라켓





00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓키트
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓키트
00.106	FITTING, CRANKCASE VENT TUBE 피팅
00.140	LINE, CRANKCASE VENT TUBE 라인
00.439	CLAMP, CRANKCASE VENT LINE 클램프
01.114	PLUG, WATER OUTLET ELBOW 플러그
01.625	CLAMP, WATER OUTLET HOUSING HOSE 클램프
02.548	MANIFOLD, INTAKE 매니폴드


02.549	MANIFOLD, EXHAUST 매니폴드
02.589	SHIELD, HEAT (AT MANIFOLD) 실드
02.631	FASTENER, HEAT SHIELD 패스너
02.928	GASKET, EXHAUST MANIFOLD 가스켓
02.929	GASKET, INTAKE MANIFOLD 가스켓
03.457	SHIELD, MANIFOLD HEAT 실드
03.726	FASTENER, INTAKE MANIFOLD 패스너
11.275	CONDENSER, IGNITION 컨덴서
11.276	FASTENER, IGNITION CONDENSER 패스너
60.830	SENSOR, ENG CONTROL OXYGEN 센서
62.142	SENSOR, ENGINE MAP 센서
62.176	FASTENER, ENGINE MAP SENSOR 패스너
62.204	LINE, PCV 라인
90.253	NUT, MANIFOLD FASTENER 너트
90.738	NUT, MANIFOLD FASTENER 너트
95.877	FASTENER, HEAD SHIELD 패스너



00.000	PRODUCTION ENGINE ASSEMBLY 엔진	02.949	LINE, INJECTOR (NO 1 CYLINDER) 라인
01.627	LINE, VAPORIZER WATER OUTLET 라인	02.950	LINE, INJECTOR (NO 2 CYLINDER) 라인
01.630	LINE, VAPORIZER WATER INLET 라인	02.951	LINE, INJECTOR (NO 3 CYLINDER) 라인
01.638	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.952	LINE, INJECTOR (NO 4 CYLINDER) 라인
01.644	CLAMP, VAPORIZER WATER INLET LINE 클램프	03.030	INJECTOR ASSEMBLY, FUEL 인젝터
01.646	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	03.033	FASTENER, FUEL INJECTOR 패스너
02.050	VALVE, LPG LOCK OFF 밸브	03.307	FITTING, FUEL LOCK-OFF VALVE INLET 피팅
02.052	CLAMP, REGULATOR OUTLET HOSE 클램프	03.310	FITTING, FUEL LOCK-OFF VALVE OUTLET 피팅
02.053	LINE, REGULATOR OUTLET 라인	03.322	BRACKET, LPG REGULATOR MOUNTING 브라켓
02.059	FITTING, LPG VAPORIZER INLET 피팅	03.338	DAMPENER, FUEL INJECTOR LINE VIBRATION 댐퍼
02.371	CONTROL UNIT, ELECTRONIC (ECU) 컨트롤유닛	03.375	REPAIR KIT, LP GAS VAPOR REGULATOR 리페어키트
02.373	FASTENER, ECU TO FUEL MODULE 패스너	03.396	REPAIR KIT, FUEL VALVE AND FILTER 리페어키트
02.601	REGULATOR, VAPORIZER ASSY 레귤레이터	03.400	LINE, FUEL LOCK-OFF VALVE OUTLET 라인
02.940	LINE, INJECTOR LEAK OFF 라인	03.401	BRACKET, LPG LOCK-OFF VALVE MOUNTING 브라켓
02.944	NOZZLE, FUEL INJECTOR 노즐	03.437	CLAMP, FUEL INJECTOR LINE 클램프

03.479	NOZZLE, TIP FUEL INJECTOR 노즐
03.564	NOZZLE, VACUUM REDUCTION 노즐
03.638	CLAMP, VACUUM LINE 클램프
03.733	SWITCH, LPG PRESSURE 스위치
03.761	FASTENER, THROTTLE POSITIONER BRACKET 패스너
03.762	HOSE, VACUUM 호스
03.826	GASKET, THROTTLE BODY 가스켓
03.829	THROTTLE BODY AND SHAFT 스로틀
11.213	FASTENER, TRANSISTOR IGNITION RESISTOR 패스너
11.274	TRANSISTOR, ENGINE IGNITION 트랜지스터
11.277	COVER, ENGINE IGNITION TRANSISTOR 커버
15.641	WIRING HARNESS, ENGINE 와이어하네스
60.045	GASKET, FORK POSITIONING SWITCH COVER 가스켓
62.205	BRACKET, FUEL INJECTOR 브라켓
62.249	GUARD, ENGINE VAPORIZER WATER INLET 가드
62.250	U-BOLT CLAMP, FUEL LPG LOCK-OFF 클램프
62.256	REPAIR KIT, FUEL INJECTOR 리페어키트
62.261	COIL, FUEL INJECTOR 코일
62.306	SENSOR, ENGINE FUEL PRESSURE & TEMPERATURE 센서
93.405	NUT, FUEL INJECTOR FASTENER 너트
94.884	FASTENER, LPG VAPORIZER MOUNTING 패스너
97.373	FASTENER, ENGINE IGNITION TRANSISTOR COVER 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




INTAKE SYSTEM

03-698

02.225	CLEANER ASSEMBLY, ENGINE INTAKE AIR 에어클리너
02.236	CLAMP, MAIN AIR CLEANER INLET HOSE 클램프
02.246	FASTENER, ENGINE INTAKE AIR CLEANER ATTACHING 패스너
02.257	INDICATOR, ENGINE INTAKE AIR CLEANER AIR RES 인디케이터
02.262	HOSE, MAIN AIR CLEANER OUTLET 호스
02.266	HOSE, MAIN AIR CLEANER OUTLET 호스
02.267	CLAMP, MAIN AIR CLEANER OUTLET HOSE 클램프
02.269	CLAMP, MAIN AIR CLEANER OUTLET HOSE 클램프
02.386	FASTENER, ENGINE INTAKE AIR CLEANER SUPPORT 패스너


02.457	FITTING, MAIN AIR CLEANER OUTLET TUBE 피팅
03.202	CLAMP, ENGINE AIR INTAKE ADAPTOR 클램프
03.383	LINE, MAIN AIR CLEANER INLET LINE 라인
03.517	BRACKET, AIR CLEANER MOUNTING 브라켓





04.470	GASKET, HYDRAULIC PUMP MOUNTING 가스켓	05.130	SHAFT, CONVERTER PUMP IDLER GEAR 샤프트
05.000	CONVERTER ASSEMBLY, TORQUE 컨버터	05.132	THRUST WASHER, CONVERTOR PUMP IDLER GEAR 스러스트와셔
05.001	GEAR, CONVERTER RING 기어	05.133	GEAR, CONVERTOR PUMP IDLER 기어
05.004	FASTENER, CONVERTER DRIVE & REINFORCING PLATE 패스너	05.134	BEARING, CONVERTOR PUMP IDLER GEAR 베어링
05.021	BEARING, IMPELLER HUB 베어링	05.137	LOCATOR, CONVERTER STATOR SUPPORT (OUTER) 로케이터
05.023	SEAL, CONVERTER IMPELLER HUB 씰	05.140	LOCATOR, CONVERTER STATOR SUPPORT (INNER) 로케이터
05.030	GEAR, IMPELLER HUB 기어	05.141	ADAPTOR, CONVERTER DRIVE 어댑터
05.056	RING-RETAINING, PUMP DRIVE GEAR 링	05.151	BREATHER, CONVERTER AIR 브리더
05.057	GEAR, PUMP DRIVE 기어	05.173	FASTENER, CONVERTER PUMP COVER 패스너
05.067	GASKET, CONVERTER PUMP 가스켓	05.178	COVER, CONVERTER PUMP 커버
05.098	SLEEVE, IMPELLER COVER 슬리브	05.192	LOCKWASHER, CONVERTER PUMP FASTENER 로크와셔
05.104	SPRING, INNER 스프링	05.218	BODY, PRESSURE REGULATING VALVE 바디
05.114	FASTENER, CONVERTER TO CASE 패스너	05.219	PISTON, PRESSURE REGULATING VALVE 피스톤
05.119	FASTENER, CONVERTER CASE 패스너	05.530	FITTING, TORQUE CONVERTER INLET LINE 피팅
05.120	FASTENER, CONVERTER TO CASE 패스너	06.220	GEAR, REVERSE IDLER 기어


06.386	ADAPTOR, CONVERTER END 어댑터
06.393	WASHER KIT, FORWARD CLUTCH CYLINDER THRUST 와셔키트
06.447	PLUG, TRANSMISSION CASE 플러그
06.456	GASKET, TRANSMISSION ADAPTOR 가스켓
06.471	HOUSING, CONVERTER 하우징
06.506	SEAL, CONVERTER HOUSING TO CASE-INNER 씰
06.521	BALL, INCHING RELIEF VALVE 볼
06.556	DISTRIBUTOR, TRANSMISSION DIRECTION SEL OIL 디스트리뷰터
06.557	SEAL, TRANSMISSION DIRECTION SELECTOR OIL DIST 씰
06.573	BEARING, FORWARD GEAR 베어링
06.574	GEAR & BEARING FORWARD 기어& 베어링
06.580	THRUST WASHER, REVERSE CLUTCH HUB & DRUM 스러스트와셔
06.581	BEARING, REVERSE GEAR 베어링
06.582	GEAR & BEARING, REVERSE 기어& 베어링
06.594	GEAR & BEARING, 2ND 기어& 베어링
06.656	LINE, TRANS VALVE PRESS PUMP INLET 라인
06.704	VALVE, TRANSMISSION PRESSURE RELIEF 밸브
06.948	SLEEVE, CLUTCH OIL DISTRIBUTION 슬리브
06.975	BEARING, REVERSE CLUTCH HUB (AXLE END) 베어링
06.977	BEARING, REVERSE CLUTCH HUB (ENGINE END) 베어링
10.105	ELEMENT & GASKET, OIL FILTER 엘리먼트& 가스켓
13.010	CONTROL, CONVERTOR TEMPERATURE INDICATOR 컨트롤
20.100	TRANSAXLE ASSEMBLY 트랜스액슬
29.300	PUMP ASSEMBLY, CONVERTER CHARGING 펌프
44.124	SPRING, TRANSMISSION SAFETY VALVE 스프링
44.144	COVER, CONVERTER HOUSING 커버
44.163	STOP, TRANSMISSION SAFETY VALVE 스톱
44.181	BEARING, CLUTCH SHAFT THRUST 베어링
44.360	TURBINE SHAFT, DRUM & CLUTCH ASSY 터빈샤프트
91.126	DOWEL RING, FLYWHEEL HOUSING FASTENER 다웰링
91.428	LOCKWASHER, CONVERTER CHARGING PUMP FAST 로크와셔
95.426	FASTENER, CONVERTER DRIVE ADAPTOR 패스너
95.704	FASTENER, CONVERTER HOUSING PLATE 패스너
96.236	SPACER, CONVERTER PRESSURE REGULATING VALVE 스페이서



05.167	FASTENER, CONVERTER PUMP INLET LINE 패스너
05.168	LINE, CONVERTER PUMP INLET 라인
05.226	SEAL, CONVERTER PRESSURE PORT PLUG 씰
05.525	PLUG, TRANSMISSION CASE 플러그
05.527	PLUG, TRANSMISSION CASE 플러그
06.377	PLUG, TRANSMISSION SUMP OIL LEVEL 플러그
06.400	CONTROL COVER & VALVE ASSEMBLY 컨트롤커버&밸브
06.408	GASKET, CONTROL COVER ATTACHING 가스켓
06.424	FASTENER, CONTROL COVER 패스너
06.550	COVER, TRANSMISSION HOUSING INSPECTION 커버
06.657	SEAL, TRANS VALVE PRESS PUMP INLET LINE 씰
06.949	RETAINER, CLUTCH OIL DISTRIBUTION SLEEVE 리테이너
06.964	RING, OUTPUT SHAFT GEAR LOCATING 링
08.037	CASE, TRANSMISSION 케이스
08.260	TUBE, TRAN OIL LEVEL DIPSTICK SUPPORT 튜브

08.373	DIPSTICK, TRANSMISSION 딕스틱
09.005	GEAR, OUTPUT 기어
20.100	TRANSAXLE ASSEMBLY 트랜스액슬
20.101	HOUSING, TRANSAXLE WHEEL END - LH 하우징
20.102	HOUSING, TRANSAXLE WHEEL END - RH 하우징
20.201	SHIM, DIFF BRG CARRIER TO AXLE HOUSING 심
20.203	NUT, DIFFERENTIAL PINION COMPANION FLANGE 너트
20.232	CONE, DIFFERENTIAL PINION OUTER BEARING 콘
20.233	CUP, DIFFERENTIAL PINION OUTER BEARING 컵
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 심
20.240	SPACER, DIFFERENTIAL PINION BEARING 스페이서
20.244	SEAL, DIFFERENTIAL OIL LEVEL DIPSTICK SUPPORT 씰
20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링
20.264	CONE, DIFFERENTIAL BEARING 콘


20.265	CUP, DIFFERENTIAL BEARING 컵
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.281	FASTENER, DIFF SIDE PINION PIN 패스너
20.282	SPIDER, DIFFERENTIAL PINION 스파이더
20.283	GEAR, DIFFERENTIAL SIDE PINION 기어
20.284	WASHER, DIFF SIDE PINION GEAR THRUST 와셔
20.285	GEAR, DIFFERENTIAL SIDE 기어
20.286	WASHER, DIFFERENTIAL SIDE GEAR THRUST 와셔
20.287	CASE & GEAR ASSEMBLY, DIFFERENTIAL 케이스& 기어
20.512	SHIM, DRIVE AXLE HUB BEARING 심
20.513	RETAINER, DRIVE AXLE HUB BEARING 리테이너
20.514	LOCKPLATE, DRIVE AXLE HUB BEARING RETAINER 로크플레이트
20.547	FASTENER, DRIVE AXLE END 패스너
20.554	FASTENER, DRIVE AXLE HUB CAP 패스너
20.570	FASTENER, DRIVE WHEEL MOUNTING 패스너
20.572	LOCATOR, DRIVE AXLE SHAFT BEARING 로케이터
20.581	HUB ASSEMBLY, DRIVE AXLE 허브
20.586	SHAFT, DRIVE AXLE 샤프트
20.602	SEAL, DRIVE AXLE HUB INNER OIL 씰
20.608	CONE, DRIVE AXLE HUB INNER BEARING 콘
20.612	CUP, DRIVE AXLE HUB INNER BEARING 컵
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.663	SPACER, DRIVE AXLE HUB BEARING 스페이서
22.898	CABLE, PARKING BRAKE DRAW - LH 케이블
22.900	CABLE, PARKING BRAKE DRAW - RH 케이블
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
23.246	FASTENER, BRAKE ASSEMBLY 패스너
94.940	FASTENER, DRIVE AXLE HUB BEARING RETAINER 패스너
95.783	NUT, CONVERTER OIL SUCTION TUBE FASTENER 너트



06.310	SEAL, FORWARD CLUCH PISTON INNER 씰
06.311	SEAL, FORWARD CLUTCH PISTON OUTER 씰
06.312	PISTON, FORWARD CLUTCH 피스톤
06.314	DISC, FORWARD CLUTCH INNER 디스크
06.315	DISC, FORWARD CLUTCH OUTER 디스크
06.317	PLATE, FORWARD CLUTCH DISC END 플레이트
06.430	SPRING, FORWARD CLUTCH PISTON RETURN 스프링
06.434	SHAFT & GEAR, CLUTCH DRIVE 샤프트& 기어
06.462	PLUG, REVERSE UNIT 플러그

06.579	FASTENER, REVERSE CLUTCH SPRING RETAINER 패스너
44.101	THRUST WASHER, CLUTCH SHAFT PILOT BEARING 스러스트와셔
44.354	RING, CLUTCH PACK RETAINING 링
44.360	TURBINE SHAFT, DRUM & CLUTCH ASSY 터빈샤프트






CONTROL VALVE

06-114


05.511	SEAL, INCHING PISTON HOUSING 씰	06.540	SEAL, INCHING PISTON HOUSING 씰
05.515	SPOOL, INCHING 스풀	06.544	HOUSING, INCHING PISTON 하우징
06.400	CONTROL COVER & VALVE ASSEMBLY 컨트롤커버& 밸브	06.660	SOLENOID ASSEMBLY, TRANSMISSION 솔레노이드
06.402	VENT, CONTROL COVER AIR 벤트	06.717	SEAL, CONTROL COVER OIL PASSAGE 씰
06.425	PLUG, CONTROL COVER OIL PASSAGE 플러그	06.847	FASTENER, ACCUMULATOR HOUSING 패스너
06.472	PLUG, CONTROL VALVE HOUSING OIL PASSAGE 플러그	08.493	PLUG, SPEED CHANGE NEEDLE VALVE HOUSING 플러그
06.476	RETAINER, INCHING VALVE PISTON 리테이너	08.601	GASKET, MODULATION VALVE 가스켓
06.477	WASHER, INCHING VALVE PISTON 와셔	43.061	HOUSING, CONTROL VALVE INCHING PISTON 하우징
06.478	SPRING, INCHING PISTON RETURN 스프링	43.093	PLUG, CONTROL VALVE HOUSING 플러그
06.479	PISTON, INCHING 피스톤	44.105	SPRING, TRANSMISSION ACCUMULATOR OUTER 스프링
06.480	SEAL, INCHING PISTON 씰	44.106	SPRING, TRANSMISSION ACCUMULATOR MIDDLE 스프링
06.481	FITTING, INCHING VALVE PISTON PORT 피팅	44.107	SPRING, TRANSMISSION ACCUMULATOR INNER 스프링
06.513	SPRING, INCHING VALVE 스프링	44.109	SEAL, TRANSMISSION ACCUMULATOR BORE PLUG 씰
06.514	ROD, INCHING VALVE 로드	44.131	SPOOL, FORWARD & REVERSE 스풀
06.517	SEAL, INCHING VALVE PISTON PORT FITTING 씰	44.145	SPOOL, MODULATOR 스풀

44.146	SPRING, MODULATOR SPOOL 스프링
44.147	HOUSING, TRANSMISSION CONTROL ACCUMULATOR 하우징
44.148	SPOOL, ACCUMULATOR 스풀
44.149	SEAL, ACCUMULATOR HOUSING TO CONTROL VALVE 씰
44.160	SEAT, TRANSMISSION SHIFT MODULATOR SPOOL SPRING 시트
44.161	STOP, TRANSMISSION ACCUMULATOR SPOOL 스톱
44.164	SPRING, TRANSMISSION FORWARD & REVERSE VALVE SPO 스프링
44.165	CAP, TRANSMISSION FORWARD & REVERSE VALVE SPOOL 캡
44.166	SEAL, TRANSMISSION FORWARD & REVERSE VALVE SPOOL 씰
44.170	COIL, TRANSMISSION CONTROL COVER SOLENOID 코일
44.194	LOCATOR, CONTROL COVER 로케이터
44.197	BLEEDER, CONTROL VALVE SLAVE CYLINDER 블리더
44.198	SEAT, SLAVE CYLINDER BRAKE LINE 시트
44.199	NUT, SLAVE CYLINDER ADJUSTING 너트
44.212	CARTRIDGE, CONTROL VALVE SHIFT SOLENOID 카트리지
44.213	SPRING, INCHING SPOOL BALANCE- OUTER 스프링
44.214	SPRING, INCHING SPOOL BALANCE- INNER 스프링
44.301	SEAL KIT, SOLENOID VALVE 씰키트
92.616	LOCKWASHER, ACCUMULATOR HOUSING FASTENER 로크와셔
95.082	FASTENER, CONTROL SELECTOR SOLENOID RELAY 패스너





- | | |
|--------|---|
| 07.012 | FASTENER, TRANSMISSION TO ENGINE
패스너 |
| 07.013 | FASTENER, TRANSMISSION TO ENGINE
패스너 |
| 20.100 | TRANSAXLE ASSEMBLY
트랜스액슬 |




TRANS COOLING LINES

10-129


10.021	FASTENER, COOLER OUTLET LINE CLAMP 패스너
10.029	FITTING, TRANSMISSION COOLING LINE 피팅
10.055	FITTING, COOLER OUTLET 피팅
10.077	CHECK VALVE, OIL COOLING LINES 체크밸브
10.140	CLAMP, COOLER LINE 클램프
10.225	LINE, OIL COOLING 라인
10.226	LINE, OIL COOLING 라인
10.227	LINE, OIL COOLING 라인
10.229	CHECK VALVE, OIL COOLING 체크밸브

10.231	FITTING, OIL COOLING LINES 피팅
10.232	FITTING, CHECK VALVE OIL COOLING 피팅
10.235	FITTING, OIL COOLING 피팅
10.243	FITTING, COOLING LINE 피팅
10.245	SEAL, COOLING LINE FITTING 씰




00.000	PRODUCTION ENGINE ASSEMBLY 엔진
01.854	SENSOR, ENGINE COOLANT TEMPERATURE 센서
01.886	SEAL, ENGINE COOLANT TEMPERATURE SENSOR 씰
11.020	MOTOR ASSEMBLY, STARTING 모터
11.034	FASTENER, STARTING MOTOR 패스너
11.201	COIL, IGNITION 코일
11.203	FASTENER, COIL 패스너
11.250	SPARK PLUG 스파크
11.256	HARNESS, IGNITION COIL WIRING 하네스


62.138	SENSOR, ENGINE CRANKSHAFT POSITION 센서
62.140	FASTENER, ENGINE CRANKSHAFT POSITION SENSOR 패스너
62.169	SENSOR, ENGINE CAMSHAFT POSITION 센서
62.170	FASTENER, ENGINE CAMSHAFT POSITION SENSOR 패스너
62.171	SENSOR, ENGINE KNOCK 센서
62.172	FASTENER, ENGINE KNOCK SENSOR 패스너
62.173	SWITCH, ENGINE OIL PRESSURE 스위치



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
12.016	FASTENER, GENERATOR THRU 패스너
12.019	BEARING, GENERATOR DRIVE END 베어링
12.029	SPACER, GENERATOR DRIVE END 스페이서
12.053	SUPPORT, GENERATOR MOUNTING BRACKET 서포트
12.107	FASTENER, ADJUSTING STRAP TO ALTERNATOR 패스너
12.152	BRACKET, ALTERNATOR ADJUSTING STRAP 브라켓
12.154	FASTENER, ALTERNATOR MOUNTING 패스너
12.171	HOUSING, ALTERNATOR RECTIFIER 하우징

12.200	ALTERNATOR ASSEMBLY 알터네이터
12.201	FASTENER, ALTERNATOR PULLEY TO SHAFT 패스너
12.202	PULLEY, ALTERNATOR 폴리
12.212	FASTENER, ALTERNATOR DRIVE END BEARING RETAINER PL 패스너
12.214	ROTOR ASSEMBLY, ALTERNATOR 로터
12.216	STATOR ASSEMBLY, ALTERNATOR 스테이터
12.228	BEARING, ALTERNATOR SLIP RING FRAME END 베어링
12.313	COVER, ALTERNATOR BRUSH ACCESS 커버
12.316	REGULATOR, ALTERNATOR VOLTAGE OUTPUT 레귤레이터
12.317	RECTIFIER ASSEMBLY, ALTERNATOR 정류기
12.423	FASTENER, ADJUSTING STRAP TO ALTERNATOR 패스너
93.555	FASTENER, ALTERNATOR RECTIFIER HOUSING COVER 패스너







12.009	SUPPORT, BATTERY 서포트
12.010	BATTERY 배터리
12.011	CLAMP, BATTERY HOLD DOWN 클램프
12.013	FASTENER, BATTERY HOLD DOWN (AT CLAMP) 패스너
12.049	FASTENER, BATTERY SUPPORT 패스너
14.025	CABLE, BATTERY TO STARTER 케이블
14.026	CABLE, BATTERY GROUND 케이블
14.042	FASTENER, BATTERY GROUND CABLE 패스너
14.147	CABLE, BATTERY NEGATIVE 케이블

97.272 FASTENER, CABLE & WIRE TO STARTER
패스너






- | | |
|--------|---|
| 13.047 | SWITCH, CIRCUIT LOCKING
스위치 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |
| 14.502 | WIRE, IGNITION SWITCH TO ENGINE HARNESS
와이어 |
| 60.260 | KEY, CIRCUIT LOCKING SWITCH
키 |




- | | |
|--------|--|
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |



13.332	ASSEMBLY, WARNING LIGHT 경고등
13.333	BULB, WARNING LIGHT 전구
60.821	GLOBE, STROBE LIGHT 글로브
60.822	BASE, STROBE LIGHT 베이스


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STROBE LIGHT MOUNTING

13-183


13.330	BRACKET, WARNING LIGHT 브라켓
13.331	FASTENER, WARNING LIGHT BRACKET 패스너
13.332	ASSEMBLY, WARNING LIGHT 경고등
60.664	HARNESS, WARNING DEVICE 하네스



BACK-UP ALARM INSTALLATION


13-228

- | | |
|--------|--|
| 13.681 | FASTENER, WARNING DEVICE
패스너 |
| 42.001 | WARNING DEVICE, AUDIBLE (AIR OPER)
경고장치 |
| 42.011 | CLIP, AUDIBLE WARNING DEVICE CABLE
클립 |



13.142	SWITCH, BRAKE INTERLOCK 스위치
13.206	BULB, BACK-UP LAMP 전구
13.217	FASTENER, COM STOP & TAIL LAMP ASSY MTG 패스너
13.218	BULB, STOP & TAIL LAMP 전구
13.675	BULB, TURN LIGHT 전구
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
18.033	CLIP, HARNESS 클립
18.034	FASTENER, HARNESS CLIP 패스너
60.795	LIGHT, REAR WORK 라이트


60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.924	FASTENER, REAR WORK LAMP MOUNTING 패스너
60.960	HARNESS, REAR WORK LAMP EXTENSION 하네스
60.962	SPACER, REAR WORK LAMP MOUNTING 스페이서



- | | |
|--------|--|
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 13.284 | BRACKET, ADJUSTABLE HEADLAMP
브라켓 |
| 13.285 | FASTENER, ADJUSTABLE HEADLAMP BRACKET
패스너 |
| 13.299 | GUARD, HEADLIGHT
가드 |
| 13.660 | LIGHT, TURN SIGNAL
라이트 |
| 13.661 | BULB, TURN SIGNAL LIGHT
전구 |
| 13.673 | BRACKET, TURN LIGHT
브라켓 |
| 15.436 | HARNESS, RH HEADLAMP WIRING
하네스 |
| 15.437 | HARNESS, HEADLAMP WIRING
하네스 |

15.714	FLASHER, UNIT 플래셔
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너







13.270	HEADLAMP, ADJUSTABLE 헤드 램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.436	HARNESS, RH HEADLAMP WIRING 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래서

60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너






- | | |
|--------|---------------------------------------|
| 11.001 | RELAY, STARTER
릴레이 |
| 11.002 | FASTENER, STARTER RELAY
패스너 |
| 13.688 | RELAY, ENGINE CONDITION SIGNAL
릴레이 |
| 14.114 | HARNESS, MACHINE WIRING
하네스 |
| 15.447 | DIODE, HARNESS
다이오드 |
| 18.000 | CLIP, WIRING HARNESS
클립 |
| 18.001 | FASTENER, WIRING HARNESS CLIP
패스너 |
| 18.002 | CLIP, WIRING HARNESS
클립 |
| 18.008 | CLIP, WIRING HARNESS
클립 |




- | | |
|--------|---|
| 13.000 | PANEL, INSTRUMENT CLUSTER
판넬 |
| 13.003 | HORN
혼 |
| 13.004 | FASTENER, HORN MOUNTING BRACKET
패스너 |
| 13.079 | FASTENER, INSTRUMENT CLUSTER TO INST PANEL
패스너 |
| 14.352 | FUSE, CONTROL CIRCUIT
퓨즈 |
| 14.690 | WIRE, HORN FILTER
와이어 |
| 15.433 | GROMMET, CONTROL CIRCUIT WIRING HARNESS
그로멧 |
| 15.447 | DIODE, HARNESS
다이오드 |
| 15.640 | WIRING HARNESS, MACHINE COWL
와이어하네스 |

15.710	RELAY, ELECTRICAL 릴레이
18.009	FASTENER, HARNESS CLIP 패스너
18.010	CLIP, HARNESS 클립
18.020	CLIP, HARNESS 클립
60.383	GROMMET, CONTROL CIRCUIT WIRING HARNESS 그로멧
65.289	BODY, FUSE BOX 바디
65.832	COVER, FUSE BOX 커버
95.009	FASTENER, FUSE BOX MOUNTING 패스너






- 39.417 GROUND STRAP, ELECTRIC TRUCK
접지케이블
- 39.418 FASTENER, ELECTRIC TRUCK GROUND STRAP
패스너





- | | |
|--------|---|
| 15.769 | WIRE HARNESS, TIMER DELAY
와이어하네스 |
| 15.815 | TIMER, FUEL BLOCK SOLENOID
타이머 |
| 15.816 | FASTENER, FUEL BLOCK SOLENOID TIMER
패스너 |
| 60.952 | BRACKET, ENGINE CONDITION SIGNAL RELAY SUPPORT
브라켓 |



22.280	SPRING, BRAKE SHOE GUIDE PIN 스프링
22.325	FASTENER, BRAKE SHOE ADJUSTOR 패스너
22.326	PLUG, BRAKE LINING INSPECTION 플러그
22.328	LOCKWASHER, BRAKE SHOE ADJUSTOR FASTENER 로크와셔
23.214	CYLINDER ASSEMBLY, LH BRAKE 실린더
23.223	BLEEDER, BRAKE WHEEL CYLINDER 블리더
23.237	COVER, RH BRAKE ADJUSTOR 커버
23.243	PLATE, RH BRAKE BACKING 플레이트
23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크


23.250	SPRING, RH BRAKE RETURN 스프링
23.259	FASTENER, RH WHEEL CYLINDER 패스너
23.262	SPRING, BRAKE SHOE RETURN 스프링
23.293	RING-RETAINING, BRAKE SHOE ANCHOR PIN 링
23.294	WASHER, BRAKE SHOE GUIDE PIN 와셔
23.475	ADJUSTOR, BRAKE SHOE 어드저스터
23.664	PLATE, BRAKE SHOE RETAINER 플레이트
24.392	SHOE & LINING, BRAKE (AXLE SET) 슈& 라이닝
90.398	LOCKWASHER, WHEEL CYLINDER FASTENER 로크와셔






22.280	SPRING, BRAKE SHOE GUIDE PIN 스프링
22.325	FASTENER, BRAKE SHOE ADJUSTOR 패스너
22.326	PLUG, BRAKE LINING INSPECTION 플러그
22.328	LOCKWASHER, BRAKE SHOE ADJUSTOR FASTENER 로크와셔
23.215	CYLINDER ASSEMBLY, RH BRAKE 실린더
23.223	BLEEDER, BRAKE WHEEL CYLINDER 블리더
23.237	COVER, RH BRAKE ADJUSTOR 커버
23.243	PLATE, RH BRAKE BACKING 플레이트
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크

23.247	SHOE SET, BRAKE LINING 슈
23.259	FASTENER, RH WHEEL CYLINDER 패스너
23.262	SPRING, BRAKE SHOE RETURN 스프링
23.293	RING-RETAINING, BRAKE SHOE ANCHOR PIN 링
23.294	WASHER, BRAKE SHOE GUIDE PIN 와셔
23.475	ADJUSTOR, BRAKE SHOE 어드저스터
23.664	PLATE, BRAKE SHOE RETAINER 플레이트
23.735	SHOE & LINING SET, BRAKE 슈& 라이닝
90.398	LOCKWASHER, WHEEL CYLINDER FASTENER 로크와셔



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE WHEEL & TIRE MOUNTING

22-013

- | | |
|--------|---|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠& 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER WHEEL & TIRE MOUNTING

22-014

- | | |
|--------|---|
| 23.026 | FASTENER, STEER WHEEL
패스너 |
| 23.031 | STEER WHEEL AND TIRE ASSEMBLY
스티어휠 & 타이어 |

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE (SOLID TYPE)

22-024

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어

ASSEMBLY
COMPLETE — 23.031




STEER WHEEL & TIRE (SOLID TYPE)

22-025

22.990	TIRE ASSEMBLY, STEER 타이어
23.000	RIM ASSEMBLY, STEER WHEEL 립
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠 & 타이어

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE

22-041

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.016	TIRE, DRIVE WHEEL 타이어
23.018	TUBE, DRIVE WHEEL 튜브
23.019	FLAP, DRIVE WHEEL TUBE 플랩
23.029	FASTENER, DRIVE WHEEL ASSEMBLY 패스너
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어


ASSEMBLY
COMPLETE — 23.031




STEER WHEEL & TIRE

22-042

22.990	TIRE ASSEMBLY, STEER 타이어
23.000	RIM ASSEMBLY, STEER WHEEL 립
23.006	TIRE, STEER WHEEL 타이어
23.007	TUBE, STEER WHEEL 튜브
23.008	FLAP, STEER WHEEL 플랩
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠& 타이어
23.036	FASTENER, STEER WHEEL ASSEMBLY 패스너




22.131	BOOT, INCHING MASTER CYLINDER 부트
23.800	CYLINDER ASSEMBLY, INCHING MASTER COMPLETE 실린더
23.811	REPAIR KIT, INCHING MASTER CYLINDER 리페어키트
24.319	FITTING, INCHING MASTER CYLINDER INLET 피팅
24.326	BOLT, INCHING MASTER CYLINDER INLET FITTING 볼트
24.327	SEAL, INCHING MASTER CYLINDER INLET FITTING 셀



22.055	ROD, MASTER CYLINDER ACTUATING 로드
22.359	SEAT, MASTER CYLINDER BRAKE LINE PORT 시트
22.417	SPRING, MASTER CYLINDER PISTON RETURN 스프링
22.522	FITTING-BOLT, BRAKE CYLINDER INLET 피팅
22.524	SEAL, BRAKE CYLINDER INLET FITTING-BOLT 셀
22.565	VALVE ASSY, BRAKE ENERGIZER ASSY 밸브
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.161	BOOT, MASTER CYLINDER 부트
23.621	FITTING, MASTER CYLINDER CAP 피팅

23.732	REPAIR KIT, BRAKE CYLINDER 리페어키트
24.166	SEAT, BRAKE VALVE PISTON SPRING 시트
94.398	NUT, BRAKE MASTER CYLINDER ACTUATING ROD FASTENER 너트







BRAKE & INCHING LINES

23-390

22.026	ROD END, BRAKE PEDAL LINKAGE 로드엔드
22.856	RETAINER, PARKING BRAKE PEDAL PIVOT 리테이너
23.051	FASTENER, MASTER CYLINDER MOUNTING BRACKET 패스너
23.098	PEDAL, AUX BRAKE 페달
23.100	PEDAL, BRAKE 페달
23.101	SHAFT, BRAKE PEDAL 샤프트
23.105	BEARING, BRAKE PEDAL 베어링
23.114	PAD & FASTENER, BRAKE PEDAL 패드& 패스너
23.136	SPRING, BRAKE PEDAL RETURN 스프링


23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.157	FASTENER, BRAKE MASTER CYLINDER ATTACHING 패스너
23.160	ROD, PUSH 로드
23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.435	FASTENER, BRAKE PEDAL PIVOT BRACKET 패스너
23.538	ARM, BRAKE LINKAGE PIVOT 암
23.589	RETAINER, BRAKE ACTUATING LEVER 리테이너
23.665	SPRING, INCHING PEDAL RETURN 스프링
23.800	CYLINDER ASSEMBLY, INCHING MASTER COMPLETE 실린더
92.026	RETAINER, BRAKE MASTER CYLINDER ACTUATING ROD PIN 리테이너





- | | |
|--------|--|
| 13.142 | SWITCH, BRAKE INTERLOCK
스위치 |
| 22.338 | CLAMP, BRAKE FLUID RESERVOIR
클램프 |
| 22.452 | CLAMP, BRAKE MASTER CYLINDER FILLER LINE
클램프 |
| 22.528 | BLEEDER, BRAKE LINES ADAPTOR
블리더 |
| 22.604 | CLAMP, BRAKE FLUID RESERVOIR LINE
클램프 |
| 22.627 | TEE, BRAKE LINE
티 |
| 23.173 | FITTING, BRAKE MASTER CYLINDER OUTLET
피팅 |
| 23.176 | GASKET, BRAKE MASTER CYLINDER OUTLET FTG BOLT
가스켓 |
| 23.186 | LINE, BRAKE MASTER CYLINDER OUTLET
라인 |


23.199	FASTENER, BRAKE LINE TEE 패스너
23.207	LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.616	LINE, BRAKE MASTER CYLINDER OUTLET 라인
23.792	RESERVOIR, BRAKE FLUID 리저버
23.793	FASTENER, BRAKE FLUID RESERVOIR 패스너
23.795	FITTING, BRAKE MASTER CYLINDER INLET 피팅
23.856	PLUG, BRAKE LINE TEE 플러그
23.921	LINE, RESERVOIR OUTLET 라인
23.941	LINE, BRAKE CYLINDER (LH) 라인
23.943	LINE, BRAKE CYLINDER LINE (RH) 라인
24.373	ADHESIVE, BRAKE FITTING MOUNTING TO COWL 접착제
37.906	PLATE, COWL 플레이트
97.009	FASTENER, COWL PLATE 패스너
97.054	FASTENER, ADHESIVE TIE MOUNTING 패스너



- | | |
|--------|---|
| 13.101 | PLATE, BRAKE LOCK ACTUATING SWITCH
플레이트 |
| 22.045 | BRACKET, PARKING BRAKE PEDAL PIVOT MTG
브라켓 |
| 22.263 | RETAINER, PARKING BRAKE RELEASE LEVER PIVOT
리테이너 |
| 22.264 | ADJUSTOR, PARKING BRAKE
어드저스터 |
| 22.442 | PAD, PARKING BRAKE PEDAL
패드 |
| 22.853 | SWITCH, PARKING BRAKE PEDAL ACTUATING
스위치 |
| 22.854 | FASTENER, PARKING BRAKE PEDAL ACTUATING
패스너 |
| 22.855 | PIVOT, PARKING BRAKE PEDAL
피봇 |
| 22.856 | RETAINER, PARKING BRAKE PEDAL PIVOT
리테이너 |

22.860	PEDAL, PARKING BRAKE 페달
22.895	FASTENER, PARKING BRAKE PEDAL PIVOT RETAINER 패스너
23.264	BRAKE ASSEMBLY, PARKING 브레이크
23.269	FASTENER, PARKING BRAKE LEVER 패스너
23.284	FASTENER, PARKING BRAKE CABLE BRACKET 패스너
23.410	BEARING, PARKING BRAKE CAM ROLLER 베어링
23.481	LEVER, PARKING BRAKE RELEASE 레버
23.482	SPRING, PARKING BRAKE RELEASE LEVER 스프링
23.483	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
23.489	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
23.571	BUMPER, PARKING BRAKE LEVER 범퍼
23.638	ANCHOR, PARKING BRAKE CABLE 앵커
23.639	FASTENER, PARKING BRAKE CABLE ANCHOR 패스너
23.767	SPRING, PARKING BRAKE DRAW 스프링
23.851	LINK, PARKING BRAKE 링크
23.918	FASTENER, PARKING BRAKE PEDAL PIVOT BRACKET 패스너
23.959	FASTENER, PARKING BRAKE RELEASE VALVE 패스너
92.855	NUT, PARKING BRAKE FASTENER 너트

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEER COLUMN & GEAR MOUNTING

25-050


- | | |
|--------|--|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 06.101 | LEVER ASSEMBLY, FORWARD & REVERSE
레버 |
| 13.110 | SWITCH, DIRECTIONAL CONTROL (FORWARD)
스위치 |
| 13.111 | FASTENER, DIRECTIONAL CONTROL SWITCH
패스너 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 13.655 | SWITCH, TURN INDICATOR
스위치 |
| 13.656 | BRACKET, TURN INDICATOR SWITCH
브라켓 |
| 25.034 | FASTENER, STEERING GEAR ATTACHING
패스너 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |

25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
40.002	LEGEND, SHIFT PATTERN 범례
40.069	DECAL, FORWARD-BACKWARD 데칼
44.250	DIRECTIONAL CONTROL ASSEMBLY 방향컨트롤
44.251	HOUSING, DIRECTIONAL CONTROL ASSEMBLY 하우징
44.252	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING 커버
44.254	FASTENER, DIRECTIONAL CONTROL ASSY HOUSING COVER 패스너
44.255	SEAL, DIRECTIONAL CONTROL ASSY LEVER 씰
44.356	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING REAR 커버
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
60.686	RING, HORN CONTACT 링
60.773	HARNESS, TURN SIGNAL 하네스
60.951	GROMMET, TURN INDICATOR SWITCH 그로멧
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링
96.000	FASTENER, TURN INDICATOR SWITCH 패스너

ASSEMBLY
COMPLETE — 25.150

SEAL KIT
INCLUDES ITEMS
MARKED "K" — 25.109


NEEDLE BEARING KIT
INCLUDES ITEMS
MARKED "R" — 25.972



STEERING UNIT

25-076


- | | |
|--------|-------------------------------------|
| 25.109 | KIT, STEER GEAR SEAL
키트 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |
| 25.972 | BEARING KIT, STEERING GEAR
베어링키트 |



25.010	JACKET, STEERING COLUMN 자켓
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.130	FASTENER, DIRECTIONAL ASSEMBLY 패스너
25.137	KEY, DIRECTIONAL ASSEMBLY 키
25.141	SHAFT, STEERING GEAR 샤프트
25.312	UNIVERSAL JOINT, STEER 유니버설조인트
25.315	FASTENER, STEERING U-JOINT CLAMPING 패스너
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼

25.771	SHAFT, STEERING COLUMN (TILT) 샤프트
25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.841	BUSHING, STEERING GEAR SHAFT 부싱
25.933	FASTENER, STEERING COLUMN 패스너
25.991	PIN, STEERING UNIVERSAL JOINT 핀
37.344	SPRING, STEERING COLUMN TILTING 스프링







14.060	WIRE, HORN BUTTON TERM TO CONNECTOR 와이어
25.002	HORN BUTTON KIT 혼버튼키트
25.003	NUT, HANDWHEEL 너트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.190	FASTENER, HORN BUTTON 패스너
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.221	FASTENER, STEERING SPINNER KNOB 패스너
25.222	CAP, STEERING SPINNER KNOB 캡
25.778	WIRE, CONTACT HORN 와이어

25.779	CONTACT, HORN 컨택트
25.780	HORN BUTTON 혼버튼
90.453	WASHER, STEERING SPINNER KNOB FASTENER 와셔
96.358	WASHER, STEERING HANDWHEEL SPINNER KNOB FASTENER 와셔
96.695	FASTENER, WIRE MOUNTING 패스너
96.756	WASHER, WIRE MOUNTING FASTENER 와셔






28.259	FITTING, SUMP RETURN LINE 피팅
28.506	LINE, SUMP RETURN 라인
29.048	PIPE, HYDRAULIC FILTER 파이프
31.208	FITTING, MAIN VALVE LIFT PORT (LOWER) 피팅
31.387	CLAMP, MAIN VALVE TO SUMP LINE 클램프
31.445	FITTING, MAIN VALVE TO FILTER LINE 피팅
31.595	CLAMP, SUMP RETURN LINE FITTING 클램프
31.827	LINE, FILTER INLET 라인



STEER AXLE MOUNTING


26-219

- | | |
|--------|--|
| 26.100 | AXLE ASSEMBLY, STEERING
스티어액슬 |
| 26.147 | WASHER, STEER AXLE PIVOT PIN THRUST
와셔 |
| 26.151 | BUSHING, STEER AXLE TO SUPPORT
부싱 |
| 26.153 | FITTING, STEER AXLE TO FRAME LUBRICATION
피팅 |
| 26.175 | FASTENER, SILENT BLOCK TO FRAME (REAR)
패스너 |
| 38.047 | BRACKET, STEER AXLE MOUNTING
브라켓 |




25.391	BEARING, STEERING ARM 베어링
26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.086	FASTENER, STEERING CYLINDER ANCHOR END 패스너
26.100	AXLE ASSEMBLY, STEERING 스티어 액슬
26.119	AXLE, STEER 액슬
26.125	PIN, STEER AXLE KNUCKLE 핀
26.126	ARM, RH STEERING 암
26.129	FITTING - LUB, STEER AXLE KNUCKLE 피팅
26.132	KNUCKLE, STEER AXLE (RH) 너트

26.136	HUB & CUP, STEER WHEEL 허브& 컵
26.141	FASTENER, STEER WHEEL HUB 패스너
26.142	PIN KIT, STEER AXLE KNUCKLE 핀키트
26.143	CAP, STEER WHEEL HUB 캡
26.190	SEAL, STEER AXLE KNUCKLE OIL 씰
26.239	SEAL, STEER AXLE FORK COVER 씰
26.290	RETAINER, STEER AXLE KNUCKLE PIN LOWER BEARING 리테이너
26.337	LOCATOR, STEER AXLE KNUCKLE PIN 로케이터
26.347	PIN, STEER ARM 핀
26.348	LOCATOR, STEER CYLINDER 로케이터
26.380	CUP, STEER AXLE KNUCKLE PIN 컵
26.381	CONE, STEER AXLE KNUCKLE 콘
93.793	WASHER, STEERING ARM PIVOT FASTENER 와셔
94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너
94.854	COTTER, STEER AXLE KNUCKLE PIN FASTENER 커터
94.855	RETAINER, STEERING ARM PIN 리테이너



26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.003	SEAL KIT, PISTON ROD 씰키트
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 스티어실린더피스톤
26.093	GLAND, STEERING CYLINDER 그랜드
26.099	BUSHING, STEERING CYLINDER GLAND 부싱




STEERING LINES

26-309

28.052	FITTING, STEERING GEAR 피팅
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.759	FITTING, STEER VALVE OUTLET PORT 피팅
31.479	CLAMP, STEERING LINES 클램프
31.664	LINE, STEERING CYLINDER ANCHOR PORT 라인
31.665	FITTING, STEERING CYLINDER ANCHOR PORT 피팅
31.668	LINE, STEERING CYLINDER ROD PORT 라인
31.779	CLAMP, POWER STEERING LINES 클램프

31.793	CLAMP, POWER STEERING LINES 클램프
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너






29.001	GASKET SET, HYDRAULIC OIL FILTER 가스켓세트
29.012	SEAL, HYDRAULIC OIL FILTER BODY 씰
29.738	FILTER ASSEMBLY, HYDRAULIC SUMP 필터
29.739	FASTENER, HYDRAULIC SUMP FILTER 패스너
29.740	CARTRIDGE KIT, SUMP FILTER GASKET 카트리지키트
29.743	GASKET, HYDRAULIC SUMP FILTER 가스켓
29.745	COVER, HYDRAULIC SUMP FILTER INLET 커버
29.757	SEAL, HYDRAULIC SUMP FILTER INLET COVER 씰
29.799	ELEMENT, SUMP BREATHER 엘리먼트

29.803	GUARD, SUMP FILLER 가드
29.830	ADAPTOR, HYDRAULIC FILTER MTG 어댑터


ФОРКЛИФТ
www.forklift.ru



HYDRAULIC PUMP MOUNTING

29-230


- | | |
|--------|--|
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.106 | FASTENER, PUMP TO PLATE
패스너 |
| 29.146 | GASKET & SEAL KIT, PUMP
가스켓& 씬 |
| 29.150 | GASKET, HYDRAULIC PUMP MOUNTING
가스켓 |




29.386	LINE, SUMP BREATHER 라인
29.605	FILTER, AIR BREATHER 필터
29.738	FILTER ASSEMBLY, HYDRAULIC SUMP 필터
29.766	COVER, SUMP TANK 커버
29.767	SEAL, SUMP TANK COVER 셀
29.768	FASTENER, SUMP TANK COVER 패스너
29.786	FASTENER, SUMP BREATHER 패스너
29.788	BREATHER, SUMP 브리더
29.798	SCREEN, HYDRAULIC SUMP PRE FILTER 스크린

29.809	DIPSTICK, SUMP LEVEL 딤스틱
29.859	SEAL, DIPSTICK SUMP LEVEL ADAPTOR 셀
31.163	CLAMP, SUMP RETURN LINE 클램프
31.825	LINE, FILTER INLET 라인
31.826	CLAMP, FILTER INLET LINE 클램프





30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.063	PLUG, INLET SECTION PRESSURE PORT 플러그
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 셀킷
30.753	SPOOL SEAL KIT 스풀셀킷
31.613	TIE STUD KIT, HYDRAULIC VALVE 타이스터드킷
49.076	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 셀
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션




30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.063	PLUG, INLET SECTION PRESSURE PORT 플러그
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 셀킷
30.753	SPOOL SEAL KIT 스풀셀킷
31.613	TIE STUD KIT, HYDRAULIC VALVE 타이스터드킷
49.076	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 셀
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션

49.179

AUX SECTION, HYDRAULIC VALVE
보조섹션

ФОРКЛИФТ
www.forklift.ru




30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.063	PLUG, INLET SECTION PRESSURE PORT 플러그
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 셀킷
30.753	SPOOL SEAL KIT 스풀셀킷
31.613	TIE STUD KIT, HYDRAULIC VALVE 타이스터드킷
49.076	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 셀
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션

- | | |
|--------|--------------------------------------|
| 49.115 | AUX SECTION, HYDRAULIC VALVE
보조섹션 |
| 49.179 | AUX SECTION, HYDRAULIC VALVE
보조섹션 |



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE





HYDRAULIC VALVE MOUNTING (2 SPOOL)

30-209

30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너
30.442	SPACER, CONTROL LEVERS 스페이서


30.787	BOOT, VALVE CONTROL LEVER 부트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드






30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너
30.442	SPACER, CONTROL LEVERS 스페이서


30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.083	CAP, VALVE CONTROL LEVER DECAL 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드





30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너

30.642	CAP, AUXILIARY VALVE SPOOL 캡
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.083	CAP, VALVE CONTROL LEVER DECAL 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드




HYDRAULIC LIFT & TILT LINES

31-128

31.030	LINE, VALVE TO LIFT CYLINDER 라인
31.061	FITTING, VALVE TILT PORT "A" 피팅
31.062	FITTING, VALVE TILT PORT "B" 피팅
31.072	LINE, RH TILT CYLINDER ROD PORT 라인
31.077	FITTING, LH TILT CYLINDER ROD PORT 피팅
31.083	LINE, RH TILT CYLINDER ANCHOR PORT 라인
31.160	FITTING, LH TILT CYLINDER ANCHOR PORT 피팅
31.162	FITTING, RH TILT CYLINDER ANCHOR PORT 피팅
31.175	LINE, VALVE TILT PORT "B" 라인

31.182	LINE, VALVE TILT PORT "A" 라인
31.200	FITTING, MAIN VALVE LIFT PORT 피팅
31.600	FITTING, RH TILT CYLINDER ROD PORT 피팅

ФОРКЛИФТ
www.forklift.ru




TILT LIMIT WITH OVERRIDE

31-130

13.323	FASTENER, WARNING BUZZER 패스너
13.471	BUZZER, WARNING 부저
13.624	BRACKET, TILT LIMIT SWITCH 브라켓
13.625	FASTENER, TILT LIMIT SWITCH 패스너
15.083	CONDUCTOR, TILT LIMIT DEVICE FEED 컨덕터
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.136	RELAY, TILT LIMIT DEVICE 릴레이
32.147	WASHER, TILT LIMIT FASTENER 와셔
32.157	SWITCH, TILT LIMIT 스위치


32.158	BRACKET, TILT LIMIT SWITCH 브라켓
32.159	RETAINER, TILT LIMIT SWITCH BRACKET 리테이너
96.784	WASHER, TILT LIMIT SWITCH FASTENER 와셔







28.055	FITTING, STEERING GEAR 피팅
28.210	FITTING, MAIN VALVE INLET LINE 피팅
28.291	FITTING, PUMP OUTLET 피팅
28.397	FITTING, STEERING GEAR LINE 피팅
28.493	LINE, PRESSURE SENSING 라인
28.847	LINE, MAIN VALVE INLET 라인
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프

31.008	FITTING, PUMP INLET 피팅
31.014	FITTING, PUMP OUTLET 피팅
31.018	LINE, PUMP OUTLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.422	LINE, PUMP OUTLET (COVER END) 라인
31.448	FITTING, PUMP OUTLET LINE 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
31.947	FITTING, PRIORITY VALVE 피팅
33.000	VALVE ASSEMBLY, FLOW CONTROL 밸브
95.090	FASTENER, HYDRAULIC PRIORITY VALVE 패스너





32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드 & 피스톤
32.072	PACKING KIT, TILT CYLINDER 패킹키트




32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.030	PIN, TILT CYLINDER TO UPRIGHT 핀
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링

32.053	BEARING, TILT CYLINDER ROD END 베어링
97.214	FASTENER, TILT CYLINDER TO FRAME PIN 패스너
97.224	FASTENER, TILT CYLINDER TO UPRIGHT PIN 패스너




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT AMOUNT GP

32-167

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심




32.800	ACCUMULATOR, HYDRAULIC 어큐물레이터
32.801	CLAMP, HYDRAULIC ACCUMULATOR MOUNTING 클램프
32.802	BRACKET, HYDRAULIC ACCUMULATOR 브라켓
32.805	SEAL, HYDRAULIC ACCUMULATOR CONNECTOR 씰
32.806	CONNECTOR, HYDRAULIC ACCUMULATOR 커넥터
32.810	LINE, HYDRAULIC ACCUMULATOR 라인
32.814	FITTING, HYDRAULIC ACCUMULATOR LINE 피팅
32.841	NUT, HYDRAULIC ACCUMULATOR FITTING 너트
32.842	SEAL, HYDRAULIC ACCUMULATOR FITTING 씰


75.029

HYDRAULIC ACCUMULATOR INSTALLATION
유압어큐플레이터







33.000	VALVE ASSEMBLY, FLOW CONTROL 밸브
33.001	SPRING, FLOW CONTROL VALVE 스프링
33.008	PLUG, FLOW VALVE 플러그
33.010	SEAL, FLOW VALVE PORT PLUG 씰
33.011	PLUG, FLOW VALVE PORT 플러그
33.012	SEAL, FLOW CONTROL VALVE SPRING PLUG 씰



- 33.600 RELIEF VALVE, DEVICE VARIABLE PRESSURE
릴리프밸브
- 33.601 LEVER, DEVICE VARIABLE RELIEF VALVE
레버
- 33.610 SEAL, DEVICE PRESS RELIEF VAL CHECK PORT PLUG
씰
- 33.613 SEAL, DEVICE RELIEF VALVE PISTON ADJ END
씰
- 33.618 CARTRIDGE KIT, DEVICE VARIABLE RELIEF VALVE
카트리지키트
- 33.631 FASTENER, DEVICE RELIEF VALVE
패스너




- 33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
밸브
- 33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너
- 33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
씰키트
- 33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어키트




34.998 FASTENER, LOAD SAFETY BACK REST
패스너


66.431 RETAINER, LBR CAPSCREW
리테이너



34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.037	CAP, UPRIGHT TRUNNION 캡
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너
34.039	FITTING-LUB, UPRIGHT TRUNNION 피팅
34.220	FASTENER, UPRIGHT TRUNNION CAP DOWEL 패스너
66.167	SHIM, LIFT CYLINDER UPPER 심




34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.328	ROLLER, CARRIAGE CAPTIVE 롤러
34.329	RETAINER, CARRIAGE CAPTIVE ROLLER 리테이너
34.330	FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER 패스너
34.332	SHIM, CARRIAGE CAPTIVE ROLLER 심
34.340	CARRIAGE WELDED ASSEMBLY 캐리지용 접합물



OVERHEAD GUARD COVER

37-003

38.243 COVER ASSEMBLY, OVERHEAD GUARD TOP
커버




COWL MOUNTING

37-029

37.748	DAMPENER, COWL VIBRATION 댐프너
39.546	COWL ASSEMBLY 카울
39.547	FASTENER, COWL ASSEMBLY 패스너
96.307	FASTENER, COWL PLATE 패스너
96.317	FASTENER, COWL PLATE SOUND SEAL 패스너


ASSEMBLY
COMPLETE 37.300



REAR WIPER INSTALLATION

37-050

37.300	CAB ASSEMBLY 캐빈
37.454	NOZZLE, REAR WINDOW GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
39.230	MOTOR, REAR WINDOW WIPER 모터
39.233	ARM, REAR WINDOW WIPER 암
39.234	BLADE, REAR WINDOW WIPER 블레이드




37.799	LATCH, CAB DOOR WINDOW ASSEMBLY 래치
39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
39.298	CHANNEL, FRONT DOOR GLASS - FRONT 채널
39.347	FASTENER, CAB REAR WINDOW LATCH 패스너
39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우
47.303	GLASS, CAB DOOR (FRONT) 글래스
47.304	GLASS, CAB DOOR (REAR) 글래스
47.307	CHANNEL, CAB SIDE DOOR WINDOW 채널

ASSEMBLY
COMPLETE — 37.300

SIDE DOOR
ASSEMBLY COMPLETE — 39.152LH
39.131RH

NOTE :
ITEMS TO BE NOT SOLD
SEPARATELY MARKED "NSS"

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



ENCLOSED CAB


37-056

37.300	CAB ASSEMBLY 캐빈	39.144	HANDLE, RH DOOR OUTSIDE 핸들
37.551	HANGER, CAB REAR GLASS 행거	39.145	FASTENER, RH DOOR HANDLE 패스너
37.559	PIN, CABIN REAR GLASS HANGER 핀	39.147	FASTENER, RIGHT HAND DOOR LATCH 패스너
37.560	RETAINER, CAB REAR GLASS HANGER PIN 리테이너	39.152	DOOR ASSEMBLY, LEFT HAND 도어
37.679	HANDLE, RH DOOR INSIDE 핸들	39.192	GLASS, RIGHT HAND DOOR (LOWER) 글래스
37.689	SEAL, DOOR OUTSIDE HANDLE 씰	39.193	WEATHERSEAL, RH DOOR GLASS (LOWER) 웨더씰
37.691	SEAL, DOOR OUTSIDE HANDLE 씰	39.228	WEATHERSEAL, WINDSHIELD SETTING 웨더씰
39.101	GLASS, WINDSHIELD 글래스	39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
39.102	WEATHERSEAL, WINDSHIELD SETTING 웨더씰	39.280	GLASS, REAR WINDOW - MOVEABLE 글래스
39.109	GLASS, REAR 글래스	39.318	PANEL, REAR LOWER 판넬
39.110	WEATHERSEAL, REAR GLASS SETTING 웨더씰	39.319	FASTENER, LOWER REAR PANEL 패스너
39.117	ROOF SCREEN 루프스크린	39.339	FASTENER, RH DOOR INSIDE HANDLE 패스너
39.119	SEAL STRIP, ROOF WINDOW 씰스트립	39.344	WEATHERSEAL, RH DOOR WINDOW ASSEMBLY 웨더씰
39.131	DOOR ASSEMBLY, RIGHT HAND 도어	39.349	WEATHERSEAL, CAB REAR WINDOW 웨더씰
39.138	WEATHERSEAL, RIGHT HAND DOOR 웨더씰	39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우

47.144	LATCH, RH DOOR INSIDE 래치
47.145	LATCH, LH DOOR INSIDE 래치
47.269	BRACKET, CAB REAR GLASS GAS SPRING SUPPORT 브라켓
47.270	RUBBER, CAB REAR GLASS GAS SPRING MOUNTING 러버
47.271	RUBBER, CAB REAR GLASS GAS SPRING MOUNTING 러버
47.272	BRACKET, CAB REAR GLASS GAS SPRING MOUNTING 브라켓
47.274	HANDLE, CAB REAR GLASS 핸들
47.371	CAP, CAB REAR GLASS GAS SPRING MOUNTING FASTENER 캡
47.373	SHOCK ABSORBER, CAB REAR GLASS 쇼크업쇼버
47.375	BRACKET, CAB REAR GLASS HANGER 브라켓
47.378	SUPPORT, CAB DOOR INSIDE LATCH 서포트
95.358	FASTENER, REAR GLASS HANGER 패스너
96.877	FASTENER, DOOR INSIDE LATCH STRIKER 패스너
97.063	FASTENER, REAR DOOR HANDLE MOUNTING 패스너
97.171	FASTENER, CAB REAR GLASS GAS SPRING MOUNTING 패스너



ASSEMBLY
COMPLETE — 39.689




BACK MIRROR

37-076

39.184 FASTENER, REAR VIEW MIRROR
패스너


39.689 MIRROR, REAR VIEW
미러



OVERHEAD GUARD MOUNTING

37-083


37.048	FASTENER, OVERHEAD GUARD BUMPER 패스너
37.214	PLUG-BUTTON 플러그
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.401	WEATHERSTRIP, OVERHEAD GUARD REAR SUPPORT 웨더스트립



SEAT ARMREST ASSEMBLY

37-124



- | | |
|--------|---------------------------------------|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |



COUNTWEIGHT MOUNTING

38-247


38.083	FASTENER, DRIVE AXLE SUPPORT CAP 패스너
38.234	CAP, FRAME TRUNNION 캡
38.869	COUNTERWEIGHT 카운터웨이트
38.870	FASTENER, COUNTERWEIGHT (LOWER) 패스너
38.920	PIN, COUPLER 핀
38.921	PIN, COUPLER PIN CROSS 핀



FRAME TANK BOTTOM PLUG

38-270


- | | |
|--------|---------------------------------------|
| 38.246 | PLUG, FRAME BOTTOM MAGNETIC
플러그 |
| 38.280 | SEAL, FRAME BOTTOM MAGNETIC PLUG
씰 |



LEAD WIRE GROUND


39-012

60.908 WIRE, LEAD GROUND
와이어



13.228	LAMP ASSEMBLY, DOME 램프
13.229	BULB, DOME LAMP 전구
13.233	FASTENER, DOME LAMP 패스너
15.430	GROMMET, CABIN WIRING HARNESS 그로멧
37.300	CAB ASSEMBLY 캐빈
37.437	PUMP & TANK, WINDSHIELD WASHER 펌프& 탱크
37.461	NOZZLE, WINDSHIELD GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
37.624	SPEAKER, CABIN 스피커


37.636	COVERING, CAB INSIDE ROOF 커버링
37.759	GROMMET, COVER WINDSHIELD WIPER MOTOR 그로멧
37.818	BRACKET, WINDSHIELD WASHER TANK 브라켓
39.178	SWITCH, WINDSHIELD WIPER 스위치
39.200	MOTOR, WINDSHIELD WIPER 모터
39.203	ARM, WINDSHIELD WIPER 암
39.204	BLADE, WINDSHIELD WIPER 블레이드
41.404	ANTENNA, AUDIO 안테나
47.260	SWITCH ASSY, CABIN 스위치
60.292	COVER, CAB SWITCH PANEL 커버
60.297	SWITCH, WINDSHIELD WASHER 스위치
60.299	SWITCH, HEATER ON/OFF 스위치
60.330	WIRING HARNESS, CAB 와이어하네스
60.746	PROTECTION, HARNESS 보호장치
94.497	FASTENER, WINDSHIELD WASHER TANK 패스너
94.570	FASTENER, CAB SWITCH PANEL COVER 패스너
95.302	FASTENER, LOUDSPEAKER 패스너
96.695	FASTENER, WIRE MOUNTING 패스너




LOAD BACK REST

39-519

- | | |
|--------|---|
| 34.977 | RETAINER, LOAD BACK REST TRUNNION PIN
리테이너 |
| 34.991 | FASTENER, LOAD SAFETY BACK REST EXT
패스너 |
| 34.995 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 92.226 | NUT, LOAD SAFETY BACK REST FASTENER
너트 |





37.300	CAB ASSEMBLY 캐빈
41.402	COVER, AUDIO AND TRANSCEIVER MOUNTING BOX 커버
41.407	AUDIO 오디오
41.411	BRACKET, AUDIO AND TRANSCEIVER BOX MOUNTING 브라켓
47.245	MANUAL, CASSETTE 매뉴얼
95.305	FASTENER, AUDIO AND TRANSCEIVER BOX TO MOUNTING BR 패스너



37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.531	BRACKET, SEAT SAFETY BELT MOUNTING 브라켓
37.720	COVER, OPERATOR SEAT LATERAL RESTRAINT 커버
37.743	COVER, SEAT SUPPORT LATCH 커버
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너






FLOOR PLATE MOUNTING

39-674

- | | |
|--------|----------------------------|
| 37.902 | MAT, FLOORPLATE
매트 |
| 39.475 | PLATE, FRONT FLOOR
플레이트 |


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




SEAT MOUNTING

39-829

39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔




37.300	CAB ASSEMBLY 캐빈
37.663	PLUG, CAB FRAME 플러그
39.101	GLASS, WINDSHIELD 글래스
39.102	WEATHERSEAL, WINDSHIELD SETTING 웨더셀
39.117	ROOF SCREEN 루프스크린
39.119	SEAL STRIP, ROOF WINDOW 셀스트립
39.228	WEATHERSEAL, WINDSHIELD SETTING 웨더셀




37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.915	SUSPENSION COVER, SEAT SUSPENSION 서스펜션커버
37.918	SUSPENSION ASSEMBLY, SEAT 서스펜션
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션
39.721	CUSHION, SEAT BACK REST 쿠션

39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너



ASSEMBLY
COMPLETE — 39.500




POD INSTALLATION

39-969

- | | |
|--------|----------------------------------|
| 13.000 | PANEL, INSTRUMENT CLUSTER
판넬 |
| 37.250 | HOUSING, INSTRUMENT PANEL
하우징 |
| 39.510 | HOUSING, INSTRUMENT PANEL
하우징 |


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



CAB MOUNTING

39-976


37.048	FASTENER, OVERHEAD GUARD BUMPER 패스너
37.214	PLUG-BUTTON 플러그
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.300	CAB ASSEMBLY 캐빈
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.003	COVER, RADIATOR 커버



OVERHEAD GUARD MOUNTING


39-977

37.048	FASTENER, OVERHEAD GUARD BUMPER 패스너
37.214	PLUG-BUTTON 플러그
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너



37.312	STOP, TOP HOOD 스톱
37.352	BRACKET, TOP HOOD SPRING (RH) 브라켓
37.362	BRACKET, TOP HOOD SPRING (LH) 브라켓
37.934	SEAL, HOOD ACCESS COVER 씰
38.001	BRACKET, HOOD SUPPORT 브라켓
39.535	BRACKET, TOP HOOD MOUNTING 브라켓
39.594	HOOD, TOP 후드
39.595	FASTENER, TOP HOOD 패스너
39.641	PLATE, TOP HOOD LATCH MOUNTING 플레이트

39.643	CATCH, TOP HOOD LATCH 캐치
39.644	LATCH, TOP HOOD 래치
39.648	FASTENER, TOP HOOD LATCH CATCH 패스너
39.662	FASTENER, TOP HOOD LATCH BRACKET 패스너
39.701	STOP, HOOD PROP 스톱
39.702	PROP, HOOD 지지대
39.705	FASTENER, HOOD PROP 패스너
39.944	FASTENER, OVERHEAD GUARD BRACKET 패스너
41.104	SOUND SEAL, RH SIDE HOOD 사운드씰
41.105	SOUND SEAL, LH SIDE HOOD 사운드씰
41.251	SOUND SEAL, TOP HOOD 사운드씰
41.602	SOUND SEAL, ENGINE HOOD 사운드씰
41.603	SOUND SEAL, ENGINE HOOD 사운드씰
47.074	FASTENER, TOP HOOD SPRING BRACKET 패스너
93.399	FASTENER, TOP HOOD STOP 패스너
94.763	FASTENER, HOOD SUPPORT 패스너





SHEET METAL & TRIM

39-983

37.108	SHIELD, RH REAR 실드
37.200	PANEL, FRONT 판넬
37.201	PANEL, LH SIDE 판넬
37.202	PANEL, RH SIDE 판넬
38.016	SHIELD, LH REAR 실드
38.049	STEP ASSEMBLY, RH 스텝
38.050	STEP ASSEMBLY, LH 스텝
38.052	FASTENER, STEP FRONT 패스너
39.545	FASTENER, COWL ACCESS HOLE COVER 패스너

39.570	COVER ASSEMBLY, DASH 커버
39.571	FASTENER, DASH COVER 패스너
39.860	BRACKET, RADIATOR BAFFLE MOUNTING 브라켓
47.003	COVER, RADIATOR 커버
47.004	SEAL, RADIATOR COVER 씰
47.251	GROMMET, RADIATOR COVER 그로멧
91.977	FASTENER, REAR SHIELD 패스너
94.743	FASTENER, RADIATOR COVER TRIM 패스너






40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트	40.158	DECAL, WARNING INDICATOR 데칼
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너	40.206	DECAL, SLING EYE 데칼
40.010	DECAL, CLARK 데칼	40.236	DECAL, FUEL 데칼
40.012	DECAL, CLARK LOGO-SMALL 데칼	40.240	DECAL, FUEL WARNING 데칼
40.024	PLATE, UNDERWRITERS LABEL 플레이트	40.241	DECAL, BRAKE OIL SPEC 데칼
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너	40.247	DECAL, LPG FUEL CYL REPLACEMENT PROCEDURE 데칼
40.030	DECAL, CLARK VERTICAL 데칼	40.248	DECAL, SERVICE CHART 데칼
40.062	DECAL, DRIVERS CAUTION 데칼	40.260	DECAL, HOT SURFACE WARNING 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼	40.271	DECAL, LP GAS 데칼
40.089	PLATE, SAFETY INSTRUCTION 플레이트	40.279	DECAL, STARTING PROCEDURE 데칼
40.130	LEGEND, SAFETY 범례	40.310	DECAL, EXHAUST GAS 데칼
40.131	LEGEND, SAFETY 범례	40.327	DECAL, FAN WARNING 데칼
40.134	DECAL, OPERATORS MANUAL LOCATION 데칼	40.328	DECAL, WHEEL NUT WARNING 데칼
40.138	DECAL, SAFETY 데칼	40.333	REFLECTOR, COUNTERWEIGHT 리플렉터
40.143	DECAL, OPERATORS INSTRUCTIONS 데칼	40.344	REFLECTOR, COUNTERWEIGHT LOWER 리플렉터

40.346	DECAL, OVERHEAD GUARD DROP TEST 데칼
40.349	PLATE, LESS LP TANK 플레이트
40.350	FASTENER, PLATE LESS LP TANK 패스너
40.352	DECAL, USE LOW SULFUR FUEL 데칼
40.353	DECAL, AUTHORIZED REPRESENTATIVE 데칼






MODEL & SPECIFICATION DECALS

40-285


40.014	DECAL, MODEL NAME 데칼
40.268	DECAL, SPEC 데칼
40.296	DECAL, TIRE PRESSURE 데칼
40.311	DECAL, SOUND POWER LEVEL 데칼



STORAGE CONSOLE MOUNTING

41-008

- | | |
|--------|--|
| 41.026 | FASTENER, STORAGE CONSOLE DOCUMENT CLIP
패스너 |
| 41.027 | CLIP, STORAGE CONSOLE DOCUMENT
클립 |
| 41.028 | CONSOLE, OPERATOR STORAGE CONSOLE
콘솔 |
| 41.030 | FASTENER, STORAGE CONSOLE
패스너 |




41.039	GROMMET, HEATER LINE 그로멧
41.050	HEATER ASSEMBLY 히터
41.057	LINE, HEATER INLET 라인
41.058	CLAMP, HEATER INLET LINE 클램프
41.061	LINE, HEATER OUTLET 라인
41.062	CLAMP, HEATER OUTLET LINE 클램프
41.464	BRACKET, HEATER 브라켓
41.606	SLEEVE, HEATER HOSE 슬리브
41.607	GUARD, HEATER HOSE 가드

96.055 FASTENER, HEATER MOUNTING BRACKET
패스너



SEAT SAFETY
WING KIT


37.970




SEAT WING KIT

47-000

- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 37.970 | KIT, SEAT SAFETY
키트 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |




- | | |
|--------|---|
| 37.421 | GROMMET, OVERHEAD GUARD REAR SUPPORT PIVOT
그로멧 |
| 47.385 | GRIP, OVERHEAD GUARD REAR HAND
그립 |
| 60.968 | WIRE, OVERHEAD GUARD REAR HAND GRIP SWITCH
와이어 |
| 97.216 | FASTENER, OVERHEAD GUARD REAR HAND GRIP
패스너 |



50.009	SHEAVE, DEVICE HOSE LOWER шнёр
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING сальник
50.132	BRACKET, DEVICE HOSE REEL крюк
50.156	CLIP, DEVICE HOSE зажим
50.200	COUPLING, DEVICE HOSE соединитель
50.215	TERMINAL BLOCK, DEVICE HOSE терминальный блок
50.295	ROLLER, DEVICE HOSE UPPER ролик
50.298	BRACKET, DEVICE HOSE TERMINAL крюк
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK винт

50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-781

50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.156	CLIP, DEVICE HOSE 클립	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.200	COUPLING, DEVICE HOSE 커플링	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.112	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
50.811	NUT, DEVICE HOSE FITTING 너트	95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너


96.316 FASTENER, DEVICE HOSE REEL
패스너






50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅

50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너

50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-784

50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.156	CLIP, DEVICE HOSE 클립	50.811	NUT, DEVICE HOSE FITTING 너트
50.200	COUPLING, DEVICE HOSE 커플링	50.826	TERMINAL, DEVICE CABLE 터미널
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.686	WIRE, DEVICE 와이어	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터	93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너

93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너






50-785

50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.686	WIRE, DEVICE 와이어
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.156	CLIP, DEVICE HOSE 클립	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.200	COUPLING, DEVICE HOSE 커플링	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.811	NUT, DEVICE HOSE FITTING 너트
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.826	TERMINAL, DEVICE CABLE 터미널
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.382	ROLLER, DEVICE HOSE 롤러	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링	59.112	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인


59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-786

50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.200	COUPLING, DEVICE HOSE 커플링	59.072	GUARD, DEVICE HOSE 가드
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.316	GUARD, DEVICE RH HOSE 가드	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.811	NUT, DEVICE HOSE FITTING 너트	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록	95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓	96.316	FASTENER, DEVICE HOSE REEL 패스너
59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브	97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-787


50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.200	COUPLING, DEVICE HOSE 커플링	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.316	GUARD, DEVICE RH HOSE 가드	59.112	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.811	NUT, DEVICE HOSE FITTING 너트	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너

95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너







**MODEL: GTX162
GEX162**
UPRIGHT: STANDARD




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE & HI-LO




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: STANDARD



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: STANDARD



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: HI-LO

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-791


- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-794


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-796


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링




QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION

50-798

- | | |
|--------|---|
| 59.092 | QUICK DISCONNECT, DEVICE HOSE
퀵디स्क넥트 |
| 59.131 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |
| 59.132 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |




- | | |
|--------|---|
| 59.130 | TIE STRAP, DEVICE LINE FOR HIGH TERMINATION
타이스트랩 |
| 59.134 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.140 | COUPLING, DEVICE LINE FOR HIGH TERMINATION
커플링 |
| 59.141 | COUPLING, DEVICE LINE FOR HIGH TERMINATION
커플링 |
| 59.142 | FITTING, DEVICE LINE FOR HIGH TERMINATION
피팅 |
| 59.143 | CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
캡 |
| 59.144 | BRACKET, DEVICE LINE FOR HIGH TERMINATION
브라켓 |
| 97.235 | FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION
패스너 |
| 97.238 | FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION
패스너 |



HIGH TERMINATION FOR DEVICE HOSE ADAPTATION

50-800


59.134	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.135	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.136	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.137	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.138	CLAMP, DEVICE LINE FOR HIGH TERMINATION 클램프
59.139	CLAMP, DEVICE LINE FOR HIGH TERMINATION 클램프
97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너



14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디स्क넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT 피팅
59.132	FITTING, DEVICE LINE QUICK DISCONNECT 피팅






HIGH TERMINATION FOR DEVICE HOSE ADAPTATION

50-818


- | | |
|--------|---|
| 34.340 | CARRIAGE WELDED ASSEMBLY
캐리지용접물 |
| 59.134 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |



DEVICE LINE ADAPTORS

50-819

- | | |
|--------|---|
| 59.081 | FITTING, DEVICE HOSE ADAPTOR (AT UPRIGHT)
피팅 |
| 59.082 | FITTING, DEVICE HOSE ADAPTOR (AT UPRIGHT)
피팅 |




40.343	DECAL, ATTACHMENT SAFETY 데칼
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링

54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서
54.314	SPACER, SIDE SHIFTER CYLINDER REAR 스페이서



ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹키트
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT 볼

97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
 세트스크류






52.149	NUT, SIDE SHIFTER CYLINDER ANCHOR PORT LINE FITTING 너트
53.023	ANCHOR, SIDE SHIFTER CYLINDER ROD END 앵커
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인


54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트



FORK STOP
PIN KIT — 34.359



KNOB TYPE - CASCADE




LEVER TYPE - HEBEI

FORK

66-058

- | | |
|--------|------------------------------------|
| 34.350 | FORK ASSEMBLY
포크 |
| 34.359 | KIT, FORK STOP PIN (CAPTIVE)
키트 |




LIFT CYLINDER PIPING

66-060

28.729	LINE, LIFT CYLINDER 라인
31.033	CLAMP, LIFT CYLINDER LINE TO SUPPORT 클램프
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.215	FASTENER, LIFT LINE CLAMP 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드

66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.163	PLUG, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD PO 플러그
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너





LIFT CYLINDER PIPING

66-062

28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피벗
28.729	LINE, LIFT CYLINDER 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
31.033	CLAMP, LIFT CYLINDER LINE TO SUPPORT 클램프
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.215	FASTENER, LIFT LINE CLAMP 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인

34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.139	BUSHING, LIFT CHAIN HOSE SHEAVE 부싱
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.164	FITTING, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD 피팅
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너






LIFT CYLINDER PIPING

66-065


28.741	LINE ASSY, LIFT CYLINDER 라인
28.742	LINE, LIFT CYLINDER LEFT HAND 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
28.790	FITTING, FINAL LIFT CYLINDER LINE 피팅
31.033	CLAMP, LIFT CYLINDER LINE TO SUPPORT 클램프
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.215	FASTENER, LIFT LINE CLAMP 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인

34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.163	PLUG, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD PO 플러그
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
66.250	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너

34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
94.059	NUT, LIFT CYLINDER FASTENER 너트




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.084	SHEAVE, LIFT CHAIN 쉬브
34.101	CHAIN, LIFT 체인
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트

91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커

34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.152	ANCHOR, RAIL LIFT CHAIN 앵커
34.153	SHEAVE, UPRIGHT RAIL CHAIN 쉬브
34.156	FASTENER, RAIL CHAIN TO ANCHOR 패스너
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트
91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트




34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.525	BEARING, LIFT CYLINDER ROD 베어링
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브

34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔



34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.146	SUPPORT, LIFT CYLINDER BARREL 서포트


34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트




HI-LO SECONDARY CYLINDER

66-083


66.207	PISTON, FINAL LIFT CYLINDER 피스톤
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.404	CAP, FINAL LIFT CYLINDER GLAND 캡



34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 워셔




- | | |
|--------|---|
| 66.395 | CHECK VALVE, FINAL LIFT CYLINDER
체크밸브 |
| 66.397 | WASHER, FINAL LIFT CYLINDER CHECK VALVE
와셔 |
| 66.398 | SNAP RING, FINAL LIFT CYLINDER CHECK VALVE
스냅링 |
| 66.400 | CYLINDER ASSEMBLY, FINAL LIFT
실린더 |
| 66.401 | BARREL, FINAL LIFT CYLINDER
배럴 |
| 66.402 | PACKING KIT, FINAL LIFT CYLINDER
패킹키트 |
| 66.403 | PISTON ROD, FINAL LIFT CYLINDER
피스톤로드 |
| 66.413 | SPACER, FINAL LIFT CYLINDER PISTON ROD
스페이서 |
| 66.444 | GLAND, FINAL LIFT CYLINDER
그랜드 |



34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.037	CAP, UPRIGHT TRUNNION 캡
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일


34.146	SUPPORT, LIFT CYLINDER BARREL 서포트
34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트



EXTENSION FORK


66-245

- | | |
|--------|---|
| 34.704 | EXTENSION, FORK ASSEMBLY COMPLETE
익스텐션 |
| 66.465 | PIN, EXTENSION FORK
핀 |
| 66.526 | FASTENER, EXTENSION FORK PIN
패스너 |




34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트

66.135	SPACER, SHEAVE CARRIER GUIDE 스페이서
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트




28.955	SEAL, AUXILIARY VALVE "A" PORT FITTING 씰
28.956	SEAL, AUXILIARY VALVE "B" PORT FITTING 씰
50.027	FITTING, 1ST AUXILIARY VALVE A PORT 피팅
50.028	SEAL, 1ST AUXILIARY VALVE "A" PORT FITTING 씰
50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.074	SEAL, 1ST AUX VALVE "B" PORT FITTING 씰
50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인




50.027	FITTING, 1ST AUXILIARY VALVE A PORT 피팅
50.028	SEAL, 1ST AUXILIARY VALVE "A" PORT FITTING 씰
50.057	FITTING, 2ND AUX VALVE "A" PORT 피팅
50.058	SEAL, 1ST AUX VALVE "B" PORT FITTING 씰
50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.074	SEAL, 1ST AUX VALVE "B" PORT FITTING 씰
50.075	SEAL, AUXILIARY VALVE PORT FITTING 씰
50.220	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.221	LINE, 2ND AUXILIARY VALVE "B" PORT 라인

50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인
50.862	SEAL, AUXILIARY VALVE A PORT 씰
50.867	FITTING, AUXILIARY VALVE B PORT LINE 피팅
50.869	SEAL, AUXILIARY VALVE B PORT 씰





30.956	SEAL, RELIEF VALVE PLUG 씰	33.712	COUPLING, DEVICE RELIEF VALVE DISCHARGE HOSE 커플링
33.054	PLUG, RELIEF VALVE PORT 플러그	33.713	LINE, DEVICE RELIEF VALVE DISCHARGE 라인
33.055	SEAL, RELIEF VALVE PORT PLUG 씰	33.714	COUPLING, DEVICE RELIEF VALVE DISCHARGE LINE 커플링
33.600	RELIEF VALVE, DEVICE VARIABLE PRESSURE 릴리프밸브	33.732	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.603	BRACKET, DEVICE CARIABLE RELIEF VALVE 브라켓	33.733	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.604	FASTENER, DEVICE VARIABLE RELIEF VALVE 패스너	33.900	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.617	SPACER, DEV VARIABLE RELIEF VAL BRKT 스페이서	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.661	FITTING, DEVICE RELIEF VALVE OUTLET PORT 피팅	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.701	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	33.935	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.702	LINE, DEVICE RELIEF VALVE INLET 라인	75.311	KIT, RELIEF VALVE INSTALLATION 키트
33.703	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	90.854	BOLT, DEVICE MOUNTING BRACKET FASTENER 볼트
33.706	FITTING, DEVICE RELIEF VALVE INLET PORT 피팅	90.855	LOCKWASHER, DEVICE MOUNTING BRACKET FASTENER 로크와셔
33.707	SEAL, DEVICE RELIEF VALVE INLET PORT FITTING 씰	91.221	NUT, DEV VARIABLE RELIEF VALVE FASTENER 너트
33.710	FITTING, DEVICE RELIEF VALVE DISCHARGE PORT 피팅	91.712	LOCKWASHER, DEVICE RELIEF VALVE FASTENER 로크와셔
33.711	SEAL, DEVICE RELIEF VALVE DISCHARGE PORT FTG 씰		



- | | |
|--------|--|
| 33.720 | GAUGE, DEVICE HYDRAULIC PRESSURE
게이지 |
| 33.724 | FITTING, DEVICE HYD PRESSURE GAUGE
피팅 |
| 75.301 | DEVICE, HYDRAULIC PRESSURE GAUGE
디바이스 |


ENGINE
SHUTDOWN KIT — 75.046



SEAT OPERATED BRAKE SWITCH


75-001

- | | |
|--------|--|
| 13.135 | SWITCH, SEAT SAFETY
스위치 |
| 15.483 | CLAMP, SEAT SWITCH INSTALLATION CABLE
클램프 |
| 15.646 | HARNESS, ENGINE DISCONNECT
하네스 |
| 75.046 | KIT, SEAT ACTUATED ENGINE SHUTDOWN
키트 |
| 95.916 | FASTENER, SEAT SWITCH
패스너 |
| 95.917 | NUT, SEAT SWITCH FASTENER
너트 |



15.490 HARNESS, SEAT ACTUATED ENGINE SHUTDOWN WIRING
하네스

18.087 CLIP, SEAT SAFETY SWITCH WIRE
클립



39.706	SUPPORT, SEAT 서포트
39.719	SEAT ASSEMBLY 시트
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트