


부품 매뉴얼 PARTS MANUAL

EPX16/18/20s

SERIAL NUMBER : EPX162 - XXXX - 9818 KF

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Part No. 8040124

Dec. 2013




(본사) 경기도 부천시 오정구 오정동 202-1
(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea
(공장) 경남 창원시 웅남동 40-1
(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea

02-487	ACCELERATOR PEDAL & LINKAGE 악셀레이터 페달& 링크이지	25-144	STEERING COLUMN ASSEMBLY 스티어링 컬럼 어셈블리
13-148	VALVE SWITCH WIRING 밸브 스위치 와이어링	25-146	STEERING UNIT 스티어링 유닛
13-182	STROBE LIGHT 경광등	25-365	STEERING HANDWHEEL MOUNTING 스티어링 핸드 휠 마운팅
13-194	WORK LIGHT 작업등	25-367	STEERING COLUMN MOUNTING 스티어링 컬럼 마운팅
13-224	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드& 턴시그널 라이트 조립그룹	25-368	STEERING GEAR MOUNTING 스티어링 기어 마운팅
13-265	TRAVEL ALARM INSTALLATION 주행 알람 조립그룹	26-237	STEER LINES 스티어링 라인
13-307	INSTRUMENT PANEL 계기판	26-238	STEER AXLE MOUNTING 스티어링 액슬 마운팅
13-327	REAR ACCESSORY MOUNTING 리어 액세서리 마운팅	26-239	STEER AXLE ASSEMBLY 스티어링 액슬 어셈블리
13-345	FORK HEIGHT ALARM MOUNTING 포크 높이 경고 장착	26-240	STEERING CYLINDER 스티어링 실린더
14-135	SEAT BUCKLE OPERATED 시트 버클 작동	29-239	HYDRAULIC OIL FILTER 유압 오일 필터
14-401	ELECTRICAL COMPONENTS 전기장치 구성품	29-240	SUMP TANK MOUNTING 섬프 탱크 마운팅
14-426	LICENSE PLATE MOUNTING 번호판 장착	29-296	HYDRAULIC PUMP ASSEMBLY 유압 펌프 어셈블리
14-455	ELECTRICAL WIRING 전기장치 와이어링	29-322	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
15-022	CABLE INSTALLATION 케이블 조립그룹	30-530	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
16-105	PUMP MOTOR MOUNTING 펌프 모터 마운팅	30-531	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
16-256	DRIVE MOTOR ASSEMBLY 드라이브 모터 어셈블리	30-532	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
16-257	PUMP MOTOR ASSEMBLY 펌프 모터 어셈블리	30-533	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
16-258	DRIVE MOTOR MOUNTING 드라이브 모터 어셈블리	30-534	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
17-111	LINE CONTACTOR ASSEMBLY 라인 컨택터 어셈블리	30-535	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
19-026	CONTROLLER MOUNTING 컨트롤러 마운팅	30-536	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
20-186	DRIVE AXLE & BRAKE MOUNTING 드라이브 액슬& 브레이크 마운팅	30-537	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
20-187	DRIVE AXLE ASSEMBLY 드라이브 액슬 어셈블리	30-543	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
20-188	DRIVE AXLE - RH 드라이브 액슬 - 우	30-544	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
20-189	AXLE END-RH 액슬 엔드 (우)	30-545	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
20-190	DRIVE AXLE - LH 드라이브 액슬 - 좌	30-546	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
20-191	AXLE END-LH 액슬 엔드 (좌)	30-547	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브 휠& 타이어 마운팅	30-548	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-014	STEER WHEEL & TIRE MOUNTING 스티어링 휠& 타이어 마운팅	30-549	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
22-024	DRIVE WHEEL & TIRE (SOLID TYPE) 드라이브 휠& 타이어 (솔리드 타입)	30-565	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-027	STEER WHEEL & TIRE (SOLID TYPE) 스티어링 휠& 타이어 (솔리드 타입)	30-597	HYDRAULIC CONTROL VALVE 유압 컨트롤 밸브
22-058	BRAKE ASSEMBLY 브레이크 어셈블리	30-674	HYDRAULIC CONTROL VALVE-4 SPOOL 유압 컨트롤 밸브 - 4 스풀
22-130	BRAKE ASSEMBLY 브레이크 어셈블리	31-145	AUX. VALVE PLUMBING 보조 밸브 기관
23-404	DRIVE WHEEL & TIRE MOUNTING 드라이브 휠& 타이어 마운팅	31-146	AUX. VALVE PLUMBING 보조 밸브 기관
23-429	BRAKE SYSTEM 브레이크 시스템	31-190	HYDRAULIC RETURN LINES 유압 리턴 라인
23-430	BRAKE MASTER CYLINDER 브레이크 마스터 실린더	31-232	HYDRAULIC SUPPLY LINES 유압 공급 라인
23-534	PARKING BRAKE LINKAGE 파킹 브레이크 링크이지	31-312	HYDRAULIC LIFT LINES 유압 리프트 라인

31-319	HYDRAULIC TILT LINES 유압 틸트 라인	50-782	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
31-320	HYDRAULIC SUPPLY LINES 유압 공급 라인	50-783	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
32-128	TILT CYLINDER MOUNTING 틸트 실린더 마운팅	50-784	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
32-131	TILT CYLINDER 틸트 실린더	50-786	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
32-169	TILT AMOUNT GROUP 틸트 어마운트 그룹	50-787	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
32-850	ACCUMULATOR 어큐뮬레이터	50-788	ATTACHMENT HOSE & CABLE SETTINGS (UPRIGHT) 어태치 호스& 케이블 세팅 (마스트)
33-130	SELECTOR SOLENOID VALVE 셀렉터 솔레노이드 밸브	50-791	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
34-044	LOAD BACK REST MOUNTING 로드 백 레스트 마운팅	50-792	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
34-109	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-798	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)
34-325	UPRIGHT MOUNTING 마스트 마운팅	50-799	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적용)
37-003	OVERHEAD GUARD COVER 오버헤드가드 커버	50-800	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적용)
37-024	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅	50-807	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적용)
37-025	BATTERY COVER 배터리 커버	53-170	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
37-026	BATTERY COVER MOUNTING 배터리 커버 마운팅	53-187	SIDE SHIFT ASSEMBLY 사이드 쉬프트 어셈블리
37-027	COWL & DASH COVER MOUNTING 카울& 대시커버 마운팅	53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더
37-028	FLOOR PLATE MOUNTING 플로어 플레이트 마운팅	54-015	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
37-076	BACK MIRROR 백미러	66-058	FORK 포크
37-077	OVERHEAD GUARD REAR INSERT 오버헤드 가드 리어 인서트	66-065	LIFT CYLINDER PIPING 리프트 실린더 파이핑
37-106	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅	66-072	STANDARD UPRIGHT 표준 마스트
37-124	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	66-073	LIFT CHAIN 리프트 체인
38-275	MODEL DECALS & COUNTERWEIGHT MOUNTING 모델 데칼& 카운터웨이트 마운팅	66-074	LIFT CYLINDER PIPING 리프트 실린더 파이핑
38-276	SIDE BATTERY REMOVAL(SBR) 사이드 배터리 제거 (SBR)	66-075	TRIPLE STAGE UPRIGHT 3단 마스트
39-519	LOAD BACK REST 로드 백 레스트	66-076	LIFT CHAIN 리프트 체인
39-583	SEAT MOUNTING 시트 마운팅	66-078	PRIMARY CYLINDER 프라이머리 실린더
39-661	SEAT ASSEMBLY 시트 어셈블리	66-082	HI-LO UPRIGHT 하이-로우 마스트
39-829	SEAT MOUNTING 시트 마운팅	66-083	HI-LO SECONDARY CYLINDER 하이-로우 2차 실린더
39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리	66-157	LIFT CYLINDER ASSEMBLY 리프트 실린더 어셈블리
40-260	TRUCK FLUIDS 트럭 윤활유	66-158	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
40-268	LOGO & WIRING DIAGRAM DECALS 로고& 와이어링 데칼	66-241	LIFT CYLINDER PIPING 리프트 실린더 파이핑
40-269	DECALS 데칼	66-265	HI-LO UPRIGHT 하이-로우 마스트
41-120	COLD STORAGE ENVIRONMENT 냉장사양	66-335	LIFT CHAIN 리프트 체인
47-005	REAR HAND GRIP MOUNTING 리어 핸드 그립 마운팅	75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치
47-010	SEAT SWITCH INSTALLATION 시트 스위치 조립그룹		
50-120	AUXILIARY VALVE LINES 보조 밸브 라인		
50-780	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)		
50-781	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)		

PEDAL ASSEMBLY
INCLUDES ITEMS
MARKED "P"

62.050




ACCELERATOR PEDAL & LINKAGE

02-487

02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.284	FASTENER, PEDAL TO BRACKET PIVOT PIN 패스너
02.285	STOP, ACCELERATOR PEDAL LINKAGE 스톱
02.317	ROLLER, ACCELERATOR PEDAL 롤러
02.329	FASTENER, ACCELERATOR PEDAL 패스너
02.465	FASTENER, ACCELERATOR CONTROL LINKAGE 패스너
03.419	WEAR PLATE, ACCELERATOR PEDAL ROLLER 웨어플레이트
03.671	ACTUATOR, ACCELERATOR CONTROL 엑추에이터

13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너
13.572	BRACKET, ACCEL CONTROL ASSEMBLY MOUNTING 브라켓
13.573	FASTENER, ACCELERATOR CONTROL ASSY MOUNTING BRACKE 패스너
62.050	PEDAL ASSEMBLY, ACCELERATOR 페달
90.673	NUT, ACCELERATOR PEDAL BRKT MOUNTING FASTENER 너트



VALVE SWITCH WIRING

13-148

- 13.035 RELAY, VALVE SWITCH WIRING HARNESS
릴레이
- 14.146 HARNESS, VALVE SWITCH WIRING
하네스


ASSEMBLY
COMPLETE

13.332

13.333

60.821

60.822




STROBE LIGHT

13-182

13.332	ASSEMBLY, WARNING LIGHT 경고등
13.333	BULB, WARNING LIGHT 전구
60.821	GLOBE, STROBE LIGHT 글로브
60.822	BASE, STROBE LIGHT 베이스


60.795 ASSEMBLY
COMPLETE



WORK LIGHT


13-194

- | | |
|--------|--|
| 13.281 | FASTENER, ADJ HEADLAMP SWIVEL
패스너 |
| 13.284 | BRACKET, ADJUSTABLE HEADLAMP
브라켓 |
| 13.285 | FASTENER, ADJUSTABLE HEADLAMP BRACKET
패스너 |
| 60.325 | BULB, HEADLAMP
전구 |
| 60.795 | LIGHT, REAR WORK
라이트 |



13.270	HEADLAMP, ADJUSTABLE 헤드램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래서

60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.324	BULB, HEADLAMP 전구
60.368	RELAY, HEADLIGHTS 릴레이
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.535	SWITCH, WORK LIGHT 스위치
95.299	FASTENER, HEADLAMP GUARD 패스너




TRAVEL ALARM INSTALLATION

13-265

- | | |
|--------|--|
| 13.681 | FASTENER, WARNING DEVICE
패스너 |
| 42.001 | WARNING DEVICE, AUDIBLE (AIR OPER)
경고장치 |


ASSEMBLY
COMPLETE — 13.000



INSTRUMENT PANEL


13-307

13.000	PANEL, INSTRUMENT CLUSTER 판넬
37.250	HOUSING, INSTRUMENT PANEL 하우징
39.510	HOUSING, INSTRUMENT PANEL 하우징




13.206	BULB, BACK-UP LAMP 전구
13.217	FASTENER, COM STOP & TAIL LAMP ASSY MTG 패스너
13.218	BULB, STOP & TAIL LAMP 전구
13.330	BRACKET, WARNING LIGHT 브라켓
13.331	FASTENER, WARNING LIGHT BRACKET 패스너
13.332	ASSEMBLY, WARNING LIGHT 경고등
13.675	BULB, TURN LIGHT 전구
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
60.795	LIGHT, REAR WORK 라이트

60.797	GROMMET, REAR ACCESSORY WIRE 그롬멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.904	SWITCH, STROBE LIGHT 스위치
60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.960	HARNESS, REAR WORK LAMP EXTENSION 하네스
60.962	SPACER, REAR WORK LAMP MOUNTING 스페이서
60.964	RELAY, FOOT BRAKE 릴레이




13.621	SWITCH, LIFT HEIGHT LIMIT 스위치
13.622	BRACKET, HEIGHT LIMIT SWITCH MOUNTING 브라켓
13.623	FASTENER, HEIGHT LIMIT SWITCH 패스너
13.637	FASTENER, HEIGHT LIMIT SWITCH BRACKET 패스너
13.645	RELAY, HEIGHT LIMIT SWITCH SEQUENCE 릴레이
13.646	FASTENER, HEIGHT LIMIT SWITCH SEQUENCE RELAY 패스너
14.619	CLAMP, HEIGHT LIMIT SWITCH WIRES 클램프
15.448	DIODE, HARNESS 다이오드
60.974	BRACKET, LIFT HEIGHT LIMIT SWITCH RELAY MOUNTING 브라켓

60.975 WIRE HARNESS, LIFT HEIGHT LIMIT SWITCH
와이어하네스



- | | |
|--------|--|
| 14.352 | FUSE, CONTROL CIRCUIT
퓨즈 |
| 15.214 | CONNECTOR, WIRE HARNESS
커넥터 |
| 15.479 | SWITCH, SEAT INSTALLATION
스위치 |
| 15.484 | HARNESS, SEAT SWITCH INSTALLATION
하네스 |
| 60.716 | RELAY, SAFETY START
릴레이 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




ELECTRICAL COMPONENTS

14-401

13.000	PANEL, INSTRUMENT CLUSTER 판넬
13.003	HORN 혼
13.004	FASTENER, HORN MOUNTING BRACKET 패스너
37.967	PLUG, INSTRUMENT PANEL 플러그
39.417	GROUND STRAP, ELECTRIC TRUCK 접지케이블
39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP 패스너
44.409	SWITCH, SPEED REDUCTION 스위치
49.101	SENSOR, LEVER POSITION 센서
49.204	BRACKET, LEVER POSITION SENSOR 브라켓


49.205	BRACKET, LEVER POSITION SENSOR SUPPORT 브라켓
60.725	POTENTIOMETER, STEERING INTERLOCK 포텐션메터
67.217	CONVERTER, DC-DC FOR ACCESSORY 컨버터
67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL 컨버터
96.596	FASTENER, STEERING INTERLOCK POTENTIOMETER 패스너
97.142	FASTENER, LEVER POSITION SENSOR 패스너
97.143	FASTENER, LEVER POSITION SENSOR BRACKET 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL 패스너



LICENSE PLATE MOUNTING


14-426

02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
15.833	WIRE HARNESS, LICENCE LAMP 와이어하네스
18.032	FASTENER, WIRE HARNESS CLAMP 패스너
18.158	CLAMP, WIRE HARNESS 클램프
60.042	HEAD, FORK POSITIONING SWITCH ACTUATOR 헤드
60.043	ARM, FORK POSITIONING INDICATOR SWITCH 암
62.004	PLATE, LICENSE 플레이트
62.007	SHIM, TANK BRACKET 심
62.280	LINE, ENGINE TURBOCHARGER INTAKE 라인



- | | |
|--------|---|
| 12.392 | FASTENER, CHASSIS GROUND
패스너 |
| 14.114 | HARNESS, MACHINE WIRING
하네스 |
| 14.352 | FUSE, CONTROL CIRCUIT
퓨즈 |
| 14.745 | FASTENER, FUSE HOLDER MOUNTING BRACKET
패스너 |
| 15.447 | DIODE, HARNESS
다이오드 |
| 18.010 | CLIP, HARNESS
클립 |
| 18.011 | FASTENER, HARNESS CLIP
패스너 |
| 18.012 | CLIP, WIRE HARNESS
클립 |
| 18.013 | FASTENER, HARNESS CLIP
패스너 |


18.187	TERMINAL, FUSE 터미널
65.832	COVER, FUSE BOX 커버
93.661	FASTENER, TERMINAL BLOCK 패스너



14.039	RECEPTACLE & LEAD ASSEMBLY, BATTERY 리셉터클& 리드
14.040	RECEPTACLE, BATTERY 리셉터클
15.623	CABLE, CONTACTOR R+ 케이블
15.625	CABLE, CONTACTOR L+ 케이블
15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블
15.770	CABLE, DRIVE MOTOR (TMUR TO TCUR) 케이블
15.771	CABLE, DRIVE MOTOR (TMWR TO TCVR) 케이블
15.772	CABLE, DRIVE MOTOR (TMVR TO TCWR) 케이블
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블

15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
15.820	BOOT, CABLE 부트
94.069	FASTENER, BATTERY RECEPTACLE 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



PUMP MOTOR MOUNTING


16-105

- | | |
|--------|--|
| 16.500 | MOTOR ASSEMBLY, PUMP
모터 |
| 16.704 | DAMPENER, PUMP MOTOR VIBRATION
댐프너 |
| 16.708 | FASTENER, PUMP MOTOR VIBRATION DAMPENER
패스너 |



16.000	MOTOR ASSEMBLY, DRIVE 모터
16.002	BEARING, DRIVE MOTOR COMMUTATOR END 베어링
16.013	SPACER, DRIVE MOTOR DRIVE END 스페이서
16.029	SEAL, DRIVE MOTOR ARMATURE SHAFT DRIVE END 씰
16.068	FASTENER, DRIVE MOTOR END FRAME 패스너
16.090	COVER, DRIVE MOTOR COMMUTATOR END 커버
16.106	TERMINAL BLOCK, DRIVE MOTOR 터미널블록
16.114	WASHER, DRIVE MOTOR DRIVE END THRUST 와셔
16.116	FASTENER, DRIVE MOTOR TERMINAL 패스너


16.148	RING, DRIVE MOTOR ROTOR BEARING 링
16.149	ROTOR, DRIVE MOTOR 로터
16.162	SEAL, DRIVE MOTOR DRIVE END 씰
16.165	BEARING, DRIVE MOTOR DRIVE END 베어링
16.185	STATOR ASSY, DRIVE MOTOR 스테이터
16.186	BASE, DRIVE MOTOR TERMINAL 베이스
16.187	SENSOR KIT, DRIVE MOTOR ROTOR 센서키트
16.189	COVER, DRIVE MOTOR DRIVE END 커버
16.191	SENSOR KIT, DRIVE MOTOR TEMPERATURE 센서키트
16.192	RING, DRIVE MOTOR ARMATURE 링
16.194	PLATE, DRIVE MOTOR ROTOR SENSOR TARGET 플레이트
16.283	COVER, DRIVE MOTOR ROTOR SENSOR PLATE 커버
16.284	RING, DRIVE MOTOR ROTOR SENSOR PLATE 링
93.232	WASHER, DRIVE MOTOR TERMINAL BLOCK FASTENER 와셔
93.233	FASTENER, DRIVE MOTOR TERMINAL 패스너
93.731	NUT, DRIVE MOTOR FASTENER 너트
97.068	FASTENER, DRIVE MOTOR SPEED SENSOR 패스너
97.144	FASTENER, DRIVE MOTOR ROTOR SENSOR PLATE COVER 패스너



16.151	FITTING KEY, PUMP MOTOR ROTOR 피팅키
16.153	FAN, PUMP MOTOR 팬
16.154	COVER, PUMP MOTOR ROTOR END 커버
16.155	WASHER, PUMP MOTOR ROTOR BEARING 와셔
16.157	ROTOR, PUMP MOTOR 로터
16.178	BASE, PUMP MOTOR TERMINAL 베이스
16.180	SENSOR KIT, PUMP MOTOR ROTOR 센서
16.181	PLATE, PUMP MOTOR ROTOR SENSOR TARGET 플레이트
16.182	COVER, PUMP MOTOR DRIVE END 커버

16.183	BEARING, PUMP MOTOR ROTOR END 베어링
16.184	SENSOR KIT, PUMP MOTOR TEMPERATURE 센서키트
16.285	SEAL, PUMP MOTOR ROTOR BEARING 씰
16.286	RING, PUMP MOTOR ROTOR 링
16.500	MOTOR ASSEMBLY, PUMP 모터
16.502	BEARING, PUMP MOTOR DRIVE END 베어링
16.538	COVER ASSEMBLY, PUMP MOTOR FAN HOLE 커버
16.571	SEAL, HYDRAULIC PUMP MOTOR ARMATURE SHAFT DRIVE EN 씰
16.573	TERMINAL BLOCK, HYDRAULIC PUMP MOTOR 터미널블록
16.593	STATOR ASSY, HYDRAULIC-PUMP MOTOR 스테이터
93.258	FASTENER, PUMP MOTOR DRIVE END FRAME COVER 패스너
93.265	FASTENER, HYDRAULIC PUMP MOTOR TERMINAL 패스너
95.045	WASHER, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 와셔
95.501	FASTENER, PUMP MOTOR TERMINAL BLOCK CONNECTOR 패스너
95.873	NUT, HYDRAULIC PUMP MOTOR TERMINAL CLAMP FASTENER 너트
97.069	FASTENER, PUMP MOTOR SPEED SENSOR 패스너
97.145	NUT, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 너트
97.146	FASTENER, PUMP MOTOR FAN COVER 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE MOTOR MOUNTING

16-258

- | | |
|--------|------------------------------|
| 16.000 | MOTOR ASSEMBLY, DRIVE
모터 |
| 16.001 | FASTENER, DRIVE MOTOR
패스너 |


ASSEMBLY
COMPLETE — 65.130



LINE CONTACTOR ASSEMBLY

17-111


65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.930	ASSEMBLED COIL & MAGNET FRAME, LINE CONTACTOR 코일& 마그넷
65.931	TOP COVER, LINE CONTACTOR 탑커버
65.932	FASTENER, LINE CONTACTOR 패스너
65.933	CONTACT KIT, LINE CONTACTOR 컨택트키트
65.942	CONTACT SET, LINE CONTACTOR 컨택트세트



18.184	BRACKET, CONTROLLER FAN MOUNTING 브라켓
19.240	FASTENER, CONTROL PANEL MOUNTING 패스너
65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.492	FAN, ELECTRICAL COOLING 팬
65.896	CONDUCTOR, CONTROL PANEL 컨덕터
67.064	CONDUCTOR, LINE CONTACTOR 컨덕터
67.118	BRACKET, LINE CONTACTOR MOUNTING 브라켓
67.188	COVER, FAN 커버
67.208	FAN, COOLING 팬

67.211	FUSE, TRACTION CONTROLLER 퓨즈
67.213	FUSE, PUMP CONTROLLER 퓨즈
67.300	CONTROLLER, TRACTION 컨트롤러
67.400	CONTROLLER, PUMP 컨트롤러
93.089	FASTENER, CONTACTOR PANEL CONNECTING CONDUCTOR 패스너
94.296	FASTENER, ELECTRICAL COOLING FAN 패스너
96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너
96.976	FASTENER, CONTACTOR MOUNTING 패스너
97.055	FASTENER, FAN BRACKET MOUNTING 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE AXLE & BRAKE MOUNTING


20-186

16.001	FASTENER, DRIVE MOTOR 패스너
16.071	SEAL, DRIVE MOTOR TO AXLE 씰
20.008	SHIELD, DRIVE HOUSING SPINDLE DUST 실드
20.120	SPACER, DRIVE AXLE MOUNTING 스페이서
20.321	LOCATOR, DRIVE AXLE MOUNTING 로케이터
20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.377	FASTENER, DRIVE AXLE TO FRAME 패스너
22.224	BRAKE ASSEMBLY, MOTOR 브레이크
22.627	TEE, BRAKE LINE 티

22.948	FITTING, TEE BRAKE LINE 피팅
23.207	LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
90.998	FASTENER, DRIVE MOTOR BRAKE 패스너




20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.373	GASKET, DIFFERENTIAL HOUSING INSPECTION COVER 가스켓
20.374	FASTENER, DIFF HOUSING INSPECTION COVER 패스너
20.375	COVER, DIFFERENTIAL HOUSING INSPECTION 커버
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
20.546	FASTENER, DRIVE AXLE END 패스너
23.256	DISK OR DRUM, DRIVE WHEEL BRAKE 디스크




20.201	SHIM, DIFF BRG CARRIER TO AXLE HOUSING 심
20.212	SEAL, DIFFERENTIAL PINION OIL 씰
20.221	FASTENER, DIFF PINION OIL SEAL RET & BRG CAGE 패스너
20.230	BEARING ASSEMBLY, DIFF PINION OUTER 베어링
20.236	BEARING, CARRIER PINION 베어링
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 심
20.239	FASTENER, DIFFERENTIAL PINION BEARING CARRIER 패스너
20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링

20.261	RETAINER, DIFF PINION OUTER BEARING 리테이너
20.316	CUP, DIFFERENTIAL PINION BEARING (OUTER) 컵
20.387	HOUSING, DIFFERENTIAL & AXLE 하우징
20.424	PLUG, DIFFERENTIAL & AXLE HOUSING FILLER 플러그
20.427	PLUG, DIFFERENTIAL & AXLE HOUSING DRAIN 플러그
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.542	BEARING, DRIVE AXLE SHAFT 베어링
20.544	SEAL, DRIVE AXLE SHAFT 씰
20.573	CUP, DRIVE AXLE SHAFT BEARING (OUTBOARD) 컵
20.586	SHAFT, DRIVE AXLE 샤프트
91.169	LOCKWASHER, PINION BRG CAGE FASTENER 로크와셔
92.493	LOCKWASHER, DIFFERENTIAL PINION BEARING CARRIER FA 로크와셔




20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.519	FASTENER, DRIVE AXLE SHAFT GEAR RETAINER 패스너
20.520	RETAINER, DRIVE AXLE SHAFT GEAR 리테이너
20.521	SHIM, DRIVE AXLE SHAFT GEAR 심
20.522	GEAR, DRIVE AXLE SHAFT 기어
20.524	BEARING, DRIVE AXLE INTERMEDIATE GEAR SHAFT 베어링
20.553	BEARING, DRIVE AXLE SHAFT (INBOARD) 베어링

20.579	CUP, DRIVE AXLE SHAFT BEARING (INBOARD) 컵
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.636	SHAFT, DRIVE AXLE RING GEAR 샤프트
20.638	BEARING, RING GEAR SHAFT OUTBOARD 베어링
20.639	RETAINING RING, RING GEAR SHAFT OUTBOARD BEARING 리테이닝 링
20.640	SEAL, RING GEAR SHAFT BEARING HOUSING 씰
20.641	SHIM, RING GEAR SHAFT BEARING HOUSING 심
20.642	HOUSING, RING GEAR SHAFT BEARING 하우징
20.643	SEAL, RING GEAR SHAFT 씰
20.647	LOCATOR, DRIVE AXLE SHAFT INBOARD BEARING 로케이터
20.659	SHIM, DRIVE AXLE RING GEAR SHAFT BEARING CAP 심
20.832	CAP, DRIVE AXLE RING GEAR BEARING 캡
20.837	BEARING, DRIVE AXLE RING GEAR SHAFT 베어링
91.051	BOLT, DRIVE AXLE RING GEAR BEARING CAP 볼트
91.052	LOCKWASHER, DRIVE AXLE RING GEAR BEARING CAP FAST 로크와셔
93.270	FASTENER, RING GEAR SHAFT BEARING HOUSING 패스너
93.272	LOCKWASHER, RING GEAR SHAFT BEARING HOUSING FASTEN 로크와셔



20.201	SHIM, DIFF BRG CARRIER TO AXLE HOUSING 심
20.212	SEAL, DIFFERENTIAL PINION OIL 씰
20.221	FASTENER, DIFF PINION OIL SEAL RET & BRG CAGE 패스너
20.230	BEARING ASSEMBLY, DIFF PINION OUTER 베어링
20.236	BEARING, CARRIER PINION 베어링
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 심
20.239	FASTENER, DIFFERENTIAL PINION BEARING CARRIER 패스너
20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링


20.261	RETAINER, DIFF PINION OUTER BEARING 리테이너
20.316	CUP, DIFFERENTIAL PINION BEARING (OUTER) 컵
20.388	HOUSING, DRIVE AXLE (LH) 하우징
20.424	PLUG, DIFFERENTIAL & AXLE HOUSING FILLER 플러그
20.427	PLUG, DIFFERENTIAL & AXLE HOUSING DRAIN 플러그
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
20.542	BEARING, DRIVE AXLE SHAFT 베어링
20.544	SEAL, DRIVE AXLE SHAFT 씰
20.573	CUP, DRIVE AXLE SHAFT BEARING (OUTBOARD) 컵
20.586	SHAFT, DRIVE AXLE 샤프트
91.169	LOCKWASHER, PINION BRG CAGE FASTENER 로크와셔
92.493	LOCKWASHER, DIFFERENTIAL PINION BEARING CARRIER FA 로크와셔



20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
20.519	FASTENER, DRIVE AXLE SHAFT GEAR RETAINER 패스너
20.520	RETAINER, DRIVE AXLE SHAFT GEAR 리테이너
20.521	SHIM, DRIVE AXLE SHAFT GEAR 심
20.522	GEAR, DRIVE AXLE SHAFT 기어
20.524	BEARING, DRIVE AXLE INTERMEDIATE GEAR SHAFT 베어링
20.553	BEARING, DRIVE AXLE SHAFT (INBOARD) 베어링

20.579	CUP, DRIVE AXLE SHAFT BEARING (INBOARD) 컵
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.636	SHAFT, DRIVE AXLE RING GEAR 샤프트
20.638	BEARING, RING GEAR SHAFT OUTBOARD 베어링
20.639	RETAINING RING, RING GEAR SHAFT OUTBOARD BEARING 리테이닝 링
20.640	SEAL, RING GEAR SHAFT BEARING HOUSING 씰
20.641	SHIM, RING GEAR SHAFT BEARING HOUSING 심
20.642	HOUSING, RING GEAR SHAFT BEARING 하우징
20.643	SEAL, RING GEAR SHAFT 씰
20.647	LOCATOR, DRIVE AXLE SHAFT INBOARD BEARING 로케이터
20.659	SHIM, DRIVE AXLE RING GEAR SHAFT BEARING CAP 심
20.832	CAP, DRIVE AXLE RING GEAR BEARING 캡
20.837	BEARING, DRIVE AXLE RING GEAR SHAFT 베어링
91.051	BOLT, DRIVE AXLE RING GEAR BEARING CAP 볼트
91.052	LOCKWASHER, DRIVE AXLE RING GEAR BEARING CAP FAST 로크와셔
93.270	FASTENER, RING GEAR SHAFT BEARING HOUSING 패스너
93.272	LOCKWASHER, RING GEAR SHAFT BEARING HOUSING FASTEN 로크와셔

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE WHEEL & TIRE MOUNTING

22-013

- | | |
|--------|---|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠& 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER WHEEL & TIRE MOUNTING

22-014

- | | |
|--------|---|
| 23.026 | FASTENER, STEER WHEEL
패스너 |
| 23.031 | STEER WHEEL AND TIRE ASSEMBLY
스티어휠 & 타이어 |

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE (SOLID TYPE)

22-024

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어

ASSEMBLY
COMPLETE — 23.031



STEER WHEEL & TIRE (SOLID TYPE)


22-027

22.990	TIRE ASSEMBLY, STEER 타이어
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠 & 타이어
23.033	FASTENER, STEER WHEEL 패스너
23.034	OUTER HALF, STEER WHEEL 아우터하프
23.035	INNER HALF, STEER WHEEL 인너하프
23.036	FASTENER, STEER WHEEL ASSEMBLY 패스너

ASSEMBLY
COMPLETE — 22.224

BRAKE LINING SEAL KIT
INCLUDES ITEMS
MARKED "K" — 23.836

NOTE:
NON SERVICEABLE
ITEMS MARKED "N"




BRAKE ASSEMBLY

22-058


- | | |
|--------|--|
| 22.224 | BRAKE ASSEMBLY, MOTOR
레이크 |
| 22.346 | LEVER, PARKING BRAKE CAM (LH)
레버 |
| 22.347 | PIVOT, PARKING BRAKE SHOE
피봇 |
| 22.351 | CAM, PARKING BRAKE OPERATING (RH INBOARD)
캠 |
| 22.481 | SPACER, WHEEL BRAKE ASSEMBLY
스페이서 |
| 22.811 | BUSHING, BRAKE ASSEMBLY
부싱 |
| 22.812 | PIN, PARKING BRAKE ACTUATING PIN
핀 |
| 22.813 | SLEEVE, BRAKE
슬리브 |
| 22.814 | BRACKET, BRAKE MOUNTING RH
브라켓 |

22.815	BRACKET, BRAKE MOUNTING LH 브라켓
22.816	NUT, PARKING BRAKE PIN FASTENER 너트
22.817	FASTENER, BRAKE PIVOT RETAINER 패스너
23.222	SCREW, BRAKE CYLINDER BLEEDER (LH) 스크류
23.246	FASTENER, BRAKE ASSEMBLY 패스너
23.247	SHOE SET, BRAKE LINING 슈
23.366	PIN, PARKING BRAKE LEVER PIVOT 핀
23.564	PISTON, WHEEL BRAKE CYLINDER 피스톤
23.605	FASTENER, BRAKE SHOE LINING 패스너
23.735	SHOE & LINING SET, BRAKE 슈& 라이닝
23.836	KIT, BRAKE LINING SEAL 키트
92.463	WASHER, BRAKE CAM FOLLOWER FASTENER 와셔




- 22.224 BRAKE ASSEMBLY, MOTOR
브레이크
- 22.346 LEVER, PARKING BRAKE CAM (LH)
레버
- 22.347 PIVOT, PARKING BRAKE SHOE
피봇
- 22.351 CAM, PARKING BRAKE OPERATING (RH INBOARD)
캠
- 22.481 SPACER, WHEEL BRAKE ASSEMBLY
스페이서
- 22.811 BUSHING, BRAKE ASSEMBLY
부싱
- 22.812 PIN, PARKING BRAKE ACTUATING PIN
핀
- 22.813 SLEEVE, BRAKE
슬리브
- 22.814 BRACKET, BRAKE MOUNTING RH
브라켓

22.815	BRACKET, BRAKE MOUNTING LH 브라켓
22.816	NUT, PARKING BRAKE PIN FASTENER 너트
22.817	FASTENER, BRAKE PIVOT RETAINER 패스너
23.222	SCREW, BRAKE CYLINDER BLEEDER (LH) 스크류
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.246	FASTENER, BRAKE ASSEMBLY 패스너
23.366	PIN, PARKING BRAKE LEVER PIVOT 핀
23.564	PISTON, WHEEL BRAKE CYLINDER 피스톤
23.828	KIT, BRAKE LINING 키트
23.836	KIT, BRAKE LINING SEAL 키트
92.463	WASHER, BRAKE CAM FOLLOWER FASTENER 와셔



23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.016	TIRE, DRIVE WHEEL 타이어
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




BRAKE LINES


23-429

- | | |
|--------|---|
| 13.142 | SWITCH, BRAKE INTERLOCK
스위치 |
| 13.143 | BRACKET, BRAKE INTERLOCK SWITCH
브라켓 |
| 13.145 | FASTENER, BRAKE INTERLOCK SWITCH
패스너 |
| 22.338 | CLAMP, BRAKE FLUID RESERVOIR
클램프 |
| 22.420 | CLEVIS, MASTER CYLINDER PUSH ROD
클레비스 |
| 22.604 | CLAMP, BRAKE FLUID RESERVOIR LINE
클램프 |
| 23.051 | FASTENER, MASTER CYLINDER MOUNTING BRACKET
패스너 |
| 23.100 | PEDAL, BRAKE
페달 |
| 23.101 | SHAFT, BRAKE PEDAL
샤프트 |

23.105	BEARING, BRAKE PEDAL 베어링
23.114	PAD & FASTENER, BRAKE PEDAL 패드& 패스너
23.118	FASTENER, BRAKE PEDAL TO MASTER CYL PUSH ROD 패스너
23.136	SPRING, BRAKE PEDAL RETURN 스프링
23.145	FASTENER, BRAKE PEDAL SHAFT 패스너
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.157	FASTENER, BRAKE MASTER CYLINDER ATTACHING 패스너
23.160	ROD, PUSH 로드
23.173	FITTING, BRAKE MASTER CYLINDER OUTLET 피팅
23.174	GASKET, BRAKE MASTER CYLINDER OUTLET FITTING 가스켓
23.186	LINE, BRAKE MASTER CYLINDER OUTLET 라인
23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.435	FASTENER, BRAKE PEDAL PIVOT BRACKET 패스너
23.792	RESERVOIR, BRAKE FLUID 리저버
23.793	FASTENER, BRAKE FLUID RESERVOIR 패스너
23.794	LINE, BRAKE MASTER CYLINDER INLET 라인
94.398	NUT, BRAKE MASTER CYLINDER ACTUATING ROD FASTENER 너트



17.804	STOP PLATE, CYLINDER PISTON 스톱플레이트
22.973	HOUSING, BRAKE MASTER CYLINDER 하우징
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.159	REPAIR KIT, MASTER CYLINDER 리페어키트
23.161	BOOT, MASTER CYLINDER 부트
23.175	BOLT, BRAKE MASTER CYLINDER OUTLET FITTING 볼트
23.176	GASKET, BRAKE MASTER CYLINDER OUTLET FTG BOLT 가스켓
23.427	SEAL, MASTER CYLINDER OUTLET HOUSING 셀
23.795	FITTING, BRAKE MASTER CYLINDER INLET 피팅




PARKING BRAKE SYSTEM

23-534

- | | |
|--------|---|
| 13.101 | PLATE, BRAKE LOCK ACTUATING SWITCH
플레이트 |
| 22.045 | BRACKET, PARKING BRAKE PEDAL PIVOT MTG
브라켓 |
| 22.263 | RETAINER, PARKING BRAKE RELEASE LEVER PIVOT
리테이너 |
| 22.442 | PAD, PARKING BRAKE PEDAL
패드 |
| 22.853 | SWITCH, PARKING BRAKE PEDAL ACTUATING
스위치 |
| 22.854 | FASTENER, PARKING BRAKE PEDAL ACTUATING
패스너 |
| 22.855 | PIVOT, PARKING BRAKE PEDAL
피봇 |
| 22.856 | RETAINER, PARKING BRAKE PEDAL PIVOT
리테이너 |
| 22.860 | PEDAL, PARKING BRAKE
페달 |

22.895	FASTENER, PARKING BRAKE PEDAL PIVOT RETAINER 패스너
23.264	BRAKE ASSEMBLY, PARKING 브레이크
23.269	FASTENER, PARKING BRAKE LEVER 패스너
23.272	CABLE, PARKING BRAKE 케이블
23.283	FASTENER, PARKING BRAKE END CLEVIS 패스너
23.284	FASTENER, PARKING BRAKE CABLE BRACKET 패스너
23.410	BEARING, PARKING BRAKE CAM ROLLER 베어링
23.481	LEVER, PARKING BRAKE RELEASE 레버
23.482	SPRING, PARKING BRAKE RELEASE LEVER 스프링
23.489	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
23.571	BUMPER, PARKING BRAKE LEVER 범퍼
23.767	SPRING, PARKING BRAKE DRAW 스프링
23.918	FASTENER, PARKING BRAKE PEDAL PIVOT BRACKET 패스너
23.959	FASTENER, PARKING BRAKE RELEASE VALVE 패스너
92.855	NUT, PARKING BRAKE FASTENER 너트

ASSEMBLY
COMPLETE 25.770



STEERING COLUMN ASSEMBLY

25-144

25.010	JACKET, STEERING COLUMN 자켓
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.130	FASTENER, DIRECTIONAL ASSEMBLY 패스너
25.137	KEY, DIRECTIONAL ASSEMBLY 키
25.141	SHAFT, STEERING GEAR 샤프트
25.312	UNIVERSAL JOINT, STEER 유니버설조인트
25.315	FASTENER, STEERING U-JOINT CLAMPING 패스너
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼


25.771	SHAFT, STEERING COLUMN (TILT) 샤프트
25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.841	BUSHING, STEERING GEAR SHAFT 부싱
25.933	FASTENER, STEERING COLUMN 패스너
25.991	PIN, STEERING UNIVERSAL JOINT 핀
37.344	SPRING, STEERING COLUMN TILTING 스프링

ASSEMBLY
COMPLETE — 25.150

SEAL KIT — 25.109

NEEDLE
BEARING KIT — 25.630


NOTE :
NO SERVICEABLE
ITEMS MARKED "N"



STEERING UNIT


25-146

25.097	FASTENER, END COVER 패스너
25.109	KIT, STEER GEAR SEAL 키트
25.150	GEAR BOX ASSEMBLY, STEERING 기어박스
25.271	SPRING, STEERING GEAR VALVE CENTERING 스프링
25.630	REPAIR KIT, STEERING COLUMN 리페어키트
26.063	PLUG, CHECK VALVE CHANNEL 플러그



25.002	HORN BUTTON KIT 혼버튼키트
25.003	NUT, HANDWHEEL 너트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.221	FASTENER, STEERING SPINNER KNOB 패스너
25.222	CAP, STEERING SPINNER KNOB 캡
25.780	HORN BUTTON 혼버튼
90.453	WASHER, STEERING SPINNER KNOB FASTENER 와셔
96.358	WASHER, STEERING HANDWHEEL SPINNER KNOB FASTENER 와셔

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEERING COLUMN MOUNTING

25-367

- | | |
|--------|---|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 06.101 | LEVER ASSEMBLY, FORWARD & REVERSE
레버 |
| 13.047 | SWITCH, CIRCUIT LOCKING
스위치 |
| 13.110 | SWITCH, DIRECTIONAL CONTROL (FORWARD)
스위치 |
| 13.111 | FASTENER, DIRECTIONAL CONTROL SWITCH
패스너 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 13.655 | SWITCH, TURN INDICATOR
스위치 |
| 13.656 | BRACKET, TURN INDICATOR SWITCH
브라켓 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |

25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
40.002	LEGEND, SHIFT PATTERN 범례
40.069	DECAL, FORWARD-BACKWARD 데칼
44.250	DIRECTIONAL CONTROL ASSEMBLY 방향컨트롤
44.251	HOUSING, DIRECTIONAL CONTROL ASSEMBLY 하우징
44.252	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING 커버
44.254	FASTENER, DIRECTIONAL CONTROL ASSY HOUSING COVER 패스너
44.255	SEAL, DIRECTIONAL CONTROL ASSY LEVER 씰
44.356	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING REAR 커버
60.260	KEY, CIRCUIT LOCKING SWITCH 키
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
60.686	RING, HORN CONTACT 링
60.773	HARNESS, TURN SIGNAL 하네스
60.951	GROMMET, TURN INDICATOR SWITCH 그로멧
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링
96.000	FASTENER, TURN INDICATOR SWITCH 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEERING GEAR MOUNTING

25-368


- | | |
|--------|--|
| 25.034 | FASTENER, STEERING GEAR ATTACHING
패스너 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |



STEER LINES

26-237


28.051	LINE, STEERING GEAR 라인
28.052	FITTING, STEERING GEAR 피팅
28.054	LINE, STEERING GEAR 라인
28.055	FITTING, STEERING GEAR 피팅
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
28.448	FITTING, STEER CYLINDER LINE 피팅
31.479	CLAMP, STEERING LINES 클램프
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너



STEER AXLE MOUNTING

26-238


- | | |
|--------|---|
| 26.100 | AXLE ASSEMBLY, STEERING
스티어액슬 |
| 26.175 | FASTENER, SILENT BLOCK TO FRAME (REAR)
패스너 |



STEER AXLE ASSEMBLY

26-239


25.391	BEARING, STEERING ARM 베어링	26.144	FASTENER, STEER AXLE HUB CAP 패스너
25.392	FITTING-LUB, STEERING ARM 피팅	26.170	PLUG - EXPANSION, STEER AXLE KNUCKLE PIN 플러그
26.000	CYLINDER ASSEMBLY, STEERING 실린더	26.171	SILENT BLOCK, AXLE MOUNTING (FRONT) 사일런트블록
26.086	FASTENER, STEERING CYLINDER ANCHOR END 패스너	26.190	SEAL, STEER AXLE KNUCKLE OIL 씰
26.100	AXLE ASSEMBLY, STEERING 스티어액슬	26.239	SEAL, STEER AXLE FORK COVER 씰
26.108	FASTENER, STEER AXLE SPIDER COVER 패스너	26.242	FASTENER, STEER AXLE SHAFT 패스너
26.119	AXLE, STEER 액슬	26.281	RETAINER, STEER AXLE HUB BRG KNUCKLE NUT 리테이너
26.124	SHIM, STEER AXLE KNUCKLE 심	26.347	PIN, STEER ARM 핀
26.126	ARM, RH STEERING 암	26.348	LOCATOR, STEER CYLINDER 로케이터
26.130	BEARING, STEER AXLE KNUCKLE PIN 베어링	26.419	CUP & CONE, STEER WHEEL HUB BEARING (INNER) 컵& 콘
26.132	KNUCKLE, STEER AXLE (RH) 너트	26.420	CUP & CONE, STEER WHEEL HUB BEARING (OUTER) 컵& 콘
26.136	HUB & CUP, STEER WHEEL 허브& 컵	93.700	FASTENER, STEER AXLE KNUCKLE PIN COVER 패스너
26.137	FASTENER, STEER WHEEL 패스너	93.793	WASHER, STEERING ARM PIVOT FASTENER 와셔
26.140	WASHER, STEER WHEEL HUB BEARING THRUST 와셔	94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너
26.143	CAP, STEER WHEEL HUB 캡	94.855	RETAINER, STEERING ARM PIN 리테이너




26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.003	SEAL KIT, PISTON ROD 씰키트
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 스티어실린더피스톤
26.093	GLAND, STEERING CYLINDER 그랜드

ASSEMBLY
COMPLETE

29.000



29.906




29.007

HYDRAULIC OIL FILTER

29-239

29.000	FILTER, HYDRAULIC OIL 필터
29.007	CARTRIDGE, HYDRAULIC OIL FILTER 카트리지
29.906	HEAD ASSEMBLY, HYDROSTATIC OIL FILTER 헤드




SUMP TANK MOUNTING

29-240

29.591	RUBBER, SUMP TANK MOUNTING 러버
29.609	PLUG, SUMP TANK 플러그
29.701	TANK, SUMP 탱크
29.702	FASTENER, SUMP TANK 패스너
29.703	SEAL, SUMP TANK 셀
29.766	COVER, SUMP TANK 커버
29.767	SEAL, SUMP TANK COVER 셀

ASSEMBLY
COMPLETE — 29.100

SEAL KIT — 29.028




HYDRAULIC PUMP ASSEMBLY

29-296

29.028	SEAL KIT, HYDRAULIC UNIT PUMP 씰키트
29.087	SEAL, HYDRAULIC PUMP HOUSING 씰
29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.268	COUPLING, MAIN HYDRAULIC PUMP 커플링


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC PUMP MOUNTING


29-322

- | | |
|--------|--|
| 16.559 | LEAD ASSEMBLY, PUMP MOTOR BRUSH
리드 |
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.119 | FASTENER, PUMP HOUSING
패스너 |
| 29.474 | SEAL, PUMP INLET FITTING
씰 |
| 29.608 | MANIFOLD, HYDRAULIC PUMP INLET SUCTION
매니폴드 |
| 97.097 | FASTENER, HYDRAULIC PUMP INLET SUCTION MANIFOLD
패스너 |




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓


30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



- | | |
|--------|---|
| 13.537 | SWITCH, CONTROL VALVE PUMP OPERATING
스위치 |
| 30.000 | VALVE ASSEMBLY, HYDRAULIC
밸브 |
| 30.033 | FASTENER, HYDRAULIC VALVE MOUNTING
패스너 |
| 30.087 | PIN, VALVE CONTROL LEVER PIVOT
핀 |
| 30.089 | LEVER, LIFT CONTROL
레버 |
| 30.090 | LEVER, TILT CONTROL
레버 |
| 30.094 | KNOB, LIFT CONTROL LEVER
노브 |
| 30.097 | KNOB, TILT CONTROL LEVER
노브 |
| 30.102 | BRACKET, HYDRAULIC VALVE SWITCH
브라켓 |

30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (2 SPOOL)


30-533

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.042	CAP, TILT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.438	BUSHING, LIFT CONTROL LEVER 부싱	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.442	SPACER, CONTROL LEVERS 스페이서	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.787	BOOT, VALVE CONTROL LEVER 부트	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
32.138	SWITCH, PUSH BUTTON 스위치	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트		



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.138	SWITCH, PUSH BUTTON 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.042	CAP, TILT CONTROL LEVER 캡
30.089	LEVER, LIFT CONTROL 레버	49.081	CAP, LIFT CONTROL LEVER 캡
30.090	LEVER, TILT CONTROL 레버	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.094	KNOB, LIFT CONTROL LEVER 노브	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.438	BUSHING, LIFT CONTROL LEVER 부싱	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.442	SPACER, CONTROL LEVERS 스페이서	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.787	BOOT, VALVE CONTROL LEVER 부트	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터

52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537 SWITCH, CONTROL VALVE PUMP OPERATING
스위치

15.339 HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스

30.000 VALVE ASSEMBLY, HYDRAULIC
밸브

30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너

30.087 PIN, VALVE CONTROL LEVER PIVOT
핀

30.089 LEVER, LIFT CONTROL
레버

30.090 LEVER, TILT CONTROL
레버

30.094 KNOB, LIFT CONTROL LEVER
노브

30.097 KNOB, TILT CONTROL LEVER
노브

30.102 BRACKET, HYDRAULIC VALVE SWITCH
브라켓

30.256 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.438 BUSHING, LIFT CONTROL LEVER
부싱

30.787 BOOT, VALVE CONTROL LEVER
부트

30.817 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.843 LEVER, AUXILIARY VALVE CONTROL (1ST AUX)
레버

30.844 LEVER, AUXILIARY VALVE CONTROL (2ND AUX)
레버

32.138 SWITCH, PUSH BUTTON
스위치

32.142 PLATE, SWITCH MOUNTING BRACKET
플레이트

33.347 RELIEF VALVE, LIFT LINE CHECK VALVE
릴리프밸브

49.042 CAP, TILT CONTROL LEVER
캡

49.081 CAP, LIFT CONTROL LEVER
캡

49.102 FASTENER, VALVE CONTROL LEVER PIVOT RETAINER
패스너

49.103 RETAINER, VALVE CONTROL LEVER PIVOT PIN
리테이너

49.104 PIN, VALVE CONTROL LEVER CLEVIS ROD
핀

49.105 RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN
리테이너

49.109 ROD, VALVE CONTROL CLEVIS
로드


49.110 PIN, VALVE SPOOL CLEVIS ROD
핀

49.111 RETAINER, VALVE SPOOL CLEVIS ROD PIN
리테이너

49.124 CAP, AUXILIARY CONTROL LEVER
캡

52.162 CONNECTOR, AUXILIARY VALVE LEVER WIRE
커넥터

52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537 SWITCH, CONTROL VALVE PUMP OPERATING
스위치

30.000 VALVE ASSEMBLY, HYDRAULIC
밸브

30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너

30.087 PIN, VALVE CONTROL LEVER PIVOT
핀

30.089 LEVER, LIFT CONTROL
레버

30.090 LEVER, TILT CONTROL
레버

30.094 KNOB, LIFT CONTROL LEVER
노브

30.097 KNOB, TILT CONTROL LEVER
노브

30.102 BRACKET, HYDRAULIC VALVE SWITCH
브라켓

30.438 BUSHING, LIFT CONTROL LEVER
부싱

30.442 SPACER, CONTROL LEVERS
스페이서

30.787 BOOT, VALVE CONTROL LEVER
부트

30.817 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.843 LEVER, AUXILIARY VALVE CONTROL (1ST AUX)
레버

32.138 SWITCH, PUSH BUTTON
스위치

32.142 PLATE, SWITCH MOUNTING BRACKET
플레이트

33.347 RELIEF VALVE, LIFT LINE CHECK VALVE
릴리프밸브

39.572 COVER, AUXILIARY VALVE LEVER HOLE
커버

49.042 CAP, TILT CONTROL LEVER
캡

49.081 CAP, LIFT CONTROL LEVER
캡

49.102 FASTENER, VALVE CONTROL LEVER PIVOT RETAINER
패스너

49.103 RETAINER, VALVE CONTROL LEVER PIVOT PIN
리테이너

49.104 PIN, VALVE CONTROL LEVER CLEVIS ROD
핀

49.105 RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN
리테이너

49.109 ROD, VALVE CONTROL CLEVIS
로드

49.110 PIN, VALVE SPOOL CLEVIS ROD
핀


49.111 RETAINER, VALVE SPOOL CLEVIS ROD PIN
리테이너

49.124 CAP, AUXILIARY CONTROL LEVER
캡

52.162 CONNECTOR, AUXILIARY VALVE LEVER WIRE
커넥터

52.171 LOCK, AUXILIARY VALVE LEVER WIRE
로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버

32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (2SPOOL)

30-543

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.442	SPACER, CONTROL LEVERS 스페이스
30.787	BOOT, VALVE CONTROL LEVER 부트
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (3SPOOL)

30-544

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING(4SPOOL)

30-545


13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브

30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버


32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



BUTTON LEVER DETAIL



DETAIL - A



HYDRAULIC VALVE MOUNTING (4SPOOL)

30-548

13.537 SWITCH, CONTROL VALVE PUMP OPERATING
스위치

15.339 HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스

30.000 VALVE ASSEMBLY, HYDRAULIC
밸브

30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너

30.087 PIN, VALVE CONTROL LEVER PIVOT
핀

30.089 LEVER, LIFT CONTROL
레버

30.090 LEVER, TILT CONTROL
레버

30.094 KNOB, LIFT CONTROL LEVER
노브

30.097 KNOB, TILT CONTROL LEVER
노브

30.102 BRACKET, HYDRAULIC VALVE SWITCH
브라켓

30.256 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.438 BUSHING, LIFT CONTROL LEVER
부싱

30.787 BOOT, VALVE CONTROL LEVER
부트

30.817 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.843 LEVER, AUXILIARY VALVE CONTROL (1ST AUX)
레버

30.844 LEVER, AUXILIARY VALVE CONTROL (2ND AUX)
레버

32.138 SWITCH, PUSH BUTTON
스위치

32.142 PLATE, SWITCH MOUNTING BRACKET
플레이트

49.042 CAP, TILT CONTROL LEVER
캡

49.081 CAP, LIFT CONTROL LEVER
캡

49.102 FASTENER, VALVE CONTROL LEVER PIVOT RETAINER
패스너

49.103 RETAINER, VALVE CONTROL LEVER PIVOT PIN
리테이너

49.104 PIN, VALVE CONTROL LEVER CLEVIS ROD
핀

49.105 RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN
리테이너

49.109 ROD, VALVE CONTROL CLEVIS
로드

49.110 PIN, VALVE SPOOL CLEVIS ROD
핀

49.111 RETAINER, VALVE SPOOL CLEVIS ROD PIN
리테이너


49.124 CAP, AUXILIARY CONTROL LEVER
캡

52.162 CONNECTOR, AUXILIARY VALVE LEVER WIRE
커넥터

52.171 LOCK, AUXILIARY VALVE LEVER WIRE
로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (3SPOOL)

30-549

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.042	CAP, TILT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.442	SPACER, CONTROL LEVERS 스페이서	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
32.138	SWITCH, PUSH BUTTON 스위치	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트		


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (4SPOOL)


30-565

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.042	CAP, TILT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
32.138	SWITCH, PUSH BUTTON 스위치		




30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.250	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너

30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.230	VALVE ASSEMBLY, LIFT SOLENOID 밸브
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.077	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 씰
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.206	VALVE, HYDRAULIC SHUT-OFF 밸브
49.209	VALVE, HYDRAULIC SHUT-OFF (LIFT) 밸브




30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.250	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너

30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.077	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 씰
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.206	VALVE, HYDRAULIC SHUT-OFF 밸브



- | | |
|--------|---|
| 50.027 | FITTING, 1ST AUXILIARY VALVE A PORT
피팅 |
| 50.072 | FITTING, 1ST AUXILIARY VALVE "B" PORT
피팅 |
| 50.425 | LINE, 1ST AUXILIARY VALVE "A" PORT
라인 |
| 50.426 | LINE, 1ST AUXILIARY VALVE "B" PORT
라인 |




AUX VALVE PLUMBING(DOUBLE)

31-146

- | | |
|--------|---|
| 50.027 | FITTING, 1ST AUXILIARY VALVE A PORT
피팅 |
| 50.220 | LINE, 2ND AUXILIARY VALVE "A" PORT
라인 |
| 50.221 | LINE, 2ND AUXILIARY VALVE "B" PORT
라인 |
| 50.425 | LINE, 1ST AUXILIARY VALVE "A" PORT
라인 |
| 50.426 | LINE, 1ST AUXILIARY VALVE "B" PORT
라인 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC RETURN LINES

31-190

- | | |
|--------|---|
| 28.266 | CLAMP, POWER STEERING SUMP RETURN LINE
클램프 |
| 28.914 | FITTING, VALVE SUMP RETURN PORT
피팅 |
| 29.000 | FILTER, HYDRAULIC OIL
필터 |
| 29.002 | FASTENER, HYDRAULIC OIL FILTER
패스너 |
| 29.386 | LINE, SUMP BREATHER
라인 |
| 29.727 | TUBE, SUMP FILLER
튜브 |
| 29.728 | CAP, HYDRAULIC SUMP FILLER
캡 |
| 29.784 | CLAMP, SUMP BREATHER LINE
클램프 |
| 29.798 | SCREEN, HYDRAULIC SUMP PRE FILTER
스크린 |

29.802	ADAPTOR, SUMP FILLER CAP 어댑터
29.809	DIPSTICK, SUMP LEVEL 딥스틱
29.913	FASTENER, SUMP FILLER TUBE 패스너
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프
31.120	LINE, SUMP RETURN (POWER STEERING) 라인
31.163	CLAMP, SUMP RETURN LINE 클램프
31.197	LINE, MAIN VALVE TO SUMP RETURN 라인
31.446	FITTING, FILTER OUTLET PORT 피팅
31.639	FITTING, FILTER INLET PORT 피팅
31.746	FITTING, POWER STEERING SUMP RETURN PORT 피팅
31.822	LINE, FILTER OUTLET TO SUMP 라인




HYDRAULIC SUPPLY LINES

31-232

28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.801	SEAL, HYD PUMP OUTLET PORT FITTING 셀
28.855	FITTING, POWER STEERING LINE 피팅
29.607	MANIFOLD, HYDRAULIC PUMP OUTLET LINE 매니폴드
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.014	FITTING, PUMP OUTLET 피팅


31.018	LINE, PUMP OUTLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
31.438	FITTING, PUMP TO VALVE LINE 피팅
31.468	FITTING, STEERING VALVE OUTLET PORT 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
97.096	FASTENER, HYDRAULIC PUMP OUTLET LINE MANIFOLD 패스너



HYDRAULIC LIFT LINES

31-312

- | | |
|--------|-------------------------------------|
| 31.030 | LINE, VALVE TO LIFT CYLINDER
라인 |
| 31.200 | FITTING, MAIN VALVE LIFT PORT
피팅 |




HYDRAULIC TILT LINES

31-319

28.691	BRACKET, TILT HOSE MOUNTING 브라켓
28.698	BOLT, TILT HOSE BRACKET SUPPORT 볼트
28.889	FITTING, TILT LINE 피팅
31.061	FITTING, VALVE TILT PORT "A" 피팅
31.062	FITTING, VALVE TILT PORT "B" 피팅
31.072	LINE, RH TILT CYLINDER ROD PORT 라인
31.073	LINE, LH TILT CYLINDER ROD PORT 라인
31.077	FITTING, LH TILT CYLINDER ROD PORT 피팅
31.083	LINE, RH TILT CYLINDER ANCHOR PORT 라인

31.158	LINE, LH TILT CYLINDER ANCHOR PORT 라인
31.160	FITTING, LH TILT CYLINDER ANCHOR PORT 피팅
31.162	FITTING, RH TILT CYLINDER ANCHOR PORT 피팅
31.175	LINE, VALVE TILT PORT "B" 라인
31.182	LINE, VALVE TILT PORT "A" 라인
31.600	FITTING, RH TILT CYLINDER ROD PORT 피팅
96.013	NUT, TILT LINE FITTING 너트




HYDRAULIC SUPPLY LINES

31-320


28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.801	SEAL, HYD PUMP OUTLET PORT FITTING 씰
28.855	FITTING, POWER STEERING LINE 피팅
29.607	MANIFOLD, HYDRAULIC PUMP OUTLET LINE 매니폴드
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.014	FITTING, PUMP OUTLET 피팅

31.018	LINE, PUMP OUTLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
97.096	FASTENER, HYDRAULIC PUMP OUTLET LINE MANIFOLD 패스너




32.000	CYLINDER ASSEMBLY, TILT 실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링
32.053	BEARING, TILT CYLINDER ROD END 베어링
32.057	FASTENER, TILT CYLINDER ROD END 패스너

90.439 BOLT, TILT CYLINDER TO FRAME PIN LOCK
볼트



32.000	CYLINDER ASSEMBLY, TILT 실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드& 피스톤
32.072	PACKING KIT, TILT CYLINDER 패킹키트


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT AMOUNT GP


32-169

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심
32.132	SPACER, TILT CYLINDER ROD END 스페이서
32.133	SHIM, TILT CYLINDER STROKE ADJUSTING 심




- | | |
|--------|--|
| 32.800 | ACCUMULATOR, HYDRAULIC
어큐플레이터 |
| 32.801 | CLAMP, HYDRAULIC ACCUMULATOR MOUNTING
클램프 |
| 32.802 | BRACKET, HYDRAULIC ACCUMULATOR
브라켓 |
| 32.805 | SEAL, HYDRAULIC ACCUMULATOR CONNECTOR
씰 |
| 32.806 | CONNECTOR, HYDRAULIC ACCUMULATOR
커넥터 |
| 32.810 | LINE, HYDRAULIC ACCUMULATOR
라인 |
| 32.814 | FITTING, HYDRAULIC ACCUMULATOR LINE
피팅 |
| 32.841 | NUT, HYDRAULIC ACCUMULATOR FITTING
너트 |
| 32.842 | SEAL, HYDRAULIC ACCUMULATOR FITTING
씰 |

75.029 HYDRAULIC ACCUMULATOR INSTALLATION
유압어큐뮬레이터



- 33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
밸브
- 33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너
- 33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
씰키트
- 33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어키트




LOAD BACK REST MOUNTING


34-044

34.998 FASTENER, LOAD SAFETY BACK REST
패스너

66.431 RETAINER, LBR CAPSCREW
리테이너




34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.328	ROLLER, CARRIAGE CAPTIVE 롤러
34.329	RETAINER, CARRIAGE CAPTIVE ROLLER 리테이너
34.330	FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER 패스너
34.332	SHIM, CARRIAGE CAPTIVE ROLLER 심
34.340	CARRIAGE WELDED ASSEMBLY 캐리지용 접합물



UPRIGHT MOUNTING

34-325


- | | |
|--------|--|
| 34.091 | FASTENER, TILT CYLINDER TO UPRIGHT RETAINER
패스너 |
| 34.600 | SUPPORT, UPRIGHT
서포트 |
| 34.605 | FASTENER, UPRIGHT SUPPORT PIN LOCK PLATE
패스너 |
| 34.607 | FITTING-LUB, UPRIGHT SUPPORT
피팅 |



OVERHEAD GUARD COVER

37-003


38.243 COVER ASSEMBLY, OVERHEAD GUARD TOP
커버



OVERHEAD GUARD MOUNTING

37-024


- | | |
|--------|--|
| 37.422 | BUMPER, OVERHEAD GUARD REAR SUPPORT
범퍼 |
| 37.746 | PLUG, DRIVER OVERHEAD GUARD
플러그 |
| 39.932 | GUARD, OVERHEAD
가드 |
| 39.933 | FASTENER, OVERHEAD GUARD
패스너 |
| 39.934 | FASTENER, OVERHEAD GUARD
패스너 |
| 39.938 | BRACKET, OVERHEAD GUARD REAR SUPPORT
브라켓 |
| 39.939 | FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET
패스너 |
| 47.082 | INSERT, DRIVER OVERHEAD GUARD
인서트 |



BATTERY COVER

37-025

37.497	HANDLE, TOP HOOD LATCH 핸들
39.594	HOOD, TOP 후드
96.900	FASTENER, CAB REAR HANDLE GRIP 패스너




BATTERY COVER MOUNTING

37-026

36.211	BUSHING, PIVOT PIN FASTENER 부싱
37.210	BRACKET, HOOD PROP 브라켓
37.359	SPACER, TOP HOOD PIVOT 스페이서
37.543	PLATE, TOP HOOD SPRING BRACKET REINFORCING 플레이트
37.897	BUMPER, TOP HOOD 범퍼
39.423	FASTENER, TOP HOOD 패스너
39.535	BRACKET, TOP HOOD MOUNTING 브라켓
39.536	BRACKET, TOP HOOD MOUNTING 브라켓
39.595	FASTENER, TOP HOOD 패스너

39.599	FASTENER, HOOD PIVOT HINGE 패스너
39.616	FASTENER, TOP HOOD LATCH 패스너
39.644	LATCH, TOP HOOD 래치
39.704	SPRING, HOOD PROP (OUTER) 스프링
39.705	FASTENER, HOOD PROP 패스너
41.028	CONSOLE, OPERATOR STORAGE CONSOLE 콘솔
41.030	FASTENER, STORAGE CONSOLE 패스너
41.251	SOUND SEAL, TOP HOOD 사운드씰
47.099	SHIM, HOOD LATCH 십




COWL & DASH COVER MOUNTING

37-027

37.200	PANEL, FRONT 판넬
37.201	PANEL, LH SIDE 판넬
37.202	PANEL, RH SIDE 판넬
39.363	FASTENER, RH SIDE PANEL 패스너
39.544	COVER, COWL ACCESS HOLE 커버
39.545	FASTENER, COWL ACCESS HOLE COVER 패스너
39.546	COWL ASSEMBLY 카울
39.547	FASTENER, COWL ASSEMBLY 패스너
39.570	COVER ASSEMBLY, DASH 커버

39.571 FASTENER, DASH COVER
패스너




FLOOR PLATE MOUNTING

37-028

37.902	MAT, FLOORPLATE 매트
37.903	MAT, FLOORPLATE 매트
38.196	ACID TRAY, BATTERY 에시트트레이
38.471	PAD, LH STEP NON-SKID 패드
38.472	PAD, RH STEP NON-SKID 패드
39.475	PLATE, FRONT FLOOR 플레이트
39.479	FASTENER, FRONT FLOOR PLATE 패스너
47.461	FLOOR PLATE ASSEMBLY 플로어매트

ASSEMBLY
COMPLETE — 39.689




BACK MIRROR


37-076

39.184 FASTENER, REAR VIEW MIRROR
패스너

39.689 MIRROR, REAR VIEW
미러




47.383 INSERT, OVERHEAD GUARD REAR
인서트



OVERHEAD GUARD MOUNTING

37-106


37.422	BUMPER, OVERHEAD GUARD REAR SUPPORT 범퍼
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
47.082	INSERT, DRIVER OVERHEAD GUARD 인서트
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스



SEAT ARMREST ASSEMBLY

37-124


- | | |
|--------|---------------------------------------|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |



MODEL DECALS & COUNTERWEIGHT MOUNTING

38-275

38.362	FASTENER, COUNTERWEIGHT COMPARTMENT COVER 패스너
38.862	COVER, COUNTERWEIGHT COMPARTMENT 커버
38.869	COUNTERWEIGHT 카운터웨이트
38.870	FASTENER, COUNTERWEIGHT (LOWER) 패스너
38.920	PIN, COUPLER 핀
38.921	PIN, COUPLER PIN CROSS 핀
40.139	DECAL, MODEL DESIGNATION 데칼
40.268	DECAL, SPEC 데칼




SIDE BATTERY REMOVAL(SBR)

38-276

12.190	SWITCH, BATTERY RETAINER INTERLOCK 스위치
12.191	HARNESS, BATTERY RETAINER INTERLOCK SWITCH 하네스
12.192	FASTENER, BATTERY RETAINER INTERLOCK SWITCH 패스너
12.375	SLIDE, BATTERY 슬라이드
12.376	SLIDE, BATTERY 슬라이드
12.377	FASTENER, BATTERY SLIDE 패스너
38.121	ROLLER, BATTERY 롤러
38.146	PLATE, BATTERY STOP 플레이트
38.196	ACID TRAY, BATTERY 에시드트레이


97.207 FASTENER, BATTERY ROLLER
패스너




LOAD BACK REST

39-519

- | | |
|--------|---|
| 34.977 | RETAINER, LOAD BACK REST TRUNNION PIN
리테이너 |
| 34.991 | FASTENER, LOAD SAFETY BACK REST EXT
패스너 |
| 34.995 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 92.226 | NUT, LOAD SAFETY BACK REST FASTENER
너트 |




- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 48.347 | FASTENER, SEAT ASSEMBLY
패스너 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |



- | | |
|--------|--|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
안전벨트 |
| 37.531 | BRACKET, SEAT SAFETY BELT MOUNTING
브라켓 |
| 37.720 | COVER, OPERATOR SEAT LATERAL RESTRAINT
커버 |
| 37.743 | COVER, SEAT SUPPORT LATCH
커버 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



SEAT MOUNTING


39-829

39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔



37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.915	SUSPENSION COVER, SEAT SUSPENSION 서스펜션커버
37.918	SUSPENSION ASSEMBLY, SEAT 서스펜션
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션
39.721	CUSHION, SEAT BACK REST 쿠션

39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너




NOTE: All Trucks Do Not Use All Fluid Key Numbers


TRUCK FLUIDS

40-260

99.901	ENGINE OIL 엔진오일
99.902	TRANSMISSION FLUID 트랜스미션오일
99.903	DRIVE AXLE FLUID 드라이브액슬
99.904	HYDRAULIC SUMP OIL 유압섬프오일
99.905	BRAKE FLUID 브레이크오일
99.906	AXLE END FLUID 액슬엔드오일
99.907	ENGINE ANTIFREEZE 부동액




40.010	DECAL, CLARK 데칼
40.012	DECAL, CLARK LOGO-SMALL 데칼
40.013	DECAL, CLARK LOGO-LARGE 데칼
40.142	DECAL, ELECTRICAL CIRCUIT DIAGRAM 데칼
40.309	DECAL, AC LOGO 데칼




40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너
40.006	LEGEND, PATENT 범례
40.042	DECAL, POLARITY 데칼
40.062	DECAL, DRIVERS CAUTION 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼
40.076	DECAL, ELECTRIC TRUCK CAUTION 데칼
40.089	PLATE, SAFETY INSTRUCTION 플레이트
40.130	LEGEND, SAFETY 범례

40.131	LEGEND, SAFETY 범례
40.138	DECAL, SAFETY 데칼
40.141	DECAL, HYDRAULIC SCHEMATIC 데칼
40.173	DECAL, IMPORTANT 데칼
40.183	DECAL, BATTERY DISCONNECT WARNING 데칼
40.241	DECAL, BRAKE OIL SPEC 데칼
40.248	DECAL, SERVICE CHART 데칼
40.326	DECAL, EE MARKING 데칼
40.328	DECAL, WHEEL NUT WARNING 데칼
40.329	FASTENER, ATTACHMENT NAME PLATE 패스너
40.330	PLATE, ATTACHMENT NAME 플레이트



- | | |
|--------|---|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 06.101 | LEVER ASSEMBLY, FORWARD & REVERSE
레버 |
| 13.111 | FASTENER, DIRECTIONAL CONTROL SWITCH
패스너 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |
| 14.245 | HARNESS, SWITCH HEATER CONTROL WIRING
하네스 |
| 14.986 | BRACKET, SWITCH HEATER CONTROL
브라켓 |
| 15.187 | HEATER, HYDRAULIC VALVE SWITCH
히터 |
| 15.700 | HEATER, STEER ANGLE SENSOR
히터 |


22.045	BRACKET, PARKING BRAKE PEDAL PIVOT MTG 브라켓
41.008	CONTROL, SWITCH HEATER 컨트롤
41.018	FASTENER, SWITCH HEATER CONTROL 패스너
41.425	HEATER, FOOT BRAKE SWITCH 히터
41.426	HEATER, PARKING BRAKE SWITCH 히터
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링



REAR HAND GRIP MOUNTING

47-005


- | | |
|--------|---|
| 37.421 | GROMMET, OVERHEAD GUARD REAR SUPPORT PIVOT
그로멧 |
| 47.385 | GRIP, OVERHEAD GUARD REAR HAND
그립 |
| 60.968 | WIRE, OVERHEAD GUARD REAR HAND GRIP SWITCH
와이어 |
| 97.216 | FASTENER, OVERHEAD GUARD REAR HAND GRIP
패스너 |



SEAT SWITCH INSTALLATION

47-010

- 37.976 CLAMP, SEAT WIRING HARNESS
클램프
- 40.306 DECAL, SEAT SWITCH
데칼




AUXILIARY VALVE LINES

50-120


50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인
50.427	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.428	LINE, 2ND AUXILIARY VALVE "B" PORT 라인
50.440	FITTING, 1ST AUXILIARY VALVE "A" PORT 피팅
50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅
50.862	SEAL, AUXILIARY VALVE A PORT 씰

50.869 SEAL, AUXILIARY VALVE B PORT
씰



50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.132	BRACKET, DEVICE HOSE REEL 브라켓
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.295	ROLLER, DEVICE HOSE UPPER 롤러
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너

50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-781


50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.156	CLIP, DEVICE HOSE 클립	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.200	COUPLING, DEVICE HOSE 커플링	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널 블록	59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널 블록	59.112	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
50.811	NUT, DEVICE HOSE FITTING 너트	95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너

96.316 FASTENER, DEVICE HOSE REEL
패스너



50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅

50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-783

50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너

50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-784

50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.156	CLIP, DEVICE HOSE 클립	50.811	NUT, DEVICE HOSE FITTING 너트
50.200	COUPLING, DEVICE HOSE 커플링	50.826	TERMINAL, DEVICE CABLE 터미널
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
50.660	BEARING, DEVICE HOSE LOWER SHEAVE 베어링	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.686	WIRE, DEVICE 와이어	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터	93.214	FASTENER, DEVICE HOSE SHEAVE PIVOT 패스너


93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-786

50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.200	COUPLING, DEVICE HOSE 커플링	59.072	GUARD, DEVICE HOSE 가드
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.316	GUARD, DEVICE RH HOSE 가드	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.811	NUT, DEVICE HOSE FITTING 너트	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록	95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓	96.316	FASTENER, DEVICE HOSE REEL 패스너
59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브	97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)


50-787

50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.200	COUPLING, DEVICE HOSE 커플링	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.316	GUARD, DEVICE RH HOSE 가드	59.112	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.811	NUT, DEVICE HOSE FITTING 너트	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너





95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너





STANDARD UPRIGHT



TRIPLE STAGE UPRIGHT



STANDARD UPRIGHT WITH WIRE




TRIPLE STAGE UPRIGHT WITH WIRE


ATTACHMENT HOSE & CABLE SETTINGS (UPRIGHT)

50-788


50.686	WIRE, DEVICE 와이어
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인




**MODEL: GTX162
GEX162**
UPRIGHT: STANDARD




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE & HI-LO




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: STANDARD



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: STANDARD



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: HI-LO

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-791


- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-792


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅
59.091	FITTING, DEVICE HYDRAULIC LINE 피팅




QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION

50-798

- | | |
|--------|---|
| 59.092 | QUICK DISCONNECT, DEVICE HOSE
퀵디스커넥트 |
| 59.131 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |
| 59.132 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |




- | | |
|--------|---|
| 59.130 | TIE STRAP, DEVICE LINE FOR HIGH TERMINATION
타이스트랩 |
| 59.134 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.140 | COUPLING, DEVICE LINE FOR HIGH TERMINATION
커플링 |
| 59.141 | COUPLING, DEVICE LINE FOR HIGH TERMINATION
커플링 |
| 59.142 | FITTING, DEVICE LINE FOR HIGH TERMINATION
피팅 |
| 59.143 | CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
캡 |
| 59.144 | BRACKET, DEVICE LINE FOR HIGH TERMINATION
브라켓 |
| 97.235 | FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION
패스너 |
| 97.238 | FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION
패스너 |



HIGH TERMINATION FOR DEVICE HOSE ADAPTATION


50-800

59.134	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.135	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.136	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.137	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.138	CLAMP, DEVICE LINE FOR HIGH TERMINATION 클램프
59.139	CLAMP, DEVICE LINE FOR HIGH TERMINATION 클램프
97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너



14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디스커넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT 피팅
59.132	FITTING, DEVICE LINE QUICK DISCONNECT 피팅




FORK POSITIONER (BASIC)

53-170

53.054	GUIDE, FORK 가이드
53.069	FASTENER, FORK CYLINDER ROD END 패스너
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.746	LINE, FORK CYLINDER ROD END 라인
53.772	LINE, FORK CYLINDER ANCHOR END 라인
53.887	LINE, FORK CYLINDER ANCHOR END 라인
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그

54.215	LINE, FORK CYLINDER ROD END 라인
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크
54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
54.553	FITTING - LUB, FORK POSITIONER 피팅
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너




40.343	DECAL, ATTACHMENT SAFETY 데칼
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링

54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서
54.314	SPACER, SIDE SHIFTER CYLINDER REAR 스페이서

ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

- | | |
|--------|---|
| 53.020 | CYLINDER ASSEMBLY, SIDE SHIFTER
실린더 |
| 53.109 | GLAND, SIDE SHIFTER CYLINDER
그랜드 |
| 53.110 | RETAINER, SIDE SHIFTER CYLINDER GLAND
리테이너 |
| 53.117 | BUSHING, SIDE SHIFTER CYLINDER GLAND
부싱 |
| 53.215 | FITTING, SIDE SHIFTER CYLINDER ROD PORT
피팅 |
| 53.676 | ROD, SIDE SHIFTER CYLINDER PISTON
로드 |
| 54.222 | PACKING KIT, SIDE SHIFTER CYLINDER
패킹키트 |
| 54.416 | BARREL, SIDE SHIFT CYLINDER
배럴 |
| 54.556 | BALL, SIDE SHIFTER CYLINDER ROD PORT
볼 |


97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
세트스크류




52.149	NUT, SIDE SHIFTER CYLINDER ANCHOR PORT LINE FITTING 너트
53.023	ANCHOR, SIDE SHIFTER CYLINDER ROD END 앵커
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인

54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트

FORK STOP
PIN KIT — 34.359



KNOB TYPE - CASCADE




LEVER TYPE - HEBEI

FORK

66-058

- | | |
|--------|------------------------------------|
| 34.350 | FORK ASSEMBLY
포크 |
| 34.359 | KIT, FORK STOP PIN (CAPTIVE)
키트 |




LIFT CYLINDER PIPING

66-065


28.741	LINE ASSY, LIFT CYLINDER 라인
28.742	LINE, LIFT CYLINDER LEFT HAND 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
28.790	FITTING, FINAL LIFT CYLINDER LINE 피팅
31.033	CLAMP, LIFT CYLINDER LINE TO SUPPORT 클램프
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.215	FASTENER, LIFT LINE CLAMP 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인

34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.163	PLUG, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD PO 플러그
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
66.250	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너

34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
94.059	NUT, LIFT CYLINDER FASTENER 너트




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.084	SHEAVE, LIFT CHAIN 쉬브
34.101	CHAIN, LIFT 체인
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트

91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너




28.729	LINE, LIFT CYLINDER 라인
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.869	FITTING, LIFT CYLINDER INLET 피팅
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드

66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.163	PLUG, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD PO 플러그
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.146	SUPPORT, LIFT CYLINDER BARREL 서포트

34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트




34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커

34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.152	ANCHOR, RAIL LIFT CHAIN 앵커
34.153	SHEAVE, UPRIGHT RAIL CHAIN 쉬브
34.156	FASTENER, RAIL CHAIN TO ANCHOR 패스너
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트
91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트




34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.525	BEARING, LIFT CYLINDER ROD 베어링
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브

34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔



34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.146	SUPPORT, LIFT CYLINDER BARREL 서포트


34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트




HI-LO SECONDARY CYLINDER

66-083


66.207	PISTON, FINAL LIFT CYLINDER 피스톤
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.404	CAP, FINAL LIFT CYLINDER GLAND 캡



34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 워셔




- | | |
|--------|---|
| 66.395 | CHECK VALVE, FINAL LIFT CYLINDER
체크밸브 |
| 66.397 | WASHER, FINAL LIFT CYLINDER CHECK VALVE
와셔 |
| 66.398 | SNAP RING, FINAL LIFT CYLINDER CHECK VALVE
스냅링 |
| 66.400 | CYLINDER ASSEMBLY, FINAL LIFT
실린더 |
| 66.401 | BARREL, FINAL LIFT CYLINDER
배럴 |
| 66.402 | PACKING KIT, FINAL LIFT CYLINDER
패킹키트 |
| 66.403 | PISTON ROD, FINAL LIFT CYLINDER
피스톤로드 |
| 66.413 | SPACER, FINAL LIFT CYLINDER PISTON ROD
스페이서 |
| 66.444 | GLAND, FINAL LIFT CYLINDER
그랜드 |



28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피봇
28.729	LINE, LIFT CYLINDER 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인
31.869	FITTING, LIFT CYLINDER INLET 피팅
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더


34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.139	BUSHING, LIFT CHAIN HOSE SHEAVE 부싱
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.164	FITTING, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD 피팅
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너



24.271	PLUG, AIR COMPRESSOR CYLINDER HEAD 플러그
28.729	LINE, LIFT CYLINDER 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
28.746	FITTING, LIFT CYLINDER LINE 피팅
28.747	FITTING, LIFT CYLINDER LINE 피팅
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.037	CAP, UPRIGHT TRUNNION 캡
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너


34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.081	SPACER, LIFT CHAIN SHEAVE CARRIER 스페이서
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.186	ROLLER, UPRIGHT 롤러
34.271	FASTENER, LIFT CYLINDER LOWER 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더

34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.167	SHIM, LIFT CYLINDER UPPER 심
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
66.304	FASTENER, LIFT CYLINDER LINE CLAMP 패스너
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.471	LINE, LIFT CYLINDER FEED 라인
66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리지
66.507	TEE, LIFT CYLINDER LINE 티
66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
66.509	CLAMP, LIFT CYLINDER LINE 클램프
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너



34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트

66.135	SPACER, SHEAVE CARRIER GUIDE 스페이서
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트



39.706	SUPPORT, SEAT 서포트
39.719	SEAT ASSEMBLY 시트
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트