


부품 매뉴얼 PARTS MANUAL

EPX 20/25/30/32

SERIAL NUMBER : EPX360 - XXXX - 9652KF

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Part No. 8041027

Dec. 2013



(본사) 경기도 부천시 오정구 오정동 202-1
(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea
(공장) 경남 창원시 웅남동 40-1
(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea




02-487	ACCELERATOR PEDAL & LINKAGE 악셀레이터 페달& 링크이지	25-368	STEERING GEAR MOUNTING 스티어링 기어 마운팅
13-182	STROBE LIGHT 경광등	26-242	STEER LINES 스티어링 라인
13-194	WORK LIGHT 작업등	26-266	STEER CYLINDER 스티어링 실린더
13-224	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드& 턴시그널 라이트 조립그룹	26-278	STEER AXLE ASSEMBLY 스티어링 액슬 어셈블리
13-265	TRAVEL ALARM INSTALLATION 주행 알람 조립그룹	26-279	STEER AXLE MOUNTING 스티어링 액슬 마운팅
13-307	INSTRUMENT PANEL 계기판	29-017	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
13-327	REAR ACCESSORY MOUNTING 리어 악세서리 마운팅	29-027	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
14-023	ELECTRICAL COMPONENTS 전기장치 구성품	29-233	HYDRAULIC PUMP 유압 펌프
14-025	ELECTRICAL WIRING 전기장치 와이어링	29-239	HYDRAULIC OIL FILTER 유압 오일 필터
14-426	LICENSE PLATE MOUNTING 번호판 장착	29-242	SUMP TANK MOUNTING 섬프 탱크 마운팅
15-038	ELECTRICAL COMPONENTS (EE) 전기장치 구성품 (EE)	29-296	HYDRAULIC PUMP ASSEMBLY 유압 펌프 어셈블리
15-071	CABLE INSTALLATION 케이블 조립그룹	30-342	PUSH BUTTON WIRING 푸시버튼 와이어링
16-010	TRACTION & PUMP MOTORS MOUNTING 트랙션& 펌프 모터 마운팅	30-530	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
16-194	PUMP MOTOR ASSEMBLY 펌프 모터 어셈블리	30-531	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
16-195	DRIVE MOTOR ASSEMBLY 드라이브 모터 어셈블리	30-532	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
17-118	CONTACTOR ASSEMBLY 컨택터 어셈블리	30-533	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
19-027	CONTROLLER MOUNTING 컨트롤러 마운팅	30-534	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
19-028	CONTROLLER MOUNTING (EE) 컨트롤러 마운팅 (EE)	30-535	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
20-097	DRIVE AXLE MOUNTING 드라이브 액슬 마운팅	30-536	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
20-129	DRIVE AXLE 드라이브 액슬	30-537	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
20-442	DIFFERENTIAL & CARRIER 디퍼렌셜& 캐리어	30-543	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
20-443	DIFFERENTIAL CASE & GEAR 디퍼렌셜 케이스& 기어	30-544	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
20-444	DRIVE AXLE 드라이브 액슬	30-545	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-008	BRAKE ASSEMBLY 브레이크 어셈블리	30-546	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)
22-011	BRAKE ASSEMBLY LH 브레이크 어셈블리 - 좌	30-547	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브휠& 타이어 마운팅	30-548	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-014	STEER WHEEL & TIRE MOUNTING 스티어링휠& 타이어 마운팅	30-549	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)
22-041	DRIVE WHEEL AND TIRE 드라이브 휠& 타이어	30-565	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)
22-054	BRAKE ASSEMBLY RH 브레이크 어셈블리 - 우	30-597	HYDRAULIC CONTROL VALVE 유압 컨트롤 밸브
23-414	BRAKE MASTER CYLINDER 브레이크 마스터 실린더	30-674	HYDRAULIC CONTROL VALVE-4 SPOOL 유압 컨트롤 밸브 - 4 스풀
23-468	BRAKE LINES 브레이크 라인	31-142	HYDRAULIC TILT LINES 유압 틸트 라인
23-533	PARKING BRAKE LINKAGE 파킹 브레이크 링크이지	31-195	HYDRAULIC SUPPLY LINES 유압 공급 라인
25-049	STEERING HANDWHEEL MOUNTING 스티어링 핸들 휠 마운팅	31-312	HYDRAULIC LIFT LINES 유압 리프트 라인
25-076	STEERING UNIT 스티어링 유닛	31-328	HYDRAULIC RETURN LINES 유압 리턴 라인
25-144	STEERING COLUMN ASSEMBLY 스티어링 컬럼 어셈블리	31-787	HYDRAULIC LIFT LINE 유압 리프트 라인
25-367	STEERING COLUMN MOUNTING 스티어링 컬럼 마운팅	32-129	TILT CYLINDER 틸트 실린더

32-167	TILT AMOUNT GROUP 틸트 어마운트 그룹	47-010	SEAT SWITCH INSTALLATION 시트 스위치 조립그룹
32-171	ACCUMULATOR INSTALLATION 어큐뮬레이터 조립그룹	50-171	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
32-173	TILT CYLINDER MOUNTING 틸트 실린더 마운팅	50-172	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적용)
33-069	RELIEF VALVE ASSEMBLY 릴리프 밸브 어셈블리	50-175	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적용)
33-130	SELECTOR SOLENOID VALVE 셀렉터 솔레노이드 밸브	50-176	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적용)
34-044	LOAD BACK REST MOUNTING 로드 백 레스트 마운팅	50-177	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적용)
34-103	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-232	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
34-126	UPRIGHT MOUNTING 마스트 마운팅	50-269	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
34-209	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-270	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
37-003	OVERHEAD GUARD COVER 오버헤드가드 커버	50-289	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
37-076	BACK MIRROR 백미러	50-290	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
37-077	OVERHEAD GUARD REAR INSERT 오버헤드 가드 리어 인서트	50-291	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
37-103	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅	50-292	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
37-124	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	50-293	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) 어태치 호스& 케이블 적용 (마스트)
38-238	MODEL DECALS & COUNTERWEIGHT MOUNTING 모델 데칼& 카운터웨이트 마운팅	50-407	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
38-281	SIDE BATTERY REMOVAL(SBR) 사이드 배터리 제거 (SBR)	50-410	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
39-514	SEAT MOUNTING 시트 마운팅	50-432	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
39-519	LOAD BACK REST 로드 백 레스트	50-439	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적용 (마스트)
39-547	LOAD BACK REST 로드 백 레스트	50-765	HIGH TERMINATION PLUMBING 하이 터미네이션 기관
39-577	SEAT ASSEMBLY 시트 어셈블리	50-791	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
39-583	SEAT MOUNTING 시트 마운팅	50-794	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
39-661	SEAT ASSEMBLY 시트 어셈블리	50-796	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
39-773	SHEET METAL & TRIM 시트 메탈& 트림	50-797	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적용 (캐리지)
39-774	COWL & DASH COVER MOUNTING 카울& 대시커버 마운팅	50-798	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)
39-775	FLOOR PLATE MOUNTING 플로어 플레이트 마운팅	50-819	DEVICE LINE ADAPTORS 디바이스 라인 어댑터
39-781	BATTERY COVER MOUNTING 배터리 커버 마운팅	50-820	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적용)
39-829	SEAT MOUNTING 시트 마운팅	53-024	FORK POSITIONER 포크 포지셔너
39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리	53-084	FORK POSITIONER 포크 포지셔너
39-932	BATTERY COVER MOUNTING 배터리 커버 마운팅	53-146	F/P SIDESHIFT CYLINDER 포크포지셔너 사이드 쉬프트 실린더
40-252	DECALS 데칼	53-164	FORK POSITIONER 포크 포지셔너
40-253	LOGO & WIRING DIAGRAM DECALS 로고& 와이어링 데칼	53-168	FORK POSITIONER (SHIFTING) 포크 포지셔너 (쉬프트 타입)
40-260	TRUCK FLUIDS 트럭 윤활유	53-170	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
41-008	STORAGE CONSOLE 저장 콘솔	53-187	SIDE SHIFT ASSEMBLY 사이드 쉬프트 어셈블리
41-120	COLD STORAGE ENVIRONMENT 냉장사양	53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더
47-005	REAR HAND GRIP MOUNTING 리어 핸드 그립 마운팅	53-223	FORK POSITIONER CYLINDER 포크 포지셔너 실린더
47-009	OVERHEAD GUARD 오버헤드가드	54-015	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)

66-058	FORK 포크
66-088	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-159	LIFT CYLINDER ASSEMBLY 리프트 실린더 어셈블리
66-160	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-179	STANDARD UPRIGHT 표준 마스트
66-232	TRIPLE STAGE UPRIGHT 3단 마스트
66-233	HI-LO UPRIGHT 하이-로우 마스트
66-235	PRIMARY CYLINDER ASSEMBLY 프라이머리 실린더 어셈블리
66-236	PRIMARY CYLINDER ASSEMBLY 프라이머리 실린더 어셈블리
75-(17)212	LIFT LIMIT SWITCH 리프트 제어 스위치
75-(31)505	TILT LIMIT DEVICE 틸트 제어 장치
75-(33)014	VARIABLE RELIEF VALVE INSTALLATION 가변 릴리프 밸브 조립그룹
75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치

PEDAL ASSEMBLY
INCLUDES ITEMS
MARKED "P"

62.050




ACCELERATOR PEDAL & LINKAGE


02-487

02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.284	FASTENER, PEDAL TO BRACKET PIVOT PIN 패스너
02.285	STOP, ACCELERATOR PEDAL LINKAGE 스톱
02.317	ROLLER, ACCELERATOR PEDAL 롤러
02.329	FASTENER, ACCELERATOR PEDAL 패스너
02.465	FASTENER, ACCELERATOR CONTROL LINKAGE 패스너
03.419	WEAR PLATE, ACCELERATOR PEDAL ROLLER 웨어플레이트
03.671	ACTUATOR, ACCELERATOR CONTROL 액추에이터


13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너
13.572	BRACKET, ACCEL CONTROL ASSEMBLY MOUNTING 브라켓
13.573	FASTENER, ACCELERATOR CONTROL ASSY MOUNTING BRACKE 패스너
62.050	PEDAL ASSEMBLY, ACCELERATOR 페달
90.673	NUT, ACCELERATOR PEDAL BRKT MOUNTING FASTENER 너트



- | | |
|--------|--------------------------------|
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |
| 13.333 | BULB, WARNING LIGHT
전구 |
| 60.821 | GLOBE, STROBE LIGHT
글로브 |
| 60.822 | BASE, STROBE LIGHT
베이스 |




- | | |
|--------|--|
| 13.281 | FASTENER, ADJ HEADLAMP SWIVEL
패스너 |
| 13.284 | BRACKET, ADJUSTABLE HEADLAMP
브라켓 |
| 13.285 | FASTENER, ADJUSTABLE HEADLAMP BRACKET
패스너 |
| 60.325 | BULB, HEADLAMP
전구 |
| 60.795 | LIGHT, REAR WORK
라이트 |



13.270	HEADLAMP, ADJUSTABLE 헤드 램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래서

60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧
60.324	BULB, HEADLAMP 전구
60.368	RELAY, HEADLIGHTS 릴레이
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.535	SWITCH, WORK LIGHT 스위치
95.299	FASTENER, HEADLAMP GUARD 패스너






TRAVEL ALARM INSTALLATION

13-265

- | | |
|--------|--|
| 13.681 | FASTENER, WARNING DEVICE
패스너 |
| 42.001 | WARNING DEVICE, AUDIBLE (AIR OPER)
경고장치 |


ASSEMBLY
COMPLETE — 13.000



INSTRUMENT PANEL


13-307

- | | |
|--------|----------------------------------|
| 13.000 | PANEL, INSTRUMENT CLUSTER
판넬 |
| 37.250 | HOUSING, INSTRUMENT PANEL
하우징 |
| 39.510 | HOUSING, INSTRUMENT PANEL
하우징 |




13.206	BULB, BACK-UP LAMP 전구
13.217	FASTENER, COM STOP & TAIL LAMP ASSY MTG 패스너
13.218	BULB, STOP & TAIL LAMP 전구
13.330	BRACKET, WARNING LIGHT 브라켓
13.331	FASTENER, WARNING LIGHT BRACKET 패스너
13.332	ASSEMBLY, WARNING LIGHT 경고등
13.675	BULB, TURN LIGHT 전구
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
60.795	LIGHT, REAR WORK 라이트

60.797	GROMMET, REAR ACCESSORY WIRE 그롬멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.904	SWITCH, STROBE LIGHT 스위치
60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.960	HARNESS, REAR WORK LAMP EXTENSION 하네스
60.962	SPACER, REAR WORK LAMP MOUNTING 스페이서
60.964	RELAY, FOOT BRAKE 릴레이



13.000	PANEL, INSTRUMENT CLUSTER 판넬
13.003	HORN 혼
13.004	FASTENER, HORN MOUNTING BRACKET 패스너
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL 패스너
15.710	RELAY, ELECTRICAL 릴레이
16.153	FAN, PUMP MOTOR 팬
16.159	BRACKET, PUMP MOTOR FAN MOUNTING 브라켓
37.967	PLUG, INSTRUMENT PANEL 플러그
39.417	GROUND STRAP, ELECTRIC TRUCK 접지케이블


39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP 패스너
44.409	SWITCH, SPEED REDUCTION 스위치
49.101	SENSOR, LEVER POSITION 센서
49.204	BRACKET, LEVER POSITION SENSOR 브라켓
49.205	BRACKET, LEVER POSITION SENSOR SUPPORT 브라켓
60.368	RELAY, HEADLIGHTS 릴레이
67.217	CONVERTER, DC-DC FOR ACCESSORY 컨버터
67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL 컨버터
97.142	FASTENER, LEVER POSITION SENSOR 패스너
97.143	FASTENER, LEVER POSITION SENSOR BRACKET 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL 패스너
97.212	FASTENER, PUMP MOTOR FAN MOUNTING BRACKET 패스너
97.213	FASTENER, PUMP MOTOR FAN MOUNTING 패스너




12.392	FASTENER, CHASSIS GROUND 패스너
14.114	HARNESS, MACHINE WIRING 하네스
14.352	FUSE, CONTROL CIRCUIT 퓨즈
14.745	FASTENER, FUSE HOLDER MOUNTING BRACKET 패스너
15.447	DIODE, HARNESS 다이오드
18.010	CLIP, HARNESS 클립
18.011	FASTENER, HARNESS CLIP 패스너
18.187	TERMINAL, FUSE 터미널
65.832	COVER, FUSE BOX 커버

93.661 FASTENER, TERMINAL BLOCK
패스너






02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
15.833	WIRE HARNESS, LICENCE LAMP 와이어하네스
18.032	FASTENER, WIRE HARNESS CLAMP 패스너
18.158	CLAMP, WIRE HARNESS 클램프
60.042	HEAD, FORK POSITIONING SWITCH ACTUATOR 헤드
60.043	ARM, FORK POSITIONING INDICATOR SWITCH 암
62.004	PLATE, LICENSE 플레이트
62.007	SHIM, TANK BRACKET 심
62.280	LINE, ENGINE TURBOCHARGER INTAKE 라인



ELECTRICAL COMPONENTS (EE)

15-038


40.024	PLATE, UNDERWRITERS LABEL 플레이트
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너
40.326	DECAL, EE MARKING 데칼
47.087	CONNECTOR, ELECTRIC TRUCK GROUND STRAP 커넥터
47.310	CHAIN, GROUND STRAP 체인
47.311	CHAIN, GROUND STRAP 체인




14.039	RECEPTACLE & LEAD ASSEMBLY, BATTERY 리셉터클& 리드
14.040	RECEPTACLE, BATTERY 리셉터클
15.623	CABLE, CONTACTOR R+ 케이블
15.625	CABLE, CONTACTOR L+ 케이블
15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블
15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블

15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
15.820	BOOT, CABLE 부트
94.069	FASTENER, BATTERY RECEPTACLE 패스너






16.000	MOTOR ASSEMBLY, DRIVE 모터
16.001	FASTENER, DRIVE MOTOR 패스너
16.042	FASTENER, DRIVE MOTOR 패스너
16.071	SEAL, DRIVE MOTOR TO AXLE 씰
16.287	WIRE, LEAD GROUND FROM MOTOR 와이어
16.500	MOTOR ASSEMBLY, PUMP 모터
16.704	DAMPENER, PUMP MOTOR VIBRATION 댐프너
16.708	FASTENER, PUMP MOTOR VIBRATION DAMPENER 패스너




- | | |
|--------|--|
| 16.152 | SENSOR BEARING, PUMP MOTOR ROTOR
센서베어링 |
| 16.154 | COVER, PUMP MOTOR ROTOR END
커버 |
| 16.155 | WASHER, PUMP MOTOR ROTOR BEARING
와셔 |
| 16.156 | RING, PUMP MOTOR ROTOR BEARING
링 |
| 16.157 | ROTOR, PUMP MOTOR
로터 |
| 16.178 | BASE, PUMP MOTOR TERMINAL
베이스 |
| 16.182 | COVER, PUMP MOTOR DRIVE END
커버 |
| 16.184 | SENSOR KIT, PUMP MOTOR TEMPERATURE
센서키트 |
| 16.185 | STATOR ASSY, DRIVE MOTOR
스테이터 |

16.500	MOTOR ASSEMBLY, PUMP 모터
16.502	BEARING, PUMP MOTOR DRIVE END 베어링
16.573	TERMINAL BLOCK, HYDRAULIC PUMP MOTOR 터미널블록
16.593	STATOR ASSY, HYDRAULIC-PUMP MOTOR 스테이터
16.594	RETAINER, HYDRAULIC PUMP MOTOR DRIVE END FRAME 리테이너
93.258	FASTENER, PUMP MOTOR DRIVE END FRAME COVER 패스너
93.265	FASTENER, HYDRAULIC PUMP MOTOR TERMINAL 패스너
95.045	WASHER, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 와셔
95.501	FASTENER, PUMP MOTOR TERMINAL BLOCK CONNECTOR 패스너
95.873	NUT, HYDRAULIC PUMP MOTOR TERMINAL CLAMP FASTENER 너트



ASSEMBLY
COMPLETE 16.000

NOTE :
ITEMS TO BE NOT SOLD
SEPARATELY MARKED "NSS"




DRIVE MOTOR ASSEMBLY

16-195


16.000	MOTOR ASSEMBLY, DRIVE 모터
16.013	SPACER, DRIVE MOTOR DRIVE END 스페이서
16.023	FASTENER, DRIVE MOTOR DRIVE END FRAME 패스너
16.068	FASTENER, DRIVE MOTOR END FRAME 패스너
16.071	SEAL, DRIVE MOTOR TO AXLE 셀
16.077	RETAINER, DRIVE MOTOR ARMATURE (PULLER) 리테이너
16.090	COVER, DRIVE MOTOR COMMUTATOR END 커버
16.092	RETAINER, DRIVE MOTOR ARMATURE SHAFT PINION BEARING 리테이너
16.105	SPACER, DRIVE MOTOR MOUNTING 스페이서

16.106	TERMINAL BLOCK, DRIVE MOTOR 터미널블록
16.114	WASHER, DRIVE MOTOR DRIVE END THRUST 와셔
16.116	FASTENER, DRIVE MOTOR TERMINAL 패스너
16.120	FASTENER, DRIVE MOTOR ARMATURE SHAFT PINION GEAR 패스너
16.147	SENSOR BEARING, DRIVE MOTOR ROTOR 센서베어링
16.149	ROTOR, DRIVE MOTOR 로터
16.165	BEARING, DRIVE MOTOR DRIVE END 베어링
16.185	STATOR ASSY, DRIVE MOTOR 스테이터
16.189	COVER, DRIVE MOTOR DRIVE END 커버
16.191	SENSOR KIT, DRIVE MOTOR TEMPERATURE 센서키트
16.290	SEAL, DRIVE MOTOR ROTOR BEARING 씰
16.544	FASTENER, COMMUTATOR END BEARING COVER 패스너
93.232	WASHER, DRIVE MOTOR TERMINAL BLOCK FASTENER 와셔
93.233	FASTENER, DRIVE MOTOR TERMINAL 패스너
93.731	NUT, DRIVE MOTOR FASTENER 너트



65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.664	CONDUCTOR, CONTACTOR STATIONARY CONTACT 컨덕터
65.930	ASSEMBLED COIL & MAGNET FRAME, LINE CONTACTOR 코일& 마그넷
65.942	CONTACT SET, LINE CONTACTOR 컨택트세트
67.170	SUPPORT, LINE CONTACTOR STATIONARY CONTACT 서포트

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




CONTROLLER MOUNTING

19-027

19.240	FASTENER, CONTROL PANEL MOUNTING 패스너
65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.492	FAN, ELECTRICAL COOLING 팬
67.118	BRACKET, LINE CONTACTOR MOUNTING 브라켓
67.188	COVER, FAN 커버
67.208	FAN, COOLING 팬
67.211	FUSE, TRACTION CONTROLLER 퓨즈
67.213	FUSE, PUMP CONTROLLER 퓨즈
67.300	CONTROLLER, TRACTION 컨트롤러

67.400	CONTROLLER, PUMP 컨트롤러
94.296	FASTENER, ELECTRICAL COOLING FAN 패스너
96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너
97.976	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너






- | | |
|--------|--|
| 15.396 | BOX, FUSE MOUNTING
박스 |
| 17.539 | GROMMET, CONTACTOR BOX
그로멧 |
| 19.240 | FASTENER, CONTROL PANEL MOUNTING
패스너 |
| 19.573 | CONDUCTOR, CONTACTOR PANEL CONNECTING
컨덕터 |
| 19.636 | FASTENER, CONTACTOR CONTROL TERMINAL
패스너 |
| 60.936 | BRACKET, CONTACTOR COVERING BODY
브라켓 |
| 60.937 | BRACKET, CONTACTOR COVERING
브라켓 |
| 60.938 | TERMINAL, CONTACTOR CONNECTING
터미날 |
| 60.939 | GROMMET, CONTACTOR CONNECTING CONDUCTOR
그로멧 |

65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.336	CONDUCTOR, CONTROL PANEL FUSE CONNECTING 컨덕터
65.492	FAN, ELECTRICAL COOLING 팬
65.707	COVER, CONTROL PANEL FUSE BOX 커버
67.064	CONDUCTOR, LINE CONTACTOR 컨덕터
67.188	COVER, FAN 커버
67.208	FAN, COOLING 팬
67.211	FUSE, TRACTION CONTROLLER 퓨즈
67.213	FUSE, PUMP CONTROLLER 퓨즈
67.300	CONTROLLER, TRACTION 컨트롤러
67.400	CONTROLLER, PUMP 컨트롤러
92.112	FASTENER, CONTACTOR BOX 패스너
94.016	FASTENER, CONTROL PANEL FUSE BOX COVER 패스너
94.296	FASTENER, ELECTRICAL COOLING FAN 패스너
95.009	FASTENER, FUSE BOX MOUNTING 패스너
96.976	FASTENER, CONTACTOR MOUNTING 패스너
97.086	FASTENER, CONTACTOR BOX BODY 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



DRIVE AXLE MOUNTING

20-097


- | | |
|--------|--------------------------------------|
| 20.370 | AXLE ASSEMBLY, DRIVE
드라이브액슬 |
| 20.377 | FASTENER, DRIVE AXLE TO FRAME
패스너 |



20.228	FASTENER, THIN FLANGE TO AXLE 패스너
20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.376	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.403	GASKET, DIFFERENTIAL & CARRIER HOUSING 가스켓
20.427	PLUG, DIFFERENTIAL & AXLE HOUSING DRAIN 플러그
20.555	FASTENER, DRIVE AXLE SHAFT PULLER 패스너
20.560	GASKET, AXLE END HUB CAP 가스켓
20.586	SHAFT, DRIVE AXLE 샤프트
92.859	WASHER, DIFFERENTIAL AND CARRIER FASTENER 와셔


96.737 LOCKWASHER, DRIVE AXLE SHAFT FASTENER
로크와셔

ФОРКЛИФТ
www.forklift.ru




09.005	GEAR, OUTPUT 기어
09.006	FASTENER, OUTPUT GEAR TO PINION 패스너
09.013	BEARING, INPUT PINION SHAFT 베어링
09.016	GEAR, INPUT PINION 기어
09.079	CONE, INPUT PINION SHAFT - INNER 콘
09.080	CUP, INPUT PINION SHAFT - INNER 컵
09.083	CARRIER, INPUT PINION SHAFT BEARING 캐리어
09.084	FASTENER, INPUT PINION SHAFT BEARING CARRIER 패스너
09.085	RETAINER, INPUT PINION SHAFT OUTER BEARING 리테이너

20.203	NUT, DIFFERENTIAL PINION COMPANION FLANGE 너트
20.219	BEARING, DIFFERENTIAL 베어링
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 심
20.240	SPACER, DIFFERENTIAL PINION BEARING 스페이서
20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링
20.259	CARRIER & CAP ASSEMBLY, DIFFERENTIAL 캐리어& 캡
20.267	NUT, DIFFERENTIAL BEARING ADJUSTING 너트
20.268	BEARING, DIFFERENTIAL 베어링
20.271	LOCK, DIFFERENTIAL BEARING ADJUSTING NUT 로크
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.287	CASE & GEAR ASSEMBLY, DIFFERENTIAL 케이스& 기어
20.288	SPACER, PINION BEARING CONE 스페이서
20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.376	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.404	DOWEL PIN, DIFFERENTIAL CARRIER AND CAP ASSEMBLY 다웰핀
93.229	WASHER, DIFFERENTIAL CASE TO RING GEAR FASTENER 와셔
96.739	WASHER, INPUT PINION SHAFT BEARING CARRIER FASTENER 와셔




20.281	FASTENER, DIFF SIDE PINION PIN 패스너
20.282	SPIDER, DIFFERENTIAL PINION 스파이더
20.283	GEAR, DIFFERENTIAL SIDE PINION 기어
20.284	WASHER, DIFF SIDE PINION GEAR THRUST 와셔
20.285	GEAR, DIFFERENTIAL SIDE 기어
20.286	WASHER, DIFFERENTIAL SIDE GEAR THRUST 와셔
20.287	CASE & GEAR ASSEMBLY, DIFFERENTIAL 케이스 & 기어
20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.376	AXLE ASSEMBLY, DRIVE 드라이브액슬



08.261	DIPSTICK, TRANSMISSION OIL LEVEL 디프스틱
09.060	SEAL, TRANSFER CASE DIPSTICK SUPPORT 씰
20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.376	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.387	HOUSING, DIFFERENTIAL & AXLE 하우징
20.539	SUPPORT, DRIVE AXLE SPINDLE (RH) 서포트
20.540	SUPPORT, DRIVE AXLE SPINDLE (LH) 서포트
20.570	FASTENER, DRIVE WHEEL MOUNTING 패스너
20.575	CUP, DRIVE AXLE HUB OUTER BEARING 컵


20.581	HUB ASSEMBLY, DRIVE AXLE 허브
20.599	NUT, DRIVE AXLE HUB BEARING OUTER RETAINING 너트
20.600	LOCK, DRIVE AXLE HUB BEARING RETAINING NUT 로크
20.612	CUP, DRIVE AXLE HUB INNER BEARING 컵
20.616	SEAL, DRIVE AXLE HUB 씰
20.627	VENT, DIFFERENTIAL & AXLE 벤트
21.212	TUBE, TRANSMISSION OIL LEVEL DIPSTICK 튜브
22.898	CABLE, PARKING BRAKE DRAW - LH 케이블
22.900	CABLE, PARKING BRAKE DRAW - RH 케이블
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
23.246	FASTENER, BRAKE ASSEMBLY 패스너
23.256	DISK OR DRUM, DRIVE WHEEL BRAKE 디스크
23.730	FASTENER, BRAKE ASSEMBLY 패스너
29.065	PIN, WET DISC COOLING PUMP HOUSING DOWEL 핀
90.383	WASHER, DRIVE AXLE HUB BEARING FASTENER 와셔
96.117	WASHER, DRIVE WHEEL MOUNTING FASTENER 와셔
96.738	NUT, DRIVE WHEEL MOUNTING FASTENER 너트



22.088	RETAINER, PARKING BRAKE LINKAGE LEVER FULCRUM 리테이너	23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
22.195	CUP, BRAKE SHOE GUIDE 컵	23.247	SHOE SET, BRAKE LINING 슈
22.202	PIN, BRAKE CABLE CLEVIS 핀	23.249	SPRING, LH BRAKE RETURN 스프링
22.218	SPRING, BRAKE SHOE ADJUSTING CAM STUD 스프링	23.258	FASTENER, LH WHEEL CYLINDER 패스너
22.280	SPRING, BRAKE SHOE GUIDE PIN 스프링	23.262	SPRING, BRAKE SHOE RETURN 스프링
22.898	CABLE, PARKING BRAKE DRAW - LH 케이블	23.292	ANCHOR, BRAKE SHOE 앵커
22.900	CABLE, PARKING BRAKE DRAW - RH 케이블	23.342	FASTENER, BRAKE SPRING ANCHOR 패스너
23.048	SPRING, PARKING BRAKE OPERATING ARM ANTI-RATTLE 스프링	23.346	ARM, PARKING BRAKE 암
23.214	CYLINDER ASSEMBLY, LH BRAKE 실린더	23.389	RETAINER, PARKING BRAKE CABLE 리테이너
23.216	REPAIR KIT, BRAKE CYLINDER (LH) 리페어키트	23.546	CABLE, BRAKE ADJUSTER (RH) 케이블
23.223	BLEEDER, BRAKE WHEEL CYLINDER 블리더	23.550	LEVER, BRAKE ADJUSTER (LH) 레버
23.237	COVER, RH BRAKE ADJUSTOR 커버	23.551	LEVER, BRAKE ADJUSTER (RH) 레버
23.242	PLATE, LH BRAKE BACKING 플레이트	23.552	SPRING, BRAKE ADJUSTER (LH) 스프링
23.243	PLATE, RH BRAKE BACKING 플레이트	23.553	SPRING, BRAKE ADJUSTER (RH) 스프링
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크	23.698	LEVER, PARKING BRAKE OPERATING LH 레버

23.699	ARM, BRAKE ADJUSTOR REACTION LH 암
23.735	SHOE & LINING SET, BRAKE 슈& 라이닝
23.738	SPRING, BRAKE SHOE RETURN (RH) 스프링
23.747	SPRING, BRAKE SHOE RETURN (LH) 스프링
23.762	ARM, PARKING BRAKE OPERATING 암
23.776	SHEAVE, PARKING BRAKE CABLE 쉬브






22.088	RETAINER, PARKING BRAKE LINKAGE LEVER FULCRUM 리테이너
22.174	WASHER, PARKING BRAKE LINKAGE LEVER FULCRUM 와셔
22.194	SPRING, BRAKE SHOE GUIDE 스프링
22.195	CUP, BRAKE SHOE GUIDE 컵
22.196	LOCATOR, BRAKE SHOE 로케이터
22.898	CABLE, PARKING BRAKE DRAW - LH 케이블
23.048	SPRING, PARKING BRAKE OPERATING ARM ANTI-RATTLE 스프링
23.214	CYLINDER ASSEMBLY, LH BRAKE 실린더
23.223	BLEEDER, BRAKE WHEEL CYLINDER 블리더

23.236	COVER, LH BRAKE ADJUSTOR 커버
23.238	GUIDE, LH BRAKE SHOE 가이드
23.242	PLATE, LH BRAKE BACKING 플레이트
23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
23.249	SPRING, LH BRAKE RETURN 스프링
23.258	FASTENER, LH WHEEL CYLINDER 패스너
23.389	RETAINER, PARKING BRAKE CABLE 리테이너
23.545	CABLE, BRAKE ADJUSTER (LH) 케이블
23.547	GUIDE, BRAKE ADJUSTOR CABLE (LH) 가이드
23.550	LEVER, BRAKE ADJUSTER (LH) 레버
23.552	SPRING, BRAKE ADJUSTER (LH) 스프링
23.698	LEVER, PARKING BRAKE OPERATING LH 레버
23.699	ARM, BRAKE ADJUSTOR REACTION LH 암
23.735	SHOE & LINING SET, BRAKE 슈& 라이닝
23.738	SPRING, BRAKE SHOE RETURN (RH) 스프링
23.747	SPRING, BRAKE SHOE RETURN (LH) 스프링
24.336	ADJUSTOR, BRAKE SHOE LH 어드저스터
24.404	CAP, BRAKE WHEEL CYLINDER BLEEDER 캡
97.344	FASTENER, BRAKE ADJUSTOR CABLE GUIDE 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE WHEEL & TIRE MOUNTING

22-013

- | | |
|--------|---|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠& 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER WHEEL & TIRE MOUNTING

22-014

- | | |
|--------|---|
| 23.026 | FASTENER, STEER WHEEL
패스너 |
| 23.031 | STEER WHEEL AND TIRE ASSEMBLY
스티어휠 & 타이어 |


ASSEMBLY
COMPLETE — 23.030



DRIVE WHEEL & TIRE


22-041

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.016	TIRE, DRIVE WHEEL 타이어
23.018	TUBE, DRIVE WHEEL 튜브
23.019	FLAP, DRIVE WHEEL TUBE 플랩
23.029	FASTENER, DRIVE WHEEL ASSEMBLY 패스너
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어



22.088	RETAINER, PARKING BRAKE LINKAGE LEVER FULCRUM 리테이너
22.174	WASHER, PARKING BRAKE LINKAGE LEVER FULCRUM 와셔
22.194	SPRING, BRAKE SHOE GUIDE 스프링
22.195	CUP, BRAKE SHOE GUIDE 컵
22.196	LOCATOR, BRAKE SHOE 로케이터
22.900	CABLE, PARKING BRAKE DRAW - RH 케이블
23.048	SPRING, PARKING BRAKE OPERATING ARM ANTI-RATTLE 스프링
23.215	CYLINDER ASSEMBLY, RH BRAKE 실린더
23.223	BLEEDER, BRAKE WHEEL CYLINDER 블리더

23.237	COVER, RH BRAKE ADJUSTOR 커버
23.239	GUIDE, RH BRAKE SHOE 가이드
23.243	PLATE, RH BRAKE BACKING 플레이트
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.247	SHOE SET, BRAKE LINING 슈
23.250	SPRING, RH BRAKE RETURN 스프링
23.259	FASTENER, RH WHEEL CYLINDER 패스너
23.263	LEVER, PARKING BRAKE OPERATING 레버
23.298	ARM, BRAKE ADJUSTOR REACTION 암
23.389	RETAINER, PARKING BRAKE CABLE 리테이너
23.475	ADJUSTOR, BRAKE SHOE 어드져스터
23.546	CABLE, BRAKE ADJUSTER (RH) 케이블
23.548	GUIDE, BRAKE ADJUSTER CABLE (RH) 가이드
23.551	LEVER, BRAKE ADJUSTER (RH) 레버
23.553	SPRING, BRAKE ADJUSTER (RH) 스프링
23.738	SPRING, BRAKE SHOE RETURN (RH) 스프링
23.747	SPRING, BRAKE SHOE RETURN (LH) 스프링
24.404	CAP, BRAKE WHEEL CYLINDER BLEEDER 캡
97.344	FASTENER, BRAKE ADJUSTOR CABLE GUIDE 패스너




22.026	ROD END, BRAKE PEDAL LINKAGE 로드엔드
22.417	SPRING, MASTER CYLINDER PISTON RETURN 스프링
22.565	VALVE ASSY, BRAKE ENERGIZER ASSY 밸브
22.821	SNAP RING, BRK ENERGIZER/MASTER CYL SHAFT RETAININ 스냅링
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.160	ROD, PUSH 로드
23.495	SEAL KIT, MASTER CYLINDER 셀키트
23.795	FITTING, BRAKE MASTER CYLINDER INLET 피팅
24.166	SEAT, BRAKE VALVE PISTON SPRING 시트

94.398 NUT, BRAKE MASTER CYLINDER ACTUATING ROD FASTENER
너트



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




BRAKE LINES


23-468

- | | |
|--------|---|
| 13.142 | SWITCH, BRAKE INTERLOCK
스위치 |
| 13.143 | BRACKET, BRAKE INTERLOCK SWITCH
브라켓 |
| 13.145 | FASTENER, BRAKE INTERLOCK SWITCH
패스너 |
| 22.338 | CLAMP, BRAKE FLUID RESERVOIR
클램프 |
| 22.528 | BLEEDER, BRAKE LINES ADAPTOR
블리더 |
| 22.604 | CLAMP, BRAKE FLUID RESERVOIR LINE
클램프 |
| 22.627 | TEE, BRAKE LINE
티 |
| 23.051 | FASTENER, MASTER CYLINDER MOUNTING BRACKET
패스너 |
| 23.100 | PEDAL, BRAKE
페달 |

23.101	SHAFT, BRAKE PEDAL 샤프트
23.105	BEARING, BRAKE PEDAL 베어링
23.114	PAD & FASTENER, BRAKE PEDAL 패드& 패스너
23.118	FASTENER, BRAKE PEDAL TO MASTER CYL PUSH ROD 패스너
23.136	SPRING, BRAKE PEDAL RETURN 스프링
23.145	FASTENER, BRAKE PEDAL SHAFT 패스너
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.157	FASTENER, BRAKE MASTER CYLINDER ATTACHING 패스너
23.173	FITTING, BRAKE MASTER CYLINDER OUTLET 피팅
23.186	LINE, BRAKE MASTER CYLINDER OUTLET 라인
23.199	FASTENER, BRAKE LINE TEE 패스너
23.207	LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.435	FASTENER, BRAKE PEDAL PIVOT BRACKET 패스너
23.792	RESERVOIR, BRAKE FLUID 리저버
23.793	FASTENER, BRAKE FLUID RESERVOIR 패스너
23.794	LINE, BRAKE MASTER CYLINDER INLET 라인
23.856	PLUG, BRAKE LINE TEE 플러그


PARKING BRAKE SYSTEM
23-533

13.101	PLATE, BRAKE LOCK ACTUATING SWITCH 플레이트	23.284	FASTENER, PARKING BRAKE CABLE BRACKET 패스너
22.045	BRACKET, PARKING BRAKE PEDAL PIVOT MTG 브라켓	23.410	BEARING, PARKING BRAKE CAM ROLLER 베어링
22.263	RETAINER, PARKING BRAKE RELEASE LEVER PIVOT 리테이너	23.481	LEVER, PARKING BRAKE RELEASE 레버
22.264	ADJUSTOR, PARKING BRAKE 어드저스터	23.482	SPRING, PARKING BRAKE RELEASE LEVER 스프링
22.442	PAD, PARKING BRAKE PEDAL 패드	23.483	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
22.853	SWITCH, PARKING BRAKE PEDAL ACTUATING 스위치	23.489	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
22.854	FASTENER, PARKING BRAKE PEDAL ACTUATING 패스너	23.571	BUMPER, PARKING BRAKE LEVER 범퍼
22.855	PIVOT, PARKING BRAKE PEDAL 피봇	23.638	ANCHOR, PARKING BRAKE CABLE 앵커
22.856	RETAINER, PARKING BRAKE PEDAL PIVOT 리테이너	23.639	FASTENER, PARKING BRAKE CABLE ANCHOR 패스너
22.860	PEDAL, PARKING BRAKE 페달	23.767	SPRING, PARKING BRAKE DRAW 스프링
22.895	FASTENER, PARKING BRAKE PEDAL PIVOT RETAINER 패스너	23.851	LINK, PARKING BRAKE 링크
23.264	BRAKE ASSEMBLY, PARKING 브레이크	23.918	FASTENER, PARKING BRAKE PEDAL PIVOT BRACKET 패스너
23.266	FASTENER, PARKING BRAKE CABLE CLAMP 패스너	23.959	FASTENER, PARKING BRAKE RELEASE VALVE 패스너
23.269	FASTENER, PARKING BRAKE LEVER 패스너	92.855	NUT, PARKING BRAKE FASTENER 너트
23.273	CLAMP, PARKING BRAKE LEVER TO CABLE 클램프		




25.002	HORN BUTTON KIT 혼버튼키트
25.003	NUT, HANDWHEEL 너트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.221	FASTENER, STEERING SPINNER KNOB 패스너
25.222	CAP, STEERING SPINNER KNOB 캡
25.780	HORN BUTTON 혼버튼
90.453	WASHER, STEERING SPINNER KNOB FASTENER 와셔
96.358	WASHER, STEERING HANDWHEEL SPINNER KNOB FASTENER 와셔

ASSEMBLY
COMPLETE — 25.150

SEAL KIT
INCLUDES ITEMS
MARKED "K" — 25.109


NEEDLE BEARING KIT
INCLUDES ITEMS
MARKED "R" — 25.972



STEERING UNIT

25-076

- | | |
|--------|-------------------------------------|
| 25.109 | KIT, STEER GEAR SEAL
키트 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |
| 25.972 | BEARING KIT, STEERING GEAR
베어링키트 |




25.010	JACKET, STEERING COLUMN 자켓
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.130	FASTENER, DIRECTIONAL ASSEMBLY 패스너
25.137	KEY, DIRECTIONAL ASSEMBLY 키
25.141	SHAFT, STEERING GEAR 샤프트
25.312	UNIVERSAL JOINT, STEER 유니버설조인트
25.315	FASTENER, STEERING U-JOINT CLAMPING 패스너
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼

25.771	SHAFT, STEERING COLUMN (TILT) 샤프트
25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.841	BUSHING, STEERING GEAR SHAFT 부싱
25.933	FASTENER, STEERING COLUMN 패스너
25.991	PIN, STEERING UNIVERSAL JOINT 핀
37.344	SPRING, STEERING COLUMN TILTING 스프링



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEERING COLUMN MOUNTING

25-367

- | | |
|--------|---|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 06.101 | LEVER ASSEMBLY, FORWARD & REVERSE
레버 |
| 13.047 | SWITCH, CIRCUIT LOCKING
스위치 |
| 13.110 | SWITCH, DIRECTIONAL CONTROL (FORWARD)
스위치 |
| 13.111 | FASTENER, DIRECTIONAL CONTROL SWITCH
패스너 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 13.655 | SWITCH, TURN INDICATOR
스위치 |
| 13.656 | BRACKET, TURN INDICATOR SWITCH
브라켓 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |

25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
40.002	LEGEND, SHIFT PATTERN 범례
40.069	DECAL, FORWARD-BACKWARD 데칼
44.250	DIRECTIONAL CONTROL ASSEMBLY 방향컨트롤
44.251	HOUSING, DIRECTIONAL CONTROL ASSEMBLY 하우징
44.252	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING 커버
44.254	FASTENER, DIRECTIONAL CONTROL ASSY HOUSING COVER 패스너
44.255	SEAL, DIRECTIONAL CONTROL ASSY LEVER 씰
44.356	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING REAR 커버
60.260	KEY, CIRCUIT LOCKING SWITCH 키
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
60.686	RING, HORN CONTACT 링
60.773	HARNESS, TURN SIGNAL 하네스
60.951	GROMMET, TURN INDICATOR SWITCH 그로멧
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링
96.000	FASTENER, TURN INDICATOR SWITCH 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEERING GEAR MOUNTING

25-368

- | | |
|--------|--|
| 25.034 | FASTENER, STEERING GEAR ATTACHING
패스너 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |




STEER LINES

26-242


28.083	CLAMP, STEERING LINE UPPER 클램프
28.272	LINE, STEER CYLINDER INLET 라인
28.273	FITTING, STEER CYLINDER 피팅
31.115	LINE, STEERING PUMP OUTLET 라인
31.139	FITTING, STEER VALVE OUTLET UPPER PORT 피팅
31.479	CLAMP, STEERING LINES 클램프
31.663	FITTING, STEER VALVE INLET PORT 피팅
31.664	LINE, STEERING CYLINDER ANCHOR PORT 라인
31.668	LINE, STEERING CYLINDER ROD PORT 라인

94.662 FASTENER, POWER STEERING LINES CLAMP
패스너






26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.003	SEAL KIT, PISTON ROD 씰키트
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 스티어실린더피스톤
26.093	GLAND, STEERING CYLINDER 그랜드
26.099	BUSHING, STEERING CYLINDER GLAND 부싱



26.000	CYLINDER ASSEMBLY, STEERING 실린더	26.141	FASTENER, STEER WHEEL HUB 패스너
26.086	FASTENER, STEERING CYLINDER ANCHOR END 패스너	26.143	CAP, STEER WHEEL HUB 캡
26.100	AXLE ASSEMBLY, STEERING 스티어액슬	26.148	KNUCKLE, STEER AXLE (LH) 너트
26.119	AXLE, STEER 액슬	26.180	WASHER, STEER AXLE KNUCKLE THRUST 와셔
26.125	PIN, STEER AXLE KNUCKLE 핀	26.190	SEAL, STEER AXLE KNUCKLE OIL 씰
26.129	FITTING - LUB, STEER AXLE KNUCKLE 피팅	26.227	SEAL, STEER AXLE FORK HOUSING 씰
26.131	BEARING, STEER AXLE KNUCKLE PIN LOWER 베어링	26.239	SEAL, STEER AXLE FORK COVER 씰
26.132	KNUCKLE, STEER AXLE (RH) 너트	26.281	RETAINER, STEER AXLE HUB BRG KNUCKLE NUT 리테이너
26.133	SEAL, STEER WHEEL HUB 씰	26.290	RETAINER, STEER AXLE KNUCKLE PIN LOWER BEARING 리테이너
26.134	CONE, STEER WHEEL HUB BEARING (INNER) 콘	26.337	LOCATOR, STEER AXLE KNUCKLE PIN 로케이터
26.135	CUP, STEER WHEEL HUB BEARING (INNER) 컵	26.338	PIN, STEERING ARM 핀
26.136	HUB & CUP, STEER WHEEL 허브& 컵	26.339	LUB-FITTING, STEERING ARM 윤활피팅
26.137	FASTENER, STEER WHEEL 패스너	26.340	BEARING, STEERING ARM PIN 베어링
26.138	CUP, STEER WHEEL HUB BEARING (OUTER) 컵	26.348	LOCATOR, STEER CYLINDER 로케이터
26.139	CONE, STEER WHEEL HUB BEARING (OUTER) 콘	26.351	WASHER, STEERING ARM PIN 와셔


26.417	ARM, STEERING 암
92.507	WASHER, STEERING ARM FASTENER 와셔
94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너
94.854	COTTER, STEER AXLE KNUCKLE PIN FASTENER 커터
94.855	RETAINER, STEERING ARM PIN 리테이너





- | | |
|--------|---|
| 26.100 | AXLE ASSEMBLY, STEERING
스티어액슬 |
| 26.174 | SILENT BLOCK, AXLE MOUNTING (REAR)
사일런트블록 |
| 26.175 | FASTENER, SILENT BLOCK TO FRAME (REAR)
패스너 |
| 38.047 | BRACKET, STEER AXLE MOUNTING
브라켓 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC PUMP MOUNTING

29-017

29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.119	FASTENER, PUMP HOUSING 패스너
29.474	SEAL, PUMP INLET FITTING 씰
29.608	MANIFOLD, HYDRAULIC PUMP INLET SUCTION 매니폴드
97.097	FASTENER, HYDRAULIC PUMP INLET SUCTION MANIFOLD 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC PUMP MOUNTING

29-027


29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.119	FASTENER, PUMP HOUSING 패스너
29.474	SEAL, PUMP INLET FITTING 씰
29.608	MANIFOLD, HYDRAULIC PUMP INLET SUCTION 매니폴드
97.097	FASTENER, HYDRAULIC PUMP INLET SUCTION MANIFOLD 패스너




29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.116	SEAL KIT, PUMP SHAFT 씰키트
29.186	SEAL, PUMP SHAFT 씰
29.198	FASTENER, PUMP HOUSING 패스너

ASSEMBLY
COMPLETE

29.000



29.906




29.007


HYDRAULIC OIL FILTER

29-239


29.000	FILTER, HYDRAULIC OIL 필터
29.007	CARTRIDGE, HYDRAULIC OIL FILTER 카트리지
29.906	HEAD ASSEMBLY, HYDROSTATIC OIL FILTER 헤드



29.591	RUBBER, SUMP TANK MOUNTING 러버
29.701	TANK, SUMP 탱크
29.702	FASTENER, SUMP TANK 패스너

**ASSEMBLY
COMPLETE** — 29.100**SEAL KIT** — 29.028**HYDRAULIC PUMP ASSEMBLY****29-296**


- | | |
|--------|--------------------------------------|
| 29.028 | SEAL KIT, HYDRAULIC UNIT PUMP
씰키트 |
| 29.087 | SEAL, HYDRAULIC PUMP HOUSING
씰 |
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.268 | COUPLING, MAIN HYDRAULIC PUMP
커플링 |



PUSH BUTTON WIRING


30-342

- | | |
|--------|---|
| 15.339 | HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스 |
| 17.653 | RELAY, AUXILIARY PLUGGING
릴레이 |
| 18.020 | CLIP, HARNESS
클립 |




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓


30.442	SPACER, CONTROL LEVERS 스페이스
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (2 SPOOL)

30-533

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프 밸브
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.042	CAP, TILT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.438	BUSHING, LIFT CONTROL LEVER 부싱	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.442	SPACER, CONTROL LEVERS 스페이서	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.787	BOOT, VALVE CONTROL LEVER 부트	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
32.138	SWITCH, PUSH BUTTON 스위치	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트		




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버

32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터

52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너





13.537 SWITCH, CONTROL VALVE PUMP OPERATING
스위치

15.339 HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스

30.000 VALVE ASSEMBLY, HYDRAULIC
밸브

30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너

30.087 PIN, VALVE CONTROL LEVER PIVOT
핀

30.089 LEVER, LIFT CONTROL
레버

30.090 LEVER, TILT CONTROL
레버

30.094 KNOB, LIFT CONTROL LEVER
노브

30.097 KNOB, TILT CONTROL LEVER
노브

30.102 BRACKET, HYDRAULIC VALVE SWITCH
브라켓

30.256 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.438 BUSHING, LIFT CONTROL LEVER
부싱

30.787 BOOT, VALVE CONTROL LEVER
부트

30.817 KNOB, AUXILIARY VALVE CONTROL LEVER
노브

30.843 LEVER, AUXILIARY VALVE CONTROL (1ST AUX)
레버

30.844 LEVER, AUXILIARY VALVE CONTROL (2ND AUX)
레버

32.138 SWITCH, PUSH BUTTON
스위치

32.142 PLATE, SWITCH MOUNTING BRACKET
플레이트

33.347 RELIEF VALVE, LIFT LINE CHECK VALVE
릴리프밸브

49.042 CAP, TILT CONTROL LEVER
캡

49.081 CAP, LIFT CONTROL LEVER
캡

49.102 FASTENER, VALVE CONTROL LEVER PIVOT RETAINER
패스너

49.103 RETAINER, VALVE CONTROL LEVER PIVOT PIN
리테이너

49.104 PIN, VALVE CONTROL LEVER CLEVIS ROD
핀

49.105 RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN
리테이너

49.109 ROD, VALVE CONTROL CLEVIS
로드

49.110 PIN, VALVE SPOOL CLEVIS ROD
핀


49.111 RETAINER, VALVE SPOOL CLEVIS ROD PIN
리테이너

49.124 CAP, AUXILIARY CONTROL LEVER
캡

52.162 CONNECTOR, AUXILIARY VALVE LEVER WIRE
커넥터

52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너






13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.042	CAP, TILT CONTROL LEVER 캡
30.089	LEVER, LIFT CONTROL 레버	49.081	CAP, LIFT CONTROL LEVER 캡
30.090	LEVER, TILT CONTROL 레버	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.094	KNOB, LIFT CONTROL LEVER 노브	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.438	BUSHING, LIFT CONTROL LEVER 부싱	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.442	SPACER, CONTROL LEVERS 스페이서	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.787	BOOT, VALVE CONTROL LEVER 부트	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
32.138	SWITCH, PUSH BUTTON 스위치	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너

ФОРКЛИФТ
www.forklift.ru




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버

32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너

ФОРКЛИФТ
www.forklift.ru

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (2SPOOL)

30-543

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.442	SPACER, CONTROL LEVERS 스페이스
30.787	BOOT, VALVE CONTROL LEVER 부트
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (3SPOOL)

30-544

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING(4SPOOL)

30-545


13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓

30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브


30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.138	SWITCH, PUSH BUTTON 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.042	CAP, TILT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.081	CAP, LIFT CONTROL LEVER 캡
30.089	LEVER, LIFT CONTROL 레버	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.090	LEVER, TILT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.094	KNOB, LIFT CONTROL LEVER 노브	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.097	KNOB, TILT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.438	BUSHING, LIFT CONTROL LEVER 부싱	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.442	SPACER, CONTROL LEVERS 스페이서	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너

ФОРКЛИФТ
www.forklift.ru




13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
15.339	HARNESS, AUXILIARY VALVE SWITCH WIRING 하네스
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.438	BUSHING, LIFT CONTROL LEVER 부싱
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버

30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.138	SWITCH, PUSH BUTTON 스위치
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크

93.393 FASTENER, HYDRAULIC VALVE SWITCH BRACKET
패스너

ФОРКЛИФТ
www.forklift.ru

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (3SPOOL)

30-549

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.042	CAP, TILT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.442	SPACER, CONTROL LEVERS 스페이서	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
32.138	SWITCH, PUSH BUTTON 스위치	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트		


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (4SPOOL)

30-565


13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.042	CAP, TILT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.081	CAP, LIFT CONTROL LEVER 캡
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.089	LEVER, LIFT CONTROL 레버	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.094	KNOB, LIFT CONTROL LEVER 노브	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.097	KNOB, TILT CONTROL LEVER 노브	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
32.138	SWITCH, PUSH BUTTON 스위치		



30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.250	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너


30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.230	VALVE ASSEMBLY, LIFT SOLENOID 밸브
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.077	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 씰
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.206	VALVE, HYDRAULIC SHUT-OFF 밸브
49.209	VALVE, HYDRAULIC SHUT-OFF (LIFT) 밸브






30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.100	INLET SECTION, HYDRAULIC VALVE 인렛섹션
30.250	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.435	RELIEF VALVE ASSEMBLY, AUXILIARY VALVE 릴리프밸브
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너


30.762	END COVER, HYDRAULIC VALVE 엔드커버
33.347	RELIEF VALVE, LIFT LINE CHECK VALVE 릴리프밸브
49.077	SEAL, MAIN HYDRAULIC VALVE INLET SECTION 씰
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.199	SPOOL SEAL KIT, AUX SECTION 스풀씰키트
49.206	VALVE, HYDRAULIC SHUT-OFF 밸브





- | | |
|--------|---|
| 28.691 | BRACKET, TILT HOSE MOUNTING
브라켓 |
| 28.979 | FITTING, HYDRAULIC LINES
피팅 |
| 31.061 | FITTING, VALVE TILT PORT "A"
피팅 |
| 31.062 | FITTING, VALVE TILT PORT "B"
피팅 |
| 31.073 | LINE, LH TILT CYLINDER ROD PORT
라인 |
| 31.077 | FITTING, LH TILT CYLINDER ROD PORT
피팅 |
| 31.083 | LINE, RH TILT CYLINDER ANCHOR PORT
라인 |
| 31.158 | LINE, LH TILT CYLINDER ANCHOR PORT
라인 |
| 31.160 | FITTING, LH TILT CYLINDER ANCHOR PORT
피팅 |

31.162	FITTING, RH TILT CYLINDER ANCHOR PORT 피팅
31.440	LINE, LH TILT LOCK OUTLET (CYL ANCHOR PORT) 라인
31.441	LINE, RH TILT CYLINDER OUTLET (CYL ANCHOR PORT) 라인
31.600	FITTING, RH TILT CYLINDER ROD PORT 피팅
96.430	FASTENER, HYDRAULIC LINES BRACKET 패스너
96.536	NUT, HYDRAULIC LINES MOUNTING BRACKET FASTENER 너트




HYDRAULIC SUPPLY LINES

31-195

28.061	LINE, STEER VALVE CONTROL 라인
28.062	LINE, STEER VALVE CONTROL 라인
28.397	FITTING, STEERING GEAR LINE 피팅
28.452	CHECK VALVE, POWER STEERING LINE 체크밸브
28.801	SEAL, HYD PUMP OUTLET PORT FITTING 셀
28.855	FITTING, POWER STEERING LINE 피팅
29.607	MANIFOLD, HYDRAULIC PUMP OUTLET LINE 매니폴드
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.014	FITTING, PUMP OUTLET 피팅

31.018	LINE, PUMP OUTLET 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.122	FITTING, POWER STEERING RETURN LINE 피팅
31.149	FITTING, STEER VALVE INLET PORT 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
97.096	FASTENER, HYDRAULIC PUMP OUTLET LINE MANIFOLD 패스너




HYDRAULIC LIFT LINES

31-312

- | | |
|--------|-------------------------------------|
| 31.030 | LINE, VALVE TO LIFT CYLINDER
라인 |
| 31.200 | FITTING, MAIN VALVE LIFT PORT
피팅 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC RETURN LINES

31-328


29.000	FILTER, HYDRAULIC OIL 필터
29.002	FASTENER, HYDRAULIC OIL FILTER 패스너
29.386	LINE, SUMP BREATHER 라인
29.727	TUBE, SUMP FILLER 튜브
29.728	CAP, HYDRAULIC SUMP FILLER 캡
29.784	CLAMP, SUMP BREATHER LINE 클램프
29.798	SCREEN, HYDRAULIC SUMP PRE FILTER 스크린
29.802	ADAPTOR, SUMP FILLER CAP 어댑터
29.809	DIPSTICK, SUMP LEVEL 딤스틱

29.913	FASTENER, SUMP FILLER TUBE 패스너
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프
31.120	LINE, SUMP RETURN (POWER STEERING) 라인
31.150	FITTING, STEER VALVE DISCHARGE PORT 피팅
31.197	LINE, MAIN VALVE TO SUMP RETURN 라인
31.390	CLAMP, VALVE SUMP RETURN LINE 클램프
31.445	FITTING, MAIN VALVE TO FILTER LINE 피팅
31.446	FITTING, FILTER OUTLET PORT 피팅
31.595	CLAMP, SUMP RETURN LINE FITTING 클램프
31.639	FITTING, FILTER INLET PORT 피팅
31.822	LINE, FILTER OUTLET TO SUMP 라인
31.823	CLAMP, FILTER OUTLET LINE 클램프






28.798	SEAL, MAIN VALVE LIFT PORT LINE FITTING 씰
31.026	SEAL, MAIN VALVE LOWER (LIFT) PORT 씰
31.030	LINE, VALVE TO LIFT CYLINDER 라인
31.200	FITTING, MAIN VALVE LIFT PORT 피팅
66.148	SEAL, LIFT CYLINDER PRESSURE LINE 씰



32.000	CYLINDER ASSEMBLY, TILT 실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드& 피스톤
32.072	PACKING KIT, TILT CYLINDER 패킹키트


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT AMOUNT GP

32-167

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심




32.196	ROD, HYDRAULIC ACCUMULATOR LINE 로드
32.800	ACCUMULATOR, HYDRAULIC 어큐물레이터
32.801	CLAMP, HYDRAULIC ACCUMULATOR MOUNTING 클램프
32.802	BRACKET, HYDRAULIC ACCUMULATOR 브라켓
32.805	SEAL, HYDRAULIC ACCUMULATOR CONNECTOR 씰
32.806	CONNECTOR, HYDRAULIC ACCUMULATOR 커넥터
32.810	LINE, HYDRAULIC ACCUMULATOR 라인
32.814	FITTING, HYDRAULIC ACCUMULATOR LINE 피팅
32.841	NUT, HYDRAULIC ACCUMULATOR FITTING 너트

32.842 SEAL, HYDRAULC ACCUMULATOR FITTING
셀

ФОРКЛИФТ
www.forklift.ru

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




TILT CYLINDER MOUNTING

32-173


32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.030	PIN, TILT CYLINDER TO UPRIGHT 핀
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링

32.053	BEARING, TILT CYLINDER ROD END 베어링
97.214	FASTENER, TILT CYLINDER TO FRAME PIN 패스너
97.224	FASTENER, TILT CYLINDER TO UPRIGHT PIN 패스너






- | | |
|--------|---|
| 33.600 | RELIEF VALVE, DEVICE VARIABLE PRESSURE
릴리프밸브 |
| 33.601 | LEVER, DEVICE VARIABLE RELIEF VALVE
레버 |
| 33.610 | SEAL, DEVICE PRESS RELIEF VAL CHECK PORT PLUG
씰 |
| 33.613 | SEAL, DEVICE RELIEF VALVE PISTON ADJ END
씰 |
| 33.618 | CARTRIDGE KIT, DEVICE VARIABLE RELIEF VALVE
카트리지기트 |
| 33.631 | FASTENER, DEVICE RELIEF VALVE
패스너 |



- 33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
밸브
- 33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너
- 33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
씰키트
- 33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어키트




LOAD BACK REST MOUNTING


34-044

- | | |
|--------|--|
| 34.998 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 66.431 | RETAINER, LBR CAPSCREW
리테이너 |


ASSEMBLY
COMPLETE 34.300




TYPE - 1



TYPE - 2



TYPE - 3



TYPE - 4


CARRIAGE ASSEMBLY

34-103

34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.307	ROLLER, CARRIAGE INNER THRUST 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.321	FASTENER, CARRIAGE ROLLER SHAFT 패스너
34.328	ROLLER, CARRIAGE CAPTIVE 롤러
34.329	RETAINER, CARRIAGE CAPTIVE ROLLER 리테이너
34.330	FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER 패스너
34.332	SHIM, CARRIAGE CAPTIVE ROLLER 심

34.340 CARRIAGE WELDED ASSEMBLY
캐리지용 접물

ФОРКЛИФТ
www.forklift.ru



UPRIGHT MOUNTING

34-126

34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.037	CAP, UPRIGHT TRUNNION 캡
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너
34.039	FITTING-LUB, UPRIGHT TRUNNION 피팅
34.191	FASTENER, UPRIGHT TRUNNION BUSHING 패스너
66.167	SHIM, LIFT CYLINDER UPPER 심
66.442	KEEPER, UPRIGHT TRUNNION CAP 키퍼


This Carriage assembly was manufactured by the CASCADE CORPORATION and is not serviced by CLARK Material Handling Company.

CASCADE parts manuals, technical specifications and lists of worldwide distributors are available on-line at:

<http://www.cascorp.com>.

When ordering service parts, it will be necessary to provide CASCADE with the CASCADE model and serial numbers of the carriage. CASCADE will not recognize the CLARK carriage part number listed on the PIC or in PartsPRO.

34.300	CARRIAGE ASSEMBLY COMPLETE
34.340	CARRIAGE WELDED ASSEMBLY




OVERHEAD GUARD COVER

37-003

38.243 COVER ASSEMBLY, OVERHEAD GUARD TOP
커버

ASSEMBLY
COMPLETE 39.689




BACK MIRROR


37-076

39.184 FASTENER, REAR VIEW MIRROR
패스너

39.689 MIRROR, REAR VIEW
미러




47.383 INSERT, OVERHEAD GUARD REAR
인서트



OVERHEAD GUARD MOUNTING

37-103


37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.082	INSERT, DRIVER OVERHEAD GUARD 인서트




SEAT ARMREST ASSEMBLY

37-124

- | | |
|--------|---------------------------------------|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |




38.362	FASTENER, COUNTERWEIGHT COMPARTMENT COVER 패스너
38.862	COVER, COUNTERWEIGHT COMPARTMENT 커버
38.869	COUNTERWEIGHT 카운터웨이트
38.870	FASTENER, COUNTERWEIGHT (LOWER) 패스너
38.920	PIN, COUPLER 핀
38.921	PIN, COUPLER PIN CROSS 핀
40.139	DECAL, MODEL DESIGNATION 데칼
40.268	DECAL, SPEC 데칼
94.052	WASHER, COUNTERWEIGHT FASTENER 와셔




12.190	SWITCH, BATTERY RETAINER INTERLOCK 스위치
12.191	HARNESS, BATTERY RETAINER INTERLOCK SWITCH 하네스
12.192	FASTENER, BATTERY RETAINER INTERLOCK SWITCH 패스너
12.310	SPACER, BATTERY COMPARTMENT 스페이서
12.311	FASTENER, BATTERY COMPARTMENT SPACER 패스너
12.374	FITTING, BATTERY RETAINER INTERLOCK SWITCH HARNESS 피팅
12.375	SLIDE, BATTERY 슬라이드
12.376	SLIDE, BATTERY 슬라이드
12.377	FASTENER, BATTERY SLIDE 패스너

12.446	SLIDE, BATTERY 슬라이더
38.121	ROLLER, BATTERY 롤러
38.146	PLATE, BATTERY STOP 플레이트
97.207	FASTENER, BATTERY ROLLER 패스너







37.447	RESTRAINT, OPERATOR SEAT LATERAL 레스트레인트
39.710	SUPPORT, SEAT ADJUSTOR (RH) 서포트
39.719	SEAT ASSEMBLY 시트
39.728	FASTENER, SEAT FRAME TO ADJUSTOR 패스너
90.307	LOCKWASHER, ADJUSTOR TO SEAT SUPPORT FASTENER 로크와셔



- | | |
|--------|---|
| 34.977 | RETAINER, LOAD BACK REST TRUNNION PIN
리테이너 |
| 34.991 | FASTENER, LOAD SAFETY BACK REST EXT
패스너 |
| 34.995 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 92.226 | NUT, LOAD SAFETY BACK REST FASTENER
너트 |




- | | |
|--------|--|
| 34.998 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 34.999 | BACK REST, LOAD SAFETY-COMPLETE
백레스트 |
| 92.499 | LOCKWASHER, LOAD SAFETY BACK REST FASTENER
로크와셔 |




37.204	COVER, SEAT BACK REST CUSHION 커버	39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
37.205	TRAY, LITERATURE 트레이	39.745	BUMPER, SEAT SUPPORT 범퍼
37.405	TRIM, SEAT MOUNTING PLATE 트림	39.747	PLATE, SEAT BACK REST CUSHION MOUNTING 플레이트
37.406	BRACKET, SEAT BACK REST COVER LH 브라켓	39.761	PLATE, SEAT CUSHION MOUNTING 플레이트
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓	47.053	LUMBAR FLEXOLATOR 롬바
37.409	HANDLE, SEAT CUSHION TENSION ADJUSTOR LEVER 핸들	47.054	GEAR KIT 기어키트
37.410	LEVER, SEAT CUSHION TENSION ADJUSTOR 레버	47.056	CLIP, SPRING 클립
37.412	SPRING, SEAT SUSPENSION TENSION 스프링	47.057	PIN, BACK FRAME SHOCK 핀
37.439	SAFETY BELT, SEAT 안전벨트	47.058	SADDLE SPRING, SPRING ARM 새들스프링
37.983	RELAY, SEAT SWITCH INTERRUPT 릴레이	47.059	SADDLE BUSHING, SPRING ARM 새들부싱
37.988	HARNESS, SEAT SWITCH INTERRUPT 하네스	47.060	SPRING ARM, SUSPENSION SEAT 스프링암
39.719	SEAT ASSEMBLY 시트	47.061	BEARING, SPRING ARM 베어링
39.720	CUSHION, SEAT 쿠션	47.062	PAN, SUSPENSION 팬
39.721	CUSHION, SEAT BACK REST 쿠션	47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTOR 노브
39.726	ADJUSTOR, SEAT 어드저스터	47.065	WEIGHT INDICATOR ASSEMBLY 웨이트인디케이터

47.066	SPACER, SEAT ASSEMBLY WEIGHT ADJUST SCREW 스페이서
47.067	CLIP, FRONT SEAT FRAME 클립
47.068	BAR, WEIGHT ADJUSTER 바
47.106	SHOCK ABSORBER, SUSPENSION SEAT 쇼크업쇼버
94.032	RETAINER, SEAT FRAME 리테이너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.047	FASTENER, SEAT BACK REST CUSHION 패스너







37.447	RESTRAINT, OPERATOR SEAT LATERAL 레스트레인트
39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
94.537	FASTENER, OPERATOR SEAT LATERAL RESTRAINT 패스너



- | | |
|--------|--|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
안전벨트 |
| 37.531 | BRACKET, SEAT SAFETY BELT MOUNTING
브라켓 |
| 37.720 | COVER, OPERATOR SEAT LATERAL RESTRAINT
커버 |
| 37.743 | COVER, SEAT SUPPORT LATCH
커버 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너







SHEET METAL & TRIM

39-773

- | | |
|--------|-----------------------------|
| 38.471 | PAD, LH STEP NON-SKID
패드 |
| 38.472 | PAD, RH STEP NON-SKID
패드 |




37.200	PANEL, FRONT 판넬
37.201	PANEL, LH SIDE 판넬
37.202	PANEL, RH SIDE 판넬
39.363	FASTENER, RH SIDE PANEL 패스너
39.546	COWL ASSEMBLY 카울
39.547	FASTENER, COWL ASSEMBLY 패스너
39.570	COVER ASSEMBLY, DASH 커버
39.571	FASTENER, DASH COVER 패스너



FLOOR PLATE MOUNTING

39-775


37.214	PLUG-BUTTON 플러그
37.902	MAT, FLOORPLATE 매트
37.903	MAT, FLOORPLATE 매트
38.196	ACID TRAY, BATTERY 에시트트레이
39.475	PLATE, FRONT FLOOR 플레이트
39.479	FASTENER, FRONT FLOOR PLATE 패스너
47.461	FLOOR PLATE ASSEMBLY 플로어매트
95.396	FASTENER, WIRING HARNESS PROTECTION SHIELD 패스너



15.790	WIRE, BATTERY STOPPER 와이어
15.791	HOLDER, BATTERY 홀더
15.792	SLEEVE, BATTERY STOPPER WIRE 슬리브
36.211	BUSHING, PIVOT PIN FASTENER 부싱
37.359	SPACER, TOP HOOD PIVOT 스페이서
37.497	HANDLE, TOP HOOD LATCH 핸들
37.897	BUMPER, TOP HOOD 범퍼
39.423	FASTENER, TOP HOOD 패스너
39.535	BRACKET, TOP HOOD MOUNTING 브라켓

39.536	BRACKET, TOP HOOD MOUNTING 브라켓
39.594	HOOD, TOP 후드
39.595	FASTENER, TOP HOOD 패스너
39.599	FASTENER, HOOD PIVOT HINGE 패스너
39.616	FASTENER, TOP HOOD LATCH 패스너
39.644	LATCH, TOP HOOD 래치
39.704	SPRING, HOOD PROP (OUTER) 스프링
39.705	FASTENER, HOOD PROP 패스너
96.900	FASTENER, CAB REAR HANDLE GRIP 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



SEAT MOUNTING


39-829


39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔



- | | |
|--------|---|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
안전벨트 |
| 37.915 | SUSPENSION COVER, SEAT SUSPENSION
서스펜션커버 |
| 37.918 | SUSPENSION ASSEMBLY, SEAT
서스펜션 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |
| 39.721 | CUSHION, SEAT BACK REST
쿠션 |

39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너






34.497	SEAL, LIFT CYLINDER GLAND 씰
36.211	BUSHING, PIVOT PIN FASTENER 부싱
37.359	SPACER, TOP HOOD PIVOT 스페이서
37.897	BUMPER, TOP HOOD 범퍼
37.933	COVER, HOOD ACCESS 커버
37.935	FASTENER, HOOD ACCESS COVER 패스너
39.535	BRACKET, TOP HOOD MOUNTING 브라켓
39.536	BRACKET, TOP HOOD MOUNTING 브라켓
39.594	HOOD, TOP 후드


39.595	FASTENER, TOP HOOD 패스너
39.599	FASTENER, HOOD PIVOT HINGE 패스너
39.616	FASTENER, TOP HOOD LATCH 패스너
39.644	LATCH, TOP HOOD 래치
39.704	SPRING, HOOD PROP (OUTER) 스프링
39.705	FASTENER, HOOD PROP 패스너
47.069	PLUG, TOP HOOD 플러그
47.302	COVER, GAS SPRING 커버
94.763	FASTENER, HOOD SUPPORT 패스너
96.900	FASTENER, CAB REAR HANDLE GRIP 패스너







40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너
40.006	LEGEND, PATENT 범례
40.042	DECAL, POLARITY 데칼
40.062	DECAL, DRIVERS CAUTION 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼
40.076	DECAL, ELECTRIC TRUCK CAUTION 데칼
40.089	PLATE, SAFETY INSTRUCTION 플레이트
40.130	LEGEND, SAFETY 범례

40.131	LEGEND, SAFETY 범례
40.138	DECAL, SAFETY 데칼
40.141	DECAL, HYDRAULIC SCHEMATIC 데칼
40.173	DECAL, IMPORTANT 데칼
40.183	DECAL, BATTERY DISCONNECT WARNING 데칼
40.241	DECAL, BRAKE OIL SPEC 데칼
40.248	DECAL, SERVICE CHART 데칼
40.326	DECAL, EE MARKING 데칼
40.328	DECAL, WHEEL NUT WARNING 데칼
40.329	FASTENER, ATTACHMENT NAME PLATE 패스너
40.330	PLATE, ATTACHMENT NAME 플레이트





40.010	DECAL, CLARK 데칼
40.012	DECAL, CLARK LOGO-SMALL 데칼
40.013	DECAL, CLARK LOGO-LARGE 데칼
40.142	DECAL, ELECTRICAL CIRCUIT DIAGRAM 데칼
40.296	DECAL, TIRE PRESSURE 데칼
40.309	DECAL, AC LOGO 데칼




NOTE: All Trucks Do Not Use All Fluid Key Numbers

TRUCK FLUIDS

40-260


99.901	ENGINE OIL 엔진오일
99.902	TRANSMISSION FLUID 트랜스미션오일
99.903	DRIVE AXLE FLUID 드라이브액슬
99.904	HYDRAULIC SUMP OIL 유압섬프오일
99.905	BRAKE FLUID 브레이크오일
99.906	AXLE END FLUID 액슬엔드오일
99.907	ENGINE ANTIFREEZE 부동액



STORAGE CONSOLE MOUNTING


41-008


- | | |
|--------|--|
| 41.026 | FASTENER, STORAGE CONSOLE DOCUMENT CLIP
패스너 |
| 41.027 | CLIP, STORAGE CONSOLE DOCUMENT
클립 |
| 41.028 | CONSOLE, OPERATOR STORAGE CONSOLE
콘솔 |
| 41.030 | FASTENER, STORAGE CONSOLE
패스너 |




- | | |
|--------|---|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 06.101 | LEVER ASSEMBLY, FORWARD & REVERSE
레버 |
| 13.111 | FASTENER, DIRECTIONAL CONTROL SWITCH
패스너 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |
| 14.245 | HARNESS, SWITCH HEATER CONTROL WIRING
하네스 |
| 14.986 | BRACKET, SWITCH HEATER CONTROL
브라켓 |
| 15.187 | HEATER, HYDRAULIC VALVE SWITCH
히터 |
| 15.700 | HEATER, STEER ANGLE SENSOR
히터 |

22.045	BRACKET, PARKING BRAKE PEDAL PIVOT MTG 브라켓
41.008	CONTROL, SWITCH HEATER 컨트롤
41.018	FASTENER, SWITCH HEATER CONTROL 패스너
41.425	HEATER, FOOT BRAKE SWITCH 히터
41.426	HEATER, PARKING BRAKE SWITCH 히터
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링







- | | |
|--------|---|
| 37.421 | GROMMET, OVERHEAD GUARD REAR SUPPORT PIVOT
그로멧 |
| 47.385 | GRIP, OVERHEAD GUARD REAR HAND
그립 |
| 60.968 | WIRE, OVERHEAD GUARD REAR HAND GRIP SWITCH
와이어 |
| 97.216 | FASTENER, OVERHEAD GUARD REAR HAND GRIP
패스너 |




**STANDARD TYPE
(TYPE - 1)**



**LESS HEIGHT THAN STANDARD TYPE
(TYPE - 2)**



**DIDT OPTION TYPE
(TYPE - 3)**




**LESS HEIGHT THAN DIDT OPTION TYPE
(TYPE - 4)**

OVERHEAD GUARD


47-009

39.932


GUARD, OVERHEAD
가드




- 37.976 CLAMP, SEAT WIRING HARNESS
클램프
- 40.306 DECAL, SEAT SWITCH
데칼



HINGED BUCKET (HB) / FORK (HF) - BASIC



ROTATING FORK (RF) - BASIC




LOAD STABILIZER (LS) - BASIC

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-171

50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.405	COUPLING, DEVICE HOSE 커플링
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅




HIGH TERMINATION FOR DEVICE HOSE ADAPTION

50-172

- | | |
|--------|---|
| 59.134 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.135 | LINE, DEVICE LH LINE FOR HIGH TERMINATION
라인 |
| 59.136 | LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인 |
| 59.137 | LINE, DEVICE RH LINE FOR HIGH TERMINATION
라인 |
| 59.142 | FITTING, DEVICE LINE FOR HIGH TERMINATION
피팅 |
| 59.143 | CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
캡 |
| 59.144 | BRACKET, DEVICE LINE FOR HIGH TERMINATION
브라켓 |
| 59.145 | SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
셀 |
| 59.146 | SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
셀 |

97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너
97.238	FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION 패스너






59.134	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.135	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.136	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.137	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.142	FITTING, DEVICE LINE FOR HIGH TERMINATION 피팅
59.143	CAP, DEVICE LINE FITTING FOR HIGH TERMINATION 캡
59.144	BRACKET, DEVICE LINE FOR HIGH TERMINATION 브라켓
59.145	SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION 셀
59.146	SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION 셀

97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너
97.238	FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION 패스너






HIGH TERMINATION FOR DEVICE HOSE ADAPTATION

50-176

59.134	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.135	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.142	FITTING, DEVICE LINE FOR HIGH TERMINATION 피팅
59.143	CAP, DEVICE LINE FITTING FOR HIGH TERMINATION 캡
59.144	BRACKET, DEVICE LINE FOR HIGH TERMINATION 브라켓
97.238	FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




SOLENOID VALVE FOR DEVICE HOSE ADAPTATION


50-177

14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.972	CLIP, DEVICE SELECTOR VALVE LINE 클립
33.973	FASTENER, DEVICE SELECTOR VALVE LINE CLIP 패스너



ATTACHMENT HOSE REFERENCE




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-232

50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.610	FASTENER, DEVICE HOSE GUARD 패스너
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.811	NUT, DEVICE HOSE FITTING 너트
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.156	CLIP, DEVICE HOSE 클립	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.200	COUPLING, DEVICE HOSE 커플링	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.571	BRACKET, DEVICE HOSE 브라켓	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.572	FASTENER, DEVICE HOSE BRACKET 패스너	75.015	MODULE, ATTACHMENT HOSE LINES 모듈

93.316	DOWEL, STEERING INTERLOCK SWITCH FASTENER 다웰
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너





50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
씰

50.132 BRACKET, DEVICE HOSE REEL
브라켓

50.155 FASTENER, DEVICE HOSE CLIP
패스너

50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.295 ROLLER, DEVICE HOSE UPPER
롤러

50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.316 GUARD, DEVICE RH HOSE
가드

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.433 BRACKET, DEVICE HOSE CLAMP
브라켓

50.571 BRACKET, DEVICE HOSE
브라켓

50.572 FASTENER, DEVICE HOSE BRACKET
패스너

50.610 FASTENER, DEVICE HOSE GUARD
패스너

50.811 NUT, DEVICE HOSE FITTING
너트

59.016 JUNCTION BLOCK, DEVICE HOSE
정크션 블록

59.023 BRACKET, DEVICE HOSE REEL MOUNTING
브라켓

59.034 TUBE, DEVICE HOSE REEL MOUNTING BRACKET
튜브

59.054 PLUG, DEVICE HOSE JUNCTION BLOCK
플러그

59.072 GUARD, DEVICE HOSE
가드

59.077 FASTENER, DEVICE HOSE GUARD
패스너

59.086 FASTENER, DEVICE HOSE CLIP BRACKET
패스너

59.101 TIE STRAP, AUXILIARY FUNCTION LINES
타이스트랩

59.118 LINE, DEVICE HYDRAULIC (OUTER RAIL)
라인

59.122 LINE, DEVICE HYDRAULIC (INNER RAIL)
라인

59.125 BRACKET, DEVICE HOSE GUARD MOUNTING
브라켓


59.126 BRACKET, DEVICE HOSE GUARD MOUNTING
브라켓

75.015 MODULE, ATTACHMENT HOSE LINES
모듈

93.316 DOWEL, STEERING INTERLOCK SWITCH FASTENER
다웰

93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너






50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.686	WIRE, DEVICE 와이어

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너

ATTACHMENT HOSE
REFERENCE 75.015




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-289

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.588	BRACKET, DEVICE CABLE CLAMP 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.590	CLAMP, DEVICE CABLE LOWER 클램프
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.591	FASTENER, DEVICE CABLE CLAMP LOWER 패스너
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.623	BRACKET, DEVICE CABLE LOWER SHEAVE 브라켓
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.624	SHEAVE, DEVICE CABLE 쉬브
50.156	CLIP, DEVICE HOSE 클립	50.625	RETAINER, DEVICE CABLE LOWER SHEAVE 리테이너
50.200	COUPLING, DEVICE HOSE 커플링	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.686	WIRE, DEVICE 와이어
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	50.732	SPACER, DEVICE CABLE SHEAVE 스페이서
50.586	CLIP, DEVICE CABLE 클립	50.733	SPACER, DEVICE CABLE CLAMP BRACKET 스페이서
50.587	FASTENER, DEVICE CABLE CLIP 패스너	50.734	BRACKET, DEVICE CABLE TERMINAL CLAMP 브라켓


50.745	BRACKET, DEVICE CABLE TERMINAL CLAMP MOUNTING 브라켓
50.746	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.182	FASTENER, DEVICE CABLE LOWER SHEAVE BRACKET 패스너



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.686	WIRE, DEVICE 와이어

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너






50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.731	PLUG, DEVICE CABLE CONNECTOR 플러그
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너

ATTACHMENT HOSE REFERENCE

-75.015




ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-292

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.588	BRACKET, DEVICE CABLE CLAMP 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.590	CLAMP, DEVICE CABLE LOWER 클램프
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.591	FASTENER, DEVICE CABLE CLAMP LOWER 패스너
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰	50.623	BRACKET, DEVICE CABLE LOWER SHEAVE 브라켓
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.624	SHEAVE, DEVICE CABLE 쉬브
50.156	CLIP, DEVICE HOSE 클립	50.625	RETAINER, DEVICE CABLE LOWER SHEAVE 리테이너
50.200	COUPLING, DEVICE HOSE 커플링	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.686	WIRE, DEVICE 와이어
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	50.732	SPACER, DEVICE CABLE SHEAVE 스페이서
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	50.733	SPACER, DEVICE CABLE CLAMP BRACKET 스페이서
50.586	CLIP, DEVICE CABLE 클립	50.734	BRACKET, DEVICE CABLE TERMINAL CLAMP 브라켓
50.587	FASTENER, DEVICE CABLE CLIP 패스너	50.745	BRACKET, DEVICE CABLE TERMINAL CLAMP MOUNTING 브라켓

50.746	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.182	FASTENER, DEVICE CABLE LOWER SHEAVE BRACKET 패스너

ATTACHMENT HOSE—75.015
REFERENCE




50-293

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 셀
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR 로크
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너

ATTACHMENT HOSE
REFERENCE 75.015




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-407


50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너




50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅

50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너




50.006	SHEAVE, DEVICE HOSE UPPER шнёр
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER шнёр
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너




50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 씰
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅

50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES 모듈
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너




50.019	FASTENER, DEVICE HOSE DISCONNECT 패스너
50.105	SEAL, DEVICE HOSE SWIVEL COUPLING PLUG 씰
50.108	SEAL, DEVICE HOSE SWIVEL COUPLING INLET PORT 씰
50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.292	FITTING, DEVICE RH HYDRAULIC HOSE 피팅
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.643	LINE, DEVICE UPPER (AT CARRIAGE) 라인
50.646	LINE, DEVICE 라인


50.786	SEAL, DEVICE RH HOSE TERMINAL BLOCK PORT 씰
50.830	CAP, DEVICE HOSE REEL FITTING 캡
53.033	FASTENER, HOSE TERMINAL BRACKET 패스너
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
75.033	KIT, CARRIAGE TERMINATION PIPING - RH 키트
75.034	KIT, CARRIAGE TERMINATION PIPING - LH 키트




**MODEL: GTX162
GEX162**
UPRIGHT: STANDARD




**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: STANDARD




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE & HI-LO




**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: TRIPLE STAGE



**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: HI-LO




**MODEL: EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: STANDARD

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-791


- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-794


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-796


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-797


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.343	FITTING, DEVICE LH LINE 피팅
50.344	FITTING, DEVICE LH LINE 피팅
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅
59.091	FITTING, DEVICE HYDRAULIC LINE 피팅



QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION

50-798


- | | |
|--------|---|
| 59.092 | QUICK DISCONNECT, DEVICE HOSE
퀵디스커넥트 |
| 59.131 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |
| 59.132 | FITTING, DEVICE LINE QUICK DISCONNECT
피팅 |



DEVICE LINE ADAPTORS

50-819


- | | |
|--------|---|
| 59.081 | FITTING, DEVICE HOSE ADAPTOR (AT UPRIGHT)
피팅 |
| 59.082 | FITTING, DEVICE HOSE ADAPTOR (AT UPRIGHT)
피팅 |




14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디स्क넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT 피팅
59.132	FITTING, DEVICE LINE QUICK DISCONNECT 피팅





37.457	HOOK, CAB CLOTHING HANGER 후크	53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
52.149	NUT, SIDE SHIFT CYLINDER ANCHOR PORT LINE FITTING 너트	53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더	54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
53.024	ANCHOR, SIDE SHIFTER CYLINDER BASE 앵커	54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
53.025	GUIDE, SIDE SHIFTER MOVABLE FRAME LOWER 가이드	54.152	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링	54.155	FITTING, SIDE SHIFTER CYLINDER ROD PORT LINE 피팅
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너	54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
53.090	FASTENER, SIDE SHIFTER MOVABLE FRAME 패스너	54.197	FASTENER, SIDE SHIFTING BASE PLATE TO ARM 패스너
53.180	SPACER, SIDE SHIFTER BEARING 스페이서	54.198	BEARING, SIDE SHIFTER BASE PLATE ARM 베어링
53.182	FASTENER, SIDE SHIFTER HANGER 패스너	54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
53.201	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT 피팅	54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인	54.403	FITTING-LUB, SIDE SHIFTER BASE PLATE ARM 피팅
53.209	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅	66.162	STOP, CARRIAGE TRAVEL 스톱
53.210	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅	92.483	NIPPLE, LUBRICATION 니플
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인		





FORK POSITIONER (BASIC)

53-084


37.457	HOOK, CAB CLOTHING HANGER 후크
52.149	NUT, SIDE SHIFTER CYLINDER ANCHOR PORT LINE FITTING 너트
53.025	GUIDE, SIDE SHIFTER MOVABLE FRAME LOWER 가이드
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.090	FASTENER, SIDE SHIFTER MOVABLE FRAME 패스너
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.209	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인

53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
54.152	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.197	FASTENER, SIDE SHIFTING BASE PLATE TO ARM 패스너
54.198	BEARING, SIDE SHIFTER BASE PLATE ARM 베어링
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
66.162	STOP, CARRIAGE TRAVEL 스톱





- 53.020 CYLINDER ASSEMBLY, SIDE SHIFTER
실린더
- 54.222 PACKING KIT, SIDE SHIFTER CYLINDER
패킹키트




FORK POSITIONER

53-164

53.054	GUIDE, FORK 가이드
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크


54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너






53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.024	ANCHOR, SIDE SHIFTER CYLINDER BASE 앵커
53.054	GUIDE, FORK 가이드
53.069	FASTENER, FORK CYLINDER ROD END 패스너
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.180	SPACER, SIDE SHIFTER BEARING 스페이서
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.210	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅


53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.403	FITTING-LUB, SIDE SHIFTER BASE PLATE ARM 피팅
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크
54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
92.483	NIPPLE, LUBRICATION 니플
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너



53.054	GUIDE, FORK 가이드
53.069	FASTENER, FORK CYLINDER ROD END 패스너
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.746	LINE, FORK CYLINDER ROD END 라인
53.772	LINE, FORK CYLINDER ANCHOR END 라인
53.887	LINE, FORK CYLINDER ANCHOR END 라인
54.190	FASTENER, FORK HANGER SUPPORT 패스너
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
54.209	PLUG, FORK CYLINDER FLOW DIVIDER 플러그

54.215	LINE, FORK CYLINDER ROD END 라인
54.224	PACKING KIT, LH FORK CYLINDER 패킹키트
54.446	FITTING - LUB, FORK POSITIONER 피팅
54.546	FITTING - LUB, FORK POSITIONER 피팅
54.548	HOOK, FORK POSITIONER HANGER 후크
54.549	STOP, FORK POSITIONER CYLINDER 스톱
54.552	FASTENER, FORK POSITIONER CYLINDER STOP 패스너
54.553	FITTING - LUB, FORK POSITIONER 피팅
66.098	BEARING, FORK HORIZONTAL THRUST ROLLER 베어링
96.259	FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER 패스너






40.343	DECAL, ATTACHMENT SAFETY 데칼
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링

54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서
54.314	SPACER, SIDE SHIFTER CYLINDER REAR 스페이서



ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹키트
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT 볼

97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
 세트스크류


ФОРКЛИФТ
www.forklift.ru



53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.637	GLAND, INBOARD LH FORK CYLINDER 그랜드
53.648	BUSHING, LH FORK CYLINDER GLAND 부싱
53.687	GLAND, INBOARD RH FORK CYLINDER 그랜드
53.698	BUSHING, RH FORK CYLINDER GLAND 부싱
54.212	SEAL KIT, FORK CYLINDER 씰키트
54.484	ROD, FORK CYLINDER PISTON 로드
54.486	PISTON, FORK CYLINDER 피스톤

54.488 NUT, FORK CYLINDER PISTON
너트







52.149	NUT, SIDE SHIFT CYLINDER ANCHOR PORT LINE FITTING 너트
53.023	ANCHOR, SIDE SHIFTER CYLINDER ROD END 앵커
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인

54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트







- 34.350 FORK ASSEMBLY
포크
- 34.359 KIT, FORK STOP PIN (CAPTIVE)
키트




66.207	PISTON, FINAL LIFT CYLINDER 피스톤
66.392	RING, FINAL LIFT CYLINDER PISTON BACK-UP 링
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.404	CAP, FINAL LIFT CYLINDER GLAND 캡
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서



34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 워셔




66.395	CHECK VALVE, FINAL LIFT CYLINDER 체크밸브
66.397	WASHER, FINAL LIFT CYLINDER CHECK VALVE 와셔
66.398	SNAP RING, FINAL LIFT CYLINDER CHECK VALVE 스냅링
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서
66.444	GLAND, FINAL LIFT CYLINDER 그랜드



28.746	FITTING, LIFT CYLINDER LINE 피팅	34.107	ANCHOR, LIFT CHAIN 앵커
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.186	ROLLER, UPRIGHT 롤러
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일	66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
34.013	ROLLER, UPRIGHT 롤러	66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
34.014	SHIM, UPRIGHT ROLLER 심	66.167	SHIM, LIFT CYLINDER UPPER 심
34.037	CAP, UPRIGHT TRUNNION 캡	66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너	66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리지
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	66.507	TEE, LIFT CYLINDER LINE 티
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
34.084	SHEAVE, LIFT CHAIN 쉬브	91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
34.101	CHAIN, LIFT 체인	91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너


93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너





28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브	34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피봇	34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
28.729	LINE, LIFT CYLINDER 라인	34.081	SPACER, LIFT CHAIN SHEAVE CARRIER 스페이서
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.084	SHEAVE, LIFT CHAIN 쉬브
28.746	FITTING, LIFT CYLINDER LINE 피팅	34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.101	CHAIN, LIFT 체인
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.102	FASTENER, SHEAVE CARRIER 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.107	ANCHOR, LIFT CHAIN 앵커
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃더레일	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.013	ROLLER, UPRIGHT 롤러	34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.014	SHIM, UPRIGHT ROLLER 심	34.186	ROLLER, UPRIGHT 롤러
34.037	CAP, UPRIGHT TRUNNION 캡	34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너	34.271	FASTENER, LIFT CYLINDER LOWER 패스너


34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.167	SHIM, LIFT CYLINDER UPPER 심
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.433	SHIM, CYLINDER MOUNT 심
66.438	SHEAVE, HOSE 쉬브
66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리지
66.506	CLAMP, LIFT CYLINDER 클램프
66.507	TEE, LIFT CYLINDER LINE 티
66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너
97.179	FASTENER, LIFT CYLINDER CLAMP 패스너



28.729	LINE, LIFT CYLINDER 라인	34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.081	SPACER, LIFT CHAIN SHEAVE CARRIER 스페이서
28.746	FITTING, LIFT CYLINDER LINE 피팅	34.084	SHEAVE, LIFT CHAIN 쉬브
28.747	FITTING, LIFT CYLINDER LINE 피팅	34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.101	CHAIN, LIFT 체인
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.102	FASTENER, SHEAVE CARRIER 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.107	ANCHOR, LIFT CHAIN 앵커
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더	34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃더레일	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
34.013	ROLLER, UPRIGHT 롤러	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.014	SHIM, UPRIGHT ROLLER 심	34.186	ROLLER, UPRIGHT 롤러
34.037	CAP, UPRIGHT TRUNNION 캡	34.271	FASTENER, LIFT CYLINDER LOWER 패스너
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브

66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.167	SHIM, LIFT CYLINDER UPPER 삼
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
66.304	FASTENER, LIFT CYLINDER LINE CLAMP 패스너
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.471	LINE, LIFT CYLINDER FEED 라인
66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE 카트리지
66.507	TEE, LIFT CYLINDER LINE 티
66.508	SPACER, LIFT CHAIN ANCHOR FASTENER 스페이서
66.509	CLAMP, LIFT CYLINDER LINE 클램프
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너






34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너

66.502	CUSHION, LIFT CYLINDER 쿠션
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔







34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너

66.502	CUSHION, LIFT CYLINDER 쿠션
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔







13.379	ARM, LIFT HEIGHT LIMIT SWITCH 암
13.621	SWITCH, LIFT HEIGHT LIMIT 스위치
13.622	BRACKET, HEIGHT LIMIT SWITCH MOUNTING 브라켓
13.623	FASTENER, HEIGHT LIMIT SWITCH 패스너
13.647	CABLE GRIP, HEIGHT LIMIT SWITCH SEQUENCE RELAY 케이블그립
14.339	WIRE, ELECTRICAL INSTALLATION 와이어
14.340	TERMINAL, ELECTRICAL INSTALLATION 터미널
14.341	CONNECTOR, ELECTRICAL INSTALLATION 커넥터
32.144	TIE STRAP, CABLE RETAINING 타이스트랩



13.621	SWITCH, LIFT HEIGHT LIMIT 스위치	32.136	RELAY, TILT LIMIT DEVICE 릴레이
13.622	BRACKET, HEIGHT LIMIT SWITCH MOUNTING 브라켓	32.146	FASTENER, TILT LIMIT RELAY 패스너
13.623	FASTENER, HEIGHT LIMIT SWITCH 패스너	32.147	WASHER, TILT LIMIT FASTENER 와셔
13.624	BRACKET, TILT LIMIT SWITCH 브라켓	32.150	FILTER, ASSY TILT LIMIT WIRING 필터
13.625	FASTENER, TILT LIMIT SWITCH 패스너	32.151	FILTER, TILT LIMIT RELAY WIRING 필터
13.634	CABLE GRIP, LIFT HEIGHT LIMIT SWITCH 케이블그립	32.157	SWITCH, TILT LIMIT 스위치
13.872	SWITCH, TILT LIMIT DEFEAT 스위치	32.158	BRACKET, TILT LIMIT SWITCH 브라켓
15.083	CONDUCTOR, TILT LIMIT DEVICE FEED 컨덕터	32.159	RETAINER, TILT LIMIT SWITCH BRACKET 리테이너
15.112	TERMINAL, TILT LIMIT DEVICE CONDUCTOR 터미널	40.126	LEGEND, TILT LIMIT OVERRIDE 범례
15.115	TERMINAL, TILT LIMIT CONDUCTOR 터미널	60.478	BRACKET, DIRECTIONAL CONTROL SWITCH ADJUSTOR 브라켓
15.121	TERMINAL, LIFT HEIGHT LIMIT SWITCH CONDUCTOR 터미널	66.367	TUBE, UPRIGHT PLUMBING 튜브
15.687	CONDUCTOR, LIFT HEIGHT LIMIT SWITCH 컨덕터	96.784	WASHER, TILT LIMIT SWITCH FASTENER 와셔
15.716	BRACKET, RELAY MOUNTING 브라켓	96.786	NUT, LIFT HEIGHT LIMIT SWITCH FASTENER 너트
32.027	END, RH TILT CYLINDER ROD 엔드	96.787	WASHER, TILT LIMIT RELAY FASTENER 와셔
32.029	FASTENER, TILT CYLINDER ROD END 패스너	96.788	NUT, TILT LIMIT RELAY FASTENER 너트



30.956	SEAL, RELIEF VALVE PLUG 씰	33.712	COUPLING, DEVICE RELIEF VALVE DISCHARGE HOSE 커플링
33.054	PLUG, RELIEF VALVE PORT 플러그	33.713	LINE, DEVICE RELIEF VALVE DISCHARGE 라인
33.055	SEAL, RELIEF VALVE PORT PLUG 씰	33.714	COUPLING, DEVICE RELIEF VALVE DISCHARGE LINE 커플링
33.600	RELIEF VALVE, DEVICE VARIABLE PRESSURE 릴리프밸브	33.732	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.603	BRACKET, DEVICE CARIABLE RELIEF VALVE 브라켓	33.733	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.604	FASTENER, DEVICE VARIABLE RELIEF VALVE 패스너	33.900	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.617	SPACER, DEV VARIABLE RELIEF VAL BRKT 스페이서	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.661	FITTING, DEVICE RELIEF VALVE OUTLET PORT 피팅	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.701	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	33.935	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.702	LINE, DEVICE RELIEF VALVE INLET 라인	75.311	KIT, RELIEF VALVE INSTALLATION 키트
33.703	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	90.854	BOLT, DEVICE MOUNTING BRACKET FASTENER 볼트
33.706	FITTING, DEVICE RELIEF VALVE INLET PORT 피팅	90.855	LOCKWASHER, DEVICE MOUNTING BRACKET FASTENER 로크와셔
33.707	SEAL, DEVICE RELIEF VALVE INLET PORT FITTING 씰	91.221	NUT, DEV VARIABLE RELIEF VALVE FASTENER 너트
33.710	FITTING, DEVICE RELIEF VALVE DISCHARGE PORT 피팅	91.712	LOCKWASHER, DEVICE RELIEF VALVE FASTENER 로크와셔
33.711	SEAL, DEVICE RELIEF VALVE DISCHARGE PORT FTG 씰		



39.706	SUPPORT, SEAT 서포트
39.719	SEAT ASSEMBLY 시트
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트