


부품 매뉴얼 PARTS MANUAL

TMX 12/13/15s/15/17/18/20/20x/23/25

SERIAL NUMBER : TMX250 - XXXX - 9803 KF

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Part No. : 8037360

Dec. 2013



(본사) 경기도 부천시 오정구 오정동 202-1
(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea
(공장) 경남 창원시 웅남동 40-1
(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea




02-487	ACCELERATOR PEDAL & LINKAGE 악셀레이터 페달& 링크이지	22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브휠& 타이어 마운팅
02-488	ACCELERATION PEDAL AND LINKAGE 악셀레이터 페달& 링크이지	22-014	STEER WHEEL & TIRE MOUNTING 스티어휠& 타이어 마운팅
02-882	ACCELERATOR CONTROL/PEDAL MTG 악셀레이터 컨트롤& 페달 어셈블리	22-024	DRIVE WHEEL & TIRE (SOLID TYPE) 드라이브 휠& 타이어 (솔리드 타입)
13-068	ACCESSORY MOUNTING 액세서리 마운팅	22-025	STEER WHEEL & TIRE (SOLID TYPE) 스티어 휠& 타이어 (솔리드 타입)
13-119	BACK-UP ALARM INSTALLATION 백-업 알람 조립그룹	22-035	DRIVE WHEEL & TIRE (CUSHION TYPE) 드라이브 휠& 타이어 (쿠션 타입)
13-135	HEAD LIGHT BRACKET MOUNTING 헤드 라이트 브라켓 마운팅	22-036	STEER WHEEL & TIRE (CUSHION TYPE) 스티어 휠& 타이어 (쿠션 타입)
13-140	REAR VIEW MIRROR 후방 미러	22-038	UNITROL SYSTEM 유닛롤 시스템
13-168	PUSH BUTTON WIRING 푸시버튼 와이어링	22-039	PARKING BRAKE & LINKAGE 파킹 브레이크& 링크이지
13-177	ACCESSORY MOUNTING 액세서리 마운팅	22-041	DRIVE WHEEL AND TIRE 드라이브 휠& 타이어
13-178	ACCESSORY MOUNTING 액세서리 마운팅	22-042	STEER WHEEL & TIRE 스티어링 휠& 타이어
13-182	STROBE LIGHT 경광등	22-058	BRAKE ASSEMBLY 브레이크 어셈블리
13-186	REAR VIEW MIRROR 후방 미러	22-130	BRAKE ASSEMBLY 브레이크 어셈블리
13-190	HEAD LAMP INSTALLATION 헤드램프 조립그룹	22-312	BRAKE MASTER CYLINDER 브레이크 마스터 실린더
13-227	REAR WORK LIGHT INSTALLATION 후방등 조립그룹	23-070	BRAKE PEDAL & LINKAGE 브레이크 페달& 링크이지
13-299	STEER ANGLE SENSOR MOUNTING 스티어 앵글센서 마운팅	23-456	PARKING BRAKE & LINKAGE 파킹 브레이크& 링크이지
13-330	BACK-UP ALARM INSTALLATION 백-업 알람 조립그룹	23-541	BRAKE PEDAL & LINKAGE 브레이크 페달& 링크이지
14-049	FORK LEVELING SYSTEM 포크 레벨링 시스템	23-994	PARKING HAND BRAKE 파킹 핸드 브레이크
14-053	FORK LEVELING SYSTEM 포크 레벨링 시스템	25-032	TILT STEERING COLUMN 틸트 스티어링 컬럼
14-159	ELECTRICAL WIRING 전기장치 와이어링	25-033	TILT STEERING COLUMN 틸트 스티어링 컬럼
14-259	ELECTRICAL COMPONENTS 전기장치 구성품	25-070	STEERING WHEEL & COLUMN MOUNTING 스티어링 휠& 컬럼 마운팅
15-020	CABLE INSTALLATION 케이블 조립그룹	25-138	STEER CYLINDER MOUNTING 스티어링 실린더 마운팅
15-021	CABLE INSTALLATION (EE) 케이블 조립그룹 (EE)	25-140	STEERING UNIT 스티어링 유닛
15-062	ELECTRICAL COMPONENTS 전기장치 구성품	25-363	STEERING GEAR MOUNTING 스티어링 기어 마운팅
15-064	ELECTRICAL COMPONENTS (EE) 전기장치 구성품 (EE)	25-366	DIRECTIONAL CONTROL LINKAGE 방향 컨트롤 링크이지
16-254	PUMP MOTOR MOUNTING 펌프 모터 마운팅	26-244	STEERING CYLINDER 스티어링 실린더
16-255	TRACTION & PUMP MOTORS 트랙션& 펌프 모터	26-318	HYDRAULIC STEERING LINES 유압 스티어링 라인
16-256	DRIVE MOTOR ASSEMBLY 드라이브 모터 어셈블리	26-769	STEER AXLE MOUNTING 스티어링 액슬 마운팅
16-257	PUMP MOTOR ASSEMBLY 펌프 모터 어셈블리	26-771	DUAL STEER AXLE MOUNTING 듀얼 스티어 액슬 마운팅
17-111	LINE CONTACTOR ASSEMBLY 라인 컨택터 어셈블리	27-002	PRIORITY VALVE ASSEMBLY 우선 밸브 어셈블리
19-025	CONTROLLER MOUNTING 컨트롤러 마운팅	29-232	HYDRAULIC SUMP TANK 유압 성트 탱크
20-186	DRIVE AXLE & BRAKE MOUNTING 드라이브 액슬& 브레이크 마운팅	29-296	HYDRAULIC PUMP ASSEMBLY 유압 펌프 어셈블리
20-187	DRIVE AXLE ASSEMBLY 드라이브 액슬 어셈블리	29-312	HYDRAULIC OIL FILTER 유압 오일 필터
20-188	DRIVE AXLE - RH 드라이브 액슬 - 우	29-318	HYDRAULIC PUMP MOUNTING 유압 펌프 마운팅
20-189	AXLE END-RH 액슬 엔드 (우)	30-139	MAIN CONTROL VALVE 2-SPOOL 메인 컨트롤 밸브 - 2 스톨
20-190	DRIVE AXLE - LH 드라이브 액슬 - 좌	30-140	MAIN CONTROL VALVE 3-SPOOL 메인 컨트롤 밸브 - 3 스톨
20-191	AXLE END-LH 액슬 엔드 (좌)	30-141	MAIN CONTROL VALVE 4-SPOOL 메인 컨트롤 밸브 - 4 스톨

30-513	HYDRAULIC CONTROL VALVE-3 SPOOL 유압 컨트롤 밸브 - 3 스푼	39-785	SAFETY BELT 안전 벨트
30-515	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)	39-829	SEAT MOUNTING 시트 마운팅
30-516	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)	39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리
30-521	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)	39-931	SEAT MOUNTING (DIDT-OHG) 시트 마운팅 (DIDT-오버헤드가드)
30-538	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)	39-970	EE CONSTRUCTION, HOOD/FRAME EE 구성품 후드& 프레임
30-539	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)	40-260	TRUCK FLUIDS 트럭 윤활유
31-309	MAIN HYDRAULIC LINES 메인 유압 라인	40-263	SAFETY & LOGO & WIRING DIAGRAM DECALS 안전& 로고& 와이어배선 데칼
31-312	HYDRAULIC LIFT LINES 유압 리프트 라인	40-266	ATTACHMENT NAME PLATE 어태치 명판
31-313	HYDRAULIC TILT LINES 유압 틸트 라인	40-267	DECALS 데칼
31-314	HYDRAULIC RETURN LINES 유압 리턴 라인	41-037	COLD STORAGE HEATER INSTALLATION 냉장 시스템 히터 조립그룹
32-143	TILT CYLINDER 틸트 실린더	47-000	SEAT WING KIT 시트윙 키트
32-168	TILT CYLINDER MOUNTING 틸트 실린더 마운팅	47-008	SEAT SWITCH INSTALLATION 시트 스위치 조립그룹
32-169	TILT AMOUNT GROUP 틸트 어마운트 그룹	47-009	OVERHEAD GUARD 오버헤드가드
32-850	ACCUMULATOR 어큐뮬레이터	47-013	OVERHEAD GUARD 오버헤드가드
33-069	RELIEF VALVE ASSEMBLY 릴리프 밸브 어셈블리	47-025	ARMREST KIT INSTALLATION 암레스트 키트 조립그룹
33-130	SELECTOR SOLENOID VALVE 셀렉터 솔레노이드 밸브	50-120	AUXILIARY VALVE LINES 보조 밸브 라인
34-044	LOAD BACK REST MOUNTING 로드 백 레스트 마운팅	50-786	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
34-109	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-787	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 어태치 호스 적응 (마스트)
34-209	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-791	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
34-325	UPRIGHT MOUNTING 마스트 마운팅	50-792	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
37-019	COWL & DASH COVER MOUNTING 카울& 대시커버 마운팅	50-793	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 어태치 호스 적응 (캐리지)
37-020	FLOOR PLATE MOUNTING 플로어 플레이트 마운팅	50-799	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
37-021	SHEET METAL 시트 메탈	50-807	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION 솔레노이드 밸브 (디바이스 호스 적응)
37-022	HOOD MOUNTING 후드 마운팅	50-817	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION 하이 터미네이션 (디바이스 호스 적응)
37-124	SEAT ARMREST ASSEMBLY 시트 암레스트 어셈블리	53-026	SIDESHIFTER 사이드 쉬프터
38-206	BATTERY STOPPER 배터리 스톱퍼	53-187	SIDE SHIFT ASSEMBLY 사이드 쉬프트 어셈블리
38-223	SIDE BATTERY REMOVAL(SBR) 사이드 배터리 제거 (SBR)	53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더
38-271	COUNTERWEIGHT MOUNTING 카운터웨이트 조립그룹	54-015	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
38-272	COUNTERWEIGHT & MODEL DECAL 카운터웨이트 & 모델 데칼	66-058	FORK 포크
38-273	SIDE BATTERY REMOVAL(SBR) 사이드 배터리 제거 (SBR)	66-065	LIFT CYLINDER PIPING 리프트 실린더 파이핑
38-274	SHEET METAL 시트 메탈	66-072	STANDARD UPRIGHT 표준 마스트
38-706	TOW EYE AND COUPLER INSTALLATION 토우 아이& 커플러 조립그룹	66-073	LIFT CHAIN 리프트 체인
39-519	LOAD BACK REST 로드 백 레스트	66-074	LIFT CYLINDER PIPING 리프트 실린더 파이핑
39-583	SEAT MOUNTING 시트 마운팅	66-075	TRIPLE STAGE UPRIGHT 3단 마스트
39-661	SEAT ASSEMBLY 시트 어셈블리	66-076	LIFT CHAIN 리프트 체인
39-669	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅	66-077	LIFT CYLINDER PIPING 리프트 실린더 파이핑

66-078	PRIMARY CYLINDER 프라이머리 실린더
66-082	HI-LO UPRIGHT 하이-로우 마스트
66-083	HI-LO SECONDARY CYLINDER 하이-로우 2차 실린더
66-123	TRIPLE STAGE UPRIGHT 3단 마스트
66-124	HI-LO UPRIGHT 하이-로우 마스트
66-157	LIFT CYLINDER ASSEMBLY 리프트 실린더 어셈블리
66-158	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-228	LIFT CYLINDER PIPING 리프트 실린더 파이핑
66-334	LIFT CHAIN 리프트 체인
66-335	LIFT CHAIN 리프트 체인
75-(12)012	SIDE BATTERY REMOVAL(SBR) 사이드 배터리 제거 (SBR)
75-(33)014	VARIABLE RELIEF VALVE INSTALLATION 가변 릴리프 밸브 조립그룹
75-(33)045	DEVICE HYDRAULIC PRESSURE GAUGE INSTALLATION 디바이스 유압 압력게이지 조립그룹
75-(38)200	AUXILIARY COUNTERWEIGHT 보조 카운터웨이트
75-(39)091	WIRE BASKET 와이어 바스켓
75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치

PEDAL ASSEMBLY
INCLUDES ITEMS
MARKED "P"

62.050




ACCELERATOR PEDAL & LINKAGE

02-487

02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.284	FASTENER, PEDAL TO BRACKET PIVOT PIN 패스너
02.285	STOP, ACCELERATOR PEDAL LINKAGE 스톱
02.317	ROLLER, ACCELERATOR PEDAL 롤러
02.329	FASTENER, ACCELERATOR PEDAL 패스너
02.465	FASTENER, ACCELERATOR CONTROL LINKAGE 패스너
03.419	WEAR PLATE, ACCELERATOR PEDAL ROLLER 웨어플레이트
03.671	ACTUATOR, ACCELERATOR CONTROL 액추에이터


13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너
13.572	BRACKET, ACCEL CONTROL ASSEMBLY MOUNTING 브라켓
13.573	FASTENER, ACCELERATOR CONTROL ASSY MOUNTING BRACKE 패스너
62.050	PEDAL ASSEMBLY, ACCELERATOR 페달
90.673	NUT, ACCELERATOR PEDAL BRKT MOUNTING FASTENER 너트



ACCELERATOR PEDAL & LINKAGE

02-488


02.285	STOP, ACCELERATOR PEDAL LINKAGE 스톱
02.317	ROLLER, ACCELERATOR PEDAL 롤러
02.465	FASTENER, ACCELERATOR CONTROL LINKAGE 패스너
03.671	ACTUATOR, ACCELERATOR CONTROL 액추에이터
13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너
13.572	BRACKET, ACCEL CONTROL ASSEMBLY MOUNTING 브라켓
13.573	FASTENER, ACCELERATOR CONTROL ASSY MOUNTING BRACKE 패스너



ACCELERATOR CONTROL AND PEDAL MOUNTING.


02.271	NUT, ACCELERATOR PUSH ROD LOCKING 너트
02.280	PEDAL, ACCELERATOR 페달
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.285	STOP, ACCELERATOR PEDAL LINKAGE 스톱
02.289	FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING 패스너
02.317	ROLLER, ACCELERATOR PEDAL 롤러
02.329	FASTENER, ACCELERATOR PEDAL 패스너
03.419	WEAR PLATE, ACCELERATOR PEDAL ROLLER 웨어플레이트
03.671	ACTUATOR, ACCELERATOR CONTROL 액추에이터

13.400	CONTROL ASSEMBLY, ACCELERATING 컨트롤
13.448	FASTENER, ACCELERATING CONTROL ASSEMBLY 패스너
13.572	BRACKET, ACCEL CONTROL ASSEMBLY MOUNTING 브라켓
13.573	FASTENER, ACCELERATOR CONTROL ASSY MOUNTING BRACKE 패스너
13.827	FASTENER, ACCELERATOR CONTROL ASSEMBLY 패스너
90.673	NUT, ACCELERATOR PEDAL BRKT MOUNTING FASTENER 너트
90.834	NUT, ACCELERATOR CONTROL ASSEMBLY FASTENER 너트
91.764	COTTER, ACCELERATOR PIN RETAINER 커터




- | | |
|--------|--|
| 13.206 | BULB, BACK-UP LAMP
전구 |
| 13.217 | FASTENER, COM STOP & TAIL LAMP ASSY MTG
패스너 |
| 13.218 | BULB, STOP & TAIL LAMP
전구 |
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 13.299 | GUARD, HEADLIGHT
가드 |
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |
| 13.675 | BULB, TURN LIGHT
전구 |

14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.535	SWITCH, WORK LIGHT 스위치
60.696	WIRING HARNESS, MAIN ACCESSORY 와이어하네스
60.697	WIRING HARNESS, FWD/REV INTERFACE 와이어하네스
60.797	GROMMET, REAR ACCESSORY WIRE 그로멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.964	RELAY, FOOT BRAKE 릴레이
67.217	CONVERTER, DC-DC FOR ACCESSORY 컨버터
67.226	BRACKET, DC-DC CONVERTER MOUNTING 브라켓
95.299	FASTENER, HEADLAMP GUARD 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.244	FASTENER, DC-DC CONVERTER MOUNTING BRACKET 패스너
97.245	FASTENER, ACCESSORY WIRE HARNESS CONNECTOR 패스너




13.681	FASTENER, WARNING DEVICE 패스너
42.001	WARNING DEVICE, AUDIBLE (AIR OPER) 경고장치
42.024	HARNESS, TRAVEL ALARM 하네스
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스



HEAD LIGHT BRACKET MOUNTING

13-135


- | | |
|--------|------------------------------------|
| 13.241 | BRACKET, HEAD LAMP
브라켓 |
| 13.243 | FASTENER, HEAD LAMP BRACKET
패스너 |




REAR VIEW MIRROR

13-140

- | | |
|--------|---|
| 39.182 | BRACKET, REAR VIEW MIRROR MOUNTING
브라켓 |
| 39.184 | FASTENER, REAR VIEW MIRROR
패스너 |
| 39.689 | MIRROR, REAR VIEW
미러 |




- | | |
|--------|---|
| 13.259 | RELAY, AUXILIARY VALVE SWITCH WIRING HARNESS
릴레이 |
| 15.339 | HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스 |
| 18.198 | CLIP, AUXILIARY VALVE SWITCH WIRING HARNESS
클립 |




- | | |
|--------|--|
| 13.206 | BULB, BACK-UP LAMP
전구 |
| 13.217 | FASTENER, COM STOP & TAIL LAMP ASSY MTG
패스너 |
| 13.218 | BULB, STOP & TAIL LAMP
전구 |
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 13.299 | GUARD, HEADLIGHT
가드 |
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |
| 13.675 | BULB, TURN LIGHT
전구 |

14.018	WIRE, HEADLIGHT 와이어
15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
18.187	TERMINAL, FUSE 터미널
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.535	SWITCH, WORK LIGHT 스위치
60.696	WIRING HARNESS, MAIN ACCESSORY 와이어하네스
60.697	WIRING HARNESS, FWD/REV INTERFACE 와이어하네스
60.797	GROMMET, REAR ACCESSORY WIRE 그로멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.964	RELAY, FOOT BRAKE 릴레이
67.217	CONVERTER, DC-DC FOR ACCESSORY 컨버터
67.226	BRACKET, DC-DC CONVERTER MOUNTING 브라켓
93.661	FASTENER, TERMINAL BLOCK 패스너
95.299	FASTENER, HEADLAMP GUARD 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.244	FASTENER, DC-DC CONVERTER MOUNTING BRACKET 패스너




- | | |
|--------|--|
| 13.206 | BULB, BACK-UP LAMP
전구 |
| 13.217 | FASTENER, COM STOP & TAIL LAMP ASSY MTG
패스너 |
| 13.218 | BULB, STOP & TAIL LAMP
전구 |
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |
| 13.675 | BULB, TURN LIGHT
전구 |
| 14.018 | WIRE, HEADLIGHT
와이어 |


15.206	GROMMET, HEADLAMP CONDUCTOR 그로멧
15.437	HARNESS, HEADLAMP WIRING 하네스
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
18.100	CLIP, HEAD LIGHT WIRE 클립
18.187	TERMINAL, FUSE 터미널
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.535	SWITCH, WORK LIGHT 스위치
60.696	WIRING HARNESS, MAIN ACCESSORY 와이어하네스
60.697	WIRING HARNESS, FWD/REV INTERFACE 와이어하네스
60.797	GROMMET, REAR ACCESSORY WIRE 그롱멧
60.899	WIRING HARNESS, REAR ACCESSORY 와이어하네스
60.964	RELAY, FOOT BRAKE 릴레이
67.217	CONVERTER, DC-DC FOR ACCESSORY 컨버터
67.226	BRACKET, DC-DC CONVERTER MOUNTING 브라켓
93.661	FASTENER, TERMINAL BLOCK 패스너
97.147	FASTENER, DC-DC CONVERTER FOR ACCESSORY 패스너
97.244	FASTENER, DC-DC CONVERTER MOUNTING BRACKET 패스너



13.332	ASSEMBLY, WARNING LIGHT 경고등
13.333	BULB, WARNING LIGHT 전구
60.821	GLOBE, STROBE LIGHT 글로브
60.822	BASE, STROBE LIGHT 베이스



39.689 MIRROR, REAR VIEW
미러



HEAD LAMP INSTALLATION


13-190

13.270	HEADLAMP, ADJUSTABLE 헤드램프
13.284	BRACKET, ADJUSTABLE HEADLAMP 브라켓
13.285	FASTENER, ADJUSTABLE HEADLAMP BRACKET 패스너
13.299	GUARD, HEADLIGHT 가드
14.011	WIRE, HEADLIGHT 와이어
14.592	GROMMET, SPOTLIGHT WIRE 그로멧
14.766	FASTENER, HEADLAMP CONDUCTOR SHIELD FITTING 패스너
15.436	HARNESS, RH HEADLAMP WIRING 하네스
60.280	GROMMET, HEADLAMP CONDUCTOR 그로멧


95.299

FASTENER, HEADLAMP GUARD
패스너






13.324	HARNES, REAR WORK LAMP 하네스
60.795	LIGHT, REAR WORK 라이트
60.796	SWITCH, REAR WORK LIGHT 스위치
60.797	GROMMET, REAR ACCESSORY WIRE 그롬멧
60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.924	FASTENER, REAR WORK LAMP MOUNTING 패스너




STEER ANGLE SENSOR MOUNTING

13-299

60.725	POTENTIOMETER, STEERING INTERLOCK 포텐션메터
60.727	BRACKET, STEERING POTENTIOMETER 브라켓
60.734	SCREW, P-CLAMP FASTENER 스크류
60.735	WASHER, P-CLAMP FASTENER 와셔
60.736	P-CLAMP 클램프
60.979	BEARING, STEERING INTERLOCK POTENTIOMETER 베어링
96.596	FASTENER, STEERING INTERLOCK POTENTIOMETER 패스너
96.597	FASTENER, STEERING INTERLOCK POTENTIOMETER MOUNTIN 패스너
96.598	FASTENER, POTENTIOMETER STEERING INTERLOCK BRACKET 패스너




13.681	FASTENER, WARNING DEVICE 패스너
42.001	WARNING DEVICE, AUDIBLE (AIR OPER) 경고장치
42.024	HARNESS, TRAVEL ALARM 하네스



13.150	SWITCH, TILT VALVE PUMP OPERATING 스위치
13.152	FASTENER, TILT VALVE PUMP OPERATING SWITCH 패스너
15.793	CONTROLLER, SIGNAL FILTER 컨트롤러
18.020	CLIP, HARNESS 클립
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
67.189	CONVERTER, ACCESSORY CONTROL 컨버터
67.201	BRACKET, CONVERTER 브라켓
70.038	FASTENER, ELECTRICAL COMPONENTS MOUNTING BRACKET 패스너

91.090	BOLT, CONT PANEL CONDUCTOR 볼트
92.559	WASHER, TILT VALVE PUMP OPERATING SWITCH FASTENER 와셔
95.733	NUT, CONTROL PANEL CONVERTER FASTENER 너트







FORK LEVELING SYSTEM

14-053

- | | |
|--------|---|
| 13.621 | SWITCH, LIFT HEIGHT LIMIT
스위치 |
| 13.623 | FASTENER, HEIGHT LIMIT SWITCH
패스너 |
| 13.647 | CABLE GRIP, HEIGHT LIMIT SWITCH SEQUENCE RELAY
케이블그립 |
| 15.710 | RELAY, ELECTRICAL
릴레이 |
| 17.548 | WIRING HARNESS, CONTROL BOARD
와이어하네스 |





- | | |
|--------|-------------------------------------|
| 14.114 | HARNESS, MACHINE WIRING
하네스 |
| 14.352 | FUSE, CONTROL CIRCUIT
퓨즈 |
| 15.575 | FUSE HOLDER, WIRING HARNESS
퓨즈홀더 |
| 18.010 | CLIP, HARNESS
클립 |
| 18.011 | FASTENER, HARNESS CLIP
패스너 |
| 18.012 | CLIP, WIRE HARNESS
클립 |
| 18.013 | FASTENER, HARNESS CLIP
패스너 |
| 18.014 | CLIP, HARNESS
클립 |
| 18.015 | FASTENER, HARNESS CLIP
패스너 |



13.000	PANEL, INSTRUMENT CLUSTER 판넬
13.003	HORN 혼
13.004	FASTENER, HORN MOUNTING BRACKET 패스너
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL 패스너
14.005	HARNESS, DASH END WIRING 하네스
15.673	RELAY, SEAT BRAKE 릴레이
15.710	RELAY, ELECTRICAL 릴레이
15.716	BRACKET, RELAY MOUNTING 브라켓
37.967	PLUG, INSTRUMENT PANEL 플러그


39.417	GROUND STRAP, ELECTRIC TRUCK 접지케이블
39.418	FASTENER, ELECTRIC TRUCK GROUND STRAP 패스너
49.101	SENSOR, LEVER POSITION 센서
49.204	BRACKET, LEVER POSITION SENSOR 브라켓
49.205	BRACKET, LEVER POSITION SENSOR SUPPORT 브라켓
67.218	CONVERTER, DC-DC FOR INSTRUMENT PANEL 컨버터
95.989	FASTENER, RELAY MOUNTING 패스너
97.142	FASTENER, LEVER POSITION SENSOR 패스너
97.143	FASTENER, LEVER POSITION SENSOR BRACKET 패스너
97.148	FASTENER, DC-DC CONVERTER FOR INSTRUMENT PANEL 패스너






14.039	RECEPTACLE & LEAD ASSEMBLY, BATTERY 리셉터클& 리드
14.040	RECEPTACLE, BATTERY 리셉터클
15.384	BRACKET, POWER WIRING SHIELD 브라켓
15.623	CABLE, CONTACTOR R+ 케이블
15.625	CABLE, CONTACTOR L+ 케이블
15.633	CABLE, CONTACTOR B-T TO CONTACTOR B-P 케이블
15.770	CABLE, DRIVE MOTOR (TMUR TO TCUR) 케이블
15.771	CABLE, DRIVE MOTOR (TMWR TO TCVR) 케이블
15.772	CABLE, DRIVE MOTOR (TMVR TO TCWR) 케이블


15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블
15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
15.820	BOOT, CABLE 부트
94.069	FASTENER, BATTERY RECEPTACLE 패스너
94.723	FASTENER, POWER WIRING SHIELD BRACKET 패스너






- | | |
|--------|---|
| 14.039 | RECEPTACLE & LEAD ASSEMBLY, BATTERY
리셉터클& 리드 |
| 14.040 | RECEPTACLE, BATTERY
리셉터클 |
| 14.370 | WIRE, CONTACTOR TO TERMINAL BLOCK
와이어 |
| 15.384 | BRACKET, POWER WIRING SHIELD
브라켓 |
| 15.623 | CABLE, CONTACTOR R+
케이블 |
| 15.625 | CABLE, CONTACTOR L+
케이블 |
| 15.633 | CABLE, CONTACTOR B-T TO CONTACTOR B-P
케이블 |
| 15.770 | CABLE, DRIVE MOTOR (TMUR TO TCUR)
케이블 |
| 15.771 | CABLE, DRIVE MOTOR (TMWR TO TCVR)
케이블 |


15.772	CABLE, DRIVE MOTOR (TMVR TO TCWR) 케이블
15.773	CABLE, DRIVE MOTOR (TMUL TO TCUL) 케이블
15.774	CABLE, DRIVE MOTOR (TMVL TO TCVL) 케이블
15.775	CABLE, DRIVE MOTOR (TMWL TO TCWL) 케이블
15.776	CABLE, PUMP MOTOR (PMU TO PCU) 케이블
15.777	CABLE, PUMP MOTOR (PMV TO PCV) 케이블
15.778	CABLE, PUMP MOTOR (PMW TO PCW) 케이블
15.820	BOOT, CABLE 부트
94.069	FASTENER, BATTERY RECEPTACLE 패스너
94.723	FASTENER, POWER WIRING SHIELD BRACKET 패스너





14.744	BRACKET, FUSE HOLDER MOUNTING 브라켓
14.745	FASTENER, FUSE HOLDER MOUNTING BRACKET 패스너
95.009	FASTENER, FUSE BOX MOUNTING 패스너
95.303	FASTENER, DC-DC CONVERTER GUARD 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




ELECTRICAL COMPONENTS(EE)

15-064

17.490	GROMMET, CONTACTOR PANEL BOX LEADS 그로멧
17.539	GROMMET, CONTACTOR BOX 그로멧
19.636	FASTENER, CONTACTOR CONTROL TERMINAL 패스너
19.728	CONDUCTOR, FUSE CONNECTING 컨덕터
40.326	DECAL, EE MARKING 데칼
47.087	CONNECTOR, ELECTRIC TRUCK GROUND STRAP 커넥터
47.310	CHAIN, GROUND STRAP 체인
47.311	CHAIN, GROUND STRAP 체인
60.936	BRACKET, CONTACTOR COVERING BODY 브라켓


60.937	BRACKET, CONTACTOR COVERING 브라켓
60.938	TERMINAL, CONTACTOR CONNECTING 터미날
60.939	GROMMET, CONTACTOR CONNECTING CONDUCTOR 그로멧
65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.345	BRACKET, CONTACTOR MOUNTING 브라켓
67.064	CONDUCTOR, LINE CONTACTOR 컨덕터
67.118	BRACKET, LINE CONTACTOR MOUNTING 브라켓
92.112	FASTENER, CONTACTOR BOX 패스너
93.133	FASTENER, CONTACTOR PANEL CONTACTOR MOUNTING BRACK 패스너
93.590	FASTENER, CONDUCTOR TERMINAL 패스너
96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너
97.976	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너





- | | |
|--------|---------------------------------------|
| 16.524 | FASTENER, PUMP MOTOR MOUNTING
패스너 |
| 16.704 | DAMPENER, PUMP MOTOR VIBRATION
댐프너 |
| 16.705 | BRACKET, PUMP MOTOR
브라켓 |
| 16.706 | FASTENER, PUMP MOTOR BRACKET
패스너 |


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TRACTION & PUMP MOTORS


16-255

- | | |
|--------|-----------------------------|
| 16.000 | MOTOR ASSEMBLY, DRIVE
모터 |
| 16.500 | MOTOR ASSEMBLY, PUMP
모터 |



16.000	MOTOR ASSEMBLY, DRIVE 모터
16.002	BEARING, DRIVE MOTOR COMMUTATOR END 베어링
16.013	SPACER, DRIVE MOTOR DRIVE END 스페이서
16.029	SEAL, DRIVE MOTOR ARMATURE SHAFT DRIVE END 씰
16.068	FASTENER, DRIVE MOTOR END FRAME 패스너
16.090	COVER, DRIVE MOTOR COMMUTATOR END 커버
16.106	TERMINAL BLOCK, DRIVE MOTOR 터미널블록
16.114	WASHER, DRIVE MOTOR DRIVE END THRUST 와셔
16.116	FASTENER, DRIVE MOTOR TERMINAL 패스너


16.148	RING, DRIVE MOTOR ROTOR BEARING 링
16.149	ROTOR, DRIVE MOTOR 로터
16.162	SEAL, DRIVE MOTOR DRIVE END 씰
16.165	BEARING, DRIVE MOTOR DRIVE END 베어링
16.185	STATOR ASSY, DRIVE MOTOR 스테이터
16.186	BASE, DRIVE MOTOR TERMINAL 베이스
16.187	SENSOR KIT, DRIVE MOTOR ROTOR 센서키트
16.189	COVER, DRIVE MOTOR DRIVE END 커버
16.191	SENSOR KIT, DRIVE MOTOR TEMPERATURE 센서키트
16.192	RING, DRIVE MOTOR ARMATURE 링
16.194	PLATE, DRIVE MOTOR ROTOR SENSOR TARGET 플레이트
16.283	COVER, DRIVE MOTOR ROTOR SENSOR PLATE 커버
16.284	RING, DRIVE MOTOR ROTOR SENSOR PLATE 링
93.232	WASHER, DRIVE MOTOR TERMINAL BLOCK FASTENER 와셔
93.233	FASTENER, DRIVE MOTOR TERMINAL 패스너
93.731	NUT, DRIVE MOTOR FASTENER 너트
97.068	FASTENER, DRIVE MOTOR SPEED SENSOR 패스너
97.144	FASTENER, DRIVE MOTOR ROTOR SENSOR PLATE COVER 패스너



16.151	FITTING KEY, PUMP MOTOR ROTOR 피팅키
16.153	FAN, PUMP MOTOR 팬
16.154	COVER, PUMP MOTOR ROTOR END 커버
16.155	WASHER, PUMP MOTOR ROTOR BEARING 와셔
16.157	ROTOR, PUMP MOTOR 로터
16.178	BASE, PUMP MOTOR TERMINAL 베이스
16.180	SENSOR KIT, PUMP MOTOR ROTOR 센서
16.181	PLATE, PUMP MOTOR ROTOR SENSOR TARGET 플레이트
16.182	COVER, PUMP MOTOR DRIVE END 커버

16.183	BEARING, PUMP MOTOR ROTOR END 베어링
16.184	SENSOR KIT, PUMP MOTOR TEMPERATURE 센서키트
16.285	SEAL, PUMP MOTOR ROTOR BEARING 씰
16.286	RING, PUMP MOTOR ROTOR 링
16.500	MOTOR ASSEMBLY, PUMP 모터
16.502	BEARING, PUMP MOTOR DRIVE END 베어링
16.538	COVER ASSEMBLY, PUMP MOTOR FAN HOLE 커버
16.571	SEAL, HYDRAULIC PUMP MOTOR ARMATURE SHAFT DRIVE EN 씰
16.573	TERMINAL BLOCK, HYDRAULIC PUMP MOTOR 터미널블록
16.593	STATOR ASSY, HYDRAULIC-PUMP MOTOR 스테이터
93.258	FASTENER, PUMP MOTOR DRIVE END FRAME COVER 패스너
93.265	FASTENER, HYDRAULIC PUMP MOTOR TERMINAL 패스너
95.045	WASHER, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 와셔
95.501	FASTENER, PUMP MOTOR TERMINAL BLOCK CONNECTOR 패스너
95.873	NUT, HYDRAULIC PUMP MOTOR TERMINAL CLAMP FASTENER 너트
97.069	FASTENER, PUMP MOTOR SPEED SENSOR 패스너
97.145	NUT, HYDRAULIC PUMP MOTOR TERMINAL FASTENER 너트
97.146	FASTENER, PUMP MOTOR FAN COVER 패스너

ASSEMBLY
COMPLETE — 65.130




LINE CONTACTOR ASSEMBLY

17-111

65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.930	ASSEMBLED COIL & MAGNET FRAME, LINE CONTACTOR 코일& 마그넷
65.931	TOP COVER, LINE CONTACTOR 탑커버
65.932	FASTENER, LINE CONTACTOR 패스너
65.933	CONTACT KIT, LINE CONTACTOR 컨택트키트
65.942	CONTACT SET, LINE CONTACTOR 컨택트세트

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



CONTROLLER MOUNTING


19-025

18.184	BRACKET, CONTROLLER FAN MOUNTING 브라켓
19.240	FASTENER, CONTROL PANEL MOUNTING 패스너
65.130	CONTACTOR ASSEMBLY, LINE 컨택터
65.492	FAN, ELECTRICAL COOLING 팬
65.896	CONDUCTOR, CONTROL PANEL 컨덕터
67.064	CONDUCTOR, LINE CONTACTOR 컨덕터
67.118	BRACKET, LINE CONTACTOR MOUNTING 브라켓
67.188	COVER, FAN 커버
67.208	FAN, COOLING 팬

67.211	FUSE, TRACTION CONTROLLER 퓨즈
67.213	FUSE, PUMP CONTROLLER 퓨즈
67.300	CONTROLLER, TRACTION 컨트롤러
67.400	CONTROLLER, PUMP 컨트롤러
94.296	FASTENER, ELECTRICAL COOLING FAN 패스너
96.606	FASTENER, LINE CONTACTOR MOUNTING BRACKET 패스너
96.976	FASTENER, CONTACTOR MOUNTING 패스너
97.055	FASTENER, FAN BRACKET MOUNTING 패스너



■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE AXLE & BRAKE MOUNTING

20-186


16.001	FASTENER, DRIVE MOTOR 패스너
16.071	SEAL, DRIVE MOTOR TO AXLE 씰
20.008	SHIELD, DRIVE HOUSING SPINDLE DUST 실드
20.120	SPACER, DRIVE AXLE MOUNTING 스페이서
20.321	LOCATOR, DRIVE AXLE MOUNTING 로케이터
20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.377	FASTENER, DRIVE AXLE TO FRAME 패스너
22.224	BRAKE ASSEMBLY, MOTOR 브레이크
22.627	TEE, BRAKE LINE 티

22.948	FITTING, TEE BRAKE LINE 피팅
23.207	LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
90.998	FASTENER, DRIVE MOTOR BRAKE 패스너







20.370	AXLE ASSEMBLY, DRIVE 드라이브액슬
20.373	GASKET, DIFFERENTIAL HOUSING INSPECTION COVER 가스켓
20.374	FASTENER, DIFF HOUSING INSPECTION COVER 패스너
20.375	COVER, DIFFERENTIAL HOUSING INSPECTION 커버
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
20.546	FASTENER, DRIVE AXLE END 패스너
23.256	DISK OR DRUM, DRIVE WHEEL BRAKE 디스크



20.201	SHIM, DIFF BRG CARRIER TO AXLE HOUSING 심
20.212	SEAL, DIFFERENTIAL PINION OIL 씰
20.221	FASTENER, DIFF PINION OIL SEAL RET & BRG CAGE 패스너
20.230	BEARING ASSEMBLY, DIFF PINION OUTER 베어링
20.236	BEARING, CARRIER PINION 베어링
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 심
20.239	FASTENER, DIFFERENTIAL PINION BEARING CARRIER 패스너
20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링


20.261	RETAINER, DIFF PINION OUTER BEARING 리테이너
20.316	CUP, DIFFERENTIAL PINION BEARING (OUTER) 컵
20.387	HOUSING, DIFFERENTIAL & AXLE 하우징
20.424	PLUG, DIFFERENTIAL & AXLE HOUSING FILLER 플러그
20.427	PLUG, DIFFERENTIAL & AXLE HOUSING DRAIN 플러그
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.542	BEARING, DRIVE AXLE SHAFT 베어링
20.544	SEAL, DRIVE AXLE SHAFT 씰
20.573	CUP, DRIVE AXLE SHAFT BEARING (OUTBOARD) 컵
20.586	SHAFT, DRIVE AXLE 샤프트
91.169	LOCKWASHER, PINION BRG CAGE FASTENER 로크와셔
92.493	LOCKWASHER, DIFFERENTIAL PINION BEARING CARRIER FA 로크와셔






20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.500	AXLE END ASSEMBLY, DRIVE RH 액슬엔드
20.519	FASTENER, DRIVE AXLE SHAFT GEAR RETAINER 패스너
20.520	RETAINER, DRIVE AXLE SHAFT GEAR 리테이너
20.521	SHIM, DRIVE AXLE SHAFT GEAR 심
20.522	GEAR, DRIVE AXLE SHAFT 기어
20.524	BEARING, DRIVE AXLE INTERMEDIATE GEAR SHAFT 베어링
20.553	BEARING, DRIVE AXLE SHAFT (INBOARD) 베어링


20.579	CUP, DRIVE AXLE SHAFT BEARING (INBOARD) 컵
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.636	SHAFT, DRIVE AXLE RING GEAR 샤프트
20.638	BEARING, RING GEAR SHAFT OUTBOARD 베어링
20.639	RETAINING RING, RING GEAR SHAFT OUTBOARD BEARING 리테이닝 링
20.640	SEAL, RING GEAR SHAFT BEARING HOUSING 씰
20.641	SHIM, RING GEAR SHAFT BEARING HOUSING 심
20.642	HOUSING, RING GEAR SHAFT BEARING 하우징
20.643	SEAL, RING GEAR SHAFT 씰
20.647	LOCATOR, DRIVE AXLE SHAFT INBOARD BEARING 로케이터
20.659	SHIM, DRIVE AXLE RING GEAR SHAFT BEARING CAP 심
20.832	CAP, DRIVE AXLE RING GEAR BEARING 캡
20.837	BEARING, DRIVE AXLE RING GEAR SHAFT 베어링
91.051	BOLT, DRIVE AXLE RING GEAR BEARING CAP 볼트
91.052	LOCKWASHER, DRIVE AXLE RING GEAR BEARING CAP FAST 로크와셔
93.270	FASTENER, RING GEAR SHAFT BEARING HOUSING 패스너
93.272	LOCKWASHER, RING GEAR SHAFT BEARING HOUSING FASTEN 로크와셔



20.201	SHIM, DIFF BRG CARRIER TO AXLE HOUSING 심
20.212	SEAL, DIFFERENTIAL PINION OIL 씰
20.221	FASTENER, DIFF PINION OIL SEAL RET & BRG CAGE 패스너
20.230	BEARING ASSEMBLY, DIFF PINION OUTER 베어링
20.236	BEARING, CARRIER PINION 베어링
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 심
20.239	FASTENER, DIFFERENTIAL PINION BEARING CARRIER 패스너
20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링

20.261	RETAINER, DIFF PINION OUTER BEARING 리테이너
20.316	CUP, DIFFERENTIAL PINION BEARING (OUTER) 컵
20.388	HOUSING, DRIVE AXLE (LH) 하우징
20.424	PLUG, DIFFERENTIAL & AXLE HOUSING FILLER 플러그
20.427	PLUG, DIFFERENTIAL & AXLE HOUSING DRAIN 플러그
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
20.542	BEARING, DRIVE AXLE SHAFT 베어링
20.544	SEAL, DRIVE AXLE SHAFT 씰
20.573	CUP, DRIVE AXLE SHAFT BEARING (OUTBOARD) 컵
20.586	SHAFT, DRIVE AXLE 샤프트
91.169	LOCKWASHER, PINION BRG CAGE FASTENER 로크와셔
92.493	LOCKWASHER, DIFFERENTIAL PINION BEARING CARRIER FA 로크와셔






20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.501	AXLE END ASSEMBLY, DRIVE LH 액슬엔드
20.519	FASTENER, DRIVE AXLE SHAFT GEAR RETAINER 패스너
20.520	RETAINER, DRIVE AXLE SHAFT GEAR 리테이너
20.521	SHIM, DRIVE AXLE SHAFT GEAR 심
20.522	GEAR, DRIVE AXLE SHAFT 기어
20.524	BEARING, DRIVE AXLE INTERMEDIATE GEAR SHAFT 베어링
20.553	BEARING, DRIVE AXLE SHAFT (INBOARD) 베어링

20.579	CUP, DRIVE AXLE SHAFT BEARING (INBOARD) 컵
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.636	SHAFT, DRIVE AXLE RING GEAR 샤프트
20.638	BEARING, RING GEAR SHAFT OUTBOARD 베어링
20.639	RETAINING RING, RING GEAR SHAFT OUTBOARD BEARING 리테이닝 링
20.640	SEAL, RING GEAR SHAFT BEARING HOUSING 씰
20.641	SHIM, RING GEAR SHAFT BEARING HOUSING 심
20.642	HOUSING, RING GEAR SHAFT BEARING 하우징
20.643	SEAL, RING GEAR SHAFT 씰
20.647	LOCATOR, DRIVE AXLE SHAFT INBOARD BEARING 로케이터
20.659	SHIM, DRIVE AXLE RING GEAR SHAFT BEARING CAP 심
20.832	CAP, DRIVE AXLE RING GEAR BEARING 캡
20.837	BEARING, DRIVE AXLE RING GEAR SHAFT 베어링
91.051	BOLT, DRIVE AXLE RING GEAR BEARING CAP 볼트
91.052	LOCKWASHER, DRIVE AXLE RING GEAR BEARING CAP FAST 로크와셔
93.270	FASTENER, RING GEAR SHAFT BEARING HOUSING 패스너
93.272	LOCKWASHER, RING GEAR SHAFT BEARING HOUSING FASTEN 로크와셔

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




DRIVE WHEEL & TIRE MOUNTING

22-013

- | | |
|--------|--|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠 & 타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STEER WHEEL & TIRE MOUNTING

22-014

- | | |
|--------|---|
| 23.026 | FASTENER, STEER WHEEL
패스너 |
| 23.031 | STEER WHEEL AND TIRE ASSEMBLY
스티어휠 & 타이어 |

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE (SOLID TYPE)

22-024

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어

ASSEMBLY
COMPLETE — 23.031




STEER WHEEL & TIRE (SOLID TYPE)

22-025

22.990	TIRE ASSEMBLY, STEER 타이어
23.000	RIM ASSEMBLY, STEER WHEEL 림
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠 & 타이어

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE (CUSHION)

22-035

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 림
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어


ASSEMBLY
COMPLETE — 23.031



STEER WHEEL & TIRE (CUSHION)


22-036

22.990	TIRE ASSEMBLY, STEER 타이어
23.000	RIM ASSEMBLY, STEER WHEEL 립
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠 & 타이어



03.903	BRACKET, ACCELERATOR PEDAL ROLLER 브라켓	22.768	PIVOT, UNITROL PEDAL 피봇
03.904	FASTENER, ACCELERATOR PEDAL ROLLER BRACKET 패스너	22.769	BEARING, UNITROL PEDAL BRACKET 베어링
18.002	CLIP, WIRING HARNESS 클립	22.770	BRACKET, UNITROL PEDAL 브라켓
18.028	CLIP, HARNESS 클립	22.771	SPRING, UNITROL PEDAL RETURN 스프링
22.754	PAD, UNITROL PEDAL 패드	22.772	BRACKET, UNITROL PEDAL MOUNTING 브라켓
22.755	SHAFT, UNITROL PEDAL PAD PIVOT 샤프트	22.773	WASHER, UNITROL PEDAL PIVOT FASTENER 와셔
22.756	FASTENER, UNITROL PEDAL PAD PIVOT 패스너	22.774	FASTENER, UNITROL PEDAL PIVOT 패스너
22.757	PLATE, UNITROL PEDAL PAD STOP 플레이트	22.880	RETAINER, UNITROL SWITCH WIRE 리테이너
22.758	SEAL, UNITROL PEDAL PAD STOP PLATE 씰	22.881	WASHER, UNITROL PEDAL PAD STOP PLATE FASTENER 와셔
22.759	FASTENER, UNITROL PEDAL PAD STOP PLATE 패스너	22.882	FASTENER, UNITROL PEDAL SWITCH 패스너
22.760	HARNESS, UNITROL PEDAL SWITCH WIRING 하네스	22.883	CONNECTOR, UNITROL PEDAL SWITCH WIRING HARNESS 커넥터
22.761	NUT, UNITROL PEDAL PAD TENSION SPRING RETAINER 너트	22.884	LOCK, UNITROL PEDAL SWITCH WIRING HARNESS CONNEC 로크
22.763	RETAINER, UNITROL PEDAL PAD TENSION SPRING 리테이너	22.885	GROMMET, UNITROL PEDAL WIRING HARNESS 그로멧
22.764	GUIDE, UNITROL PEDAL PAD TENSION SPRING 가이드	22.886	RETAINER, UNITROL PEDAL RETURN SPRING 리테이너
22.765	SPRING, UNITROL PEDAL PAD TENSION 스프링	22.888	FASTENER, UNITROL PEDAL MOUNTING BRACKET 패스너

22.889	BUMPER, UNITROL PEDAL PAD 범퍼
22.916	FASTENER, UNITROL SWITCH WIRE RETAINER 패스너
37.975	FASTENER, SEAT WIRING HARNESS CLAMP 패스너
37.976	CLAMP, SEAT WIRING HARNESS 클램프
37.977	FASTENER, SEAT WIRING HARNESS CLAMP 패스너
37.979	CLAMP, SEAT WIRING HARNESS 클램프
40.211	DECAL, WARNING UNITROL 데칼
60.596	HARNESS, UNITROL ASEMBLY TO TRUCK HARNESS 하네스
60.718	HARNESS, UNITROL SEAT SWITCH 하네스




PARKING BRAKE & LINKAGE

22-039

15.484	HARNES, SEAT SWITCH INSTALLATION 하네스	23.973	CLAMP, P/B RELEASE CYLINDER VENT LINE 클램프
20.374	FASTENER, DIFF HOUSING INSPECTION COVER 패스너	23.977	CLAMP P/B REL VALVE SUMP RETURN HOSE 클램프
22.028	ROD END, PARKING BRAKE RELEASE CYLINDER 로드 엔드	23.981	FITTING, P/B RELEASE VALVE INLET PORT 피팅
22.030	CYLINDER ASSEMBLY, PARKING BRAKE RELEASE 실린더	23.983	FITTING, P/B RELEASE VALVE PRESSURE LINE 피팅
22.231	LINE, PARKING BRAKE RELEASE VALVE PRESSURE 라인	23.985	LINE, P/B RELEASE VALVE PRESSURE 라인
22.346	LEVER, PARKING BRAKE CAM (LH) 레버	28.947	LINE, AUXILIARY VALVE SUMP RETURN 라인
22.379	COVER, PARKING BRAKE ACTUATOR 커버	31.349	FITTING, RETURN LINE SUMP 피팅
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인	33.086	VALVE, SOLENOID 밸브
23.901	FASTENER, SEAT BRAKE ACTUATING CYLINDER 패스너	33.522	FITTING, SOLENOID VALVE OPTIONAL OUTLET 피팅
23.954	SPRING, P/B RELEASE VALVE SPOOL RETURN 스프링	44.304	HOUSING, SOLENOID VALVE 하우징
23.958	SPRING, P/B RELEASE CYLINDER RETURN 스프링	90.998	FASTENER, DRIVE MOTOR BRAKE 패스너
23.964	FASTENER, P/B RELEASE VALVE ACTUATOR 패스너	91.796	NUT, PARKING BRAKE RELEASE CYLINDER ROD END 너트
23.965	BRACKET, PARKING BRAKE RELEASE CYL MTG 브라켓	91.797	WASHER, PARKING BRAKE RELEASE CYLINDER ROD END F 와셔
23.969	FITTING, P/B RELEASE CYLINDER VENT LINE 피팅	91.798	NUT, PARKING BRAKE RELEASE CYLINDER 너트
23.972	LINE, PARKING BRAKE RELEASE CYLINDER VENT 라인		

ASSEMBLY
COMPLETE — 23.030




DRIVE WHEEL & TIRE

22-041

22.989	TIRE ASSEMBLY, DRIVE 타이어
23.009	RIM ASSEMBLY, DRIVE WHEEL 립
23.016	TIRE, DRIVE WHEEL 타이어
23.018	TUBE, DRIVE WHEEL 튜브
23.019	FLAP, DRIVE WHEEL TUBE 플랩
23.029	FASTENER, DRIVE WHEEL ASSEMBLY 패스너
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠& 타이어

ASSEMBLY
COMPLETE — 23.031



STEER WHEEL & TIRE


22-042

22.990	TIRE ASSEMBLY, STEER 타이어
23.000	RIM ASSEMBLY, STEER WHEEL 립
23.006	TIRE, STEER WHEEL 타이어
23.007	TUBE, STEER WHEEL 튜브
23.008	FLAP, STEER WHEEL 플랩
23.031	STEER WHEEL AND TIRE ASSEMBLY 스티어휠& 타이어
23.036	FASTENER, STEER WHEEL ASSEMBLY 패스너

ASSEMBLY
COMPLETE — 22.224

BRAKE LINING SEAL KIT
INCLUDES ITEMS
MARKED "K" — 23.836

NOTE:
NON SERVICEABLE
ITEMS MARKED "N"





BRAKE ASSEMBLY

22-058

- | | |
|--------|--|
| 22.224 | BRAKE ASSEMBLY, MOTOR
브레이크 |
| 22.346 | LEVER, PARKING BRAKE CAM (LH)
레버 |
| 22.347 | PIVOT, PARKING BRAKE SHOE
피봇 |
| 22.351 | CAM, PARKING BRAKE OPERATING (RH INBOARD)
캠 |
| 22.481 | SPACER, WHEEL BRAKE ASSEMBLY
스페이서 |
| 22.811 | BUSHING, BRAKE ASSEMBLY
부싱 |
| 22.812 | PIN, PARKING BRAKE ACTUATING PIN
핀 |
| 22.813 | SLEEVE, BRAKE
슬리브 |
| 22.814 | BRACKET, BRAKE MOUNTING RH
브라켓 |


22.815	BRACKET, BRAKE MOUNTING LH 브라켓
22.816	NUT, PARKING BRAKE PIN FASTENER 너트
22.817	FASTENER, BRAKE PIVOT RETAINER 패스너
23.222	SCREW, BRAKE CYLINDER BLEEDER (LH) 스크류
23.246	FASTENER, BRAKE ASSEMBLY 패스너
23.247	SHOE SET, BRAKE LINING 슈
23.366	PIN, PARKING BRAKE LEVER PIVOT 핀
23.564	PISTON, WHEEL BRAKE CYLINDER 피스톤
23.605	FASTENER, BRAKE SHOE LINING 패스너
23.735	SHOE & LINING SET, BRAKE 슈& 라이닝
23.836	KIT, BRAKE LINING SEAL 키트
92.463	WASHER, BRAKE CAM FOLLOWER FASTENER 와셔







- 22.224 BRAKE ASSEMBLY, MOTOR
브레이크
- 22.346 LEVER, PARKING BRAKE CAM (LH)
레버
- 22.347 PIVOT, PARKING BRAKE SHOE
피봇
- 22.351 CAM, PARKING BRAKE OPERATING (RH INBOARD)
캠
- 22.481 SPACER, WHEEL BRAKE ASSEMBLY
스페이서
- 22.811 BUSHING, BRAKE ASSEMBLY
부싱
- 22.812 PIN, PARKING BRAKE ACTUATING PIN
핀
- 22.813 SLEEVE, BRAKE
슬리브
- 22.814 BRACKET, BRAKE MOUNTING RH
브라켓

22.815	BRACKET, BRAKE MOUNTING LH 브라켓
22.816	NUT, PARKING BRAKE PIN FASTENER 너트
22.817	FASTENER, BRAKE PIVOT RETAINER 패스너
23.222	SCREW, BRAKE CYLINDER BLEEDER (LH) 스크류
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.246	FASTENER, BRAKE ASSEMBLY 패스너
23.366	PIN, PARKING BRAKE LEVER PIVOT 핀
23.564	PISTON, WHEEL BRAKE CYLINDER 피스톤
23.828	KIT, BRAKE LINING 키트
23.836	KIT, BRAKE LINING SEAL 키트
92.463	WASHER, BRAKE CAM FOLLOWER FASTENER 와셔






- | | |
|--------|---|
| 23.150 | CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE
실린더 |
| 23.160 | ROD, PUSH
로드 |
| 23.161 | BOOT, MASTER CYLINDER
부트 |



13.142	SWITCH, BRAKE INTERLOCK 스위치	23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
13.145	FASTENER, BRAKE INTERLOCK SWITCH 패스너	23.156	FASTENER, CYLINDER & TANK ATTACHING 패스너
22.338	CLAMP, BRAKE FLUID RESERVOIR 클램프	23.173	FITTING, BRAKE MASTER CYLINDER OUTLET 피팅
22.530	BRACKET, BRAKE FLUID RESERVOIR 브라켓	23.174	GASKET, BRAKE MASTER CYLINDER OUTLET FITTING 가스켓
22.604	CLAMP, BRAKE FLUID RESERVOIR LINE 클램프	23.175	BOLT, BRAKE MASTER CYLINDER OUTLET FITTING 볼트
22.929	LINK, BRAKE PEDAL 링크	23.176	GASKET, BRAKE MASTER CYLINDER OUTLET FTG BOLT 가스켓
22.930	LINK, BRAKE MASTER CYLINDER 링크	23.186	LINE, BRAKE MASTER CYLINDER OUTLET 라인
23.051	FASTENER, MASTER CYLINDER MOUNTING BRACKET 패스너	23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.100	PEDAL, BRAKE 페달	23.617	FITTING, BRAKE MASTER CYL OUTLET LINE 피팅
23.101	SHAFT, BRAKE PEDAL 샤프트	23.749	BUSHING, BRAKE ACTUATING LEVER 부싱
23.105	BEARING, BRAKE PEDAL 베어링	23.792	RESERVOIR, BRAKE FLUID 리저버
23.114	PAD & FASTENER, BRAKE PEDAL 패드 & 패스너	23.794	LINE, BRAKE MASTER CYLINDER INLET 라인
23.136	SPRING, BRAKE PEDAL RETURN 스프링	37.849	STOP, BRAKE PEDAL 스톱
23.145	FASTENER, BRAKE PEDAL SHAFT 패스너	90.144	WASHER, BRAKE INTERLOCK SWITCH FASTENER 와셔
		90.146	NUT, BRAKE INTERLOCK SWITCH FASTENER 너트

91.170	NUT, BRAKE RESERVOIR FASTENER 너트
91.171	WASHER, BRAKE RESERVOIR FASTENER 와셔
91.974	NUT, BRAKE MASTER CYLINDER MOUNTING BRACKET FAST 너트
92.026	RETAINER, BRAKE MASTER CYLINDER ACTUATING ROD PI 리테이너
95.794	NUT, BRAKE CYLINDER FASTENER 너트






PARKING BRAKE & LINKAGE

23-456

13.136	FASTENER, SEAT SAFETY SWITCH 패스너
13.137	BRACKET, SEAT SAFETY SWITCH MOUNTING 브라켓
13.980	SWITCH, PARK/SAFETY INTERLOCK 스위치
23.260	SPACER, PARKING BRAKE LEVER 스페이서
23.266	FASTENER, PARKING BRAKE CABLE CLAMP 패스너
23.267	LEVER, PARKING BRAKE 레버
23.269	FASTENER, PARKING BRAKE LEVER 패스너
23.272	CABLE, PARKING BRAKE 케이블
23.274	CLAMP, PARKING BRAKE CABLE 클램프

23.283	FASTENER, PARKING BRAKE END CLEVIS 패스너
23.375	BRACKET, PARKING BRAKE PIVOT 브라켓
23.376	BOLT, PARKING BRAKE MOUNTING BRACKET 볼트
23.565	FASTENER, RIVET NUT 패스너
23.996	FASTENER, PARK BRAKE COUNTER BAL SPRING ANCHOR 패스너
60.724	FASTENER, SEAT SAFETY SWITCH 패스너
90.375	NUT, PARKING BRAKE LEVER FASTENER 너트
91.212	WASHER, PARKING SAFETY INTERLOCK SW FASTENER 와셔



13.101 PLATE, BRAKE LOCK ACTUATING SWITCH
플레이트

13.142 SWITCH, BRAKE INTERLOCK
스위치

13.145 FASTENER, BRAKE INTERLOCK SWITCH
패스너

22.338 CLAMP, BRAKE FLUID RESERVOIR
클램프

22.604 CLAMP, BRAKE FLUID RESERVOIR LINE
클램프

22.929 LINK, BRAKE PEDAL
링크

22.930 LINK, BRAKE MASTER CYLINDER
링크

23.049 SEAL, BRAKE MASTER CYLINDER PORT
씰

23.051 FASTENER, MASTER CYLINDER MOUNTING BRACKET
패스너

23.100 PEDAL, BRAKE
페달

23.101 SHAFT, BRAKE PEDAL
샤프트

23.105 BEARING, BRAKE PEDAL
베어링

23.114 PAD & FASTENER, BRAKE PEDAL
패드 & 패스너

23.118 FASTENER, BRAKE PEDAL TO MASTER CYL PUSH ROD
패스너

23.136 SPRING, BRAKE PEDAL RETURN
스프링

23.145 FASTENER, BRAKE PEDAL SHAFT
패스너

23.150 CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE
실린더

23.157 FASTENER, BRAKE MASTER CYLINDER ATTACHING
패스너

23.173 FITTING, BRAKE MASTER CYLINDER OUTLET
피팅

23.174 GASKET, BRAKE MASTER CYLINDER OUTLET FITTING
가스켓

23.175 BOLT, BRAKE MASTER CYLINDER OUTLET FITTING
볼트

23.176 GASKET, BRAKE MASTER CYLINDER OUTLET FTG BOLT
가스켓

23.186 LINE, BRAKE MASTER CYLINDER OUTLET
라인

23.434 BRACKET, BRAKE PEDAL PIVOT
브라켓

23.617 FITTING, BRAKE MASTER CYL OUTLET LINE
피팅


23.658 BEARING, BRAKE PEDAL LINK
베어링

23.792 RESERVOIR, BRAKE FLUID
리저버

23.793 FASTENER, BRAKE FLUID RESERVOIR
패스너

23.794 LINE, BRAKE MASTER CYLINDER INLET
라인

94.699 FASTENER, BRAKE MASTER CYLINDER SUPPORT BRACKET
패스너




PARKING HAND BRAKE

23-994

13.136	FASTENER, SEAT SAFETY SWITCH 패스너
13.137	BRACKET, SEAT SAFETY SWITCH MOUNTING 브라켓
13.980	SWITCH, PARK/SAFETY INTERLOCK 스위치
23.260	SPACER, PARKING BRAKE LEVER 스페이서
23.261	SPACER, PARKING BRAKE LEVER 스페이서
23.267	LEVER, PARKING BRAKE 레버
23.269	FASTENER, PARKING BRAKE LEVER 패스너
23.272	CABLE, PARKING BRAKE 케이블
23.283	FASTENER, PARKING BRAKE END CLEVIS 패스너

23.996	FASTENER, PARK BRAKE COUNTER BAL SPRING ANCHOR 패스너
60.724	FASTENER, SEAT SAFETY SWITCH 패스너
90.375	NUT, PARKING BRAKE LEVER FASTENER 너트
91.212	WASHER, PARKING SAFETY INTERLOCK SW FASTENER 와셔






25.011	FASTENER, STEERING COLUMN 패스너
25.130	FASTENER, DIRECTIONAL ASSEMBLY 패스너
25.137	KEY, DIRECTIONAL ASSEMBLY 키
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.771	SHAFT, STEERING COLUMN (TILT) 샤프트
25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.819	KNOB, TILT COLUMN 노브
37.344	SPRING, STEERING COLUMN TILTING 스프링


37.348

PYLON, STEERING COLUMN
파일런






25.010	JACKET, STEERING COLUMN 자켓
25.140	SHAFT & COLUMN ASSEMBLY, POWER STEERING 샤프트& 컬럼
25.141	SHAFT, STEERING GEAR 샤프트
94.888	RETAINER, STEERING COLUMN ADJUSTOR 리테이너




25.002	HORN BUTTON KIT 혼버튼키트
25.003	NUT, HANDWHEEL 너트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.140	SHAFT & COLUMN ASSEMBLY, POWER STEERING 샤프트& 컬럼
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.221	FASTENER, STEERING SPINNER KNOB 패스너
25.222	CAP, STEERING SPINNER KNOB 캡
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트& 컬럼
25.780	HORN BUTTON 혼버튼

25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
47.083	SUPPORT, DASH COVER 서포트
90.453	WASHER, STEERING SPINNER KNOB FASTENER 와셔
96.358	WASHER, STEERING HANDWHEEL SPINNER KNOB FASTENER 와셔
96.752	NUT, TILT STEERING SHAFT & COLUMN ASSEMBLY FASTENER 너트






26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.021	FASTENER, BALL STUD 패스너
26.026	FASTENER, CYLINDER ROD END 패스너
92.745	RETAINER, STEER CYLINDER ROD END FASTENER 리테이너
93.317	RETAINER, POWER STEERING CYLINDER BALL STUD FASTEN 리테이너



- | | |
|--------|--|
| 25.001 | GEAR ASSEMBLY, STEERING (GREASED)
기어어셈블리 |
| 25.022 | BEARING, STEER GEAR SPOOL
베어링 |
| 25.095 | COVER, END
커버 |
| 25.097 | FASTENER, END COVER
패스너 |
| 25.109 | KIT, STEER GEAR SEAL
키트 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |
| 25.227 | DUST SEAL, STRG INPUT SHAFT BEARING
더스트셀 |
| 25.271 | SPRING, STEERING GEAR VALVE CENTERING
스프링 |
| 25.328 | WASHER, STEERING DRIVE IDLER
와셔 |

25.329	SEAL, STEERING DRIVE IDLER 씰
25.381	RETAINER, STEER GEAR SHAFT SEAL 리테이너
25.409	TRUNNION, STEER GEAR PUMP DRIVE 트러니언
25.410	SHAFT, STEER GEAR PUMP DRIVE 샤프트
25.411	WEAR PLATE, STEER GEAR PUMP 웨어플레이트
25.412	PUMP CARTRIDGE, STEER GEAR 펌프카트리지
25.473	SPLINE, STEER GEAR PUMP DRIVE SHAFT 스플라인
25.602	CHECK VALVE, STEER GEAR VALVE 체크밸브
25.614	RELIEF VALVE, STEER GEAR PRESSURE 릴리프밸브
25.618	BUSHING, STEER GEAR CHECK VALVE 부싱
26.006	BALL, CHECK VALVE 볼
26.063	PLUG, CHECK VALVE CHANNEL 플러그
26.271	SEAL, STEERING VALVE END HOUSING 씰
26.272	HOUSING, STEERING VALVE END 하우징


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEERING GEAR MOUNTING


25-363

25.034	FASTENER, STEERING GEAR ATTACHING 패스너
25.035	FASTENER, STEERING GEAR ATTACHING 패스너
25.150	GEAR BOX ASSEMBLY, STEERING 기어박스
25.486	SPACER, STEERING GEAR MOUNTING 스페이서



05.185	BASE, DIRECTIONAL SELECTOR LEVER 베이스
06.101	LEVER ASSEMBLY, FORWARD & REVERSE 레버
13.047	SWITCH, CIRCUIT LOCKING 스위치
13.110	SWITCH, DIRECTIONAL CONTROL (FORWARD) 스위치
13.111	FASTENER, DIRECTIONAL CONTROL SWITCH 패스너
13.130	FASTENER, DIRECTION CONTROL LEVER 패스너
14.238	HARNESS, DIRECTION CONTROL SWITCH WIRING 하네스
40.002	LEGEND, SHIFT PATTERN 범례
40.069	DECAL, FORWARD-BACKWARD 데칼


44.250	DIRECTIONAL CONTROL ASSEMBLY 방향컨트롤
44.251	HOUSING, DIRECTIONAL CONTROL ASSEMBLY 하우징
44.252	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING 커버
44.254	FASTENER, DIRECTIONAL CONTROL ASSY HOUSING COVER 패스너
44.255	SEAL, DIRECTIONAL CONTROL ASSY LEVER 씰
44.356	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING REAR 커버
60.260	KEY, CIRCUIT LOCKING SWITCH 키
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
60.686	RING, HORN CONTACT 링
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링



26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.022	HOUSING, CYLINDER BALL STUD 하우징
26.025	SHIELD, CYLINDER ROD END DUST 실드
26.027	FASTENER, CYLINDER ROD END CLAMPING 패스너
26.069	PIN, STOP SCREW LOCK 핀
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 스티어실린더피스톤
26.091	U-CUP, STEERING CYLINDER PISTON U컵
26.093	GLAND, STEERING CYLINDER 그랜드

26.249	PACKING KIT, POWER STEERING CYLINDER 패킹키트
26.286	PISTON, STEERING CYLINDER 피스톤






STEERING LINES

26-318

28.052	FITTING, STEERING GEAR 피팅
28.291	FITTING, PUMP OUTLET 피팅
31.003	LINE, PUMP INLET 라인
31.014	FITTING, PUMP OUTLET 피팅
31.115	LINE, STEERING PUMP OUTLET 라인
31.120	LINE, SUMP RETURN (POWER STEERING) 라인
31.163	CLAMP, SUMP RETURN LINE 클램프
31.436	FITTING, PUMP OUTLET LINE 피팅
31.448	FITTING, PUMP OUTLET LINE 피팅


31.524	FITTING, PUMP INLET LINE 피팅
31.664	LINE, STEERING CYLINDER ANCHOR PORT 라인
31.665	FITTING, STEERING CYLINDER ANCHOR PORT 피팅
31.668	LINE, STEERING CYLINDER ROD PORT 라인
31.669	FITTING, STEERING CYLINDER ROD PORT 피팅
31.918	FITTING, SUMP RETURN PORT 피팅
31.991	FITTING, PUMP INLET LINE 피팅
46.040	STRIP TIE, STEERING CYLINDER HOSE 스트립



25.080	LEVER ASSEMBLY, STEERING 레버	26.143	CAP, STEER WHEEL HUB 캡
25.122	DRAG LINK ASSEMBLY, PITMAN ARM 드래그링크	26.224	FORK, STEER AXLE 포크
25.162	FITTING - LUB, DRAG LINK LEVER 피팅	26.227	SEAL, STEER AXLE FORK HOUSING 씰
25.387	PIVOT, STEERING ARM 피봇	26.228	CONE, STEER AXLE FORK LOWER 콘
25.390	BEARING, STEERING ARM PIVOT 베어링	26.229	CUP, STEER AXLE FORK LOWER 컵
25.391	BEARING, STEERING ARM 베어링	26.234	CUP, STEER AXLE FORK UPPER 컵
25.394	PIN, STEERING LINK (AXLE) 핀	26.235	CONE, STEERING AXLE FORK UPPER 콘
25.599	LUB FITTING, STEERING LINK (AXLE END) 윤활 피팅	26.238	FASTENER, STEER AXLE FORK UPPER BEARING 패스너
26.133	SEAL, STEER WHEEL HUB 씰	26.239	SEAL, STEER AXLE FORK COVER 씰
26.134	CONE, STEER WHEEL HUB BEARING (INNER) 콘	26.386	TRUNNION, AXLE 트러니언
26.135	CUP, STEER WHEEL HUB BEARING (INNER) 컵	93.318	NUT, STEERING LINK PIN (STEERING ARM) 너트
26.136	HUB & CUP, STEER WHEEL 허브& 컵	93.319	NUT, STEERING LINK PIN (AXLE END) 너트
26.138	CUP, STEER WHEEL HUB BEARING (OUTER) 컵	93.793	WASHER, STEERING ARM PIVOT FASTENER 와셔
26.139	CONE, STEER WHEEL HUB BEARING (OUTER) 콘	94.295	FASTENER, STEERING ARM PIVOT PIN 패스너
26.141	FASTENER, STEER WHEEL HUB 패스너	95.169	WASHER, STEERING LINK PIN 와셔

95.170	WASHER, STEERING LINK AXLE PIN 와셔
96.803	FASTENER, AXLE TRUNNION 패스너
96.804	FASTENER, AXLE TRUNNION 패스너
96.805	FASTENER, AXLE TRUNNION 패스너
96.806	LOCKWASHER, STEER AXLE 로그와셔
96.807	WASHER, STEER AXLE 와셔






25.080	LEVER ASSEMBLY, STEERING 레버	26.228	CONE, STEER AXLE FORK LOWER 콘
25.122	DRAG LINK ASSEMBLY, PITMAN ARM 드래그링크	26.229	CUP, STEER AXLE FORK LOWER 컵
25.162	FITTING - LUB, DRAG LINK LEVER 피팅	26.234	CUP, STEER AXLE FORK UPPER 컵
25.387	PIVOT, STEERING ARM 피봇	26.235	CONE, STEERING AXLE FORK UPPER 콘
25.390	BEARING, STEERING ARM PIVOT 베어링	26.238	FASTENER, STEER AXLE FORK UPPER BEARING 패스너
25.391	BEARING, STEERING ARM 베어링	26.239	SEAL, STEER AXLE FORK COVER 씰
25.394	PIN, STEERING LINK (AXLE) 핀	26.386	TRUNNION, AXLE 트러니언
25.599	LUB FITTING, STEERING LINK (AXLE END) 윤활피팅	93.318	NUT, STEERING LINK PIN (STEERING ARM) 너트
26.133	SEAL, STEER WHEEL HUB 씰	93.319	NUT, STEERING LINK PIN (AXLE END) 너트
26.136	HUB & CUP, STEER WHEEL 허브&컵	93.793	WASHER, STEERING ARM PIVOT FASTENER 와셔
26.137	FASTENER, STEER WHEEL 패스너	94.295	FASTENER, STEERING ARM PIVOT PIN 패스너
26.141	FASTENER, STEER WHEEL HUB 패스너	95.169	WASHER, STEERING LINK PIN 와셔
26.143	CAP, STEER WHEEL HUB 캡	95.170	WASHER, STEERING LINK AXLE PIN 와셔
26.224	FORK, STEER AXLE 포크	96.803	FASTENER, AXLE TRUNNION 패스너
26.227	SEAL, STEER AXLE FORK HOUSING 씰	96.804	FASTENER, AXLE TRUNNION 패스너

96.805	FASTENER, AXLE TRUNNION 패스너
96.806	LOCKWASHER, STEER AXLE 로그와셔
96.807	WASHER, STEER AXLE 와셔




ASSEMBLY
COMPLETE — 33.000



PRIORITY VALVE ASSEMBLY

27-002

27.085	SEAL, FLOW CONTROL VALVE 씰
33.000	VALVE ASSEMBLY, FLOW CONTROL 밸브




HYDRAULIC SUMP TANK

29-232

29.701	TANK, SUMP 탱크
29.702	FASTENER, SUMP TANK 패스너
29.728	CAP, HYDRAULIC SUMP FILLER 캡
29.766	COVER, SUMP TANK 커버
29.767	SEAL, SUMP TANK COVER 셀
29.768	FASTENER, SUMP TANK COVER 패스너
29.798	SCREEN, HYDRAULIC SUMP PRE FILTER 스크린
29.809	DIPSTICK, SUMP LEVEL 딤스틱
29.824	CAP, HYDRAULIC SUMP AUXILIARY OUTLET 캡

ASSEMBLY
COMPLETE — 29.100


SEAL KIT — 29.028



HYDRAULIC PUMP ASSEMBLY


29-296

- | | |
|--------|--------------------------------------|
| 29.028 | SEAL KIT, HYDRAULIC UNIT PUMP
씰키트 |
| 29.087 | SEAL, HYDRAULIC PUMP HOUSING
씰 |
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.268 | COUPLING, MAIN HYDRAULIC PUMP
커플링 |



29.000	FILTER, HYDRAULIC OIL 필터
29.007	CARTRIDGE, HYDRAULIC OIL FILTER 카트리지


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC PUMP MOUNTING

29-318


29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
29.119	FASTENER, PUMP HOUSING 패스너
29.474	SEAL, PUMP INLET FITTING 씰
29.608	MANIFOLD, HYDRAULIC PUMP INLET SUCTION 매니폴드
97.097	FASTENER, HYDRAULIC PUMP INLET SUCTION MANIFOLD 패스너




30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.753	SPOOL SEAL KIT 스풀씰키트
31.613	TIE STUD KIT, HYDRAULIC VALVE 타이스터드키트
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션



30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 셀킷
30.753	SPOOL SEAL KIT 스풀셀킷
31.613	TIE STUD KIT, HYDRAULIC VALVE 타이스터드킷
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션




30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 셀리트
30.753	SPOOL SEAL KIT 스풀셀리트
31.613	TIE STUD KIT, HYDRAULIC VALVE 타이스터드키트
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션



30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.107	FASTENER, VALVE THRU 패스너
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 씰키트
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 씰키트
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 씰키트
30.715	FASTENER, VALVE THRU 패스너
30.762	END COVER, HYDRAULIC VALVE 엔드커버


49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀씰키트
49.197	SPOOL SEAL KIT, TILT SECTION 스풀씰키트
49.198	SPOOL SEAL KIT, AUX SECTION 스풀씰키트



13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.146	BRACKET, CONTROL LINKAGE LOWER 브라켓
30.442	SPACER, CONTROL LEVERS 스페이서

30.787	BOOT, VALVE CONTROL LEVER 부트
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.126	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (3SPOOL)

30-516

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.146	BRACKET, CONTROL LINKAGE LOWER 브라켓
30.442	SPACER, CONTROL LEVERS 스페이서

30.787	BOOT, VALVE CONTROL LEVER 부트
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
49.126	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (4SPOOL)

30-521

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓
30.146	BRACKET, CONTROL LINKAGE LOWER 브라켓
30.787	BOOT, VALVE CONTROL LEVER 부트

30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
49.124	CAP, AUXILIARY CONTROL LEVER 캡
49.126	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (3SPOOL)

30-538

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	49.042	CAP, TILT CONTROL LEVER 캡
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.081	CAP, LIFT CONTROL LEVER 캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.089	LEVER, LIFT CONTROL 레버	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.090	LEVER, TILT CONTROL 레버	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.146	BRACKET, CONTROL LINKAGE LOWER 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.442	SPACER, CONTROL LEVERS 스페이서	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	49.126	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
32.138	SWITCH, PUSH BUTTON 스위치	49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




HYDRAULIC VALVE MOUNTING (4SPOOL)

30-539

13.537	SWITCH, CONTROL VALVE PUMP OPERATING 스위치	49.081	CAP, LIFT CONTROL LEVER 캡
30.000	VALVE ASSEMBLY, HYDRAULIC 밸브	49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
30.089	LEVER, LIFT CONTROL 레버	49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
30.090	LEVER, TILT CONTROL 레버	49.109	ROD, VALVE CONTROL CLEVIS 로드
30.102	BRACKET, HYDRAULIC VALVE SWITCH 브라켓	49.110	PIN, VALVE SPOOL CLEVIS ROD 핀
30.146	BRACKET, CONTROL LINKAGE LOWER 브라켓	49.111	RETAINER, VALVE SPOOL CLEVIS ROD PIN 리테이너
30.787	BOOT, VALVE CONTROL LEVER 부트	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	49.126	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버	49.210	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
32.138	SWITCH, PUSH BUTTON 스위치	52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터
32.142	PLATE, SWITCH MOUNTING BRACKET 플레이트	52.171	LOCK, AUXILIARY VALVE LEVER WIRE 로크
37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너	93.393	FASTENER, HYDRAULIC VALVE SWITCH BRACKET 패스너
49.042	CAP, TILT CONTROL LEVER 캡		


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




MAIN HYDRAULIC LINES

31-309

28.964	LINE, HYDRAULIC VALVE TO FLOW CONTROL VALVE 라인
31.036	FITTING, MAIN VALVE INLET PORT 피팅
31.947	FITTING, PRIORITY VALVE 피팅
33.000	VALVE ASSEMBLY, FLOW CONTROL 밸브
95.090	FASTENER, HYDRAULIC PRIORITY VALVE 패스너



- 31.030 LINE, VALVE TO LIFT CYLINDER
라인
- 31.200 FITTING, MAIN VALVE LIFT PORT
피팅



HYDRAULIC TILT LINES


31-313

31.061	FITTING, VALVE TILT PORT "A" 피팅
31.062	FITTING, VALVE TILT PORT "B" 피팅
31.073	LINE, LH TILT CYLINDER ROD PORT 라인
31.077	FITTING, LH TILT CYLINDER ROD PORT 피팅
31.156	LINE, TILT CYLINDER CROSS 라인
31.160	FITTING, LH TILT CYLINDER ANCHOR PORT 피팅
31.162	FITTING, RH TILT CYLINDER ANCHOR PORT 피팅
31.175	LINE, VALVE TILT PORT "B" 라인
31.182	LINE, VALVE TILT PORT "A" 라인

31.372	FITTING, TILT CYLINDER ANCHOR PORT LINE 피팅
31.600	FITTING, RH TILT CYLINDER ROD PORT 피팅




■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




29.000	FILTER, HYDRAULIC OIL 필터
29.002	FASTENER, HYDRAULIC OIL FILTER 패스너
29.014	BRACKET, HYDRAULIC OIL FILTER MOUNTING 브라켓
29.015	FASTENER, HYDRAULIC OIL FILTER MTG BRACKET 패스너
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프
31.043	CONNECTOR, FILTER INLET PORT 커넥터
31.051	LINE, VALVE SUMP RETURN 라인
31.191	LINE, MAIN VALVE TO SUMP RETURN 라인

31.195	LINE, MAIN VALVE TO SUMP RETURN 라인
31.197	LINE, MAIN VALVE TO SUMP RETURN 라인
31.349	FITTING, RETURN LINE SUMP 피팅
31.361	FITTING, SUMP RETURN LINE 피팅
31.390	CLAMP, VALVE SUMP RETURN LINE 클램프
31.570	FITTING, SUMP RETURN LINE 피팅
31.594	FITTING, SUMP RETURN LINE 피팅
46.091	CLAMP, HYDRAULIC OIL FILTER INLET LINE 클램프





32.000	CYLINDER ASSEMBLY, TILT 실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드& 피스톤
32.072	PACKING KIT, TILT CYLINDER 패킹키트
32.129	SPACER, TILT CYLINDER BARREL END 스페이서




32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.034	RETAINER, TILT CYLINDER ANCHOR PIN 리테이너
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링
32.053	BEARING, TILT CYLINDER ROD END 베어링

32.080

SPACER, TILT CYLINDER REAR MOUNTING
스페이서

ФОРКЛИФТ
www.forklift.ru


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT AMOUNT GP

32-169

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심
32.132	SPACER, TILT CYLINDER ROD END 스페이서
32.133	SHIM, TILT CYLINDER STROKE ADJUSTING 심




32.800	ACCUMULATOR, HYDRAULIC 어큐물레이터
32.801	CLAMP, HYDRAULIC ACCUMULATOR MOUNTING 클램프
32.802	BRACKET, HYDRAULIC ACCUMULATOR 브라켓
32.805	SEAL, HYDRAULIC ACCUMULATOR CONNECTOR 씰
32.806	CONNECTOR, HYDRAULIC ACCUMULATOR 커넥터
32.810	LINE, HYDRAULIC ACCUMULATOR 라인
32.814	FITTING, HYDRAULIC ACCUMULATOR LINE 피팅
32.841	NUT, HYDRAULIC ACCUMULATOR FITTING 너트
32.842	SEAL, HYDRAULIC ACCUMULATOR FITTING 씰


75.029

HYDRAULIC ACCUMULATOR INSTALLATION
유압어큐플레이터


ФОРКЛИФТ
www.forklift.ru



- | | |
|--------|---|
| 33.600 | RELIEF VALVE, DEVICE VARIABLE PRESSURE
릴리프밸브 |
| 33.601 | LEVER, DEVICE VARIABLE RELIEF VALVE
레버 |
| 33.610 | SEAL, DEVICE PRESS RELIEF VAL CHECK PORT PLUG
씰 |
| 33.613 | SEAL, DEVICE RELIEF VALVE PISTON ADJ END
씰 |
| 33.618 | CARTRIDGE KIT, DEVICE VARIABLE RELIEF VALVE
카트리지키트 |
| 33.631 | FASTENER, DEVICE RELIEF VALVE
패스너 |




- 33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
밸브
- 33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너
- 33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
씰키트
- 33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어키트



LOAD BACK REST MOUNTING

34-044

- | | |
|--------|--|
| 34.998 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 66.431 | RETAINER, LBR CAPSCREW
리테이너 |



34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.328	ROLLER, CARRIAGE CAPTIVE 롤러
34.329	RETAINER, CARRIAGE CAPTIVE ROLLER 리테이너
34.330	FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER 패스너
34.332	SHIM, CARRIAGE CAPTIVE ROLLER 심
34.340	CARRIAGE WELDED ASSEMBLY 캐리지용 접합물


This Carriage assembly was manufactured by the CASCADE CORPORATION and is not serviced by CLARK Material Handling Company.

CASCADE parts manuals, technical specifications and lists of worldwide distributors are available on-line at:

<http://www.cascorp.com>.

When ordering service parts, it will be necessary to provide CASCADE with the CASCADE model and serial numbers of the carriage. CASCADE will not recognize the CLARK carriage part number listed on the PIC or in PartsPRO.


34.300	CARRIAGE ASSEMBLY COMPLETE
34.340	CARRIAGE WELDED ASSEMBLY



UPRIGHT MOUNTING

34-325


- | | |
|--------|--|
| 34.091 | FASTENER, TILT CYLINDER TO UPRIGHT RETAINER
패스너 |
| 34.600 | SUPPORT, UPRIGHT
서포트 |
| 34.605 | FASTENER, UPRIGHT SUPPORT PIN LOCK PLATE
패스너 |
| 34.607 | FITTING-LUB, UPRIGHT SUPPORT
피팅 |




37.201	PANEL, LH SIDE 판넬
37.202	PANEL, RH SIDE 판넬
37.374	COVER, HYDRAULIC VALVE 커버
39.363	FASTENER, RH SIDE PANEL 패스너
39.546	COWL ASSEMBLY 카울
39.558	FASTENER, COWL FRONT 패스너
39.570	COVER ASSEMBLY, DASH 커버
39.571	FASTENER, DASH COVER 패스너
47.080	BRACKET, COWL COVER MOUNTING 브라켓

47.081	FASTENER, COWL COVER MOUNTING BRACKET 패스너
48.302	FASTENER, SIDE PANEL ASSEMBLY 패스너
93.671	FASTENER, HYDRAULIC VALVE COVER 패스너

ФОРКЛИФТ
www.forklift.ru




37.902	MAT, FLOORPLATE 매트
37.903	MAT, FLOORPLATE 매트
38.471	PAD, LH STEP NON-SKID 패드
38.472	PAD, RH STEP NON-SKID 패드
39.439	FASTENER, FLOOR PLATE NON-SLIP PAD 패스너
39.475	PLATE, FRONT FLOOR 플레이트
39.479	FASTENER, FRONT FLOOR PLATE 패스너



36.211	BUSHING, PIVOT PIN FASTENER 부싱
37.897	BUMPER, TOP HOOD 범퍼
38.104	PLATE, BATTERY COMPARTMENT FRONT 플레이트
39.461	PLATE, BATTERY SUPPORT 플레이트
39.644	LATCH, TOP HOOD 래치
39.662	FASTENER, TOP HOOD LATCH BRACKET 패스너
90.817	NUT, HOOD VIBRATION DAMPENER FASTENER 너트
93.649	FASTENER, TOP HOOD PIVOT 패스너
95.179	FASTENER, BATTERY COMPARTMENT FRONT PLATE 패스너

95.798 FASTENER, BATTERY COMPARTMENT TOP PLATE
 패스너






37.210	BRACKET, HOOD PROP 브라켓
37.543	PLATE, TOP HOOD SPRING BRACKET REINFORCING 플레이트
37.544	ANCHOR, TOP HOOD PROP 앵커
39.535	BRACKET, TOP HOOD MOUNTING 브라켓
39.536	BRACKET, TOP HOOD MOUNTING 브라켓
39.594	HOOD, TOP 후드
39.702	PROP, HOOD 지지대
39.705	FASTENER, HOOD PROP 패스너
93.399	FASTENER, TOP HOOD STOP 패스너

94.436 FASTENER, HOOD PROP BRACKET SUPPORT
패스너







SEAT ARMREST ASSEMBLY

37-124


- | | |
|--------|---------------------------------------|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |




- | | |
|--------|--------------------------------------|
| 38.093 | FASTENER, BATTERY BOX STOP
패스너 |
| 95.011 | NUT, BATTERY BOX STOP FASTENER
너트 |




12.375	SLIDE, BATTERY 슬라이드
12.377	FASTENER, BATTERY SLIDE 패스너
38.121	ROLLER, BATTERY 롤러
38.220	FASTENER, SIDE BATTERY REMOVAL BLOCK 패스너



38.870 FASTENER, COUNTERWEIGHT (LOWER)
패스너




38.869	COUNTERWEIGHT 카운터웨이트
40.139	DECAL, MODEL DESIGNATION 데칼
47.111	COVER, WIRING PROTECTION 커버
95.396	FASTENER, WIRING HARNESS PROTECTION SHIELD 패스너



SIDE BATTERY REMOVAL(SBR)

38-273

- | | |
|--------|--------------------------------|
| 12.375 | SLIDE, BATTERY
슬라이드 |
| 12.376 | SLIDE, BATTERY
슬라이드 |
| 12.377 | FASTENER, BATTERY SLIDE
패스너 |




SHEET METAL(SBR)


38-274

12.005	RETAINER, BATTERY 리테이너
12.190	SWITCH, BATTERY RETAINER INTERLOCK 스위치
12.191	HARNESS, BATTERY RETAINER INTERLOCK SWITCH 하네스
12.192	FASTENER, BATTERY RETAINER INTERLOCK SWITCH 패스너
12.291	COVER, KILL SWITCH 커버
96.457	WASHER, BATTERY RETAINER INTERLOCK SWITCH FASTENER 와셔






- | | |
|--------|---|
| 34.977 | RETAINER, LOAD BACK REST TRUNNION PIN
리테이너 |
| 34.991 | FASTENER, LOAD SAFETY BACK REST EXT
패스너 |
| 34.995 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 92.226 | NUT, LOAD SAFETY BACK REST FASTENER
너트 |





- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 48.347 | FASTENER, SEAT ASSEMBLY
패스너 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |



37.406	BRACKET, SEAT BACK REST COVER LH 브라켓
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓
37.439	SAFETY BELT, SEAT 안전벨트
37.531	BRACKET, SEAT SAFETY BELT MOUNTING 브라켓
37.720	COVER, OPERATOR SEAT LATERAL RESTRAINT 커버
37.743	COVER, SEAT SUPPORT LATCH 커버
38.163	BRACKET, SEAT SUPPORT RH 브라켓
39.719	SEAT ASSEMBLY 시트
39.720	CUSHION, SEAT 쿠션

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너






OVERHEAD GUARD MOUNTING

39-669


37.422	BUMPER, OVERHEAD GUARD REAR SUPPORT 범퍼
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.082	INSERT, DRIVER OVERHEAD GUARD 인서트



37.392

SAFETY BELT ASSEMBLY
안전벨트


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



SEAT MOUNTING


39-829


39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔



- | | |
|--------|---|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
안전벨트 |
| 37.915 | SUSPENSION COVER, SEAT SUSPENSION
서스펜션커버 |
| 37.918 | SUSPENSION ASSEMBLY, SEAT
서스펜션 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |
| 39.721 | CUSHION, SEAT BACK REST
쿠션 |


39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너





37.439 SAFETY BELT, SEAT
안전벨트

39.932 GUARD, OVERHEAD
가드




37.933 COVER, HOOD ACCESS
커버

37.935 FASTENER, HOOD ACCESS COVER
패스너

39.461 PLATE, BATTERY SUPPORT
플레이트

47.069 PLUG, TOP HOOD
플러그

94.763 FASTENER, HOOD SUPPORT
패스너




NOTE: All Trucks Do Not Use All Fluid Key Numbers


TRUCK FLUIDS

40-260

99.901	ENGINE OIL 엔진오일
99.902	TRANSMISSION FLUID 트랜스미션오일
99.903	DRIVE AXLE FLUID 드라이브액슬
99.904	HYDRAULIC SUMP OIL 유압섬프오일
99.905	BRAKE FLUID 브레이크오일
99.906	AXLE END FLUID 액슬엔드오일
99.907	ENGINE ANTIFREEZE 부동액




40.010	DECAL, CLARK 데칼
40.012	DECAL, CLARK LOGO-SMALL 데칼
40.130	LEGEND, SAFETY 범례
40.131	LEGEND, SAFETY 범례
40.142	DECAL, ELECTRICAL CIRCUIT DIAGRAM 데칼




40.329 FASTENER, ATTACHMENT NAME PLATE
패스너


40.330 PLATE, ATTACHMENT NAME
플레이트




40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너
40.006	LEGEND, PATENT 범례
40.024	PLATE, UNDERWRITERS LABEL 플레이트
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너
40.042	DECAL, POLARITY 데칼
40.062	DECAL, DRIVERS CAUTION 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼
40.076	DECAL, ELECTRIC TRUCK CAUTION 데칼

40.089	PLATE, SAFETY INSTRUCTION 플레이트
40.138	DECAL, SAFETY 데칼
40.141	DECAL, HYDRAULIC SCHEMATIC 데칼
40.173	DECAL, IMPORTANT 데칼
40.180	DECAL, BATTERY DISCONNECT SWITCH 데칼
40.183	DECAL, BATTERY DISCONNECT WARNING 데칼
40.196	DECAL, GENESIS SERIES 데칼
40.241	DECAL, BRAKE OIL SPEC 데칼
40.248	DECAL, SERVICE CHART 데칼
40.283	DECAL, ERROR CHECK 데칼
40.309	DECAL, AC LOGO 데칼
40.326	DECAL, EE MARKING 데칼
40.327	DECAL, FAN WARNING 데칼
40.328	DECAL, WHEEL NUT WARNING 데칼







THERMOSTAT INSTALLATION




PARKING BRAKE SWITCH




VALVE SWITCH



FOOT BRAKE&STOP LIGHT SWITCH



COLD STORAGE HEATER INSTALLATION




DETAIL - A
STEER ANGLE SENSOR

41-037


- | | |
|--------|--|
| 14.245 | HARNESS, SWITCH HEATER CONTROL WIRING
하네스 |
| 14.986 | BRACKET, SWITCH HEATER CONTROL
브라켓 |
| 15.187 | HEATER, HYDRAULIC VALVE SWITCH
히터 |
| 15.700 | HEATER, STEER ANGLE SENSOR
히터 |
| 15.702 | BRACKET, STEER ANGLE SENSOR HEATER MOUNTING
브라켓 |
| 15.780 | HEATER, STOP LIGHT SWITCH
히터 |
| 41.008 | CONTROL, SWITCH HEATER
컨트롤 |
| 41.018 | FASTENER, SWITCH HEATER CONTROL
패스너 |
| 41.425 | HEATER, FOOT BRAKE SWITCH
히터 |

41.426	HEATER, PARKING BRAKE SWITCH 히터
97.246	FASTENER, STEER ANGLE SENSOR HEATER 패스너
97.247	FASTENER, STEER ANGLE SENSOR HEATER BRACKET 패스너







37.447	RESTRAINT, OPERATOR SEAT LATERAL 레스트레인트
37.970	KIT, SEAT SAFETY 키트
94.537	FASTENER, OPERATOR SEAT LATERAL RESTRAINT 패스너




37.975	FASTENER, SEAT WIRING HARNESS CLAMP 패스너
37.976	CLAMP, SEAT WIRING HARNESS 클램프
37.977	FASTENER, SEAT WIRING HARNESS CLAMP 패스너
37.979	CLAMP, SEAT WIRING HARNESS 클램프
40.306	DECAL, SEAT SWITCH 데칼




**STANDARD TYPE
(TYPE - 1)**



**LESS HEIGHT THAN STANDARD TYPE
(TYPE - 2)**



**DIDT OPTION TYPE
(TYPE - 3)**




**LESS HEIGHT THAN DIDT OPTION TYPE
(TYPE - 4)**

OVERHEAD GUARD

47-009


39.932

GUARD, OVERHEAD
가드



15.437 HARNESS, HEADLAMP WIRING
하네스


39.932 GUARD, OVERHEAD
가드



ARMREST KIT INSTALLATION

47-025

- | | |
|--------|--|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |



AUXILIARY VALVE LINES

50-120


50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
50.425	LINE, 1ST AUXILIARY VALVE "A" PORT 라인
50.426	LINE, 1ST AUXILIARY VALVE "B" PORT 라인
50.427	LINE, 2ND AUXILIARY VALVE "A" PORT 라인
50.428	LINE, 2ND AUXILIARY VALVE "B" PORT 라인
50.440	FITTING, 1ST AUXILIARY VALVE "A" PORT 피팅
50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅
50.862	SEAL, AUXILIARY VALVE A PORT 씰

50.869


SEAL, AUXILIARY VALVE B PORT

셀

ФОРКЛИФТ
www.forklift.ru



50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.200	COUPLING, DEVICE HOSE 커플링	59.072	GUARD, DEVICE HOSE 가드
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.316	GUARD, DEVICE RH HOSE 가드	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
50.811	NUT, DEVICE HOSE FITTING 너트	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록	95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓	96.316	FASTENER, DEVICE HOSE REEL 패스너
59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브	97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-787


50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.200	COUPLING, DEVICE HOSE 커플링	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.316	GUARD, DEVICE RH HOSE 가드	59.112	JUNCTION BLOCK, DEVICE HOSE 정크션 블록
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.610	FASTENER, DEVICE HOSE GUARD 패스너	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING 브라켓
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너	59.128	TUBE, DEVICE HOSE REEL BRACKET 튜브
50.811	NUT, DEVICE HOSE FITTING 너트	59.129	TUBE, DEVICE HOSE REEL BRACKET 튜브
59.016	JUNCTION BLOCK, DEVICE HOSE 정크션 블록	93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓	93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너

95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET 패스너







**MODEL: GTX162
GEX162**
UPRIGHT: STANDARD




**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: STANDARD




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE & HI-LO




**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: TRIPLE STAGE



**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: HI-LO




**MODEL: EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: STANDARD

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-791


- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-792


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅
59.091	FITTING, DEVICE HYDRAULIC LINE 피팅




ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-793

- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |




59.130	TIE STRAP, DEVICE LINE FOR HIGH TERMINATION 타이스트랩
59.134	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.140	COUPLING, DEVICE LINE FOR HIGH TERMINATION 커플링
59.141	COUPLING, DEVICE LINE FOR HIGH TERMINATION 커플링
59.142	FITTING, DEVICE LINE FOR HIGH TERMINATION 피팅
59.143	CAP, DEVICE LINE FITTING FOR HIGH TERMINATION 캡
59.144	BRACKET, DEVICE LINE FOR HIGH TERMINATION 브라켓
97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너
97.238	FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION 패스너



14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE 터미널
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC 라인
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC 라인
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디स्क넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT 피팅
59.132	FITTING, DEVICE LINE QUICK DISCONNECT 피팅






HIGH TERMINATION FOR DEVICE HOSE ADAPTATION

50-817


59.134	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.135	LINE, DEVICE LH LINE FOR HIGH TERMINATION 라인
59.136	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.137	LINE, DEVICE RH LINE FOR HIGH TERMINATION 라인
59.138	CLAMP, DEVICE LINE FOR HIGH TERMINATION 클램프
59.139	CLAMP, DEVICE LINE FOR HIGH TERMINATION 클램프
97.235	FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION 패스너



37.457	HOOK, CAB CLOTHING HANGER 후크
53.001	ATTACHMENT, SIDE SHIFTER COMPLETE 어태치먼트
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.180	SPACER, SIDE SHIFTER BEARING 스페이서
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅

53.216	SEAL, SIDE SHIFTER CYLINDER ROD PORT FITTING 씰
53.302	FRAME ASSEMBLY, DEVICE WELDED 프레임
54.191	PLATE, SIDE SHIFT NAME 플레이트
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링






40.343	DECAL, ATTACHMENT SAFETY 데칼
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링

54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서
54.314	SPACER, SIDE SHIFTER CYLINDER REAR 스페이서



ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹키트
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT 볼

97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
세트스크류







52.149	NUT, SIDE SHIFT CYLINDER ANCHOR PORT LINE FITTING 너트
53.023	ANCHOR, SIDE SHIFTER CYLINDER ROD END 앵커
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인
53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인

54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트





- 34.350 FORK ASSEMBLY
포크
- 34.359 KIT, FORK STOP PIN (CAPTIVE)
키트





LIFT CYLINDER PIPING

66-065

28.741	LINE ASSY, LIFT CYLINDER 라인
28.742	LINE, LIFT CYLINDER LEFT HAND 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
28.790	FITTING, FINAL LIFT CYLINDER LINE 피팅
31.033	CLAMP, LIFT CYLINDER LINE TO SUPPORT 클램프
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.215	FASTENER, LIFT LINE CLAMP 패스너
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인

34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.163	PLUG, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD PO 플러그
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
66.250	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너






34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너

34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
94.059	NUT, LIFT CYLINDER FASTENER 너트






LIFT CHAIN

66-073

34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.084	SHEAVE, LIFT CHAIN 쉬브
34.101	CHAIN, LIFT 체인
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트


91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너





28.729	LINE, LIFT CYLINDER 라인
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.869	FITTING, LIFT CYLINDER INLET 피팅
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.547	SEAL, LIFT CYLINDER INLET PORT 씼
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드


66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.163	PLUG, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD PO 플러그
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너



34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터 레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너 레일
34.146	SUPPORT, LIFT CYLINDER BARREL 서포트


34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트






34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커


34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.152	ANCHOR, RAIL LIFT CHAIN 앵커
34.153	SHEAVE, UPRIGHT RAIL CHAIN 쉬브
34.156	FASTENER, RAIL CHAIN TO ANCHOR 패스너
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트
91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트



28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피벗
28.729	LINE, LIFT CYLINDER 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인
34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브

34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.139	BUSHING, LIFT CHAIN HOSE SHEAVE 부싱
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.164	FITTING, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD 피팅
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너






34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.525	BEARING, LIFT CYLINDER ROD 베어링
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브


34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔






34.000	UPRIGHT & LIFT CYL ASSEMBLY 마스트& 실린더
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아우터레일
34.002	FASTENER, LIFT CYLINDER TO SUPPORT 패스너
34.013	ROLLER, UPRIGHT 롤러
34.014	SHIM, UPRIGHT ROLLER 심
34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
34.146	SUPPORT, LIFT CYLINDER BARREL 서포트

34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
66.167	SHIM, LIFT CYLINDER UPPER 심
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트





66.207	PISTON, FINAL LIFT CYLINDER 피스톤
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.404	CAP, FINAL LIFT CYLINDER GLAND 캡



- 34.000 UPRIGHT & LIFT CYL ASSEMBLY
마스트& 실린더
- 34.001 OUTER RAIL WELDER ASSEMBLY, UPRIGHT
아우터레일
- 34.002 FASTENER, LIFT CYLINDER TO SUPPORT
패스너
- 34.013 ROLLER, UPRIGHT
롤러
- 34.014 SHIM, UPRIGHT ROLLER
심
- 34.036 BUSHING, UPRIGHT TRUNNION
부싱
- 34.042 FASTENER, LIFT CYLINDER (UPPER)
패스너
- 34.050 INNER RAIL WELDED ASSEMBLY, UPRIGHT
인너레일
- 34.146 SUPPORT, LIFT CYLINDER BARREL
서포트


34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.400	CYLINDER ASSEMBLY, LIFT 실린더
40.012	DECAL, CLARK LOGO-SMALL 데칼
40.130	LEGEND, SAFETY 범례
40.131	LEGEND, SAFETY 범례
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트







- | | |
|--------|--|
| 34.000 | UPRIGHT & LIFT CYL ASSEMBLY
мастр& цилиндр |
| 34.001 | OUTER RAIL WELDER ASSEMBLY, UPRIGHT
ауутерейл |
| 34.002 | FASTENER, LIFT CYLINDER TO SUPPORT
фастнер |
| 34.013 | ROLLER, UPRIGHT
роллер |
| 34.014 | SHIM, UPRIGHT ROLLER
шп |
| 34.036 | BUSHING, UPRIGHT TRUNNION
бушп |
| 34.042 | FASTENER, LIFT CYLINDER (UPPER)
фастнер |
| 34.050 | INNER RAIL WELDED ASSEMBLY, UPRIGHT
иннерейл |
| 34.146 | SUPPORT, LIFT CYLINDER BARREL
супорт |

34.147	FASTENER, CYLINDER LIFTING BRACKET 패스너
34.196	RETAINER, LIFT CYLINDER UPPER RING SEGMENT 리테이너
34.197	FASTENER, LIFT CYLINDER UPPER RING SEGMENT RETAINE 패스너
34.400	CYLINDER ASSEMBLY, LIFT 실린더
40.012	DECAL, CLARK LOGO-SMALL 데칼
40.130	LEGEND, SAFETY 범례
40.131	LEGEND, SAFETY 범례
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
94.059	NUT, LIFT CYLINDER FASTENER 너트






34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 씰& 팩킹키트
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 워셔




66.395	CHECK VALVE, FINAL LIFT CYLINDER 체크밸브
66.397	WASHER, FINAL LIFT CYLINDER CHECK VALVE 와셔
66.398	SNAP RING, FINAL LIFT CYLINDER CHECK VALVE 스냅링
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.401	BARREL, FINAL LIFT CYLINDER 배럴
66.402	PACKING KIT, FINAL LIFT CYLINDER 패킹키트
66.403	PISTON ROD, FINAL LIFT CYLINDER 피스톤로드
66.413	SPACER, FINAL LIFT CYLINDER PISTON ROD 스페이서
66.444	GLAND, FINAL LIFT CYLINDER 그랜드



LIFT CYLINDER PIPING
HUBZYLINDER-LEITUNG
TUYAUTERIE DE VERIN DE LEVAGE
CONDUCTOS DEL CILINDRO DE ELEVACION


28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피벗
28.729	LINE, LIFT CYLINDER 라인
28.744	FITTING, LIFT CYLINDER LINE 피팅
31.035	FITTING, LIFT CYLINDER PORT 피팅
31.217	LINE, LIFT CYLINDER INLET FITTING 라인
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인
31.556	SEAL, FLOW CONTROL VALVE INLET 셀
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브

34.547	SEAL, LIFT CYLINDER INLET PORT 씰
34.550	SEAL, FLOW CONTROL VALVE INLET PORT 씰
34.565	FITTING, LIFT CYLINDER FLOW CONTROL VALVE INLET PO 피팅
66.131	MANIFOLD, LIFT CYLINDER FLOW CONTROL VALVE 매니폴드
66.139	BUSHING, LIFT CHAIN HOSE SHEAVE 부싱
66.146	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.148	SEAL, LIFT CYLINDER PRESSURE LINE 씰
66.149	SEAL, LIFT CYLINDER LINE FITTING 씰
66.150	SEAL, LIFT CYLINDER LINE FITTING 씰
66.164	FITTING, LIFT CYLINDER FLOW CONTROL VALVE MANIFOLD 피팅
66.165	SEAL, L/CYL FLOW CONTROL VALVE MANIFOLD PORT FITTI 씰
66.216	FITTING, FLOW CONTROL VALVE MANIFOLD PORT 피팅
66.221	SEAL, LIFT CYLINDER LINE FITTING 씰
66.231	SEAL, FLOW CONTROL VALVE MANIFOLD PORT FITTING 씰
93.985	FASTENER, LIFT CYLINDER FLOW CONTROL VALVE MANIFOL 패스너




34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트

34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.152	ANCHOR, RAIL LIFT CHAIN 앵커
34.153	SHEAVE, UPRIGHT RAIL CHAIN 쉬브
34.156	FASTENER, RAIL CHAIN TO ANCHOR 패스너
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.167	SHIM, LIFT CYLINDER UPPER 심
66.172	BEARING, LIFT CYLINDER ANCHOR SELF ALIGNING 베어링
66.202	WASHER, LIFT CYLINDER MOUNTING 와셔
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
66.246	SPACER, LIFT CHAIN SHEAVE 스페이서
91.408	NUT-SPHERICAL, LIFT CHAIN FASTENER (CYL END) 너트
91.409	NUT, LIFT CHAIN FASTENER (CYLINDER END) 너트
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트



34.080	FASTENER, LIFT CHAIN SHEAVE 패스너
34.084	SHEAVE, LIFT CHAIN 쉬브
34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
34.101	CHAIN, LIFT 체인
34.102	FASTENER, SHEAVE CARRIER 패스너
34.107	ANCHOR, LIFT CHAIN 앵커
34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.109	ANCHOR, LIFT CHAIN CARRIAGE END 앵커
34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트


66.135	SPACER, SHEAVE CARRIER GUIDE 스페이서
66.222	SPACER, LIFT CHAIN ANCHOR 스페이서
66.223	BEARING, LIFT CHAIN ANCHOR SELF ALIGNING 베어링
91.410	RETAINER, LIFT CHAIN FASTENER (CYLINDER END) 리테이너
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.417	NUT, RAIL LIFT CHAIN FAST (CYL END) 너트
93.727	RETAINER, LIFT CHAIN ANCHOR 리테이너
95.018	NUT, LIFT CHAIN FASTENER 너트




12.005	RETAINER, BATTERY 리테이너
12.130	PLATE, FRONT (SIDE BATTERY REMOVAL) 플레이트
12.190	SWITCH, BATTERY RETAINER INTERLOCK 스위치
12.191	HARNESS, BATTERY RETAINER INTERLOCK SWITCH 하네스
12.192	FASTENER, BATTERY RETAINER INTERLOCK SWITCH 패스너
12.291	COVER, KILL SWITCH 커버
12.374	FITTING, BATTERY RETAINER INTERLOCK SWITCH HARNESS 피팅
12.375	SLIDE, BATTERY 슬라이드
12.376	SLIDE, BATTERY 슬라이드

12.377	FASTENER, BATTERY SLIDE 패스너
12.378	FASTENER, FRONT PLATE (SIDE BATTERY REMOVAL) 패스너
38.020	FRAME ASSEMBLY 프레임
96.457	WASHER, BATTERY RETAINER INTERLOCK SWITCH FASTENER 와셔







30.956	SEAL, RELIEF VALVE PLUG 씰	33.712	COUPLING, DEVICE RELIEF VALVE DISCHARGE HOSE 커플링
33.054	PLUG, RELIEF VALVE PORT 플러그	33.713	LINE, DEVICE RELIEF VALVE DISCHARGE 라인
33.055	SEAL, RELIEF VALVE PORT PLUG 씰	33.714	COUPLING, DEVICE RELIEF VALVE DISCHARGE LINE 커플링
33.600	RELIEF VALVE, DEVICE VARIABLE PRESSURE 릴리프밸브	33.732	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.603	BRACKET, DEVICE CARIABLE RELIEF VALVE 브라켓	33.733	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.604	FASTENER, DEVICE VARIABLE RELIEF VALVE 패스너	33.900	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.617	SPACER, DEV VARIABLE RELIEF VAL BRKT 스페이서	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.661	FITTING, DEVICE RELIEF VALVE OUTLET PORT 피팅	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.701	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	33.935	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.702	LINE, DEVICE RELIEF VALVE INLET 라인	75.311	KIT, RELIEF VALVE INSTALLATION 키트
33.703	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	90.854	BOLT, DEVICE MOUNTING BRACKET FASTENER 볼트
33.706	FITTING, DEVICE RELIEF VALVE INLET PORT 피팅	90.855	LOCKWASHER, DEVICE MOUNTING BRACKET FASTENER 로크와셔
33.707	SEAL, DEVICE RELIEF VALVE INLET PORT FITTING 씰	91.221	NUT, DEV VARIABLE RELIEF VALVE FASTENER 너트
33.710	FITTING, DEVICE RELIEF VALVE DISCHARGE PORT 피팅	91.712	LOCKWASHER, DEVICE RELIEF VALVE FASTENER 로크와셔
33.711	SEAL, DEVICE RELIEF VALVE DISCHARGE PORT FTG 씰		




- | | |
|--------|--|
| 33.720 | GAUGE, DEVICE HYDRAULIC PRESSURE
게이지 |
| 33.724 | FITTING, DEVICE HYD PRESSURE GAUGE
피팅 |
| 75.301 | DEVICE, HYDRAULIC PRESSURE GAUGE
디바이스 |



- | | |
|--------|--|
| 38.855 | FASTENER, AUXILIARY COUNTERWEIGHT
패스너 |
| 38.856 | COUNTERWEIGHT, AUXILIARY
보조카운터웨이트 |
| 38.882 | FASTENER, AUXILIARY COUNTERWEIGHT
패스너 |



- | | |
|--------|------------------------------------|
| 47.084 | BASKET, WIRE
바스킷트 |
| 47.085 | FASTENER, WIRE BASKET
패스너 |
| 47.118 | BRACKET, WIRE BASKET R.H.
브라켓 |
| 47.119 | BRACKET, WIRE BASKET L.H.
브라켓 |
| 96.774 | WASHER, WIRE BASKET FASTENER
와셔 |



39.706	SUPPORT, SEAT 서포트
39.719	SEAT ASSEMBLY 시트
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 키트